

TODAY'S TECHNICIAN™

AUTOMOTIVE SUSPENSION & STEERING SYSTEMS

5TH EDITION

SHOP MANUAL

STUCK?

GET ON-DEMAND
TUTORING & STEP-
BY-STEP SOLUTIONS

chegg

unstuck.chegg.com

chegg

aisle

1P

RACK

024



BOOK

4406

port
certification
gh


TEF

DON KNOWLES

TODAY'S TECHNICIAN™

SHOP MANUAL FOR
**AUTOMOTIVE SUSPENSION &
STEERING SYSTEMS**

FIFTH EDITION



Digitized by the Internet Archive
in 2019 with funding from
Kahle/Austin Foundation

<https://archive.org/details/automotivesuspen0000know>

TODAY'S TECHNICIAN™

SHOP MANUAL FOR **AUTOMOTIVE SUSPENSION & STEERING SYSTEMS**

DON KNOWLES

FIFTH EDITION



Australia • Canada • Mexico • Singapore • Spain • United Kingdom • United States

Today's Technician™: Suspension & Steering Systems, 5th Edition

Don Knowles

Vice President, Career and Professional
Editorial: Dave Garza

Director of Learning Solutions: Sandy Clark

Executive Editor: David Boelio

Managing Editor: Larry Main

Senior Product Manager: Matthew Thouin

Editorial Assistant: Jillian Borden

Vice President, Career and Professional
Marketing: Jennifer McAveyExecutive Marketing Manager:
Deborah S. Yarnell

Marketing Coordinator: Mark Pierro

Production Director: Wendy Troeger

Production Manager: Mark Bernard

Content Project Manager: Cheri Plasse

Art Director: Benj Gleeksman

© 2011 Delmar, Cengage Learning

ALL RIGHTS RESERVED. No part of this work covered by the copyright herein may be reproduced, transmitted, stored, or used in any form or by any means graphic, electronic, or mechanical, including but not limited to photocopying, recording, scanning, digitizing, taping, Web distribution, information networks, or information storage and retrieval systems, except as permitted under Section 107 or 108 of the 1976 United States Copyright Act, without the prior written permission of the publisher.

For product information and technology assistance, contact us at
Professional Group Cengage Learning Customer & Sales Support, 1-800-354-9706

For permission to use material from this text or product,
submit all requests online at **cengage.com/permissions**.

Further permissions questions can be e-mailed to
permissionrequest@cengage.com.

Library of Congress Control Number: 2009904277

ISBN-13: 978-1-4354-8114-5

ISBN-10: 1-4354-8114-3

Delmar5 Maxwell Drive
Clifton Park, NY 12065-2919
USA

Cengage Learning is a leading provider of customized learning solutions with office locations around the globe, including Singapore, the United Kingdom, Australia, Mexico, Brazil and Japan. Locate your local office at:
international.cengage.com/region

Cengage Learning products are represented in Canada by Nelson Education, Ltd.

For your lifelong learning solutions, visit **delmar.cengage.com**

Visit our corporate website at **cengage.com**.

Notice to the Reader

Publisher does not warrant or guarantee any of the products described herein or perform any independent analysis in connection with any of the product information contained herein. Publisher does not assume, and expressly disclaims, any obligation to obtain and include information other than that provided to it by the manufacturer. The reader is expressly warned to consider and adopt all safety precautions that might be indicated by the activities described herein and to avoid all potential hazards. By following the instructions contained herein, the reader willingly assumes all risks in connection with such instructions. The publisher makes no representations or warranties of any kind, including but not limited to, the warranties of fitness for particular purpose or merchantability, nor are any such representations implied with respect to the material set forth herein, and the publisher takes no responsibility with respect to such material. The publisher shall not be liable for any special, consequential, or exemplary damages resulting, in whole or part, from the readers' use of, or reliance upon, this material.

Photo Sequence Contents ix

Job Sheets Contents xi

Preface xiii

CHAPTER 1 Safety1

- Introduction 2 • Occupational Safety and Health Act 2 • Shop Hazards 2 • Shop Safety Rules 3
- Air Quality 5 • Shop Safety Equipment 6 • Shop Layout 9 • Safety in the Automotive Shop 10
- General Shop Safety 10 • Personal Safety 11 • Electrical Safety 13 • Gasoline Safety 13
- Fire Safety 14 • Vehicle Operation 15 • Housekeeping Safety 16 • Air Bag Safety 17
- Lifting and Carrying 19 • Hand Tool Safety 20 • Lift Safety 21 • Hydraulic Jack and Safety Stand Safety 21 • Power Tool Safety 22 • Compressed-Air Equipment Safety 23 • Cleaning Equipment Safety and Environmental Considerations 23 • Hazardous Waste Disposal 26 • Case Study 29
- Terms to Know 29 • Summary 30 • ASE-Style Review Questions 31

CHAPTER 2 Tools and Shop Procedures39

- Using Suspension and Steering Equipment 39 • Measuring Systems 39 • Basic Diagnostic Procedure 41
- Suspension and Steering Tools 42 • Hydraulic Pressing and Lifting Equipment 55 • Suspension and Steering Service, Diagnostic, and Measurement Tools 59 • Employer and Employee Obligations 70
- National Institute for Automotive Service Excellence (ASE) Certification 72 • Service Manuals 74
- Case Study 80 • Terms to Know 81 • Summary 81 • ASE-Style Review Questions 82

CHAPTER 3 Wheel Bearing and Seal Service89

- Diagnosis of Bearing Defects 89 • Service and Adjustment of Tapered Roller Bearing-Type Wheel Bearings 90 • Wheel Hub Unit Diagnosis 97 • Front Drive Axle Diagnosis 99 • Drive Axle Removal 99
- Special Procedures for Drive Axle Removal 100 • Front Wheel Bearing Hub Unit Removal and Replacement 102 • Rear-Axle Bearing and Seal Service, Rear-Wheel-Drive Cars 104 • Case Study 108
- Terms to Know 108 • ASE-Style Review Questions 108 • ASE Challenge Questions 110

CHAPTER 4 Tire and Wheel Servicing and Balancing120

- Tire Noises and Steering Problems 120 • Tire Rotation 122 • Tire and Wheel Service 123
- Tire and Wheel Service Precautions 124 • Wheel Rim Service 130 • Tire Remounting Procedure 131
- Diagnosing and Servicing Tire Pressure Monitoring Systems 132 • Tire and Wheel Runout Measurement 138 • Tread Wear Measurement 140 • Preliminary Wheel Balancing Checks 141
- Tire Inflation Pressure 142 • Static and Dynamic Wheel Balance Procedure 143 • Electronic Wheel Balancers with Lateral Force Measurement (LFM) and Radial Force Variation Capabilities 145 • On Car Wheel Balancing 149 • Vibration Diagnosis 150 • Case Study 156 • Terms to Know 156 • ASE-Style Review Questions 157 • ASE Challenge Questions 158

CHAPTER 5 Shock Absorber and Strut Diagnosis and Service171

- Shock Absorber Visual Inspection 171 • Shock Absorber or Strut Bounce Test 172
- Shock Absorber Manual Test 172 • Air Shock Absorber Diagnosis and Replacement 174 • Shock Absorber Replacement 174 • Diagnosis of Front Spring and Strut Noise 174 • Strut Removal and Replacement 176 • Removal of Strut from Coil Spring 177 • Strut Disposal Procedure 179
- Installation of Coil Spring on Strut 179 • Installation of Strut-and-Spring Assembly in Vehicle 181
- Rear Strut Replacement 183 • Installing Strut Cartridge, Off-Car 183 • Installing Strut Cartridge, On-Car 184 • Diagnosis of Electronically Controlled Shock Absorbers 187 • Case Study 188

• Terms to Know 189 • ASE-Style Review Questions 189 • ASE Challenge Questions 190

CHAPTER 6 Front Suspension System Service201

• Curb Riding Height Measurement 201 • Front Suspension Diagnosis and Service 202
• Control Arm Diagnosis and Service 213 • Removing and Replacing Longitudinally Mounted Torsion Bars 222 • Case Study 224 • Terms to Know 224 • ASE-Style Review Questions 225 • ASE Challenge Questions 226

CHAPTER 7 Rear Suspension Service235

• Lower Control Arm and Ball Joint Diagnosis and Replacement • Rear Leaf-Spring Diagnosis and Replacement 247 • Track Bar Diagnosis and Replacement 248 • Stabilizer Bar Diagnosis and Service 248 • Rear Suspension Tie Rod Inspection and Replacement 250 • Case Study 250 • Terms to Know 250 • ASE-Style Review Questions 251 • ASE Challenge Questions 252

CHAPTER 8 Computer-Controlled Suspension System Service259

• Preliminary Inspection of Computer-Controlled Suspension Systems 259 • Programmed Ride Control System Diagnosis 260 • Electronic Air Suspension Diagnosis and Service 261 • Servicing and Diagnosing Vehicle Dynamic Suspension Systems 269 • Diagnosis of Electronic Suspension Control Systems 274 • Scan Tool Diagnosis of Electronic Suspension Control 276 • Case Study 284 • Terms to Know 285 • ASE-Style Review Questions 286 • ASE Challenge Questions 287

CHAPTER 9 Steering Column and Linkage Diagnosis and Service . .295

• Air Bag Deployment Module, Steering Wheel, and Clock Spring Electrical Connector Removal and Replacement 295 • Typical Procedure for Removing a Steering Wheel 298 • Steering Column Service 300 • Steering Column Removal and Replacement 300 • Collapsible Steering Column Inspection 301 • Tilt Steering Column Disassembly 302 • Tilt Steering Column Inspection and Parts Replacement 304 • Tilt Steering Column Assembly 305 • Steering Column Flexible Coupling and Universal Joint Diagnosis and Service 307 • Steering Column Diagnosis 309 • Steering Linkage Diagnosis and Service 313 • Case Study 321 • Terms to Know 321 • ASE-Style Review Questions 321 • ASE Challenge Questions 322

CHAPTER 10 Power Steering Pump Diagnosis and Service335

• Power Steering Pump Belt Service 335 • Power Steering Pump Fluid Service 338 • Power Steering Pump Diagnosis 340 • Power Steering Pump Service 345 • Inspecting and Servicing Power Steering Lines and Hoses 348 • Power Steering Hose Replacement 349 • Hybrid Electric Vehicle (HEV) and Electrohydraulic Power Steering (EHPS) Diagnosing and Servicing Procedures 350 • Case Study 358 • Terms to Know 358 • ASE-Style Review Questions 358 • ASE Challenge Questions 359

CHAPTER 11 Recirculating Ball Steering Gear Diagnosis and Service 369

• Power Recirculating Ball Steering Gear Diagnosis 369 • Power Recirculating Ball Steering Gear Replacement 370 • Power Recirculating Ball Steering Gear Adjustments 371 • Power Recirculating Ball Steering Gear Oil Leak Diagnosis 375 • Power Recirculating Ball Steering Gear Seal

Replacement 375 • Case Study 378 • Terms to Know 378 • ASE-Style Review Questions 378
• ASE Challenge Questions 379

CHAPTER 12 Rack and Pinion Steering Gear Diagnosis and Service 387

• Manual or Power Rack and Pinion Steering Gear On-Car Inspection 387 • Manual or Power Rack and Pinion Steering Gear Removal and Replacement 389 • Manual Rack and Pinion Steering Gear Diagnosis and Service 395 • Diagnosis of Power Steering, Steering Column, and Suspension Systems 407 • Diagnosis of Magnasteer Systems 408 • Diagnosis of Rack-Drive Electronic Power Steering 409 • Diagnosis of Column-Drive Electronic Power Steering 411 • Active Steering System Preliminary Diagnosis 414 • Case Study 417 • Terms to Know 417 • ASE-Style Review Questions 418 • ASE Challenge Questions 419

CHAPTER 13 Electronic Four-Wheel Steering Diagnosis and Service 432

• Preliminary Inspection 432 • Quadrasteer Diagnosis 434 • Electronically Controlled Four-Wheel Steering Diagnosis 437 • Rear Steering Actuator Service 439 • Diagnosis of Four-Wheel Active Steering (4WAS) System 446 • Case Study 451 • Terms to Know 451 • ASE-Style Review Questions 452 • ASE Challenge Questions 453

CHAPTER 14 Frame Diagnosis and Service 461

• Indications of Frame Damage 461 • Frame Diagnosis 461 • Checking Frame Alignment 462 • Measuring Unitized Body Alignment 468 • Case Study 474 • Terms to Know 474 • ASE-Style Review Questions 475 • ASE Challenge Questions 476

CHAPTER 15 Four Wheel Alignment Procedure. 485

• Wheel Alignment Preliminary Diagnosis and Inspection 485 • Four Wheel Alignment with Computer Alignment Systems 491 • Wheel Alignment Screens 497 • Adjustment Screens 502 • Diagnostic Drawing and Text Screens 506 • Checking Toe Change and Steering Linkage Height 508 • Bent Front Strut Diagnosis 510 • Case Study 511 • Terms to Know 511 • ASE-Style Review Questions 512 • ASE Challenge Questions 513

CHAPTER 16 Four Wheel Alignment Adjustments. 523

• Wheel Alignment Procedure 523 • Camber Adjustment 524 • Caster Adjustment Procedure 531 • Setback Measurement and Correction Procedure 534 • Steering Axis Inclination (SAI) Correction Procedure 537 • Toe Adjustment 537 • Manual Steering Wheel Centering Procedure 539 • Causes of Improper Rear Wheel Alignment 541 • Rear Suspension Adjustments 541 • Rear Wheel Tracking Measurement with a Track Gauge 547 • Case Study 552 • Terms to Know 554 • ASE-Style Review Questions 555 • ASE Challenge Questions 556

Appendix A ASE Practice Examination 566

Appendix B Metric Conversions. 572

CONTENTS

<i>Appendix C Automotive Suspension and Steering Systems Special Tool Suppliers</i>	<i>573</i>
<i>Appendix D Manufacturer Websites</i>	<i>574</i>
<i>Appendix E Suspension and Steering Professional Associations ...</i>	<i>575</i>
<i>Glossary.....</i>	<i>576</i>
<i>Index</i>	<i>587</i>

PHOTO SEQUENCES

1. Typical Procedure for Removing Air Bag Module.....	18
2. Typical Procedure for Performing Four Wheel Alignment with a Computer Wheel Aligner	69
3. Typical Procedure for Adjusting Rear Wheel Bearings on a Front-Wheel-Drive Car	96
4. Typical Procedure for Measuring Front Wheel Hub Endplay—Integral, Sealed Wheel Bearing Hub Assemblies	98
5. Typical Procedure for Dismounting and Mounting a Tire on a Wheel Assembly....	133
6. Typical Off-Car Wheel Balancing Procedure	146
7. Rear Shock Absorber Visual Inspection and Bounce Test	173
8. Typical Procedure for Removing and Replacing a MacPherson Strut.....	182
9. Vertical Ball Joint Measurement	206
10. Typical Procedure for Measuring the Lower Ball Joint Horizontal Movement on a MacPherson Strut Front Suspension.....	208
11. Typical Procedure for Measuring Front and Rear Curb Riding Height	238
12. Typical Procedure for Removing a Rear Strut-and-Spring Assembly on a Front-Wheel-Drive Car	243
13. Inflate L/H Front Air Spring Using a Scan Tool.....	266
14. Reading Scan Tool Data on an Electronic Suspension Control System.....	279
15. Typical Procedure for Removing a Steering Wheel.....	298
16. Diagnosing, Removing, and Replacing an Outer Tie-Rod End on a Vehicle with a Parallelogram Steering Linkage.....	316
17. Typical Procedure for Pressure Testing a Power Steering Pump.....	344
18. Observing Safety Precautions When Servicing Hybrid Electric Vehicles (HEVs)	357
19. Typical Procedure for Performing a Worm Shaft Bearing Preload Adjustment.....	373
20. Pitman Sector Shaft Lash Adjustment.....	375
21. Typical Procedure for Removing and Replacing a Power Rack and Pinion Steering Gear	393
22. Typical Procedure for Removing and Replacing Inner Tie-Rod End, Power Rack, and Pinion Steering Gear	406
23. Preliminary Inspection, Four-Wheel Steering Diagnosis	433

PHOTO SEQUENCES

24. Typical Procedure for Diagnosing an Electronically Controlled
Four-Wheel Steering System 447

25. Typical Procedure for Performing Frame Measurement, Plumb Bob Method. 465

26. Performing Underhood Measurements..... 472

27. Typical Procedure for Performing Four-Wheel Alignment with a Computer
Wheel Aligner..... 498

28. Typical Procedure for Front Wheel Turning Radius Measurement 503

29. Typical Procedure for Adjusting Rear Wheel Camber and Toe 544

30. Typical Procedure for Performing Front and Rear Suspension
Alignment Adjustments 548

1. Demonstrate Proper Lifting Procedures	33
2. Locate and Inspect Shop Safety Equipment	35
3. Shop Housekeeping Inspection	37
4. Raise a Car with a Floor Jack and Support It on Safety Stands.....	83
5. Follow the Proper Procedure to Hoist a Car	85
6. Determine the Availability and Purpose of Suspension and Steering Tools	87
7. Service Integral Wheel Bearing Hubs	111
8. Diagnose Wheel Bearings.....	115
9. Clean, Lubricate, Install, and Adjust Nonsealed Wheel Bearings	117
10. Tire Dismounting and Mounting	159
11. Tire and Wheel Runout Measurement	161
12. Off-Car Wheel Balancing	163
13. On-Car Wheel Balancing	165
14. Diagnose Tire and Wheel Vibration, Steering Pull, and Chassis Waddle.....	167
15. Inspect, Diagnose, and Calibrate Tire Pressure Monitoring Systems	169
16. Remove Strut-and-Spring Assembly and Disassemble Strut and Spring.....	191
17. Assemble Strut and Spring and Install Strut-and-Spring Assembly.....	195
18. Install Strut Cartridge Off-Car	199
19. Measure Lower Ball Joint Vertical and Horizontal Movement, Short-and-Long Arm Suspension Systems	227
20. Ball Joint Replacement	229
21. Steering Knuckle Removal, MacPherson Strut Front Suspension.....	233
22. Remove and Service Rear Suspension Strut and Coil Spring Assembly	253
23. Remove Rear Suspension Lower Control Arm and Ball Joint Assembly.....	255
24. Install Rear Suspension Lower Control Arm and Ball Joint Assembly.....	257
25. Inspection and Preliminary Diagnosis of Computer-Controlled Suspension System.....	289
26. Adjust Vehicle Ride (Trim) Height with a Scan Tool.....	291
27. Perform an On-Demand Self-Test on a Vehicle Dynamic Suspension (VDS) System	293
28. Remove and Replace Air Bag Inflator Module and Steering Wheel.....	325
29. Remove and Replace Steering Column	329

30. Diagnose, Remove, and Replace Idler Arm	331
31. Remove and Replace Outer Tie-Rod End, Parallelogram Steering Linkage	333
32. Draining and Flushing Power Steering System.....	361
33. Testing Power Steering Pump Pressure	363
34. Measure and Adjust Power Steering Belt Tension and Alignment.....	367
35. Power Recirculating Ball Steering Gear Oil Leak Diagnosis	381
36. Adjust Power Recirculating Ball Steering Gear Worm Shaft Thrust Bearing Preload, Steering Gear Removed.	383
37. Adjust Power Recirculating Ball Steering Gear Sector Lash, Steering Gear Removed	385
38. Inspect Manual or Power Rack and Pinion Steering Gear and Tie-Rods	421
39. Remove and Replace Manual or Power Rack and Pinion Steering Gear	425
40. Diagnose Power Rack and Pinion Steering Gear Oil Leakage Problems	429
41. Retrieve Diagnostic Trouble Codes (DTCs), Four-Wheel Steering (4WS) System ...	455
42. Perform a Learn Rear Wheel Alignment Procedure on a Quadrasteer System	457
43. Quadrasteer Diagnostic System Check	459
44. Frame Measurement, Plumb Bob Method	477
45. Inspect and Measure Front Cradle	481
46. Inspect and Weld Vehicle Frame.....	483
47. Road-Test Vehicle and Diagnose Steering Operation	515
48. Measure Front and Rear Wheel Alignment Angles with a Computer Wheel Aligner.....	517
49. Check Proper Steering Linkage Height by Measuring Toe Change	521
50. Center Steering Wheel	557
51. Adjust Front Wheel Alignment Angles	559
52. Adjust Rear Wheel Alignment Angles.....	563

Thanks to the support the *Today's Technician* series has received from those who teach automotive technology, Delmar Cengage Learning, the leader in automotive-related textbooks, is able to live up to its promise to regularly provide new editions of texts of this series. We have listened and responded to our critics and our fans and present this new updated and revised fifth edition. By revising this series on a regular basis, we can respond to changes in the industry, changes in technology, changes in the certification process, and to the ever-changing needs of those who teach automotive technology.

We also listened to instructors who said something was missing or incomplete in the last edition. We responded to those and the results are included in this fifth edition.

The *Today's Technician* series features textbooks that cover all mechanical and electrical systems of automobiles and light trucks. Principally, the individual titles correspond to the certification areas for 2009 in areas of National Institute for Automotive Service Excellence (ASE) certification.

Additional titles include remedial skills and theories common to all of the certification areas and advanced or specific subject areas that reflect the latest technological trends.

This new edition, like the last, was designed to give students a chance to develop the same skills and gain the same knowledge that today's successful technician has. This edition also reflects the changes in the guidelines established by the National Automotive Technicians Education Foundation (NATEF) in 2008.

The purpose of NATEF is to evaluate technician training programs against standards developed by the automotive industry and recommend qualifying programs for certification (accreditation) by ASE. Programs can earn ASE certification upon the recommendation of NATEF. NATEF's national standards reflect the skills that students must master. ASE certification through NATEF evaluation ensures that certified training programs meet or exceed industry-recognized, uniform standards of excellence.

The technician of today and for the future must know the underlying theory of all automotive systems and be able to service and maintain those systems. Dividing the material into two volumes, a Classroom Manual and a Shop Manual, provides the reader with the information needed to begin a successful career as an automotive technician without interrupting the learning process by mixing cognitive and performance learning objectives into one volume.

The design of Delmar's *Today's Technician* series was based on features that are known to promote improved student learning. The design was further enhanced by a careful study of survey results, in which the respondents were asked to value particular features. Some of these features can be found in other textbooks, while others are unique to this series.

Each Classroom Manual contains the principles of operation for each system and subsystem. The Classroom Manual also contains discussions on design variations of key components used by the different vehicle manufacturers. It also looks into emerging technologies that will be standard or optional features in the near future. This volume is organized to build upon basic facts and theories. The primary objective of this volume is to allow the reader to gain an understanding of how each system and subsystem operates. This understanding is necessary to diagnose the complex automobiles of today and tomorrow. Although the basics contained in the Classroom Manual provide the knowledge needed for diagnostics, diagnostic procedures appear only in the Shop Manual. An understanding of the underlying theories is also a requirement for competence in the skill areas covered in the Shop Manual.

A coil-ring-bound Shop Manual covers the “how-to’s.” This volume includes step-by-step instructions for diagnostic and repair procedures. Photo Sequences are used to illustrate some of the common service procedures. Other common procedures are listed and are accompanied with fine line drawings and photos that allow the reader to visualize and conceptualize the finest details of the procedure. This volume also contains the reasons for performing the procedures, as well as when that particular service is appropriate.

The two volumes are designed to be used together and are arranged in corresponding chapters. Not only are the chapters in the volumes linked together, the contents of the chapters are also linked. This linking of content is evidenced by marginal callouts that refer the reader to the chapter and page that the same topic is addressed in the other volume. This feature is valuable to instructors. Without this feature, users of other two-volume textbooks must search the index or table of contents to locate supporting information in the other volume. This is not only cumbersome but also creates additional work for an instructor when planning the presentation of material and when making reading assignments. It is also valuable to the students, with the page references they also know exactly where to look for supportive information.

Both volumes contain clear and thoughtfully selected illustrations. Many of which are original drawings or photos specially prepared for inclusion in this series. This means that the art is a vital part of each textbook and not merely inserted to increase the number of illustrations.

The page layout, used in the series, is designed to include information that would otherwise break up the flow of information presented to the reader. The main body of the text includes all of the “need-to-know” information and illustrations. In the wide side margins of each page are many of the special features of the series. Items that are truly “nice-to-know” information such as: simple examples of concepts just introduced in the text, explanations or definitions of terms that are not defined in the text, examples of common trade jargon used to describe a part or operation, and exceptions to the norm explained in the text. This type of information is placed in the margin, out of the normal flow of information. Many textbooks attempt to include this type of information and insert it in the main body of text; this tends to interrupt the thought process and cannot be pedagogically justified. By placing this information off to the side of the main text, the reader can select when to refer to it.

Jack Erjavec
Series Editor

HIGHLIGHTS OF THIS EDITION—CLASSROOM MANUAL

The text was updated to include the latest technology in suspension and steering systems. Some of these systems include hybrid vehicle steering systems, active steering systems, rear active steering (RAS), four-wheel active steering (4WAS) systems, data network systems, computer-controlled suspension systems, and adaptive cruise control systems. The text also includes the latest technology in vehicle stability control systems, traction control systems, active roll control, lane departure warning (LDW) systems, collision mitigation systems, telematics, and tire pressure monitoring systems (TPMS).

The first chapter explains the design and purpose of basic suspension and steering systems. This chapter provides students with the necessary basic understanding of suspension and steering systems. The other chapters in the book allow the student to build upon his or her understanding of these basic systems.

The second chapter explains all the basic theories required to understand the latest suspension and steering systems described in the other chapters. Students must understand these basic theories to comprehend the complex systems explained later in the text.

The other chapters in the book explain all the current model systems and components such as wheel bearings, tires and wheels, shock absorbers and struts, front and rear suspension systems, computer-controlled suspension systems, steering columns and linkages, power steering pumps, steering gears and systems, four-wheel steering systems, frames, and four-wheel alignment. Many art pieces have been replaced or updated throughout the text to improve visual concepts of suspension and steering systems and components.

HIGHLIGHTS OF THIS EDITION—SHOP MANUAL

The chapters in the Shop Manual have been updated to explain the diagnostic and service procedures for the latest systems and components described in the Classroom Manual. Diagnostics is a very important part of an automotive technician's job. Therefore, proper diagnostic procedures are emphasized in the Shop Manual.

A number of new Photo Sequences have been added in Chapters 3 through 16. These Photo Sequences illustrate the correct diagnostic or service procedure for a specific system or component. These Photo Sequences allow the students to visualize the diagnostic or service procedure. Visualization of these diagnostic and service procedures helps students to remember the procedures, and perform them more accurately and efficiently. The text covers the information required to pass a ASE test in Suspension and Steering Systems.

Chapter 1 explains the necessary safety precautions and procedures in an automotive repair shop. General shop safety and the required shop safety equipment are explained in the text. The text describes safety procedures when operating vehicles and various types of automotive service equipment. Correct procedures for handling hazardous waste materials are detailed in the text.

Chapter 2 describes suspension and steering diagnostic and service equipment and the use of service manuals. This chapter also explains employer and employee obligations, and ASE certification requirements.

The other chapters in the text have been updated to explain the diagnostic and service procedures for the latest suspension and steering systems explained in the Classroom Manual. Some new job sheets related to the new systems and components have been added in the text. Many art pieces have been replaced or updated to improve the student's visualization of diagnostic and service procedures.

Don Knowles

CLASSROOM MANUAL

Features of this manual include the following:

COGNITIVE OBJECTIVES

These objectives define the contents of the chapter and define what the student should have learned upon completion of the chapter.

Each topic is divided into small units to promote easier understanding and learning.

CROSS-REFERENCES TO THE SHOP MANUAL

Reference to the appropriate page in the Shop Manual is given whenever necessary. Although the chapters of the two manuals are synchronized, material covered in other chapters of the Shop Manual may be fundamental to the topic discussed in the Classroom Manual.

MARGINAL NOTES

These notes add "nice-to-know" information to the discussion. They may include examples or exceptions, or may give the common trade jargon for a component.

Chapter 7

REAR SUSPENSION SYSTEMS

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO UNDERSTAND AND DESCRIBE:

- A live-axle rear suspension system.
- The advantages and disadvantages of a live-axle leaf-spring rear suspension system.
- The movement of the rear axle housing during vehicle acceleration.
- How the differential torque is absorbed in a live-axle coil-spring rear suspension system.
- The purpose of a tracking bar in a live-axle coil-spring rear suspension system.
- The difference between a semi-independent and an independent rear suspension system.
- How individual rear wheel movement is provided in a semi-independent rear suspension system.
- The difference between a MacPherson strut and a modified MacPherson strut rear suspension system.
- The advantage of attaching the differential housing to the chassis in an independent rear suspension system.
- How differential and suspension vibration, noise, and shock are insulated from the chassis in a multilink independent rear suspension system.
- How the top of the knuckle is supported in a multilink independent rear suspension system.
- The effect of sagged rear springs on caster angle and steering.

INTRODUCTION

A rear suspension system with two longitudinal leaf springs and a one-piece rear axle.

The rear suspension system plays a very important part in ride quality and in the control of suspension and differentials.

Although the front wheels actually also vital to steering control. The rear suspension maintain tire traction on the road surface. Rear suspension include live-axle, semi-independent, and independent rear suspension systems. Most front-wheel-drive (FWD) cars. Most front-wheel-drive (FWD) cars. Most front-wheel-drive (FWD) cars.

SYSTEMS

Each side of the rear suspension on some rear-wheel-drive cars. Relatively flat springs provide excellent lateral control to a well-controlled ride with very good

A pyrotechnic device contains an explosive and an ignition source.

An air bag deployment module contains the air bag and the inflator device.



CAUTION:

When servicing a vehicle equipped with an air bag or bags, follow all service precautions in the vehicle manufacturer's service manual. Failure to follow these precautions may result in an expensive, accidental air bag deployment.

The clock spring maintains positive electrical contact

required, the RCM fires a pyrotechnic device in the steering column that pulls a pin in the column and allows the energy-absorbing steel to buckle and provide faster column collapse. The result is a softer impact between the driver's air bag, column is designed to operate with the steering wheel during a collision, many steering wheels are designed to deform away from the driver to reduce the force on the driver's body.

WARNING: Small amounts of sodium hydroxide are a by-product of an air bag deployment. Sodium hydroxide is a caustic chemical that causes skin irritation and eye damage. Always wear eye protection and gloves when servicing and handling a deployed air bag.

On many cars, the air bag deployment module is mounted in the top of the steering wheel (Figure 9-6). A clock spring electrical connector, or spiral cable, is mounted under the steering wheel. This component contains a ribbon-type conductor that maintains constant electrical contact between the air bag module and the air bag electrical system during steering wheel rotation.

The steering wheel splines fit on matching splines on the top of the upper steering shaft, and a nut retains the wheel on the shaft. Most steering wheels and shafts have matching alignment marks that must be aligned when the steering wheel is installed.

An ignition switch cylinder is usually mounted in the upper right side of the column housing, and the ignition switch cylinder to the ignition switch. Ignition switches operating rod connects the ignition switch in some steering columns.

The turn signal switch and hazard warning switch are mounted on top of the steering column under the steering wheel. Lugs on the bottom of the steering wheel are used to cancel the signal lights after a turn is completed. On many vehicles, the signal light lever also operates the wiper/wash switch and the dimmer switch (Figure 9-8).

If the gear shift is mounted in the steering column, this shift lever is connected through a linkage to the transaxle or transmission shift lever. A lock plate is attached to the upper steering shaft, and a lever engages the slots in this plate to lock the steering wheel and gear shift when the vehicle is in the Park position (Figure 9-9).

supported by aluminum extrusions. This design allows the steering column, knee bolster, and pedals to move along the trajectory of the driver during a severe vehicle crash. This action helps to maintain air bag position. The driver protection module will be introduced on some 2009 vehicles, and some final design changes may be incorporated in the module. During a vehicle crash, the driver protection module movement may be controlled actively by a pyrotechnic device operated by an electronic module. The driver protection module will provide adequate crash protection for drivers from the 5th percentile to the 95th percentile. It is expected that this level of protection will be required by federal legislation in the future.

STEERING LINKAGE MECHANISMS

Parallelogram Steering Linkage

Steering linkage mechanisms are used to connect the steering gear to the front wheels. A parallelogram steering linkage may be mounted behind the front suspension (Figure 9-19) or in front of the front suspension (Figure 9-20). The parallelogram steering linkage must not interfere with the engine oil pan or chassis components.

WARNING: Always remember that a customer's life may depend on the condition of the steering linkages on his or her vehicle. State safety inspections play a very important role in maintaining suspension, steering, and other vehicle systems in safe driving condition and saving lives. During undercar service, always make a quick check of the steering linkage condition.

Regardless of the parallelogram steering linkage mounting position, this type of steering linkage contains the same components. The main components in this steering linkage mechanism are:

1. Pitman arm
2. Center link
3. Idler arm assembly
4. Tie-rods with sockets
5. Tie-rod ends




FIGURE 9-19 Parallelogram steering linkage behind the front suspension.

CAUTIONS AND WARNINGS

Throughout the text, warnings are given to alert the reader to potentially hazardous materials or unsafe conditions. Cautions are given to advise the student of things that can go wrong if instructions are not followed or if a nonacceptable part or tool is used.




FIGURE 15-9 Four wheel alignment with the thrust line adjusted so it is at the geometric centerline and the front wheel toe is referenced to the geometric centerline.

The advantages of four-wheel alignment are the following:

1. **Improved fuel mileage** After a four-wheel alignment, all four wheels are parallel, and this condition combined with proper tire inflation decreases rolling resistance, which improves fuel mileage.
2. **Longer tire life** When all four wheels are aligned properly, tire tread wear is minimized.
3. **Improved vehicle handling** When all four wheels are properly aligned and all steering and suspension components are in satisfactory condition, steering pulls, vibrations, and abnormal steering conditions are eliminated to ensure improved vehicle handling.
4. **Safer driving** Proper alignment of all four wheels plus inspection and replacement of all worn or defective steering and suspension components improves vehicle handling, and this reduces the possibility of a collision and provides safer driving.

COMPUTER ALIGNMENT SYSTEMS

Computer Wheel Aligner Features

Some computer wheel aligners have four high-resolution digital cameras that measure wheel target position and orientation. The front and rear wheel alignment angles are sensed by the digital cameras and wheel targets and then displayed on the wheel alignment monitor. The vehicle is raised to a comfortable working height on the aligner lift, and two digital cameras are mounted in each end of a crossbar on a post in front of the vehicle (Figure 15-10). The post and crossbar height may be adjusted to match the vehicle height.



FIGURE 15-10 Computer wheel aligner with digital cameras and wheel targets.



A BIT OF HISTORY

Early attempts at rear wheel alignment were slow and lacked precision. These attempts at rear wheel alignment included the use of a track bar and even backing the rear wheels of a car onto a front wheel aligner to align the rear wheels. To meet the need for fast, accurate front and rear wheel alignment, wheel alignment manufacturers designed computer wheel aligners. The technology in this equipment has greatly improved since the first models were introduced.

A BIT OF HISTORY

This feature gives the student a sense of the evolution of the automobile. This feature not only contains nice-to-know information, but also should spark some interest in the subject matter.

AUTHOR'S NOTES

This feature includes simple explanations, stories, or examples of complex topics. These are included to help students understand difficult concepts.

TERMS TO KNOW LIST

A list of new terms appears next to the Summary.

REVIEW QUESTIONS

Short answer essay, fill-in-the-blank, and multiple-choice questions are found at the end of each chapter. These questions are designed to accurately assess the student's competence in the stated objectives at the beginning of the chapter.

TYPES OF FRAME DAMAGE

Side Sway

AUTHOR'S NOTE: It has been my experience that frame damage is most commonly caused by abuse, and this problem is usually encountered on light-duty trucks or sport utility vehicles (SUVs). The frame damage may occur when the vehicle is overloaded and/or driven abusively on extremely rough terrain. Another common cause of frame damage is from a vehicle collision. In this case, the frame damage was likely ignored or overlooked during the body repairs. Regardless of the cause, frame damage usually results in excessive tire tread wear and steering complaints.

Shop Manual
Chapter 9, page 320

TERMS TO KNOW

Air bag deployment module
Center link
Clock spring electrical connector
Energy-absorbing lower bracket
Idler arm
Parallelogram steering linkage
Pitman arm
Pre-sat system
Pyrotechnic
Rack and pinion steering linkage
Silencer
Spherical bearing
Spiral cable
Tie-rod
Toe plate

SUMMARY

- Steering columns help provide steering control, driver convenience, and driver safety.
- Many steering columns provide some method of energy absorption to protect the driver during a frontal collision.
- Steering wheels and columns now contain an air bag deployment module to protect the driver in a frontal collision.
- Tilt steering columns increase driver comfort and ease while driving or getting in or out of the driver's seat.
- A clock spring electrical connector supplies positive electrical contact between the air bag module in the steering wheel and the air bag electrical system.
- The ignition switch, dimmer switch, signal light switch, hazard switch, and wipe/wash switch may be mounted in the steering column.
- When the ignition switch is in the Lock position, a locking plate and lever in the upper steering column locks the steering wheel and the gear shift.
- In some tilt steering columns, the upper column housing pivots on two bolts, and the upper steering shaft pivots on a universal joint.
- In a parallelogram steering linkage, the tie-rods are parallel to the lower control arms.
- The parallelogram steering linkage minimizes toe change as the control arms move up and down on road irregularities.
- A rack and pinion steering linkage has reduced friction points; it is lightweight and compact compared with a parallelogram steering linkage.

REVIEW QUESTIONS

Short Answer Essays

1. Explain how a collapsible steering column protects the driver in a frontal collision.
2. Explain how the driver's side air bag protects the driver in a frontal collision.
3. Describe the purpose of a clock spring.
4. List the switches commonly found in a steering column.
5. Describe the type of mechanism used to lock the steering wheel and gear shift when the ignition is in the Lock position.
6. Describe the pivot points in the upper shaft and upper column tube in a tilt steering wheel.
7. List the wear points in a parallelogram steering linkage.
8. List the five main components in a parallelogram steering linkage, and explain the purpose of each component.
9. Describe the basic design of a rack and pinion steering linkage.
10. Explain the advantages of a rack and pinion steering linkage compared with a parallelogram steering linkage.

SUMMARIES

Each chapter concludes with a summary of key points from the chapter. These are designed to help the reader review the chapter contents.

To stress the importance of safe work habits, the Shop Manual also dedicates one full chapter to safety. Other important features of this manual include:

PERFORMANCE-BASED OBJECTIVES

These objectives define the contents of the chapter and define what the student should have learned upon completion of the chapter. These objectives also correspond with the list of required tasks for NATEF certification. *Each NATEF task is addressed.*

Although this textbook is not designed to simply prepare someone for the certification exams, it is organized around the NATEF task list. These tasks are defined generically when the procedure is commonly followed and specifically when the procedure is unique for specific vehicle models. Imported and domestic model automobiles and light trucks are included in the procedures.

MARGINAL NOTES

These notes add “nice-to-know” information to the discussion. They may include examples or exceptions, or may give the common trade jargon for a component.

SPECIAL TOOLS LISTS

Whenever a special tool is required to complete a task, it is listed in the margin next to the procedure.

Chapter 16

FOUR WHEEL ALIGNMENT ADJUSTMENTS

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Adjust front wheel camber on various front suspension systems.
- Adjust front wheel caster on various front suspension systems.
- Correct setback conditions.
- Check and correct front engine cradle position.
- Correct SAI angles that are not within specifications.
- Adjust front wheel toe.
- Center steering wheel.
- Recognize the symptoms of improper rear wheel alignment.
- Diagnose the causes of improper rear wheel alignment.
- Perform rear wheel camber adjustments.
- Perform rear wheel toe adjustments.
- Use a track gauge to measure rear wheel tracking.
- Diagnose rear wheel tracking problems from the track gauge measurements.

Proper front and rear wheel alignment is extremely important because it affects directional stability, tire tread wear, and vehicle safety. Technicians must know how to check front and rear wheel alignment angles and diagnose the causes of steering and alignment problems. It is also essential for technicians to know how to adjust front and rear suspension angles while maintaining vehicle safety. On certain vehicles, some wheel alignment angles are considered non-adjustable by the vehicle manufacturer, but aftermarket suppliers often provide ways to make adjustments on these suspension systems. This chapter provides various methods to adjust suspension alignment angles as summarized in

BASIC TOOLS
Basic technician's tool set
Service manual
Chalk

Support bracket
Diagonal bracket
Track bar
Bushing
Axle assembly

FIGURE 7-27 Checking track bar bushings.

Surfaces. Worn or very dry stabilizer bar bushings may cause a squeaking noise on irregular road surfaces. All stabilizer bar components should be visually inspected for wear. Stabilizer bar removal and replacement procedures vary depending on the vehicle. Always follow the vehicle manufacturer's recommended procedure in the service manual.

Following is a typical rear stabilizer bar removal and replacement procedure:

- Lift the vehicle on a hoist and allow both sides of the rear suspension to drop downward as the vehicle chassis is supported on the hoist.
- Remove the mounting bolts at the outer ends of the stabilizer bar and remove the bushings, grommets, brackets, or spacers (Figure 7-28).
- Remove the mounting bolts in the center area of the stabilizer bar.
- Remove the stabilizer bar from the chassis.
- Visually inspect all stabilizer bar components, such as bushings, bolts, and spacer sleeves. Replace the stabilizer bar, grommets, bushings, brackets, or spacers as required. Split bushings may be removed over the stabilizer bar. Bushings that are

REPLACE THE STABILIZER BAR, GROMMETS, BUSHINGS, BRACKETS, OR SPACERS AS REQUIRED. SPLIT BUSHINGS MAY BE REMOVED OVER THE STABILIZER BAR. BUSHINGS THAT ARE

SERVICE TIP:
On rear suspension systems with an inverted U-channel, the stabilizer bar inside the U-channel sometimes breaks away where it is welded to the end plate in the U-channel. This results in a squeaking noise when the car is over road bumps.

PHOTO SEQUENCE 4

TYPICAL PROCEDURE FOR MEASURING FRONT WHEEL HUB ENDPLAY—INTEGRAL, SEALED WHEEL BEARING HUB ASSEMBLIES

P4-1 Be sure the vehicle is properly positioned on a lift before the wheel bearing hub endplay measurement is performed. The vehicle should be properly positioned on a lift with the lift raised to a comfortable working height for performing this measurement.

P4-2 Remove the wheel cover and dust cap.

P4-3 Attach a magnetic dial indicator base securely to the inside of the fender at the lower edge of the wheel opening. Position the dial indicator stem against the vertical wheel surface as close as possible to the top wheel stud, and preload the dial indicator stem.

P4-4 Zero the dial indicator pointer.

P4-5 Grasp the top of the tire with both hands. Push and pull on the top of the tire without rotating the tire, and note the dial indicator readings with the tire pushed inward and the tire pulled outward. The difference between the two readings is the wheel hub endplay. Repeat this procedure twice to verify the endplay reading.

P4-6 Maximum wheel bearing endplay should be 0.005 in. (0.127 mm). If the endplay measurement is not correct, wheel bearing hub replacement is necessary.

P4-7 Remove the dial indicator and install the dust cap and wheel cover.

98

BASIC TOOLS LISTS

Each chapter begins with a list of the basic tools needed to perform the tasks included in the chapter.

SERVICE TIPS

Whenever a short-cut or special procedure is appropriate, it is described in the text. These tips are generally those things commonly done by experienced technicians.

PHOTO SEQUENCES

Many procedures are illustrated in detailed Photo Sequences. These detailed photographs show the students what to expect when they perform particular procedures. They also can provide the student a familiarity with a system or type of equipment, which the school may not have.

CAUTIONS AND WARNINGS

Throughout the text, warnings are given to alert the reader to potentially hazardous materials or unsafe conditions. Cautions are given to advise the student of things that can go wrong if instructions are not followed or if a nonacceptable part or tool is used.

CUSTOMER CARE

This feature highlights those little things a technician can do or say to enhance customer relations.

- CAUTION:** If heat is used to loosen a rusted wheel, the wheel and/or wheel bearings may be damaged.
- WARNING:** Before the vehicle is raised on a hoist, be sure that the hoist is lifting on the car manufacturer's recommended lifting points. If the hoist is not lifting on the car manufacturer's recommended lift points, chassis components may be damaged, and the vehicle may slip off the hoist, resulting in personal injury.
- WARNING:** If the vehicle is lifted with a floor jack, place safety stands under the suspension or frame, and lower the vehicle onto the safety stands. Then remove the floor jack from under the vehicle. If the vehicle is not supported properly on safety stands, the vehicle may suddenly drop, resulting in personal injury.
3. Raise the vehicle on a hoist or with a floor jack to a convenient working level.
4. Chalk mark the tire, wheel, and one of the lug nuts so the tire and wheel can be reinstalled in the same position.
5. Remove the lug nuts and the tire-and-wheel assembly. If the wheel is rusted and will not come off, hit the inside of the wheel with a large rubber mallet. Do not hit the wheel with a steel hammer, because this action could damage the wheel. Do not heat the wheel.




FIGURE 6-4 Curb riding height adjustment, torsion bar front suspension.


If the curb riding height is not correct on a torsion bar front suspension, the torsion bar anchor adjusting bolts must be rotated until the curb riding height equals the vehicle manufacturer's specifications (Figure 6-4).

Inspecting Ball Joints

CUSTOMER CARE: Regular chassis lubrication at the vehicle manufacturer's recommended service interval is one of the keys to long ball joint life. Always advise the customer of this fact.

Wear Indicators Some ball joints have a grease fitting installed in a floating retainer. The grease fitting and retainer may be used as a ball joint wear indicator. With the vehicle weight resting on the wheels, grasp the grease fitting and check for movement (Figure 6-5).

Some car manufacturers recommend ball joint replacement if any grease fitting movement is present. In some other ball joints, the grease fitting retainer extends a short distance through the ball joint surface (Figure 6-6). On this type of joint, replacement is necessary if the grease fitting shoulder is flush with or inside the ball joint cover.



Classroom Manual Chapter 8, page 116

A ball joint wear indicator allows the technician to check ball joint wear by visually inspecting the ball joint.

CROSS-REFERENCES TO THE CLASSROOM MANUAL

Reference to the appropriate page in the Classroom Manual is given whenever necessary. Although the chapters of the two manuals are synchronized, material covered in other chapters of the Classroom Manual may be fundamental to the topic discussed in the Shop Manual.

JOB SHEET

Name _____ Date _____

REMOVE: REAR SUSPENSION LOWER CONTROL ARM AND BALL JOINT ASSEMBLY

Upon completion of this job sheet, you should be able to remove rear suspension lower control arm and ball joint assemblies.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Tasks C-3, C-5: Remove inspect, and install upper and lower control arms, bushings, shafts, and rebound bumpers. Remove, inspect, and install upper and/or lower ball joints.

Tools and Materials

- | | |
|---------------|--|
| Floor jack | Control arm removing tool |
| Safety stands | Transmission jack |
| Hoist | Ball joint removal and replacement tools |

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

1. Lift the vehicle on a hoist with the chassis supported in the hoist and control arms dropped downward. The vehicle may be lifted with a floor jack and the chassis supported on safety stands.
2. Remove the tire-and-wheel assembly.
3. Remove the stabilizer bar from the knuckle bracket.
4. Remove the parking brake cable retaining clip from the lower control arm.
5. If the car has electronic level control (ELC), disconnect the height sensor link from the control arm.
6. Install a special tool to support the lower control arm in the bushing areas.
7. Place a transmission jack under the special tool and raise the jack enough to remove the tension from the control arm bushing retaining bolts. If the car was lifted with a floor jack and supported on safety stands, place a floor jack under the special tool. Is the special control arm support tool properly installed and supported?
☐ Yes ☐ No
Instructor check _____
8. Place a safety chain through the coil spring and around the lower control arm. Is the safety chain properly installed? ☐ Yes ☐ No
Instructor check _____
9. Remove the bolt from the rear control arm bushing.

Task Completed

☐
☐
☐
☐
☐
☐
☐
☐
☐

JOB SHEETS

Located at the end of each chapter, the Job Sheets provide a format for students to perform procedures covered in the chapter. A reference to the NATEF Task addressed by the procedure is referenced on the Job Sheet.

CASE STUDIES

Case Studies concentrate on the ability to properly diagnose the systems. Beginning with Chapter 3, each chapter ends with a case study in which a vehicle has a problem, and the logic used by a technician to solve the problem is explained.

CASE STUDY

A customer brought a 2004 Silverado into the shop with multiple electric problems. The cruise control would cancel when the turn signals were turned on. This only occurred at night when the headlights were on. The customer said several instrument panel readings were randomly intermittent. When a scan tool was connected to the DLC, a U1041 was displayed indicating loss of electronic brake control module (EBCM) data on the network. The technician checked for service bulletins related to this problem and discovered this problem was detailed in a service bulletin. The bulletin indicated this problem was caused by high resistance in ground connection G110 on the vehicle frame below the driver's door. The ground connection was cleaned and tightened and the DTC erased, but the DTC reset again in a short time. The technician considered the possibility of a defective EBCM. Prior to EBCM replacement, the technician

checked the EBCM voltage supply and ground. The EBCM voltage supply was 12V. When a pair of voltmeter leads was connected from the EBCM ground terminal to the battery ground, the voltmeter indicated 3V. The technician inspected all the wiring from the EBCM module to the battery, and discovered that the battery ground cable was connected to the radiator support rather than being connected to the specified location on the left front corner of the vehicle frame. The battery ground cable and the vehicle frame attaching location were thoroughly cleaned, and the ground cable was properly tightened. Now the voltage reading from the EBCM ground terminal to the battery ground was 2V. All DTCs were erased with a scan tool, and after driving the vehicle on a road test the DTCs did not reset. All electronic systems operated normally during the road test.

TERMS TO KNOW

Antilock brake system (ABS)
Brake pressure modulator valve (BPMV)
Continuously variable road sensing suspension (CVRSS)
Data link connector (DLC)
Diagnostic trouble codes (DTCs)
Electronic brake and

TERMS TO KNOW LIST

Terms in this list can be found in the Glossary at the end of the manual.

CASE STUDY

A customer complained about the SERVICE RIDE CONTROL light being illuminated on his 2009 Cadillac XLR. When the technician visually inspected the ESC system, no defects were evident. During a diagnostic system check, the scan tool

the ohmmeter leads from each terminal in the L/R damper solenoid connector to the ground. When connected to one of the damper solenoid terminals, the ohmmeter

ASE-STYLE REVIEW QUESTIONS

- When performing a self-test on a programmed ride control system:
 - The mode select switch must be in the Auto position.
 - One of the wires in the self-test connector must be grounded.
 - The engine must be off and the ignition switch turned on.
 - The headlights must be on during the self test.
- When servicing a vehicle with an air suspension system, the air suspension switch must be turned off:
 - When changing the engine oil and filter.
 - When changing the spark plugs.
 - When jacking the vehicle to change a tire.
 - During any of the above service procedures.
- To deflate an air spring prior to removal of the spring:
 - Disconnect the air line from the air spring.
 - Turn the air spring solenoid valve to the first stage.
 - Turn the air spring solenoid valve to the second stage.
 - Energize the vent solenoid in the air compressor.
- All of these statements about performing an on-demand self-test on a VDS system are true EXCEPT:
 - The battery must be fully charged.
 - The ignition switch must be on.
 - The vehicle must be raised on a lift.
 - The 4L mode must not be selected on four-wheel-drive vehicles.
- When diagnosing a VDS system, a U1900 DTC is obtained. This DTC indicates a defect in the:
 - Controller area network (CAN).
 - L/R air spring solenoid.
 - Vent solenoid.
 - R/F height sensor.
- When diagnosing an electronic suspension control (ESC) system, Technician A says defects represented by a DTC with a U prefix must be repaired before proceeding with further diagnosis or service. Technician B says ESC system operation may be affected by low battery voltage. Who is correct?
 - A only
 - B only

ASE-STYLE REVIEW QUESTIONS

Each chapter contains ASE-style review questions that reflect the performance-based objectives listed at the beginning of the chapter. These questions can be used to review the chapter as well as to prepare for the ASE certification exam.

ASE CHALLENGE QUESTIONS

- Technician A says during air spring inflation the vehicle weight must be applied to the suspension system. Technician B says during air spring inflation the vehicle must be on a lift so the wheels are not compressed. Who is correct?
 - A only
 - B only
 - Both A and B
 - Neither A nor B
- A vehicle with an electronic air suspension system with mechanical trim height adjustment requires front and rear trim height adjustment. Technician A says to adjust the front trim height, rotate the threaded mounting bolt in the upper end of the height sensor. Technician B says to adjust the rear trim height, loosen the attaching bolt(s) on the upper height sensor bracket and move the bracket upward or downward. Who is correct?
 - A only
 - B only
 - Both A and B
 - Neither A nor B
- When removing and replacing an air spring and shock absorber assembly on a VDS:
 - The self-locking nuts on the upper strut mount can be reused.
 - Retainer tabs on the lower end of the spring must be depressed to separate the spring and the shock absorber.
 - The spring must be vented by loosening the spring solenoid valve to the first stage.
 - The VDS switch and the ignition switch must be in the On position.

ASE CHALLENGE QUESTIONS

Each technical chapter ends with five ASE challenge questions. These are not more review questions, rather they test the students' ability to apply general knowledge to the contents of the chapter.

APPENDIX A

ASE PRACTICE EXAMINATION

- After new tires and new alloy rims are installed on a sports car, the owner complains about steering wander and steering pull in either direction while braking. Technician A says there may be brake fluid on the front brake linings. Technician B says the replacement rims may have a different offset than the original rims. Who is correct?
 - Technician A
 - Technician B
 - Both A and B
 - Neither A nor B
- Technician A says when a vehicle pulls to one side, the problem will not be caused by the manual steering gear. Technician B says when an unbalanced power steering gear valve causes a vehicle to pull to one side, the steering effort will be very light in the direction of the pull and normal or heavier in the opposite direction. Who is correct?
 - Technician A
 - Technician B
 - Both A and B
 - Neither A nor B
- The outside edge of the left front tire on a rear-wheel-drive car is badly scalloped. Technician A says the cause could be worn ball joints. Technician B says the cause could be incorrect tire pressure. Who is correct?
 - Technician A
 - Technician B
 - Both A and B
 - Neither A nor B
- The owner of a large rear-wheel-drive sedan says the front tires squeal loudly during low-speed turns. The most probable cause of this condition is:
 - Excessive positive camber.
 - Negative caster adjustment.
 - Improper steering axis inclination (SAI).
 - Improper turning angle.
- A mini-pickup has a severe shudder when the vehicle is started from a stop with a load in the bed. Technician A says the problem may be worn spring eyes. Technician B says the problem may be axle torque wrap-up. Who is correct?
 - Technician A
 - Technician B
 - Both A and B
 - Neither A nor B
- A cyclic noise ("moaning," "whining," or "howling") that changes pitch with road speed and is present whenever the vehicle is in motion may be caused by any of the following EXCEPT:
 - Worn differential gears.
 - Rear axle bearings.
 - Incorrect driveshaft runout.
 - Off-road tire tread pattern.
- Technician A says hard steering may be caused by low hydraulic pressure due to a stuck flow control valve in the pump. Technician B says hard steering may be caused by low hydraulic pressure due to a worn steering gear piston ring or housing bore. Who is correct?
 - Technician A
 - Technician B
 - Both A and B
 - Neither A nor B
- Tires and wheels on a pickup truck were changed from standard 14-inch to standard 15-inch light-truck rims. The first time the brakes were applied, the truck shook and shuddered. When the 15-inch wheels were replaced by the 14-inch wheels, braking was uneventful. Technician A says the 15-inch rim is one inch wider, which causes the brakes to grab. Technician B says the additional inch diameter increases braking leverage, overloading worn suspension bushings. Who is correct?
 - Technician A
 - Technician B
 - Both A and B
 - Neither A nor B
- While discussing tire tread wear: Technician A says a scalloped pattern of tire wear indicates an out-of-round wheel or tire. Technician B says uneven wear on one side of a tire may indicate radial force variation. Who is correct?
 - Technician A
 - Technician B
 - Both A and B
 - Neither A nor B

INSTRUCTOR RESOURCES

The Instructor Resources DVD is a robust ancillary that contains all preparation tools to meet any instructor's classroom needs. It includes presentations in PowerPoint with images, video clips, and animations that coincide with each chapter's content coverage, a computerized test bank with hundreds of test questions, a searchable image library with all pictures from the text, theory-based worksheets in Word that provide homework or in-class assignments, the Job Sheets from the Shop Manual in Word, a NATEF correlation chart, and an Instructor's Guide in electronic format.

WEBTUTOR ADVANTAGE

Newly available for this title and to the Today's Technician™ Series is the *WebTutor Advantage*, for Blackboard and Angel online course management systems. The *WebTutor for Today's Technician: Suspension & Steering Systems, 5e*, will include chapter presentations in PowerPoint with video clips and animations, end-of-chapter review questions, pretests and post-tests, worksheets, discussion springboard topics, an ASE Test Prep section, ASE Checklist, Job Sheets, and more. The *WebTutor* is designed to enhance the classroom and shop experience, engage students, and help them prepare for ASE certification exams.

REVIEWERS

The author and publisher would like to extend a special thanks to the instructors who reviewed this text and offered invaluable feedback:

James Armitage

Waubonsee Community College
Sugar Grove, IL

Rodney Batch

University of Northwestern Ohio
Lima, OH

Jack Larmor

Baker College
Flint, MI

Christopher Marker

University of Northwestern Ohio
Lima, OH

Ronald L. Raines

Ranken Technical College
St. Louis, MO

Dick Rogers

Lincoln Land Community College
Springfield, IL

Stephen Tucker

University of Northwestern Ohio
Lima, OH

Chapter 1

SAFETY

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Recognize shop hazards and take the necessary steps to avoid personal injury or property damage.
- Describe the general shop rules that must be followed in an automotive shop.
- Explain the purposes of the Occupational Safety and Health Act.
- Explain two reasons why batteries are a shop hazard.
- Describe how long hair may be a shop hazard.
- Explain how incandescent trouble lights may be a shop hazard.
- Describe the harmful effects of carbon monoxide on the human body.
- Explain why asbestos dust in the shop air is a hazard.
- Describe the requirements for the location of safety equipment in the shop.
- Explain four different types of fires, and the fire extinguisher required for each type of fire.
- Describe three pieces of shop safety equipment other than fire extinguishers.
- Describe the main purposes of the Right-to-Know laws.
- Describe the purpose of MSDSs and list the information that must be contained on these sheets.
- Explain the employer's responsibility regarding hazardous materials in the shop.
- Observe all general shop safety precautions.
- Demonstrate all precautions related to personal safety when working in the shop.
- Explain why smoking is dangerous in the shop.
- Explain why drug or alcohol use is dangerous in the shop.
- Describe basic electrical safety precautions.
- Explain gasoline safety precautions.
- Describe housekeeping safety precautions.
- Explain fire safety precautions.
- Describe the proper procedure for using a fire extinguisher.
- Describe the necessary precautions to maintain air bag safety.
- Describe the precautions to be observed when driving vehicles in the shop.
- Explain the proper procedure for lifting heavy objects.
- Describe the necessary steps for hand tool safety.
- Explain the necessary precautions when operating a vehicle lift.
- Describe hydraulic jack and safety stand safety precautions.
- Explain the necessary safety precautions when using power tools.
- Describe the precautions required to maintain compressed-air equipment safety.
- Explain the precautions and environmental concerns related to cleaning equipment safety.

INTRODUCTION

Safety is extremely important in the automotive shop! The knowledge and practice of safety precautions prevent serious personal injury and expensive property damage. Automotive students and technicians must be familiar with shop hazards and shop safety rules. The first step in providing a safe shop is learning about shop hazards and safety rules. The second, and most important, step in this process is applying your knowledge of shop hazards and safety rules while working in the shop. In other words, you must develop safe working habits in the shop from your understanding of shop hazards and safety rules. When shop employees have a careless attitude toward safety, accidents are more likely to occur; therefore, all shop personnel must develop a serious attitude toward safety. The result of this attitude is serious shop personnel who will learn and adopt all shop safety rules.

Shop personnel must be familiar with their rights regarding hazardous waste disposal. These rights are explained in the **Right-to-Know laws**. Shop personnel must also be familiar with the types of hazardous materials in the automotive shop and the proper disposal methods for these materials according to state and federal regulations.

OCCUPATIONAL SAFETY AND HEALTH ACT

The **Occupational Safety and Health Act (OSHA)** was passed by the U.S. government in 1970. The purposes of this legislation are:

1. to assist and encourage the citizens of the United States in their efforts to ensure safe and healthful working conditions by providing research, information, education, and training in the field of occupational safety and health.
2. to ensure safe and healthful working conditions for working men and women by authorizing enforcement of the standards developed under the Act.

Because approximately 25 percent of workers are exposed to health and safety hazards on the job, the OSHA is necessary to monitor, control, and educate workers regarding health and safety in the workplace.

SHOP HAZARDS

Service technicians and students encounter many hazards in an automotive shop. When these hazards are known, basic shop safety rules and procedures must be followed to avoid personal injury. Some of the hazards in an automotive shop include the following:

1. Flammable liquids, such as gasoline and paint, must be handled and stored properly in approved, closed containers to comply with safety regulations.
2. Flammable materials, such as oily rags, must be stored properly in closed containers to avoid a fire hazard.
3. Batteries contain a corrosive sulfuric acid solution and produce explosive hydrogen gas while charging.
4. Loose sewer and drain covers may cause foot or toe injuries.
5. Caustic liquids, such as those in hot cleaning tanks, are harmful to skin and eyes.
6. High-pressure air in the shop's compressed-air system can be very dangerous or fatal if it penetrates the skin and enters the bloodstream. High-pressure air released near the eyes may cause eye injury.
7. Frayed cords on electrical equipment and lights may result in severe electrical shock.
8. Hazardous waste material, such as batteries and caustic cleaning solutions, must be handled with adequate personal protection to avoid injury (Figure 1-1).
9. Carbon monoxide from vehicle exhaust is poisonous and potentially fatal.
10. Loose clothing or long hair may become entangled in rotating parts on equipment or vehicles, resulting in serious injury.



FIGURE 1-1 Always wear recommended safety clothing and equipment when handling hazardous materials.

- 11.** Dust and vapors generated during some repair jobs are harmful. Asbestos dust, which may be released during brake lining service and clutch service, is a contributor to lung cancer.
- 12.** High noise levels from shop equipment such as an air chisel may be harmful to the ears.
- 13.** Oil, grease, water, or parts cleaning solutions on shop floors may cause someone to slip and fall, resulting in serious injury.
- 14.** The incandescent bulbs used in some trouble lights may shatter if the light is dropped, igniting flammable materials in the area and causing a fire. Many insurance companies now require the use of trouble lights with fluorescent bulbs in the shop.

SHOP SAFETY RULES

Applying basic shop rules helps prevent serious, expensive accidents. Failure to comply with shop rules may cause personal injury or expensive damage to vehicles and shop facilities. It is the responsibility of the employer and all shop employees to make sure that shop rules are understood and followed until these rules become automatic habits. The following basic shop rules should be observed:

- 1.** Always wear safety glasses and other protective equipment that is required by a service procedure (Figure 1-2). For example, a brake parts washer must be used to avoid breathing asbestos dust into the lungs. Asbestos dust is a known cause of lung cancer. This dust is encountered in manual transmission clutch facings and brake linings.
- 2.** Tie long hair securely behind your head, and do not wear loose or torn clothing.
- 3.** Do not wear rings, watches, or loose hanging jewelry. If jewelry such as a ring, metal watchband, or chain makes contact between an electrical terminal and ground, the jewelry becomes extremely hot, resulting in severe burns.
- 4.** Do not work in the shop while under the influence of alcohol or drugs.
- 5.** Set the parking brake when working on a vehicle. If the vehicle has an automatic transmission, place the gear selector in park unless a service procedure requires another

Classroom Manual

Chapter 1, page 8

The improper or excessive use of alcohol or drugs may be referred to as substance abuse.



FIGURE 1-2 Shop safety clothing and equipment, including safety goggles, respirator, welding shield, proper work clothes, ear protection, welding gloves, work gloves, and safety shoes.

selector position. When the vehicle is equipped with a manual transmission, position the gear selector in neutral with the engine running or in reverse with the engine stopped.

6. Always connect a shop exhaust hose to the vehicle tailpipe, and be sure the shop exhaust fan is running. If it is absolutely necessary to operate a vehicle without a shop exhaust pipe connected to the tailpipe, open the large shop door to provide adequate ventilation. Carbon monoxide in the vehicle exhaust may cause severe headaches and other medical problems. High concentrations of carbon monoxide may result in death!
7. Keep hands, clothing, and wrenches away from rotating parts such as cooling fans. Remember that electric-drive fans may start turning at any time, even with the ignition off.
8. Always leave the ignition switch off unless a service procedure requires another switch position.
9. Always follow the vehicle manufacturer's recommended procedure to disable the high-voltage electrical system and wait for 5 minutes before working on a **hybrid vehicle**. A switch under the steering column is pushed to the Off position to disable the high-voltage system on some hybrid vehicles. On other hybrid vehicles, the high-voltage disconnect switch is mounted at or near the high-voltage battery pack. On some hybrid vehicles, the high-voltage system retains voltage for 5 minutes after the disable switch is turned off.
10. Do not smoke in the shop. If the shop has designated smoking areas, smoke only in these areas.
11. Store oily rags and other discarded combustibles in covered metal containers designed for this purpose.
12. Always use the wrench or socket that fits properly on the bolt. Do not substitute metric for English wrenches, or vice versa.
13. Keep tools in good condition. For example, do not use a punch or chisel with a mushroomed end because when struck with a hammer, a piece of the mushroomed metal could break off, resulting in severe eye or other injury.

A hybrid vehicle has a power train with two power sources. The most common type of hybrid vehicle has a gasoline engine and an electric drive motor(s).

14. Do not leave power tools running and unattended.
15. Serious burns may be prevented by avoiding contact with hot metal components, such as exhaust manifolds and other exhaust system components, radiators, and some air-conditioning hoses.
16. When a lubricant such as engine oil is drained, always wear heavy plastic gloves because the oil could be hot enough to cause burns.
17. Prior to getting under a vehicle, be sure the vehicle is placed securely on safety stands.
18. Operate all shop equipment, including lifts, according to the equipment manufacturer's recommended procedure. Do not operate equipment unless you are familiar with the correct operating procedure.
19. Do not run or engage in horseplay in the shop.
20. Obey all state and federal fire, safety, and environmental regulations.
21. Do not stand in front of or behind vehicles.
22. Always place fender, seat, and floor mat covers on a customer's vehicle before working on the car.
23. Inform the shop foreman of any safety dangers, as well as suggestions for safety improvement.
24. Do not direct high-pressure air from an air gun toward human skin or near the eyes. High-pressure air may penetrate the skin and enter the bloodstream. Air in the bloodstream may be fatal! High-pressure air discharged near the eyes may cause serious eye damage.

AIR QUALITY

Vehicle exhaust contains small amounts of carbon monoxide, which is a poisonous gas. Weak concentrations of carbon monoxide in the shop air may cause nausea and headaches; strong concentrations may be fatal. All shop personnel are responsible for air quality in the shop. Shop management is responsible for providing an adequate exhaust system that can remove exhaust fumes from the maximum-allowable number of vehicles that may be running in the shop at one time. Technicians should never run a vehicle in the shop unless a shop exhaust hose is installed on the tailpipe of the vehicle. The exhaust fan must be switched on to remove exhaust fumes.

If shop heaters or furnaces have restricted chimneys, they release carbon monoxide emissions into the shop air. Therefore, chimneys should be checked periodically for restriction and proper ventilation. Diesel exhaust contains some carbon monoxide, but particulate emissions are also present in the exhaust from these engines. Particulates are small carbon particles that can be harmful to the lungs.

Monitors are available to measure the level of carbon monoxide in the shop. Some of these monitors read the amount of carbon monoxide present in the shop air; others provide an audible alarm if the concentration of carbon monoxide exceeds the danger level.

The sulfuric acid solution in car batteries is a corrosive, poisonous liquid. If a battery is charged with a fast charger at a high rate for a period of time, the battery becomes hot, and the sulfuric acid solution begins to boil. Under this condition, the battery may emit strong sulfuric acid fumes that may be harmful to the lungs. If this happens, the battery charger should be turned off or the charging rate should be reduced considerably.

Some automotive clutch facings and brake linings contain asbestos. Never use an air hose to blow dirt from these components, because this action disperses asbestos dust into the shop where it may be inhaled by technicians and other people in the shop. A brake parts washer or a vacuum cleaner with special attachments must be used to clean the dust from these components. Even though technicians take every precaution to maintain air quality in the shop, some undesirable gases may still get into the air. For example, exhaust manifolds may get oil on them during an engine overhaul. When the engine is started

and these manifolds get hot, the oil burns off the manifolds and pollutes the shop air with oil smoke. Adequate shop ventilation must be provided to take care of this type of air contamination.

SHOP SAFETY EQUIPMENT

Fire Extinguishers

Fire extinguishers are one of the most important pieces of safety equipment. All shop personnel must know the location of each fire extinguisher in the shop. If you have to waste time looking for an extinguisher after a fire starts, the fire could get out of control before you get the extinguisher into operation. Fire extinguishers should be located where they are easily accessible at all times. A decal on each fire extinguisher identifies the type of chemical in the extinguisher and provides operating information (Figure 1-3). Shop personnel should be familiar with the following types of fires and fire extinguishers:





1. *Class A fires* are those involving ordinary combustible materials such as paper, wood, clothing, and textiles. **Multipurpose dry chemical fire extinguishers** are used on these fires.
2. *Class B fires* involve the burning of flammable liquids such as gasoline, oil, paint, solvents, and greases. These fires can also be extinguished with multipurpose dry chemical fire extinguishers. In addition, fire extinguishers containing halogen, or halon, may be used to extinguish class B fires. The chemicals in this type of extinguisher attach to the hydrogen, hydroxide, and oxygen molecules to stop the combustion process almost instantly. However, the resultant gases from the use of halogen-type extinguishers are very toxic and harmful to the operator of the extinguisher.
3. *Class C fires* involve the burning of electrical equipment such as wires, motors, and switches. These fires can be extinguished with multipurpose dry chemical fire extinguishers.
4. *Class D fires* involve the combustion of metal chips, turnings, and shavings. Dry chemical fire extinguishers are the only type of extinguisher recommended for these fires.

Some multipurpose dry chemical fire extinguishers may be used on Class A, B, C, or D fires. Additional information regarding which types of extinguishers are used for various types of fires is provided in Table 1-1.



FIGURE 1-3 Types of fire extinguishers.

TABLE 1-1 GUIDE TO FIRE EXTINGUISHER SELECTION

	Class of fire	Typical fuel involved	Type of extinguisher
Class  Fires (green)	For ordinary combustibles Put out a class A fire by blowing its temperature or by coating the burning combustibles.	Wood Paper Cloth Rubber Plastics Rubbish Upholstery	Water* Foam* Multipurpose dry chemical
Class  Fires (red)	For flammable liquids Put out a class B fire by smothering it. Use an extinguisher that gives a blanketing, flame-interrupting effect; cover whole flaming liquid surface.	Gasoline Oil Grease Paint Lighter fluid	Foam* Carbon dioxide Halogenated agent Standard dry chemical Purple K dry chemical Multipurpose dry chemical
Class  Fires (blue)	For electrical equipment Put out a class C fire by shutting off power as quickly as possible and by always using a nonconducting extinguisher agent to prevent electric snock.	Motors Appliances Wiring Fuse boxes Switchboards	Carbon dioxide Halogenated agent Standard dry chemical Purple K dry chemical Multipurpose dry chemical
Class  Fires (yellow)	For combustible metals Put out a class D fire o metal chips, turnings, or shavings by smothering or coating with a specially designed extinguisher agent.	Aluminum Magnesium Potassium Sodium Titanium Zirconium	Dry power extinguisher and agents only

*Cartridge-operated water, foam, and soda-acid types of extinguishers are no longer manufactured. These extinguishers should be removed from service when they become due for their next hydrostatic pressure test.

Causes of Eye Injuries

Eye injuries can occur in various ways in the automotive shop. Some of the more common eye accidents are:

1. Thermal burns from excessive heat
2. Irradiation burns from excessive light such as from an arc welder
3. Chemical burns from strong liquids such as battery electrolyte
4. Foreign material in the eye
5. Penetration of the eye by a sharp object
6. A blow from a blunt object

Wearing safety glasses and observing shop safety rules will prevent most eye accidents.

Eyewash Fountains

If a chemical gets in your eyes, it must be washed out immediately to prevent a chemical burn. An eyewash fountain is the most effective way to wash the eyes. An eyewash fountain is similar to a drinking water fountain, but the eyewash fountain has water jets placed throughout the fountain top. Every shop should be equipped with some type of eyewash facility (Figure 1-4). Be sure you know the location of the eyewash fountain in the shop.

Safety Glasses and Face Shields

The mandatory use of eye protection, either safety glasses or a face shield, is one of the most important safety rules in an automotive shop. Face shields protect the face; safety glasses



FIGURE 1-4 Eyewash fountain.



FIGURE 1-5 Safety glasses with side protection must be worn in the automotive shop.




FIGURE 1-6 Face shield.

protect the eyes. When grinding, safety glasses must be worn, and a face shield can be worn. Many shop insurance policies require the use of eye protection in the shop. Some automotive technicians have been blinded in one or both eyes because they did not wear safety glasses. All safety glasses must be equipped with safety glass and should provide some type of side protection (Figure 1-5). When selecting a pair of safety glasses, they should feel comfortable on your face because if they are uncomfortable, you may remove them, leaving your eyes unprotected. A face shield should be worn when handling hazardous chemicals or when using an electric grinder or buffer (Figure 1-6).

First-Aid Kits

First-aid kits should be clearly identified and conveniently located (Figure 1-7). These kits contain such items as bandages in a variety of sizes and ointment required for minor cuts. All shop personnel must be familiar with the location of first-aid kits. At least one of the




FIGURE 1-7 First-aid kit.

shop personnel should have basic first-aid training. This person should be in charge of administering first aid and keeping first-aid kits filled.

SHOP LAYOUT

There are many different types of shops in the automotive service industry, including:

- New car dealers
- Independent repair shops
- Specialty shops
- Service stations
- Fleet shops

In any shop, the layout is important to maintain shop efficiency and contribute to safety. Every shop employee must be familiar with the location of all safety equipment in the shop. Shop layout includes bays for various types of repairs, equipment storage areas, and office locations. Some specific types of bays are electrical repair, wheel alignment and tires, and machining bays (Figure 1-8). Safety equipment such as fire extinguishers, first-aid kits, and eyewash fountains must be in easily accessible locations, and the location of each piece of safety equipment must be clearly marked. Areas such as the parts department and the parts cleaning area must be located so they are easily accessible from all areas of the shop. The service manager's office should also be centrally located. All shop personnel should familiarize themselves with the shop layout, especially the location of safety equipment. If you know the exact fire extinguisher locations, you may get an extinguisher into operation a few seconds faster. Those few seconds could make the difference between a fire that is quickly extinguished and one that gets out of control, causing extensive damage and personal injury!

The tools and equipment required for a certain type of work are stored in that specific bay. For example, the equipment for electrical and electronic service work is stored in the bay allotted to that type of repair. When certain bays are allotted to specific types of repair work, unnecessary equipment movement is eliminated. Each technician has his or her own tools on a portable roll cabinet that is moved to the vehicle being repaired. Special tools are provided by the shop, and these tools should be located on tool boards attached to the wall. Other shops may have a tool room where special tools are located. Adequate workbench space must be provided in those bays where bench work is required.




FIGURE 1-8 Shop layout.

SAFETY IN THE AUTOMOTIVE SHOP

Each person in an automotive shop must follow certain basic shop safety rules to remove the danger from shop hazards and prevent personal injury, vehicle damage, and property damage.


Technicians must understand shop safety as it applies to these categories:

1. General shop safety
2. Personal safety

GENERAL SHOP SAFETY

When general shop safety rules are observed, personal injury and expensive property or vehicle damage may be avoided, and shop production is increased.

1. All sewer covers must fit properly and be kept securely in place.
2. When servicing brakes or clutches from manual transmissions, always clean asbestos dust from these components with an OSHA-approved **brake parts washer** (Figure 1-9). The brake parts washer contains a Greasoff® brake cleaning solution. The washer is placed under the wheel brake assembly to be washed, and a pump in the washer forces the cleaning solution through a hose and brush that is used to clean the brake components. Removed brake components may also be washed in the top tray on the washer.



WARNING: Do not breathe asbestos dust, because this dust is a known contributor to lung cancer.

3. Always use the correct tool for the job. For example, never strike a hardened steel component, such as a piston pin, with a steel hammer. This type of component may shatter, and fragments can penetrate eyes or skin.
4. Follow the car manufacturer's recommended service procedures.
5. Avoid working on a vehicle parked on an incline.
6. Never work under a vehicle unless the vehicle chassis is supported securely on safety stands.



FIGURE 1-9 Brake parts cleaner.

7. When one end of a vehicle is raised, place wheel chocks on both sides of the wheels remaining on the floor.
8. Be sure that you know the location of shop first-aid kits, eyewash fountains, and fire extinguishers.
9. Collect oil, fuel, brake fluid, and other liquids in the proper safety containers.
10. Use only approved cleaning fluids and equipment. Do not use gasoline to clean parts.
11. Do not leave running equipment unattended.
12. Be sure the safety shields are in place on rotating equipment.
13. All shop equipment must have regularly scheduled maintenance and adjustment.
14. Some shops have safety lines around equipment. Always work within these lines when operating equipment.
15. Be sure that shop heating equipment is well-ventilated.
16. Do not run in the shop or engage in horseplay.
17. Post emergency phone numbers near the phone. These numbers should include doctor, ambulance, fire department, hospital, and police.
18. Do not place hydraulic jack handles where someone can trip over them.
19. Keep aisles clear of debris.

PERSONAL SAFETY

Personal safety is the responsibility of each technician in the shop.

Always follow these safety practices:

1. Always use the correct tool for the job. If the wrong tool is used, it may slip and cause injury.
2. Follow the vehicle manufacturer's recommended service procedures.
3. Always wear eye protection, such as safety glasses with side protection or a face shield.
4. Wear protective gloves when cleaning parts in hot or cold tanks and when handling hot parts, such as exhaust manifolds.
5. Always wear 1,000 V, class-0 rated, high-voltage gloves to protect against electrical shock when servicing hybrid vehicles.
6. Regularly inspect high-voltage gloves for pin holes or other damage that could result in electric shock. Replace high-voltage gloves at the glove manufacturer's recommended intervals.

7. Before working on a hybrid vehicle, always follow the vehicle manufacturer's recommended service procedure to disable the high-voltage electrical system. On many hybrid vehicles, the high-voltage disconnect switch is located at or near the high-voltage battery pack. Turn the high-voltage disconnect switch Off to disable the high-voltage system.
8. After the high-voltage system is disabled on a hybrid vehicle, always wait for the time period specified by the vehicle manufacturer before servicing the vehicle. On some hybrid vehicles, the high-voltage system retains voltage for 5 minutes after the disable switch is turned off.
9. Some hybrid vehicles contain nickel–metal hydride batteries in the high-voltage battery pack. These batteries contain potassium hydroxide, a highly alkaline solution that damages human tissue. Always follow the vehicle manufacturer's recommended service procedures and wear the recommended protective equipment such as a face shield and gloves when servicing these batteries.
10. Do not smoke when working in the shop. A spark from a cigarette or lighter may ignite flammable materials in the work area.
11. When working on a running engine, keep hands and tools away from rotating parts. Remember that electric-drive fans may start turning at any time.
12. Do not wear loose clothing, and keep long hair tied behind your head. Loose clothing or long hair is easily entangled in rotating parts.
13. Wear safety shoes or boots. Heavy-duty work boots or shoes with steel toe caps are best for working in the automotive shop. Footwear must protect against heavy falling objects, flying sparks, and corrosive liquids. Soles on footwear must protect against punctures by sharp objects. Athletic shoes and street shoes are not recommended in the shop.
14. Be sure that the shop has adequate ventilation. Carbon monoxide is odorless; do not expect to be able to smell it.
15. Make sure the work area has adequate lighting.
16. When servicing a vehicle, always apply the parking brake. Place the transmission in park with an automatic transmission, or neutral with a manual transmission.
17. Avoid working on a vehicle parked on an incline.
18. Never work under a vehicle unless the vehicle chassis is supported securely on safety stands.
19. Do not use electrical equipment, including trouble lights, with frayed cords.
20. Be sure the safety shields are in place on rotating equipment.
21. Before operating electric equipment, be sure the power cord has a ground connection.
22. When working in an area where noise levels are extreme, wear earplugs or ear covers.
23. Wear a respirator to protect your lungs when working in dusty conditions.
24. Do not use **incandescent bulb-type trouble lights**. Use **fluorescent trouble lights** (Figure 1-10).

Smoking, Alcohol, and Drugs in the Shop

Do not smoke when working in the shop. If the shop has designated smoking areas, smoke only in these areas. Do not smoke in customers' cars. A nonsmoker will not appreciate cigarette odor in the car. A spark from a cigarette or lighter may ignite flammable materials in the workplace. The use of drugs or alcohol must be avoided while working in the shop. Even a small amount of drugs or alcohol affects reaction time. In an emergency situation, slow reaction time may cause personal injury. If a heavy object falls off the workbench, and your reaction time is slowed by drugs or alcohol, you may not get your foot out of the way in time to avoid a foot injury. When a fire starts in the workplace, and you are a few seconds slower getting a fire extinguisher into operation because of alcohol or drug use, it could make the difference between extinguishing a fire and having expensive fire damage.

The improper or excessive use of alcoholic beverages, inhalants, and/or drugs may be referred to as substance abuse.




FIGURE 1-10 Incandescent-type trouble light and fluorescent-type trouble light.

ELECTRICAL SAFETY

In the automotive shop you will be using electric drills, shop lights, wheel balancers, and wheel aligners.

Observe the following electrical safety precautions on this equipment:

1. Frayed cords on electrical equipment must be replaced or repaired immediately.
2. All electrical cords from lights and electrical equipment must have a ground connection. The ground connector is the round terminal in a three-pronged electrical plug. Do not use a two-pronged adapter to plug in a three-pronged electrical cord. Three-pronged electrical outlets should be mandatory in all shops.
3. Do not leave electrical equipment running and unattended.

GASOLINE SAFETY

Gasoline is a very explosive liquid! One exploding gallon of gasoline has a force equal to 14 sticks of dynamite. The expanding vapors from gasoline are extremely dangerous. These vapors are present even in cold temperatures. Vapors formed in gasoline tanks on cars are controlled, but vapors from a gasoline storage can may escape from the can, resulting in a hazardous situation. Therefore, gasoline storage containers must be placed in a well-ventilated space.

Approved gasoline storage cans have a flash-arresting screen at the outlet (Figure 1-11). This screen prevents external ignition sources from igniting the gasoline within the can while the gasoline is being poured.

Follow these safety precautions regarding gasoline containers:

1. Always use approved gasoline containers that are painted red for proper identification.
2. Do not fill gasoline containers completely full. Always leave the level of gasoline at least one inch from the top of the container. This allows for expansion of the gasoline at higher temperatures. If gasoline containers are completely full, the gasoline will expand when the temperature increases. This expansion forces gasoline from the can and creates a dangerous spill.
3. If gasoline containers must be stored, place them in a well-ventilated area such as a storage shed. Do not store gasoline containers in your home or in the trunk of a vehicle.

A gasoline can may be called a jerry can.




FIGURE 1-11 Approved gasoline container.

4. When a gasoline container must be transported, be sure it is secured against upsets.
5. Do not store a partially filled gasoline container for long periods of time, because it may give off vapors and produce a potential danger.
6. Never leave gasoline containers open except while filling or pouring gasoline from the container.
7. Do not prime an engine with gasoline while cranking the engine.
8. Never use gasoline as a cleaning agent.

FIRE SAFETY

When fire safety rules are observed, personal injury and expensive fire damage to vehicles and property may be avoided. Follow these fire safety rules:

1. Familiarize yourself with the location and operation of all shop fire extinguishers.
2. If a fire extinguisher is used, report it to management so the extinguisher can be recharged.
3. Do not use any type of open-flame heater to heat the work area.
4. Do not turn on the ignition switch or crank the engine with a gasoline line disconnected.
5. Store all combustible materials such as gasoline, paint, and oily rags in approved safety containers.
6. Clean up gasoline, oil, or grease spills immediately.
7. Always wear clean shop clothes. Do not wear oil-soaked clothes.
8. Do not allow sparks and flames near batteries.
9. Be sure that welding tanks are securely fastened in an upright position.
10. Do not block doors, stairways, or exits.
11. Do not smoke when working on vehicles.
12. Do not smoke or create sparks near flammable materials or liquids.
13. Store combustible shop supplies such as paint in a closed steel cabinet.
14. Store gasoline in approved safety containers.
15. If a gasoline tank is removed from a vehicle, do not drag the tank on the shop floor.
16. Know the approved fire escape route from your classroom or shop to the outside of the building.
17. If a fire occurs, do not open doors or windows. This action creates extra draft, which makes the fire worse.
18. Do not put water on a gasoline fire, because the water will make the fire worse.
19. Call the fire department as soon as a fire begins, and then attempt to extinguish the fire.
20. If possible, stand 6 to 10 feet from the fire and aim the fire extinguisher nozzle at the base of the fire with a sweeping action.
21. If a fire produces a lot of smoke in the room, remain close to the floor to obtain oxygen and avoid breathing smoke.
22. If the fire is too hot or the smoke makes breathing difficult, get out of the building.




FIGURE 1-12 Safe procedures for flammable liquid transfer.

23. Do not re-enter a burning building.
24. Keep solvent containers covered except when pouring from one container to another. When flammable liquids are transferred from bulk storage, the bulk container should be grounded to a permanent shop fixture, such as a metal pipe. During this transfer process, the bulk container should be grounded to the portable container (Figure 1-12). These ground wires prevent the buildup of a static electric charge, which could cause a spark and a disastrous explosion. Always discard or clean empty solvent containers, because fumes in these containers are a fire hazard.
25. Familiarize yourself with different types of fires and fire extinguishers, and know the type of extinguisher to use on each type of fire.

Using a Fire Extinguisher

Everyone working in the shop must know how to operate the fire extinguishers.

There are several different types of fire extinguishers, but their operation usually involves the following steps:

1. Get as close as possible to the fire without jeopardizing your safety.
2. Grasp the extinguisher firmly and aim the extinguisher at the fire.
3. Pull the pin from the extinguisher handle.
4. Squeeze the handle to dispense the contents of the extinguisher.
5. Direct the fire extinguisher nozzle at the base of the fire, and dispense the contents of the extinguisher with a sweeping action back and forth across the fire. Most extinguishers discharge their contents in 8 to 25 seconds.
6. Always be sure the fire is extinguished.
7. Always keep an escape route open behind you so a quick exit is possible if the fire gets out of control.

VEHICLE OPERATION

When driving a customer's vehicle, observe the following precautions to prevent accidents and maintain good customer relations:

1. Prior to driving a vehicle, make sure the brakes are operating and fasten the safety belt.
2. Before you start the engine, check to be sure there is no person or object under the car.

3. If the vehicle is parked on a lift, be sure the lift is fully down and that the lift arms or components are not in contact with the vehicle chassis.
4. Before driving away, check to see if any objects are directly in front of or behind the vehicle.
5. Always drive slowly in the shop, and watch carefully for personnel and other moving vehicles.
6. Make sure the shop door is up high enough so there is plenty of clearance between the top of the vehicle and the door.
7. Watch the shop door to be certain that it is not coming down as you attempt to drive under the door.
8. If a road test is necessary, wear your seat belt, obey all traffic laws, and never drive in a reckless manner.
9. Do not squeal tires when accelerating or turning corners.

If customers observe that service personnel take good care of their car by driving carefully and by installing fender, seat, and floor mat covers, the service department's image is greatly enhanced in their eyes. These procedures impress upon the customers that shop personnel respect their car. Conversely, if grease spots are found on the upholstery or fenders after service work is completed, the customers will probably think the shop is careless, not only in car care but also in service work quality.

HOUSEKEEPING SAFETY

CUSTOMER CARE: When customers see that you are concerned about their vehicle and that you operate a shop with excellent housekeeping habits, they will be impressed and will likely keep returning for service.

Careful housekeeping habits prevent accidents and increase worker efficiency. Good housekeeping also helps impress upon the customer that quality work is a priority in this shop.

Follow these housekeeping rules:

1. Keep aisles and walkways clear of tools, equipment, and other items.
2. Be sure all sewer covers are securely in place.
3. Keep floor surfaces free of oil, grease, water, and loose material.
4. Sweep up under a vehicle before lowering the vehicle on the lift.
5. Proper trash containers must be conveniently located, and these containers should be emptied regularly.
6. Access to fire extinguishers must be unobstructed at all times, and fire extinguishers should be checked for proper charge at regular intervals.
7. Tools must be kept clean and in good condition.
8. When not in use, tools must be stored in their proper location.
9. Oily rags must be stored in approved, covered containers (Figure 1-13). A slow generation of heat occurs from the oxidation of oil on these rags. Heat may continue to be generated until the ignition temperature is reached. The oil and rags then begin to burn, causing a fire. This action is called spontaneous combustion. However, if the oily rags are in an airtight, approved container, there is not enough oxygen to cause burning.
10. Store paint, gasoline, and other flammable liquids in a closed steel cabinet (Figure 1-14).
11. Rotating components on equipment and machinery must have guards, and all shop equipment should have regular service and adjustment schedules.
12. Keep the workbenches clean. Do not leave heavy objects, such as used parts, on the bench after you are finished with them.
13. Keep parts and materials in their proper location.

Classroom Manual

Chapter 5, page 98



SERVICE TIP:

When you are finished with a tool, never set it on the customer's car. After using a tool, the best place for it is in your tool box or on the workbench. Many tools have been lost by leaving them on customers' vehicles.




FIGURE 1-13 Dirty shop towels or rags must be kept in an approved, closed container.



FIGURE 1-14 Store combustible materials in an approved safety cabinet.

14. When not in use, creepers must not be left on the shop floor. Creepers should be stored in a specific location.
15. The shop should be well-lit, and all lights should be in working order.
16. Frayed electrical cords on lights or equipment must be replaced.
17. Walls and windows should be cleaned regularly.
18. Stairs must be clean, well-lit, and free of loose material.

AIR BAG SAFETY

1. When service is performed on any **air bag system** component, always disconnect the negative battery cable, isolate the cable end, and wait for the amount of time specified by the vehicle manufacturer before proceeding with the necessary diagnosis or service. The average waiting period is two minutes, but some vehicle manufacturers specify up to ten minutes. Photo Sequence 1 shows a typical procedure for removing an air bag module.

On some recent-model vehicles, the air bag system is divided into different disabling and enabling zones for diagnostic and service purposes. When performing vehicle service on or near air bag system components, the vehicle manufacturer recommends disabling the air bag components, in the zone where the air bag components are located rather than disconnecting the vehicle battery (Figure 1-15). The air bag system components in each disabling zone are the following:

- Zone 1—Front end air bag sensors
- Zone 2—Driver/side impact sensor




FIGURE 1-15 Air bag system disabling and enabling zones.

An **air bag system** is designed to protect the driver and/or passengers in a vehicle collision.



SERVICE TIP: After disconnecting battery voltage from an air bag system, failure to wait for the specified time period before servicing the system may cause accidental air bag deployment.

PHOTO SEQUENCE 1

TYPICAL PROCEDURE FOR REMOVING AIR BAG MODULE



P1-1 Tools required to remove the air bag module: safety glasses, seat covers, screwdriver set, torx driver set, battery terminal pullers, battery pliers, assorted wrenches, ratchet and socket set, and service manual.



P1-2 Place the seat and fender covers on the vehicle.




P1-3 Place the front wheels in the straight-ahead position, and turn the ignition switch to the LOCK position.



P1-4 Disconnect the negative battery cable.




P1-5 Tape the cable terminal to prevent accidental connection with the battery post. Note: A piece of rubber hose can be substituted for the tape.



P1-6 Remove the SIR fuse from the fuse box. Wait 10 minutes to allow the reserve energy to dissipate.



P1-7 Remove the connector position assurance (CPA) from the yellow electrical connector at the base of the steering column.



P1-8 Disconnect the yellow two-way electrical connector.




P1-9 Remove the four bolts that secure the module from the rear of the steering wheel.


PHOTO SEQUENCE 1 (CONTINUED)



P1-10 Rotate the horn lead 1/4 turn and disconnect.



P1-11 Disconnect the electrical connectors.



P1-12 Remove the module.

Zone 3—Steering wheel air bag inflator module and coil

Zone 4—Air bag system sensing and diagnostic module (SDM)

Zone 5—Air bag system instrument panel module

Zone 6—Passenger/side impact sensor

Zone 7—Driver seat with L/F side impact module and seat belt pretensioner

Zone 8—Not used

Zone 9—Passenger seat with R/F side impact module and seat belt pretensioner

2. Replacement air bag system parts must have the same part number as the original part. Replacement parts of lesser or questionable quality must not be used. Improper or inferior components may result in inappropriate air bag deployment and injury to the vehicle occupants.
3. Do not strike or jar a sensor or an air bag system diagnostic monitor (ASDM). This may cause air bag deployment or make the sensor inoperative. Accidental air bag deployment may cause personal injury, and an inoperative sensor may result in air bag deployment failure, causing personal injury to vehicle occupants.
4. All sensors and mounting brackets must be properly torqued to ensure correct sensor operation before an air bag system is powered up. If sensor fasteners do not have the proper torque, improper air bag deployment may result in injury to vehicle occupants.
5. When working on the electrical system on an air-bag-equipped vehicle, use only the vehicle manufacturer's recommended tools and service procedures. The use of improper tools or service procedures may cause accidental air bag deployment and personal injury. For example, do not use 12 V or self-powered test lights when servicing the electrical system on an air-bag-equipped vehicle.
6. When handling a deployed air bag always wear safety glasses and shop gloves. Dispose of the deployed air bag through the normal refuse channels. Remove the shop gloves and wash your hands in mild soap and water.

! WARNING: A deployed air bag may be partially covered with sodium hydroxide, which is a skin and eye irritant.

LIFTING AND CARRYING

Many automotive service jobs require heavy lifting. Know your maximum weight-lifting ability, and do not attempt to lift more than this weight. If a heavy part exceeds your weight-lifting ability, have a coworker help with the lifting job.




FIGURE 1-16 Use your leg muscles, never your back, to lift heavy objects.

Follow these steps when lifting or carrying an object:

1. If the object is going to be carried, be sure your path is free from loose parts or tools.
2. Position your feet close to the object; position your back reasonably straight for proper balance.
3. Your back and elbows should be kept as straight as possible. Continue to bend your knees until your hands reach the best lifting location on the object.
4. Be certain the container is in good condition. If a container falls apart during the lifting operation, parts may drop out of the container and result in foot injury or part damage.
5. Maintain a firm grip on the object; do not attempt to change your grip while lifting is in progress.
6. Straighten your legs to lift the object and keep the object close to your body. Use your leg muscles rather than your back muscles (Figure 1-16).
7. If you have to change the direction of travel, turn your whole body. Do not twist.
8. Do not bend forward to place an object on a workbench or table. Position the object on the front surface of the workbench and slide it back. Do not pinch your fingers under the object while setting it on the front of the bench.
9. If the object must be placed on the floor or a low surface, bend your legs to lower the object. Do not bend your back forward, because this movement strains back muscles.
10. When a heavy object must be placed on the floor, place suitable blocks under the object to prevent jamming your fingers.

HAND TOOL SAFETY

Many shop accidents are caused by improper use and care of hand tools.

Follow these safety steps when working with hand tools:

1. Maintain tools in good condition and keep them clean. Worn tools may slip and result in hand injury. If a hammer with a loose head is used, the head may fly off and cause personal injury or vehicle damage. If your hand slips off a greasy tool, it may cause some part of your body to hit the vehicle, causing injury.
2. Using the wrong tool for the job may damage the tool, fastener, or your hand if the tool slips. If you use a screwdriver as a chisel or pry bar, the blade may shatter, causing serious personal injury.
3. Use sharp-pointed tools with caution. Always check your pockets before sitting on the vehicle seat. A screwdriver, punch, or chisel in the back pocket may put an expensive tear in the upholstery. Do not lean over fenders with sharp tools in your pockets.
4. Tools that are intended to be sharp should be kept sharp. A sharp chisel, for example, will do the job faster with less effort.

LIFT SAFETY

Special precautions and procedures must be followed when a vehicle is raised on a lift.

Follow these steps for safe lift operation:


1. Always be sure the lift is completely lowered before driving a vehicle on or off the lift.
2. Do not hit or run over lift arms and adaptors when driving a vehicle on or off the lift. Have a coworker guide you when driving a vehicle onto the lift. Do not stand in front of a lift with the car coming toward you.
3. Be sure the lift pads contact the car manufacturer's recommended lifting points shown in the service manual. If the proper lifting points are not used, components under the vehicle such as brake lines or body parts may be damaged. Failure to use the recommended lifting points may cause the vehicle to slip off the lift, resulting in severe vehicle damage and personal injury.
4. Before a vehicle is raised or lowered, close the doors, hood, and trunk lid.
5. When a vehicle has been lifted a short distance off the floor, stop the lift and check the contact between the hoist lift pads and the vehicle to be sure the lift pads are still on the recommended lifting points.
6. When a vehicle has been raised, be sure the safety mechanism is in place to prevent the lift from dropping accidentally.
7. Prior to lowering a vehicle, always make sure there are no objects, tools, or people under the vehicle.
8. Do not rock a vehicle on a lift during a service job.
9. When a vehicle is raised, removal of some heavy components may cause vehicle imbalance. For example, because front-wheel-drive cars have the engine and transaxle at the front of the vehicle, these cars have most of their weight on the front end. Removing a heavy rear-end component on these cars may cause the back end of the car to rise off the lift. If this happens, the vehicle could fall off the lift!
10. Do not raise a vehicle on a lift with people in the vehicle.
11. When raising pickup trucks and vans on a lift, remember these vehicles are higher than a passenger car. Be sure there is adequate clearance between the top of the vehicle and the shop ceiling or components under the ceiling.
12. Do not raise a four-wheel drive vehicle with a frame contact lift unless proper adaptors are used. Lifting a vehicle on a frame contact lift without the proper adaptors may damage axle joints.
13. Do not operate a front-wheel drive vehicle that is raised on a frame contact lift. This may damage the front drive axles.



CAUTION:

When a vehicle is raised on a lift, the vehicle must be raised high enough to allow engagement of the lift locking mechanism.

HYDRAULIC JACK AND SAFETY STAND SAFETY



WARNING: Always make sure the safety stand weight capacity rating exceeds the vehicle weight that you are planning to raise. A safety stand with insufficient weight capacity may collapse, resulting in vehicle damage and/or personal injury.



WARNING: Never lift a vehicle with a floor jack if the weight of the vehicle exceeds the rated capacity of the jack. If the vehicle weight exceeds the weight rating of the floor jack, the vehicle weight may collapse the floor jack, resulting in jack and vehicle damage and/or personal injury.

Accidents involving the use of floor jacks and safety stands may be avoided if these safety precautions are followed:

1. Never work under a vehicle unless safety stands are placed securely under the vehicle chassis and the vehicle is resting on these stands (Figure 1-17).



FIGURE 1-17 Safety stands.

2. Prior to lifting a vehicle with a floor jack, be sure that the jack lift pad is positioned securely under a recommended lifting point on the vehicle. Lifting the front end of a vehicle with the jack placed under a radiator support may cause severe damage to the radiator and support.
3. Position the safety stands under a strong chassis member such as the frame or axle housing. The safety stands must contact the vehicle manufacturer's recommended lifting points.
4. Because the floor jack is on wheels, the vehicle and safety stands tend to move as the vehicle is lowered from a floor jack onto the safety stands. Always be sure the safety stands remain under the chassis member during this operation, and be sure the safety stands do not tip. All the safety stand legs must remain in contact with the shop floor.
5. When the vehicle is lowered from the floor jack onto the safety stands, remove the floor jack from under the vehicle. Never leave a jack handle sticking out from under a vehicle, which may trip someone and cause an injury.

POWER TOOL SAFETY

Power tools use electricity, shop air, or hydraulic pressure as a power source. Careless operation of power tools may cause personal injury or vehicle damage.

Follow these steps for safe power tool operation:

1. Do not operate power tools with frayed electrical cords.
2. Be sure the power tool cord has a proper ground connection.
3. Do not stand on a wet floor while operating an electric power tool.
4. Always unplug an electric power tool before servicing the tool.
5. Do not leave a power tool running and unattended.
6. When using a power tool on small parts, do not hold the part in your hand. The part must be secured in a bench vise or with locking pliers.
7. Do not use a power tool on a job where the maximum capacity of the tool is exceeded.
8. Be sure that all power tools are in good condition; always operate these tools according to the tool manufacturer's recommended procedure.
9. Make sure all protective shields and guards are in position.
10. Maintain proper body balance while using a power tool.
11. Always wear safety glasses or a face shield.
12. Wear ear protection.
13. Follow the equipment manufacturer's recommended maintenance schedule for all shop equipment.
14. Never operate a power tool unless you are familiar with the tool manufacturer's recommended operating procedure, because serious accidents can occur.
15. Always make sure that the wheels are securely attached and in good condition on the electric grinder.

16. Keep fingers and clothing away from grinding and buffing wheels. When grinding or buffing a small part, hold the part with a pair of locking pliers.
17. Always make sure the sanding or buffing disc is securely attached to the sander pad.
18. Special heavy-duty sockets must be used on impact wrenches. If ordinary sockets are used on an impact wrench, they may break and cause serious personal injury.

COMPRESSED-AIR EQUIPMENT SAFETY

The shop air supply contains high-pressure air in the shop compressor and air lines. Serious injury or property damage may result from careless operation of compressed-air equipment.

Follow these steps to improve safety:

1. Never operate an air chisel unless the tool is securely connected to the chisel with the proper retaining device.
2. Never direct a blast of air from an air gun toward any part of your body. If air penetrates the skin and enters the bloodstream, it may cause very serious health problems and even death.
3. Safety glasses or a face shield should be worn for all shop tasks, including those tasks involving the use of compressed-air equipment.
4. Wear ear protection when using compressed-air equipment.
5. Always maintain air hoses and fittings in good condition. If an end suddenly blows off an air hose, the hose will whip around, causing possible personal injury.
6. Do not direct compressed air against the skin, because it may penetrate the skin, especially through small cuts or scratches, and enter the bloodstream, causing death or serious health complications. Use only OSHA-approved air gun nozzles.
7. Do not use an air gun to blow debris off clothing or hair.
8. Do not clean the workbench or floor with compressed air. This action may blow very small parts toward your skin or into your eye. Small parts blown by compressed air may also cause vehicle damage. For example, if the car in the next stall has the air cleaner removed, a small part may find its way into the carburetor or throttle body. When the engine is started, this part will likely be pulled into a cylinder by engine vacuum, and the part will penetrate through the top of a piston.
9. Never spin bearings with compressed air because the bearing will rotate at extremely high speed. This may damage the bearing or cause it to disintegrate, causing personal injury.
10. All pneumatic tools must be operated according to the tool manufacturer's recommended operating procedure.
11. Follow the equipment manufacturer's recommended maintenance schedule for all compressed-air equipment.

CLEANING EQUIPMENT SAFETY AND ENVIRONMENTAL CONSIDERATIONS

Cleaning Equipment Safety

All technicians are required to clean parts during their normal work routines. Face shields and protective gloves must be worn while operating cleaning equipment. In most states, environmental regulations require that the runoff from steam cleaning must be contained in the steam cleaning system. This runoff cannot be dumped into the sewer system. Because it is expensive to contain this runoff in the steam cleaning system, the popularity of steam cleaning has decreased. The solution in hot and cold cleaning tanks may be caustic, and contact between this solution and skin or eyes must be avoided. Parts cleaning often creates a slippery floor, and care must be taken when walking in the parts cleaning area. The floor in this area should be cleaned frequently. When the cleaning solution in hot or cold cleaning tanks is replaced, environmental regulations require that the old solution be handled as hazardous waste. Use caution when placing aluminum or aluminum alloy parts in a cleaning solution. Some cleaning solutions will damage these components. Always follow the cleaning equipment manufacturer's recommendations.




FIGURE 1-18 Parts washer with electromechanical agitation.

Parts Washers with Electromechanical Agitation

Some parts washers provide electromechanical agitation of the parts to provide improved cleaning action (Figure 1-18). These parts washers may be heated with gas or electricity. Various water-based **hot cleaning tank** solutions are available, depending on the type of metals being cleaned. For example, Klear-Flo Greasoff® No. 1 powdered detergent is available for cleaning iron and steel. Nonheated electromechanical parts washers are also available, and these washers use cold cleaning solutions such as Klear-Flo Degreasol® formulas.

Many cleaning solutions, such as Klear-Flo Degreasol® 99R, contain no ingredients listed as hazardous by the Environmental Protection Agency's Resource Conservation and Recovery Act (RCRA). This cleaning solution is a blend of sulfur-free hydrocarbons, wetting agents, and detergents. Degreasol® 99R does not contain aromatic or chlorinated solvents, and it conforms to California's Rule 66 for clean air. Always use the cleaning solution recommended by the equipment manufacturer.

Cold Parts Washer with Agitation Immersion Tank

Some parts washers have an agitator immersion chamber under the shelves that provides thorough parts cleaning. Folding work shelves provide a large upper cleaning area with a constant flow of solution from the dispensing hose (Figure 1-19). This **cold parts washer** operates on Degreasol® 99R cleaning solution.




FIGURE 1-19 Cold parts washer with agitated immersion tank.

A **hot cleaning tank** uses a heated solution to clean metal parts.

A **cold parts washer** uses a non-heated solution to clean metal parts.



FIGURE 1-20 Aqueous parts cleaning tank.

Aqueous Parts Cleaning Tank

The **aqueous parts cleaning tank** uses a water-based, environmentally friendly cleaning solution, such as Greasoff® 2, rather than traditional solvents. The immersion tank is heated and agitated for effective parts cleaning (Figure 1-20). A sparger bar pumps a constant flow of cleaning solution across the surface to push floating oils away, and an integral skimmer removes these oils. This action prevents floating surface oils from redepositing on cleaned parts.

Handling Shop Wastes

The shop is responsible for hazardous waste until such waste is delivered to a hazardous waste site. Many shops contract a hazardous waste hauler to transport hazardous waste from the shop to government-approved recyclers or hazardous waste disposal sites. Always hire a properly licensed waste hauler, and have a written contract with them. Be sure you know how the waste hauler disposes of shop wastes. The hazardous waste hauler fills out the necessary forms related to waste disposal and communicates with state and federal agencies that are in charge of hazardous waste disposal regulations. Keep all shipping bills from your hazardous waste hauler to prove you have recycled or disposed of hazardous waste material.

Batteries

Batteries should be recycled by shipping them to a reclaimer or back to the battery distributor. When defective batteries are stored on-site, they should be kept in watertight, acid-resistant containers. Acid residue from batteries is hazardous because it is corrosive and may contain lead and other toxins. Inspect defective batteries for cracks and leaks. Cover spilled battery acid with baking soda or lime to neutralize it, then clean up and dispose of any other hazardous material.

Oil

Used oil is commonly hauled to an oil recycling facility. Place oil drip pans under a vehicle with oil leaks so oil does not drip onto the storage area. In some states it is legal to burn used oil in a commercial space heater. State and local authorities must be contacted regarding regulations and permits.

Oil Filters

Used oil filters should be allowed to drain into an appropriate drip pan for 24 hours. After the draining process, oil filters should be squashed and recycled.

Solvents

Parts cleaning equipment that uses hazardous cleaning chemicals should be replaced with cleaning equipment that uses water-based degreasers. If hazardous chemicals are used in cleaning equipment, these chemicals must be recycled or disposed of as hazardous waste. Evaporation from spent cleaning chemicals is a contributor to ozone depletion and smog formation. Spent cleaning chemicals should be placed in closed, labeled containers and stored in drip pans or in diked areas. The storage area for waste materials should be covered to prevent rain from washing contaminants from stored materials into the groundwater. This storage area may have to be fenced and locked if vandalism is a possibility.

Liquids

Engine coolant should be collected and recycled in an approved coolant recycling machine. Other liquids such as brake fluid and transmission fluid should be labeled and stored in the same area as solvents. Used brake fluid or transmission fluid should be recycled or disposed of as hazardous waste material.

Shop Towels

When dirty shop towels are stored on-site, they should be placed in closed containers that are clearly marked "Contaminated shop towels only." Shop towels should be cleaned by a laundry service that has the capability to treat the wastewater generated by cleaning these towels.

Refrigerants

When servicing automotive air-conditioning systems, it is illegal to vent refrigerants to the atmosphere. Certified equipment must be used to recover and recycle the refrigerant and to recharge air-conditioning systems. This service work must be performed by an EPA-certified technician.

The EPA approves a Refrigerant Recovery and Recycling Review and Quiz supplied by the National Institute for Automotive Service Excellence (ASE). Upon successful completion of the ASE review and quiz, a technician is certified to service mobile A/C refrigerant systems. The ASE review and quiz meets Section 609 regulations in the Clean Air Act Amendments.

HAZARDOUS WASTE DISPOSAL

Hazardous waste materials in automotive shops are chemicals or components that the shop no longer needs. These materials pose a danger to the environment and to people if they are disposed of in ordinary trash cans or sewers. However, no material is considered hazardous waste until the shop has finished using it and is ready to dispose of it. The **Environmental Protection Agency (EPA)** publishes a list of hazardous materials, which is included in the Code of Federal Regulations. Waste is considered hazardous if it is included on the EPA list of hazardous materials, or if it has one or more of these characteristics:

1. **Reactive.** Any material that reacts violently with water or other chemicals is considered hazardous. If a material releases cyanide gas, hydrogen sulphide gas, or similar gases when exposed to low-pH acid solutions, it is hazardous.
2. **Corrosive.** If a material burns the skin or dissolves metals and other materials, it is considered hazardous.
3. **Toxic.** Materials are hazardous if they leach one or more of eight heavy metals in concentrations greater than 100 times the primary drinking water standard.
4. **Ignitable.** A liquid is hazardous if it has a flashpoint below 140°F (60°C). A solid is hazardous if it ignites spontaneously.

Federal and state laws control the disposal of hazardous waste materials. Every shop employee must be familiar with these laws. Hazardous waste disposal laws include the **Resource Conservation and Recovery Act (RCRA)**. This law states that hazardous material users are

The **Environmental Protection Agency (EPA)** is the federal agency responsible for air and water quality in the United States.

A material that is **reactive** reacts with some other chemicals and gives off gas(es) during the reaction.

A material that is **corrosive** causes another material to be gradually worn away by chemical action.

A **toxic** substance is poisonous to animal or human life.

A substance that is **ignitable** can be ignited spontaneously or by another source of heat or flame.



FIGURE 1-21 Hazardous waste hauler.

responsible for hazardous materials from the time they become waste until the proper waste disposal is completed. Many automotive shops hire an independent hazardous waste hauler to dispose of hazardous waste material (Figure 1-21). The shop owner or manager should have a written contract with the hazardous waste hauler. Rather than hauling hazardous waste material to an approved hazardous waste disposal site, a shop may choose to recycle the material in the shop; therefore, hazardous waste material must be properly and safely stored. The user is responsible for the transportation of this material until it arrives at an approved hazardous waste disposal site and is processed according to the law.

The RCRA controls these types of automotive waste:

1. Paint and body repair products waste
2. Solvents for parts and equipment cleaning
3. Batteries and battery acid
4. Mild acids used for metal cleaning and preparation
5. Waste oil, engine coolants, and antifreeze
6. Air-conditioning refrigerants
7. Engine oil filters

Never, under any circumstances, use these methods to dispose of hazardous waste material:

1. Pour hazardous wastes on weeds to kill them.
2. Pour hazardous wastes on gravel streets to prevent dust.
3. Throw hazardous wastes in a dumpster.
4. Dispose of hazardous wastes anywhere but an approved disposal site.
5. Pour hazardous wastes down sewers, toilets, sinks, or floor drains.

The Right-to-Know Laws state that employees have a right to know when the materials they use at work are hazardous. The Right-to-Know Laws started with the **Hazard Communication Standard** published by the Occupational Safety and Health Administration (OSHA) in 1983. This document was originally intended for chemical companies and manufacturers that required employees to handle hazardous materials in their work situation. Currently, most states have established their own Right-to-Know Laws. Meanwhile, federal courts have decided to apply these laws to all companies, including automotive service shops. Under the Right-to-Know Laws, the employer has three responsibilities regarding the handling of hazardous materials by its employees.

Material safety data sheets (MSDS) provide all the necessary data about hazardous materials.

First, all employees must be trained about the types of hazardous materials they will encounter in the workplace. Employees must be informed about their rights under legislation regarding the handling of hazardous materials. All hazardous materials must be properly labeled, and information about each hazardous material must be posted on **material safety data sheets (MSDS)**, which are available from the manufacturer (Figure 1-22). In Canada, MSDSs may be called **workplace hazardous materials information systems (WHMIS)**.

MATERIAL SAFETY DATA SHEET					
PRODUCT NAME: KLEAN-A-KARB (aerosol) #- HPMS 102068					
PRODUCT: 5078, 5931, 6047T					
(page 1 of 2)					
1. Ingredients	CAS #	ACGIH TLV	OSHA PEL	OTHER LIMITS	%
Acetone	67-64-1	750 ppm	750 ppm	(skin)	2-5
Xylene	1330-20-7	100 ppm	100 ppm		68-75
2-Butoxy Ethanol	111-76-2	25 ppm	25 ppm		3-5
Methanol	67-56-1	200 ppm	200 ppm		3-5
Detergent	-	NA	NA		0-1
Propane	74-98-6	NA	1000 ppm	1000 ppm	10-20
Isobutane	75-28-5	NA	NA		10-20
2. PHYSICAL DATA : (without propellent)					
Specific Gravity : 0.865		Vapor Pressure : ND		% Volatile : >99	
Boiling Point : 176°F Initial		Evaporation Rate : Moderately Fast		Vapor Density : ND	
Freezing Point : ND		pH :NA		Solubility: Partially soluble in water	
Appearance and Odor: A clear colorless liquid, aromatic odor					
3. FIRE AND EXPLOSION DATA					
Flashpoint : -40°F		Method : TCC		LEL: 1.8 UEL: 9.5	
Extinguishing Media: CO2, dry chemical, foam					
Unusual Hazards : Aerosol cans may explode when heated above 120°F.					
4. REACTIVITY AND STABILITY					
Stability : Stable		Hazardous decomposition products: CO2, carbon monoxide (thermal)			
5. PROTECTION INFORMATION					
Ventilation : Use mechanical means to ensure vapor concentration is below TLV.					
Respiratory: Use self-contained breathing apparatus above TLV.					
Gloves : Solvent resistant		Eye and Face:		Safety Glasses	
Other Protective Equipment: Not normally required for aerosol product usage					

FIGURE 1-22 Material safety data sheets (MSDS) inform employees about hazardous materials.

The employer has a responsibility to place MSDSs where they are easily accessible by all employees. The MSDSs provide extensive information about hazardous materials such as:

- 1. Chemical name.
- 2. Physical characteristics.
- 3. Protective equipment required for handling.
- 4. Explosion and fire hazards.
- 5. Other incompatible materials.
- 6. Health hazards such as signs and symptoms of exposure, medical conditions aggravated by exposure, and emergency and first-aid procedures.
- 7. Safe handling precautions.
- 8. Spill and leak procedures.

Second, the employer has a responsibility to make sure that all hazardous materials are properly labeled. The label information must include health, fire, and reactivity hazards posed by the material and the protective equipment necessary to handle the material. The manufacturer must supply all warning and precautionary information about hazardous materials, and this information must be read and understood by the employee before handling the material.

Third, employers are responsible for maintaining permanent files regarding hazardous materials. These files must include information on hazardous materials in the shop, proof of employee training programs, and information about accidents such as spills or leaks of hazardous materials. The employer's files must also include proof that employees' requests for hazardous material information such as MSDSs have been met. A general right-to-know compliance procedure manual must be maintained by the employer.

CASE STUDY

A technician raised a Grand Marquis on a lift to perform an oil and filter change and a chassis lubrication. This lift was a twin-post-type with separate front and rear lift posts. On this type of lift, the rear wheels must be positioned in depressions in the floor to position the rear axle above the rear lift arm. Then the front lift post and arms must be moved forward or rearward to position the front lift arms under the front suspension. The front lift arms must also be moved inward or outward so they are lifting on the vehicle manufacturer's specified lifting points. The technician carefully positioned the front lift post and arms properly, but forgot to check the position of the rear tires in the floor depressions. The car was raised on the lift, and the technician proceeded with the service work. Suddenly there was a loud thump,

and the rear of the car bounced up and down! The rear lift arms were positioned against the floor of the trunk rather than on the rear axle, and the lift arms punched through the floor of the trunk, narrowly missing the fuel tank. The technician was extremely fortunate the car did not fall off the lift, resulting in more severe damage. If the rear lift arms had punctured the fuel tank, a disastrous fire could have occurred! Luckily, these things did not happen. The technician learned a very important lesson about lift operation. Always follow all the recommended procedures in the lift operator's manual! The trunk floor was repaired at no cost to the customer, and fortunately, the shop and the vehicle escaped without major damage.

TERMS TO KNOW

- Air bag system
- Approved gasoline storage cans
- Aqueous parts cleaning tank
- Brake parts washer
- Cold parts washer
- Corrosive
- Environmental Protection Agency (EPA)
- Fluorescent trouble lights
- Hazard Communication Standard
- Hot cleaning tank
- Ignitable
- Incandescent bulb-type trouble lights
- Material safety data sheets (MSDSs)
- Multipurpose dry chemical fire extinguisher
- Occupational Safety and Health Act (OSHA)
- Reactive
- Resource Conservation and Recovery Act (RCRA)
- Right-to-Know Laws
- Toxic
- Workplace hazardous materials information systems (WHMIS)

SUMMARY

- The U.S. Occupational Safety and Health Act (OSHA) of 1970 ensures safe and healthful working conditions and authorizes enforcement of safety standards.
- Many hazardous materials and conditions can exist in an automotive shop, including flammable liquids and materials, corrosive acid solutions, loose sewer covers, caustic liquids, high-pressure air, frayed electrical cords, hazardous waste materials, carbon monoxide, improper clothing, harmful vapors, high noise levels, and spills on shop floors.
- Material safety data sheets (MSDSs) provide information regarding hazardous materials, labeling, and handling.
- The danger regarding hazardous conditions and materials may be avoided by eliminating shop hazards and applying the necessary shop rules and safety precautions.
- The automotive shop owner/management must supply the necessary shop safety equipment, and all shop personnel must be familiar with the location and operation of this equipment. Shop safety equipment includes gasoline safety cans, steel storage cabinets, combustible material containers, fire extinguishers, eyewash fountains, safety glasses and face shields, first-aid kits, and hazardous waste disposal containers.
- General shop safety includes following all safety rules and precautions to ensure a safe working environment and reduce on-the-job injuries.
- Maintaining adequate personal safety requires technicians to wear protective clothing such as proper footwear with steel toe caps, and safety glasses or a face shield. Technicians must avoid wearing loose fitting clothing that may become entangled in rotating equipment or components.
- To provide adequate personal safety, technicians must avoid wearing watches, jewelry, or rings.
- Shop safety requires a properly ventilated shop with an adequate exhaust removal system to avoid carbon monoxide gas in the shop.
- Shop safety equipment such as first-aid kits, eyewash fountains, and fire extinguishers must be clearly marked and easily accessible.
- Electrical cords must have a ground connection, and frayed electrical cords must be repaired or replaced immediately.
- Gasoline must be stored in clearly marked, approved gasoline containers.
- Fire safety in the shop includes storing combustible materials in approved, covered safety containers, avoiding sparks and flames near combustible materials, and quickly cleaning up gasoline, oil, or grease spills.
- To maintain shop safety, technicians must be familiar with the location and operation of fire extinguishers.
- Technicians must follow proper driving rules when driving vehicles in the shop.
- Proper lifting procedures must be followed to avoid personal injury when lifting heavy objects.
- Safe operating procedures must be followed when using hand tools and operating shop equipment such as lifts, hydraulic jacks, power tools, compressed air equipment, and cleaning equipment.

ASE-STYLE REVIEW QUESTIONS

1. Breathing carbon monoxide may cause:
A. Arthritis C. Impaired vision
B. Cancer D. Headaches
2. While discussing shop rules:
Technician A says breathing asbestos dust may cause heart defects.
Technician B says oily rags should be stored in uncovered trash containers.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. All these shop rules are correct EXCEPT:
A. USC tools may be substituted for metric tools.
B. Foot injuries may be caused by loose sewer covers.
C. Hands should be kept away from electric-drive cooling fans.
D. Power tools should not be left running and unattended.
4. While discussing personal safety:
Technician A says rings and jewelry may be worn in the automotive shop.
Technician B says some electric-drive cooling fans may start turning at any time.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
5. While lifting heavy objects in the automotive shop:
A. Bend your back to pick up the heavy object.
B. Place your feet as far as possible from the object.
C. Bend forward to place the object on the workbench.
D. Straighten your legs to lift an object off the floor.
6. While discussing power tool safety:
Technician A says an electric power tool cord does not require a ground.
Technician B says frayed electric cords should be replaced.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
7. While operating hydraulic equipment safely in the automotive shop remember that:
A. Safety stands have a maximum weight capacity.
B. The driver's door should be open when raising a vehicle on a lift.
C. A lift does not require a safety mechanism to prevent lift failure.
D. Four-wheel drive vehicles should be lifted on a frame contact lift.
8. While discussing shop hazards:
Technician A says high-pressure air from an air gun may penetrate the skin.
Technician B says air in the bloodstream may be fatal.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
9. While discussing hazardous material disposal:
Technician A says certain types of hazardous waste material can be poured down a floor drain.
Technician B says a shop is responsible for hazardous waste materials from the time they become waste until the proper waste disposal is completed.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
10. When working in an automotive shop, hazardous conditions must be avoided by:
A. Storing oily rags in open containers.
B. Storing flammable liquids such as paint in metal cupboards.
C. Leaving sewer covers loose for quick access.
D. Cleaning brake parts with an air gun.

Name _____ Date _____

DEMONSTRATE PROPER LIFTING PROCEDURES

Upon completion of this job sheet, you should be able to follow the proper procedure when lifting heavy objects.

Tools and Materials

A heavy object with a weight that is within the weight-lifting capability of the technician.

Procedure

Have various members of the class demonstrate proper weight-lifting procedures by lifting an object off the shop floor and placing it on the workbench. Other class members are to observe and record any improper weight-lifting procedures.

Task Completed

1. If the object is to be carried, be sure your path is free from loose parts or tools. ☐
2. Position your feet close to the object, and position your back reasonably straight for proper balance. ☐
3. Your back and elbows should be kept as straight as possible. Continue to bend your knees until your hands reach the best lifting location on the object to be lifted. ☐
4. Be certain the container is in good condition. If a container falls apart during the lifting operation, parts may drop out of the container, resulting in foot injury or part damage. ☐
5. Maintain a firm grip on the object; do not attempt to change your grip while lifting is in progress. ☐
6. Straighten your legs to lift the object, keeping the object close to your body. Use leg muscles rather than back muscles. ☐
7. If you have to change direction of travel, turn your whole body. Do not twist. ☐
8. Do not bend forward to place an object on a workbench or table. Position the object on the front surface of the workbench and slide it back, watching your fingers under the object to avoid pinching them. ☐
9. If the object must be placed on the floor or a low surface, bend your legs to lower the object. Do not bend your back forward because this movement strains back muscles. ☐
10. When a heavy object must be placed on the floor, put suitable blocks under the object to prevent jamming your fingers under the object. ☐

11. List any improper weight-lifting procedures observed during the weight-lifting demonstrations.

1. _____
2. _____
3. _____
4. _____
5. _____
6. _____

Instructor's Response _____

Name _____ Date _____

LOCATE AND INSPECT SHOP SAFETY EQUIPMENT

Upon completion of this job sheet, you should be familiar with the location of shop safety equipment and know if this equipment is serviced properly.

Procedure

Task Completed

1. Fire extinguishers: Are the fire extinguishers tagged to indicate they have been checked or serviced recently? ☐ Yes ☐ No

Draw a basic diagram of the shop layout in the space below, and mark the locations of the fire extinguishers and fire exits.

2. Eyewash fountain or shower: Is the eyewash fountain or shower operating properly?

☐ Yes ☐ No

Mark the location of the eyewash fountain or shower on the shop layout diagram in step 1.

3. First-aid kits: Are the first-aid kits properly stocked with supplies?

☐ Yes ☐ No

Mark the location of the first-aid kits on the shop layout diagram in step 1.

4. Electrical shut-off box: Mark the location of the shop electrical shut-off box on the shop layout diagram in step 1. ☐

5. Are the trash containers equipped with proper covers?

☐ Yes ☐ No

Mark the location of the trash containers on the shop layout diagram in step 1.

6. Metal storage cabinet: Mark the location of metal storage cabinet(s) for combustible materials on the shop layout diagram in step 1. ☐

Instructor's Response _____

Name _____ Date _____

SHOP HOUSEKEEPING INSPECTION

Upon completion of this job sheet, you should be able to apply shop housekeeping rules in your shop.

Procedure

When students from another class of Automotive Technology are working in the shop, evaluate their shop housekeeping procedures using the 16 shop housekeeping procedures. List all the improper shop housekeeping procedures that you observed in the space provided at the end of the job sheet.

Task Completed

1. Keep aisles and walkways clear of tools, equipment, and other items. ☐
2. Be sure all sewer covers are securely in place. ☐
3. Keep floor surfaces free of oil, grease, water, and loose material. ☐
4. Proper trash containers must be conveniently located, and these containers should be emptied regularly. ☐
5. Access to fire extinguishers must be unobstructed at all times; fire extinguishers should be checked for proper charge at regular intervals. ☐
6. Tools must be kept clean and in good condition. ☐
7. When not in use, tools must be stored in their proper location. ☐
8. Oily rags and other combustibles must be placed in proper, covered metal containers. ☐
9. Rotating components on equipment and machinery must have guards. All shop equipment should have regular service and adjustment schedules. ☐
10. Benches and seats must be kept clean. ☐
11. Keep parts and materials in their proper location. ☐
12. When not in use, creepers must not be left on the shop floor. Creepers should be stored in a specific location. ☐
13. The shop should be well-lit, and all lights should be in working order. ☐
14. Frayed electrical cords on lights or equipment must be replaced. ☐
15. Walls and windows should be cleaned regularly. ☐

Task Completed

☐

16. Stairs must be clean, well-lit, and free of loose material.

Observed improper shop housekeeping procedures:

1. _____
2. _____
3. _____
4. _____
5. _____
6. _____

Instructor's Response _____

Chapter 2

TOOLS AND SHOP PROCEDURES

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Diagnose steering and suspension problems using a basic diagnostic procedure.
- Raise a vehicle with a floor jack and lower the vehicle so it is supported on safety stands.
- Raise a vehicle with a lift.
- Test power steering pump pressure with an appropriate pressure gauge and valve assembly.
- Measure ball joint wear with a dial indicator designed for this purpose.
- Remove and replace a coil spring on a strut using a coil spring compressor tool.
- Use a tire changer to dismount and mount a tire.
- Use a scan tool to diagnose a computer-controlled suspension system.
- Balance tire-and-wheel assemblies with an electronic wheel balancer.
- Perform a four wheel alignment with a computer wheel aligner.
- Fulfill employee obligations when working in the shop.
- Accept job responsibility for each job completed in the shop.
- Describe the ASE automotive technician testing and certification process including the eight areas of certification.

USING SUSPENSION AND STEERING EQUIPMENT

Learn to use equipment properly the first time. When improper procedures are learned and become a habit, it is more difficult to break these wrong habits. Using service and test equipment will help you to work more safely and efficiently, and in the long term, this should improve your income. We will discuss the proper use of some of the most common service and test equipment used by suspension and steering technicians.

MEASURING SYSTEMS

Two systems of weights and measures are commonly used in the United States. One system is the **U.S. customary (USC) system**, which is commonly referred to as the English system. Well-known measurements for length in the USC system are the inch, foot, yard, and mile. In this system, the quart and gallon are measurements for volume; ounce, pound, and ton are measurements for weight. A second system of weights and measures is called the **international system (SI)**, also known as the metric system.

In the USC system, the basic linear measurement is the yard; in the metric system, it is the meter. Each unit of measurement in the metric system is related to the other metric units by a factor of 10. Thus, every metric unit can be multiplied or divided by 10 (or 100 or 1,000) to obtain larger units (multiples) or smaller units (submultiples). For example, the meter may be divided by 100 to obtain centimeters (1/100 meter) or by 1,000 to obtain millimeters (1/1,000 meter).




FIGURE 2-1 Metric tape graduated in millimeters.

The U.S. government passed the Metric Conversion Act in 1975 in an attempt to move American industry and the general public to accept and adopt the metric system. The automotive industry has adopted the metric system, and in recent years most bolts, nuts, and fittings on vehicles have been changed to metric. During the early 1980s some vehicles had a mix of English and metric bolts. Imported vehicles have used the metric system for many years. Although the automotive industry has changed to the metric system, the general public in the United States has been slow to convert from the USC system to the metric system. One of the factors involved in this change is cost. What would it cost to change every highway distance and speed sign in the United States to read kilometers? Probably hundreds of millions, or even billions, of dollars.

Service technicians must be able to work with both the USC and the metric system. One meter (m) in the metric system is equal to 39.37 inches (in.) in the USC system. A metric tape measure may be graduated in millimeters, and 10 millimeters = 1 centimeter (Figure 2-1).

Some common equivalents between the metric and USC systems are:

- 1 meter (m) = 39.378 inches
- 1 centimeter (cm) = 0.3937 inch
- 1 millimeter (mm) = 0.03937 inch
- 1 inch = 2.54 centimeter
- 1 inch = 25.4 millimeter

In the USC system, phrases such as 1/8 of an inch are used for measurements. The metric system uses a set of prefixes. For example, in the word kilometer the prefix kilo means 1,000, indicating that there are 1,000 meters in a kilometer. Common prefixes in the metric system include:

NAME	SYMBOL	MEANING
mega	M	one million
kilo	k	one thousand
hecto	h	one hundred
deca	da	ten
deci	d	one tenth of
centi	c	one hundredth of
milli	m	one thousandth of
micro	μ	one millionth of

Measurement of Mass

In the metric system mass is measured in grams, kilograms, or tonnes: 1,000 grams (g) = 1 kilogram (kg). In the USC system mass is measured in ounces, pounds, or tons. When converting pounds to kilograms, 1 pound = 0.453 kilograms.

Measurement of Length

In the metric system length is measured in millimeters, centimeters, meters, or kilometers: 10 millimeters (mm) = 1 centimeter (cm). In the USC system length is measured in inches, feet, yards, or miles.

When distance conversions are made between the two systems some of the following conversion factors are used:

- 1 inch = 25.4 millimeters
- 1 foot = 30.48 centimeters
- 1 yard = 0.91 meters
- 1 mile = 1.60 kilometers

Measurement of Volume

In the metric system volume is measured in milliliters, cubic centimeters, and liters: 1 cubic centimeter = 1 milliliter. If a cube has a length, depth, and height of 10 centimeters (cm), the volume of the cube is $10\text{ cm} \times 10\text{ cm} \times 10\text{ cm} = 1,000\text{ cm}^3 = 1\text{ liter}$. When volume conversions are made between the two systems, 1 cubic inch = 16.38 cubic centimeters. If an engine has a displacement of 350 cubic inches, $350 \times 16.38 = 5,733$ cubic centimeters, and $5,733 \div 1,000 = 5.7$ liters.

BASIC DIAGNOSTIC PROCEDURE

One of the most important parts of a technician's job is diagnosing automotive problems. Each year more vehicle systems are controlled by increasingly sophisticated electronic systems, and this makes accurate diagnosis even more important.

The following basic diagnostic procedure may be used to diagnose various automotive problems:

1. Be absolutely sure the problem is identified. Obtain all the information you can from the customer; for example, politely ask the customer to describe the exact symptoms of the problem. Ask the customer at what vehicle speed, engine temperature, and atmospheric temperature the problem occurs. From your discussion, find out when, where, and how the problem occurs.
2. Verify the problem. If necessary, road test the vehicle under the same conditions as the customer described to verify the problem.
3. Think of the possible causes of the problem based on your own experience in diagnosing similar problems on other vehicles.
4. Consult original equipment manufacturer (OEM) or generic technical service bulletin (TSB) information regarding service procedures, parts replacement, or computer reprogramming that are designed to correct the problem.
5. Perform the necessary diagnostic tests to locate the exact cause of the complaint. Always begin the diagnostic tests with the quickest, easiest test, and if the problem is not located, proceed with the more complicated, time-consuming tests. During your diagnosis watch for other problems with the vehicle that may give trouble in the near future. If there are any other potential problems such as worn belts and radiator hoses, advise the customer about them and attempt to obtain the customer's approval to repair these problems. If the customer does not approve the repair of these potential problems, describe them on the work order. If we repair a car based on a complaint on a customer's vehicle, and two weeks later the customer brings the vehicle back with another serious complaint, the customer may assume that the repairs were not completed thoroughly.
6. After the cause of the complaint is definitely located, advise the customer about the extent and cost of the repairs. After the customer approves the necessary repairs, perform the appropriate service work on the vehicle.
7. Road test the vehicle if necessary to be sure the customer's complaint is eliminated.

SUSPENSION AND STEERING TOOLS



CAUTION:

Do not hit the seal case with a hammer. This action will damage the seal.



CAUTION:

Always be sure the seal goes into the housing squarely and evenly. If the seal does not go squarely into the housing, the outer seal case may be distorted, and this condition may cause an oil leak around the seal housing.



SERVICE TIP:

When installing a seal, the garter spring must face toward the flow of lubricant.

Seal drivers are available in various diameters to fit squarely against the outside edge of different-size seals. The seal driver handle is tapped with a soft hammer to install the seal.

CUSTOMER CARE: Some automotive service centers have a policy of performing some minor service as an indication of their appreciation to the customer. This service may include cleaning all the windows and/or vacuuming the floors before the car is returned to the customer.

Although this service involves more labor costs for the shop, it may actually improve profits over a period of time. When customers find their windows cleaned and/or the floors vacuumed, it impresses them with the quality of work you do and the fact you care about their vehicle. They will likely return for service, besides telling their friends about the quality of service your shop performs.

Seal Drivers



WARNING: When using any suspension and steering tools, the vehicle manufacturer's recommended procedure in the service manual must be followed. Improper use of tools may lead to personal injury.

Seal drivers are designed to fit squarely against the seal case and inside the seal lip. A soft hammer is used to tap the seal driver and drive the seal straight into the housing. Some tool manufacturers market a seal driver kit with drivers to fit many common seals (Figure 2-2).

Bearing Pullers

A variety of **bearing pullers** are available to pull different sizes of bearings in various locations (Figure 2-3). Some bearing pullers are slide-hammer-type, whereas others are screw-type.

Axle Pullers

Axle pullers are used to pull rear axle shafts in rear-wheel-drive vehicles. Most rear axle pullers are slide-hammer-type (Figure 2-4).



FIGURE 2-2 Seal drivers.



FIGURE 2-3 Bearing pullers.



FIGURE 2-4 Axle puller.

Bearing pullers are designed to fit over the outer diameter of the bearing or through the center opening in the bearing, pulling the bearing from its mounting shaft.

Axle pullers are usually slide-hammer type. These pullers attach to the axle studs to remove the axle.

A **stethoscope** is placed in the technician's ears, and the pickup is placed on or near the suspected noise source to diagnose noise problems.

Stethoscope

A **stethoscope** is a mechanical device that amplifies sound and diagnoses the source of noises such as bearing noise. The stethoscope pickup is placed on the suspected noise source, and the ends of the two arms are placed in the technician's ears (Figure 2-5). Electronic stethoscopes provide improved sound amplification compared with mechanical stethoscopes and can locate the causes of mechanical noises, air leaks, and wind whistles.

Front Bearing Hub Tool

Front bearing hub tools are designed to remove and install front wheel bearings on front-wheel-drive cars (Figure 2-6). These bearing hub tools are usually designed for a specific make of vehicle.




FIGURE 2-5 Stethoscope.




FIGURE 2-6 Front bearing hub tool.



SERVICE TIP:

Dial indicators must be kept clean and dry for accuracy and long life.

Dial Indicator

Dial indicators are used for measuring in many different locations. In the suspension and steering area, dial indicators are used for measurements, such as tire runout and ball joint movement (Figure 2-7). Dial indicators have many different attaching devices to connect the indicator to the component to be measured.

Tire Tread Depth Gauge

A **tire tread depth gauge** measures tire tread depth. This measurement should be taken at three or four locations around the tire's circumference. The lowest reading is considered to be the tread depth (Figure 2-8). Do not place the gauge tip on a wear indicator bar. This gauge is essential when making tire warranty adjustments.




FIGURE 2-7 Dial indicator designed for ball joint measurement.



FIGURE 2-8 Tire tread depth gauge.

Tire Changer

WARNING: Never operate a tire changer until you are familiar with its operation because this may lead to serious personal injury. Your instructor will explain and demonstrate the operation of this equipment. You should read the equipment operator's manual and use this equipment under the instructor's supervision until you are familiar with it.

A **tire changer** is operated pneumatically to dismount and mount tires from the rims.

Tire changers are used to dismount and mount tires (Figure 2-9). These changers may be used on most common tire sizes. A wide variety of tire changers are available, and each one



FIGURE 2-9 Typical tire changer.



FIGURE 2-10 Typical electronic wheel balancer.

operates differently. Always follow the procedure in the equipment operator's manual and the directions provided by your instructor.

Wheel Balancer



WARNING: Using a wheel balancer before you are familiar with its operation may result in serious personal injury and property damage.

Electronic wheel balancers indicate the required weight location on the rim to obtain proper static and dynamic wheel balance.

Electronic wheel balancers are used in most automotive repair shops (Figure 2-10). Do not attempt to use this equipment until you have studied wheel balance theory. Your instructor will explain and demonstrate the use of this equipment before you attempt to use it. This equipment should be used under the supervision of your instructor until you are familiar with it.

Machinist's Rule

A **machinist's rule** performs many accurate measurements in the shop. Most machinist's rules are graduated in inches and millimeters (Figure 2-11).




FIGURE 2-11 Graduations on a typical machinist's rule.

Air Chisel or Hammer

An air chisel is an electrically operated tool to which various chisels, cutters, and punches may be attached to complete cutting and riveting jobs. The air hammer operates the attached tool with a very fast back-and-forth action (Figure 2-12). Different tools that may be attached to the air chisel are illustrated in Figure 2-13.



FIGURE 2-12 Air chisel.




FIGURE 2-13 Air chisel accessories: (A) universal joint and tie-rod end tool, (B) smoothing hammer, (C) ball joint separator, (D) panel crimper, (E) shock absorber chisel, (F) tailpipe cutter, (G) scraper, (H) tapered punch, (I) edging tool, (J) rubber bushing splitter, (K) bushing remover, and (L) busing installer.



WARNING: Always be sure the tool being used is properly attached to the air chisel. Improper tool attachment may result in serious personal injury.

Ball Joint Removal and Installation Tools

Ball joint removal and installation tools remove and install pressed-in ball joints on front suspension systems (Figure 2-14). The size of the removal and pressing tool adapter must match the size of the ball joint.

Tie Rod End and Ball Joint Puller

Some car manufacturers recommend a **tie rod end and ball joint puller** to remove tie rod ends and pull ball joint studs from the steering knuckle (Figure 2-15).

Control Arm Bushing Tools

A variety of **control arm bushing tools** are available to remove and replace control arm bushings. The bushing removal and installation tool must match the size of the control arm bushing (Figure 2-16).




FIGURE 2-14 Ball joint removal and installation tool.




FIGURE 2-15 Tie rod end and ball joint puller.




FIGURE 2-16 Control arm bushing removal and replacement tools.




FIGURE 2-17 MacPherson strut coil spring compressor tool.

Coil Spring Compressor Tool

WARNING: There is a tremendous amount of energy in a compressed coil spring. Never disconnect any suspension component that will suddenly release this tension because this may result in serious personal injury and vehicle or property damage.



CAUTION:

The vehicle manufacturer's and equipment manufacturer's recommended procedures must be followed for each type of spring compressor tool.

Many types of **coil spring compressor tools** are available to the automotive service industry (Figure 2-17). These tools compress the coil spring and hold it in the compressed position while removing the strut from the coil spring or performing other suspension work. Each type of front suspension system requires a different type of spring compressor tool. The vehicle manufacturer's and equipment manufacturer's recommended procedure must be followed.

Power Steering Pressure Gauge

WARNING: The power steering pump delivers extremely high pressure during the pump pressure test. Always follow the recommended test procedure in the vehicle manufacturer's service manual to avoid personal injury during this test.

A **power steering pressure gauge** is used to test the power steering pump pressure (Figure 2-18). Because the power steering pump delivers extremely high pressure during this test, the recommended procedure in the vehicle manufacturer's service manual must be followed.



FIGURE 2-18 Power steering pressure gauge.




FIGURE 2-19 Pitman arm puller.

Pitman Arm Puller



WARNING: Never strike a puller with a hammer when it is installed and tightened because this may result in personal injury.

A **pitman arm puller** is a heavy-duty puller that removes the pitman arm from the pitman shaft (Figure 2-19).

Vacuum Hand Pump

A **vacuum hand pump** creates a vacuum to test vacuum-operated components and hoses (Figure 2-20).

Torque Wrenches and Torque Sticks

A torque wrench is required to tighten fasteners to a specified torque. Tightening fasteners to the specified torque is extremely important. If fastener torque is less than specified, the component retained by the fastener(s) may loosen, resulting in severe component or vehicle damage. When fasteners are tightened to a torque above the specified value, the component may become warped, resulting in improper component operation. Torque wrenches can be beam, click, or dial-type (Figure 2-21). A beam-type torque wrench bends as torque



FIGURE 2-20 Vacuum hand pump.



FIGURE 2-21 Various types of torque wrenches.

is applied, and a beam on the wrench points to the torque applied on a scale attached to the wrench handle. On a click-type torque wrench, the handle is rotated to set the specified torque on a scale adjacent to the handle. When the fastener is tightened to the torque setting, the torque wrench provides an audible click. On a dial-type torque wrench, the torque applied to the fastener is indicated on the dial. Digital-type torque wrenches that indicate the torque reading on a digital display are also available.

Some tool manufacturers provide torque sticks for tightening fasteners to the specified torque with an impact wrench. One end of the torque stick has a $\frac{1}{2}$ in. drive opening, and a socket is attached to the opposite end. A spring steel, heat-treated shaft is connected between the $\frac{1}{2}$ in. drive opening and the socket end of the torque stick. Torque sticks are calibrated to twist at a specific torque with each blow of an impact wrench, and thus prevent further tightening of the fastener. Torque sticks are available in various USC and metric sizes and are usually sold in color-coded sets. The torque stick color indicates the specified torque at which they twist. For example, a yellow torque stick twists at 65 ft. lbs. Some torque sticks are a $\frac{1}{2}$ in. extension that fits between the impact wrench drive and a thin-wall impact socket (Figure 2-22).

Turning Radius Gauge

Turning radius gauge turntables are placed under the front wheels during a wheel alignment. The top plate in the turning radius gauge rotates on the bottom plate to allow the front wheels to be turned during a wheel alignment. A degree scale and a pointer on the gauge indicate the number of degrees the front wheels are turned (Figure 2-23). If the car has four-wheel steering (4WS), the turning radius gauges are also placed under the rear wheels during a wheel alignment.

Plumb Bob

A **plumb bob** is a metal weight with a tapered end (Figure 2-24). This weight is suspended on a string. Plumbers use a plumb bob to locate pipe openings directly below each other at the top and bottom of partitions. Some vehicle manufacturers recommend checking vehicle frame measurements with a plumb bob.

Tram Gauge

A **tram gauge** is a long, straight graduated bar with an adjustable pointer at each end (Figure 2-25). The tram gauge performs frame and body measurements.



SERVICE TIP: Using a torque stick allows the use of an impact wrench when tightening fasteners, and this speeds up the service operation. However, the use of torque sticks may not be as accurate as using a torque wrench. It is a good practice to double check the accuracy of a torque stick by checking the fastener torque with a torque wrench after it is tightened with a torque stick.



FIGURE 2-22 Torque stick.



FIGURE 2-23 Turning radius gauge.



FIGURE 2-24 Plumb bob.




FIGURE 2-25 Tram gauge.



SERVICE TIP:

Magnetic wheel alignment gauge mounting surfaces must be clean with no metal burrs.

Magnetic Wheel Alignment Gauge

Each **magnetic wheel alignment gauge** contains a strong magnet that holds the gauge securely on the front wheel hubs. The magnetic wheel alignment gauge measures some of the front suspension alignment angles (Figure 2-26).

Rim Clamps

When the wheel hub is inaccessible to the magnetic alignment gauge, an adjustable **rim clamp** may be attached to each front wheel. The magnetic gauges may be attached to the rim clamp (Figure 2-27). Rim clamps are also used on computer wheel aligners.

Brake Pedal Jack

A **brake pedal jack** must be installed between the front seat and the brake pedal to apply the brakes while checking some front wheel alignment angles (Figure 2-28).



FIGURE 2-26 Magnetic wheel alignment gauge.




FIGURE 2-27 Rim clamps.



FIGURE 2-28 Brake pedal jack.




FIGURE 2-29 Tie rod sleeve adjusting tool.



FIGURE 2-30 Steering wheel locking tool.

Tie Rod Sleeve Adjusting Tool

A **tie rod sleeve adjusting tool** rotates the tie rod sleeves and performs some front wheel adjustments (Figure 2-29).

Steering Wheel Locking Tool

A **steering wheel locking tool** locks the steering wheel while performing some front suspension service (Figure 2-30).

Toe Gauge

A **toe gauge** is a long, straight, graduated bar that measures front wheel toe (Figure 2-31).

Track Gauge

Some **track gauges** use a fiber-optic alignment system to measure front wheel toe and to determine if the rear wheels are tracking directly behind the front wheels. The front and rear fiber-optic gauges may be connected to the wheel hubs or to rim clamps attached to the wheel rims (Figure 2-32). A remote light source in the main control is sent through fiber-optic cables to the wheel gauges. A strong light beam between the front and rear wheel units informs the technician if the rear wheel tracking is correct.

Computer Four Wheel Aligner

Many automotive shops are equipped with a **computer four wheel aligner** (Figure 2-33). These wheel aligners perform all front and rear wheel alignment angles quickly and accurately.



CAUTION:

Do not use anything except a tie rod adjusting tool to adjust the tie rod sleeves. Tools, such as a pipe wrench, will damage the sleeves.




FIGURE 2-31 Toe gauge.



FIGURE 2-32 Fiber optic track and toe gauge.



FIGURE 2-33 Computer wheel aligner.

Scan Tool

A variety of **scan tools** are available for diagnosing automotive computer systems (Figure 2-34). These testers obtain fault codes and perform other diagnostic functions on computer-controlled suspension systems.


Bench Grinder



WARNING: Always wear a face shield when using a bench grinder. Failure to observe this precaution may cause personal injury.



WARNING: When grinding small components on a grinding wheel, wire brush wheel, or buffing wheel, always hold these components with a pair of vise grips to avoid injury to fingers and hands.



WARNING: Grinding and buffing wheels on bench grinders must be mounted on the grinder according to the manufacturer's instructions. Grinding and buffing wheels must be retained with the manufacturer's specified washers and nuts, and the retaining nuts must be tightened to the specified torque. Personal injury may occur if grinding and buffing wheels are not properly attached to the bench grinder.

Bench grinders usually have a grinding wheel and a wire wheel brush driven by an electric motor (Figure 2-35). The grinding wheel may be replaced with a grinding disc containing several layers of synthetic material (Figure 2-36). A buffing wheel may be used in place of the wire wheel brush. The grinding wheel may be used for various grinding jobs and deburring. A buffing wheel is most commonly used for polishing. Most bench grinders have grinding wheels and wire brush wheels that are 6 to 10 in. (15.24 to 25.4 cm) in diameter. Bench grinders must be securely bolted to the workbench.



FIGURE 2-34 Scan tool for diagnosing computer-controlled suspension systems.



FIGURE 2-35 Bench grinder.



FIGURE 2-36 Bench grinder accessories.

HYDRAULIC PRESSING AND LIFTING EQUIPMENT

Hydraulic Press

! WARNING: When operating a hydraulic press, always be sure that the components being pressed are supported properly on the press bed with steel supports. Improperly supported components may slip, resulting in personal injury.

! WARNING: When using a hydraulic press, never operate the pump handle if the pressure gauge exceeds the maximum pressure rating of the press. If this pressure maximum is exceeded, some part of the press may suddenly break, causing severe personal injury.

A hydraulic press uses a hydraulic cylinder and ram to remove and install precision-fit components from their mounting location.



WARNING: Be sure the safety cage is in place around the press to prevent personal injury.

When two components have a tight precision fit between them, a hydraulic press is used to either separate these components or press them together. The hydraulic press rests on the shop floor, and an adjustable steel-beam bed is retained to the lower press frame with heavy steel pins. A hydraulic cylinder and ram is mounted on the top part of the press with the ram facing downward toward the press bed (Figure 2-37). The component being pressed is placed on the press bed with appropriate steel supports. A hand-operated hydraulic pump is mounted on the side of the press. When the handle is pumped, hydraulic fluid is forced into the cylinder, and the ram is extended against the component on the press bed to complete the pressing operation. A pressure gauge on the press indicates the pressure applied from the hand pump to the cylinder. The press frame is designed for a certain maximum pressure, and this pressure must not be exceeded during hand pump operation.

Floor Jack



WARNING: The maximum lifting capacity of the floor jack is usually written on the jack decal. Never lift a vehicle that exceeds the jack lifting capacity. This action may cause the jack to break or collapse, resulting in vehicle damage or personal injury.

A **floor jack** uses hydraulic pressure supplied to a hydraulic cylinder, ram, and lift pad to lift one end or one corner of a vehicle.

A floor jack is a portable unit mounted on wheels. The lifting pad on the jack is placed under the chassis of the vehicle, and the jack handle is operated with a pumping action (Figure 2-38), forcing fluid into a hydraulic cylinder in the jack. Then this cylinder extends to force the jack lift pad upward and lift the vehicle. Always be sure that the lift pad is positioned securely under one of the car manufacturer's recommended lifting points. To release the hydraulic pressure and lower the vehicle, the handle or release lever must be turned slowly. Do not leave the jack handle where someone can trip over it.




FIGURE 2-37 Hydraulic press.




FIGURE 2-38 Hydraulic floor jack.

Vehicle Lift (Hoist)


A **vehicle lift** raises a vehicle so the technician can work under it. The lift arms must be placed under the car manufacturer's recommended lifting points prior to raising a vehicle. Twin posts are used on some lifts, whereas other lifts have a single post (Figure 2-39). Some lifts have an electric motor, which drives a hydraulic pump to create fluid pressure and force the lift upward. Other lifts use air pressure from the shop air supply to force the lift upward. If shop air pressure is used, it is applied to fluid in the lift cylinder. A control lever or switch is placed near the lift, which supplies shop air pressure to the lift cylinder and turns on the lift pump motor. Always be sure that the safety lock is engaged after the lift is raised. When the safety lock is released, a release lever is operated slowly to lower the vehicle.

Using a Floor Jack and Safety Stands

A floor jack is often used to raise a vehicle off the floor. The vehicle is then lowered onto **safety stands** to allow service work to be performed under the vehicle (Figure 2-40).

Follow this procedure to lift a vehicle with a floor jack and then support it on safety stands:

1. Check the weight ratings of the floor jack and the safety stands; be sure these ratings exceed the weight to be lifted and supported.

 **WARNING:** If the vehicle weight to be lifted and supported exceeds the weight rating of the floor jack or safety stands, the floor jack or safety stands may collapse, allowing the vehicle to drop suddenly, which may cause personal injury and/or vehicle damage.

2. Be sure the vehicle is parked on a level surface. Place wheel blocks behind the rear wheels of the vehicle if you are lifting the front end. Place these wheel blocks in front of the front wheels if you are lifting the rear end.
3. Determine the vehicle manufacturer's specified lift point from the vehicle service manual, and position the floor jack lift pad under this lift point. Pump the floor jack handle until the lift pad contacts the lift point on the vehicle.



CAUTION:

Always be sure that the lift arms are securely positioned under the car manufacturer's recommended lifting points before raising the vehicle. These lifting points are shown in the service manual. If the lift arms are not positioned on the proper lift points, chassis components may be damaged, or the vehicle may slide off the lift, resulting in vehicle damage and/or personal injury.

A **vehicle lift** may be called a hoist.

Safety stands may be called jack stands.



FIGURE 2-39 Vehicle lifts are used to raise a vehicle.



FIGURE 2-40 Typical safety stands.



CAUTION:

The maximum capacity of the vehicle lift is placed on an identification plate. Never lift a vehicle that is heavier than the maximum capacity of the lift. Lifting a vehicle with a weight greater than the lift weight rating may bend the lift or cause the vehicle to slip off the lift, resulting in vehicle damage and/or personal injury.



CAUTION:

Lifting or supporting a vehicle at a location other than the vehicle manufacturer's specified lift point may cause damage to the vehicle chassis and other components.

4. Look under the vehicle and be sure the floor jack lift pad is contacting the specified lift point. If necessary, lower the lift pad and move it so it contacts the lift point properly.
5. Pump the floor jack handle until the vehicle is at the desired height. Place safety stands adjusted to the appropriate height under the vehicle manufacturer's lift points. These lift points will be a strong chassis member such as the frame or axle housing.
6. Because the floor jack is on casters, the vehicle and floor jack tend to move slightly as the vehicle is lowered onto safety stands. Slowly operate the hydraulic pressure release on the floor jack to lower the vehicle onto the safety stands. As the vehicle is lowered, be sure the safety stands do not tip. All four legs on both safety stands must remain in contact with the floor surface. Be sure the safety stands are contacting the vehicle lift points properly, and double-check to be sure the safety stand legs are all contacting the floor.



WARNING: Never work under a vehicle unless it is securely supported on safety stands. If a vehicle is supported only by a floor jack, the jack may allow the vehicle to drop, resulting in personal injury.

7. After the vehicle is supported properly on safety stands, lower and remove the floor jack to allow more room for under-car service.



WARNING: Never under any condition leave a floor jack handle down so it is near the floor surface; someone may trip over the handle, resulting in personal injury.

Using a Vehicle Lift

A vehicle lift raises a vehicle to allow a technician to perform under-car repairs.

Follow this procedure to raise a vehicle on a lift:

1. Determine both the weight rating of the lift and the vehicle weight to be lifted. Be sure the weight rating of the lift exceeds the vehicle's weight.
2. Before driving a vehicle on a lift, be sure the lift arms are positioned properly out of the path of the vehicle. The lift arms must also be positioned to provide unobstructed clearance between the lift and the vehicle chassis.
3. After driving the vehicle on the lift, be sure the vehicle is properly positioned in relation to the lift. Make sure the vehicle doors, hood, and trunk lid are closed. Do not raise a vehicle with any person inside the vehicle.
4. Determine the specified vehicle lift points from the vehicle service manual (Figure 2-41).
5. Position the lift supports so they are directly under the specified vehicle lift points. Operate the lift so the lift supports contact the specified lift points.







FIGURE 2-41 Lift points for a typical unibody vehicle.

 **WARNING:** If the lift supports are not in proper contact with the specified vehicle lift points, the vehicle may slip off the lift, resulting in personal injury and vehicle damage.

6. Operate the lift a short distance off the shop floor and stop the lift. Look under the vehicle to be sure the lift supports are in full contact with the specified lift points. If the lift supports are not in full contact with the specified lift points, lower the vehicle onto the floor and reposition the lift supports.
7. Raise the vehicle to the desired height. Be sure the lift safety mechanism is engaged.

 **WARNING:** If heavy components are removed from one end of a vehicle, the vehicle may become unstable on the lift. Therefore, to prevent this action, chain a strong chassis component to the lift on the opposite end of the vehicle before removing heavy components from the other end.

8. Before lowering the lift, remove all tools, toolboxes, and equipment from under the vehicle, and sweep up discarded parts from under the vehicle.
9. Be sure nobody is standing under the vehicle before lowering it.
10. Lower the vehicle slowly until it is resting on the shop floor and be sure the lift is completely lowered.
11. Before driving the vehicle off the lift, be sure there is proper clearance between all parts of the lift and the vehicle chassis.

SUSPENSION AND STEERING SERVICE, DIAGNOSTIC, AND MEASUREMENT TOOLS

Using a Power Steering Pressure Gauge

The power steering pump pressure test is one of the most important indications of power steering pump condition.

Follow these steps to use the power steering pressure gauge to test power steering pump pressure:

1. Check the power steering belt condition and if it is cracked, damaged, or oil soaked, replace the belt. If a V-belt is bottomed in the pulley, excessive wear on the sides of a V-belt is indicated. This condition also requires belt replacement.
2. Measure the power steering belt tension with a belt tension gauge. If this tension is less than specified, adjust the power steering belt tension.
3. Be sure the engine is warmed up and the power steering fluid is at normal operating temperature.
4. With the engine shut off, check the fluid level in the power steering pump reservoir. If necessary, add the vehicle manufacturer's specified fluid until the proper level is obtained.
5. Listen to the power steering pump with the engine idling. A growling noise from the pump may indicate aeration of the power steering fluid in the reservoir or air in the power steering system. If air is indicated in the system, turn the steering wheel several times fully in each direction to bleed air from the system before proceeding with the power steering pump pressure test.
6. Shut the engine off and remove the high-pressure hose from the power steering pump. Connect the power steering pressure gauge and valve assembly to the fitting on the end of the high-pressure hose and to the fitting on the pump from which the high-pressure



CAUTION:

When driving a vehicle on a lift, do not run over lift arms, adapters, or axle supports. This action may damage the lift, tires, or vehicle chassis components.



CAUTION:

If the lift supports are not in proper contact with the specified vehicle lift points, chassis components such as brake lines may be damaged.

A power steering pressure gauge is connected in the power steering system to test power steering pump pressure.

Classroom Manual

Chapter 2, page 37




FIGURE 2-42 Pressure gauge connections to power steering.

hose was removed (Figure 2-42). Be sure the valve on the power steering pressure gauge is fully open.

7. With the engine idling, close the power steering gauge valve for no more than 10 seconds and observe the power steering pump pressure on the gauge. Turn the gauge valve fully open. If the power steering pump pressure is less than the vehicle manufacturer's specified pressure, replace the power steering pump.



WARNING: Wear a face shield and protective gloves during the power steering pressure test. Power steering fluid and components become hot during this test.



WARNING: If the gauge valve is closed for more than 10 seconds during the power steering pressure test, excessive power steering pump pressure may rupture power steering hoses. Hot fluid spraying from a ruptured hose may burn anyone near the vehicle.

8. Shut the engine off and remove the power steering pressure gauge. Tighten the high-pressure hose fitting to the specified torque. Start the engine and check for leaks at this fitting. Be sure the power steering reservoir is filled to the proper level.

Using a Dial Indicator

A dial indicator performs precision measurements on some suspension components such as ball joints. A special dial indicator with a stiff, flexible attaching bracket is available for measuring ball joint wear. When measuring ball joint wear, the end of this flexible bracket is clamped to a stable suspension component with a pair of vise grips. The dial indicator must be mounted so there is no movement in the indicator mounting. A dial indicator contains a movable plunger that is positioned against the component to be measured. The pointer on the dial indicator registers the amount of plunger movement. Each rotation of the pointer represents 0.100 in. (2.54 mm) of plunger movement (Figure 2-43). The dial indicator plunger must be positioned against the component to be measured so the dial indicator is preloaded approximately 0.250 in. (6.35 mm). When the dial indicator is preloaded properly, about



CAUTION:

Do not allow the power steering fluid to become too hot during the pump pressure test. Excessive fluid temperature reduces pump pressure, resulting in false test results.



FIGURE 2-43 The dial indicator pointer rotation indicates the amount of plunger movement.

one-half of the plunger should be outside the dial indicator. After the preload procedure is completed, the dial indicator face must be rotated until the zero position on the scale is aligned with the pointer. Always look squarely at the indicator face. Looking at the dial indicator face from an angle may provide an inaccurate reading.

The following is a typical procedure for measuring ball joint wear on a short-and-long arm suspension system with the coil spring positioned between the lower control arm and the chassis:

1. Lift the front of the vehicle with a floor jack positioned under the manufacturer's specified lift point, and position a safety stand under the lower control arm. Lower the vehicle so the lower control arm and vehicle weight rests on the safety stand. The tire must remain several inches off the floor.
2. Clamp the end of the dial indicator's flexible bracket onto the lower control arm.
3. Position the dial indicator plunger against the lower side of the steering knuckle next to the nut on the ball joint stud. The dial indicator plunger should be positioned at a 90° angle with the ball joint stud (Figure 2-44).
4. Preload and zero the dial indicator. Be sure the dial indicator is clamped securely to the lower control arm without any movement in the indicator mounting.
5. Position a long steel bar under the tire, and lift upward on the bar while an assistant observes the movement on the dial indicator pointer. If the dial indicator pointer movement exceeds the maximum-specified ball joint vertical movement, the ball joint must be replaced.




FIGURE 2-44 Dial indicator installed to measure vertical ball joint movement.



FIGURE 2-45 Dial indicator installed to measure horizontal joint movement.



SERVICE TIP:

The procedure for measuring ball joint wear varies depending on the type of suspension system and the type of ball joint mounting. Always consult the vehicle manufacturer's service manual.



CAUTION:

If the coil spring has an enamel-type coating, tape the spring in the areas where the compressor tool contacts the spring. If the compressor tool chips this coating, the spring may break prematurely.

6. Be sure the front wheel bearings are adjusted properly. Position the dial indicator plunger against the inner edge of the wheel rim (Figure 2-45). Preload and zero the dial indicator. Grasp the top and bottom of the tire, and attempt to tip the tire out at the bottom and in at the top. Release the tire, and repeat this procedure several times while an assistant observes the dial indicator. If the dial indicator pointer movement exceeds the maximum-specified ball joint horizontal movement, the ball joint must be replaced.

Using a Coil Spring Compressing Tool

A coil spring compressing tool is required to compress the coil spring before removing the spring from the strut on a MacPherson strut suspension system.

Follow this procedure for using a coil spring compressing tool to remove a spring from a strut:

1. With the strut-and-coil-spring assembly removed from the vehicle, install the coil spring in the compressing tool according to the tool manufacturer's or vehicle manufacturer's recommended procedure.



WARNING: Unless the coil spring is compressed, never loosen the nut on the strut rod that retains the upper strut mount on the strut and coil spring. Loosening this nut will suddenly release the coil spring tension, resulting in personal injury.

2. Adjust the compressing arms on the spring compressing tool so the arms contact the coils farthest away from the center of the spring (Figure 2-46).



WARNING: Always use the coil spring compressor tool recommended by the vehicle manufacturer. Some compressor tools are designed to work only on specific strut-and-coil-spring assemblies. If the compressor tool does not fit properly on the coil spring, the tool may slip off the spring, suddenly releasing the coil spring tension, which may result in personal injury.




FIGURE 2-46 Coil spring and strut assembly mounted in a spring compressing tool.

3. Turn the handle on top of the compressor tool until all the spring tension is removed from the upper strut mount.
4. Loosen and remove the strut rod nut in the center of the upper strut mount (Figure 2-47). Be sure all the spring tension is removed from the upper strut mount before loosening this nut.
5. Remove the upper strut mount assembly, mount bearing, and then remove the upper spring seat and insulator.
6. Rotate the handle on the spring compressing tool to release all the tension on the coil spring, and then remove the spring.
7. Remove the dust shield and jounce bumper from the strut rod, and then remove the lower spring insulator (Figure 2-48).
8. Replace all worn or defective parts, and be sure the strut rod is fully extended. Install the lower insulator on the lower strut spring seat, and be sure the insulator is properly positioned on the seat.
9. Install the spring bumper on the strut rod.
10. Place the coil spring properly in the spring compressing tool, and rotate the handle on the spring compressing tool to compress the coil spring.



CAUTION:

Never clamp the lower end of the strut in a vise, which may cause internal strut damage.



SERVICE TIP:

The tire dismounting and mounting procedure varies depending on the type of tire changer. Always follow the dismounting and mounting procedure recommended by the tire changer manufacturer.



CAUTION:

Always use the tire changer attachments recommended by the tire changer manufacturer. For example, specific bead removal and installation attachments may be recommended for certain types of wheel rims.




FIGURE 2-47 After the compressing tool is operated to removed all the spring tension, remove the strut rod nut.




FIGURE 2-48 Removal of the dust shield, jounce bumper, and lower spring insulator.

11. Install the strut into the coil spring, and be sure the lower insulator is properly positioned on the coil spring.
12. Install the upper spring insulator and upper strut mount, and be sure these components are properly positioned.
13. Install the strut rod nut and tighten this nut to the specified torque.
14. Rotate the handle on the spring compressing tool to slowly release all the spring tension, and remove the strut and spring assembly from the tool.

Using a Tire Changer

A tire changer dismounts and mounts tires on wheel rims without damaging the rims. Most tire changers are operated by shop air pressure.



WARNING: If the tire changer manufacturer's recommended procedure for dismounting and mounting tires is not followed, personal injury and/or rim damage may occur.

The following is a typical tire dismounting and mounting procedure:

1. Position the tire-and-wheel assembly in the specified location on the tire changer (Figure 2-49). Be sure the tire-and-wheel assembly is properly positioned and secured.
2. Remove the valve cap and valve core, and be sure the tire is completely deflated.
3. Position the bead unseating tool to unseat the outer bead, and operate the changer to unseat this bead.



FIGURE 2-49 Typical tire changer.

4. Operate the changer to unseat the bead on the inner side of the rim.
5. Position the bead removal tool to remove the outer bead over the rim, and operate the changer to remove this bead over the rim.
6. Position the bead removal tool to remove the inner bead over the rim, and operate the changer to remove this bead over the rim.
7. After the beads are removed over the rim, remove the tire from the changer.
8. Clean dirt and rust from the rim sealing flanges with a wire brush, and apply a coating of rubber compound to the bead area of the tire.
9. Install the tire on top of the rim in the desired position. Many tires have a dot painted on the tire that should be aligned with the valve stem when the tire is mounted on the rim. Therefore, this dot must be on the outer side of the tire prior to mounting.
10. Position the bead installation tool to install the inner bead over the rim, and operate the changer to install this bead over the rim.
11. Position the bead installation tool to install the outer bead over the rim, and operate the changer to install this bead over the rim.
12. Rotate the tire on the rim to align the painted dot with the valve stem, and install the valve core. Be sure the tire is centered properly on the rim.
13. Inflate the tire to the specified tire pressure, install the valve cap, and remove the tire and wheel from the tire changer.

Using a Scan Tool

A **scan tool** performs an electronic diagnosis of computer-controlled suspension systems and other electronic systems. Various test modules may be plugged into the scan tool, depending on the vehicle and system being diagnosed (Figure 2-50). The scan tool cable is connected to the data link connector (DLC) under the dash. On 1996 and newer vehicles with on-board diagnostic II (OBD II) systems, the scan tool is powered from a terminal in the DLC. On most



SERVICE TIP:

Many shops have a policy of always installing a new valve stem when repairing or replacing a tire, which prevents problems with cracked or defective valve stems.



SERVICE TIP:

Aligning the painted dot on the tire sidewall ensures proper tire balancing with a minimum amount of balance weight.



SERVICE TIP:

The valve core may be left out of the valve stem and the tire partially inflated. This action allows the air pressure to enter the tire quicker and seat the beads against the rim flanges. After the beads are seated, allow most of the air to escape from the tire, and then install the valve core.




FIGURE 2-50 Scan tool and related modules.



CAUTION:

Never connect or disconnect the scan tool data cable with the ignition switch on. This action may damage expensive electronic components on the vehicle or the scan tool.

pre-1996 vehicles, a power cable on the scan tool has to be connected to a 12V power source such as the cigarette lighter.

After the scan tool is connected, the vehicle make, model year, and engine size usually has to be selected on the scan tool display. On vehicles with several different computer systems, the technician must select the computer system to be diagnosed from the list of computer systems on the vehicle. For example, if the technician wants to diagnose the continuously variable road sensing suspension system (CVRSS), then RSS must be selected from the list of computer systems displayed on the scan tool display. After the RSS selection, the scan tool display will ask the technician to select diagnostic trouble codes (DTCs), data, inputs, outputs, or clear codes.

On OBD II vehicles, the DTCs contain five digits. A typical DTC from a CVRSS is C1712. The “C” indicates this DTC is in the chassis group, and the “1” informs the technician this is a manufacturer specific code. A common DTC dictated by Society of Automotive Engineers (SAE) standards is indicated if the second digit is a “0.” The digits 712 in the DTC indicate an open circuit in the left front (LF) damper actuator circuit. On a CVRSS, the damper actuators are solenoids in each shock absorber or strut. Diagnostic trouble codes (DTCs) indicate a defect in a certain electrical area, but they do not indicate a defect in a specific component. For example, the C1712 DTC indicates there is an open circuit in the LF damper actuator solenoid or in the connecting wires between this solenoid and the suspension computer. The technician usually has to use a volt-ohm meter to locate the exact cause of the DTC. Diagnostic trouble codes (DTCs) may be identified on the scan tool display as CURRENT or HISTORY. A CURRENT DTC is one that is present at the time of testing. A HISTORY DTC represents an intermittent defect that occurred in the past, which has since disappeared.

If “data” is selected, the scan tool display indicates data related to the CVRSS. This data includes readings from the input sensors and readings such as battery voltage or vehicle speed. When “inputs” is selected, the scan tool displays readings from the input sensors in the CVRSS. In the “output” parameter the scan tool displays readings from the outputs in the CVRSS. The output displays may be a voltage reading or solenoids displayed as being “on” or “off.” If “clear codes” is selected on the scan tool display, the DTCs are erased from the computer memory.

Depending on the computer-controlled suspension system being diagnosed, the scan tool may be used to perform different functions. For example, on some computer-controlled air suspension systems, the scan tool may be used to command the suspension computer to fill and vent each air spring. This test mode may be used to check the operation of system components. The scan tool may be used to flash program the suspension computer memory. This mode installs new software in the computer as directed by service bulletins from the original


equipment manufacturer (OEM). On some computer-controlled suspension systems, such as the system on the 2002 Lincoln Blackwood, the scan tool is used to adjust the suspension ride height.

Using an Electronic Wheel Balancer


The most popular type of wheel balancer in automotive service shops is the electronic balancer. Most electronic wheel balancers have an electric motor that spins the tire-and-wheel assembly at moderate speed during the balance procedure. On some electronic wheel balancers, the tire-and-wheel assembly is spun by hand for balance purposes. Certain preliminary checks must be performed on the tire-and-wheel assembly before installing this assembly on an electronic wheel balancer.

These preliminary checks include the following:

1. Clean all mud and debris from the tire-and-wheel assembly.
2. Remove all old wheel weights from the rim.


 **WARNING:** Improperly installed wheel weights may fly off the rim when the wheel is spun on the balancer, resulting in personal injury.

3. Remove objects such as stones from the tire tread.

 **WARNING:** Stones or other objects in the tire tread may fly out when the wheel is spun on the balancer, resulting in personal injury.

4. Inspect the tire tread and sidewall for defects, such as splits, cuts, chunks out of the tread or sidewall, and bulges indicating ply separation. Replace tires with these defects.
5. Inflate the tire to the specified pressure.

The tire-and-wheel assembly must be installed on the wheel balancer according to the instructions of the wheel balancer manufacturer. After the tire-and-wheel assembly is installed securely on the balancer, slowly rotate the tire by hand and listen for objects such as balls of rubber rolling inside the tire. Objects inside the tire must be removed, because they make wheel balancing difficult or impossible.

 **WARNING:** If the tire-and-wheel assembly is not securely installed on the wheel balancer, the wheel may come loose and fly off the balancer during the balance procedure, resulting in personal injury.

Use a dial indicator to measure vertical and lateral tire and wheel runout. If tire and wheel runout is excessive, wheel balancing may be difficult. Enter the wheel diameter, width, and offset in the wheel balancer. The balancer must have this information to calculate the required amount of wheel weight and the weight position. Lower the safety hood on the wheel balancer, and activate the balancer to spin the wheel. Apply the brake on the balancer to stop the wheel. Install the indicated amount of wheel weight in the proper position as indicated on the wheel balancer display. Be sure the weight(s) are securely attached to the wheel rim.

Using a Computer Four Wheel Aligner

If a vehicle has a frame and a live-axle rear suspension system, it is not as likely to require rear wheel alignment as a unibody vehicle with a semi-independent or independent rear suspension system. Because of increased four wheel alignment requirements on unibody cars, most

**Classroom
Manual**
Chapter 2, page 34

A **computer four wheel aligner** uses a wheel sensor mounted on each wheel to measure all the front and rear wheel alignment angles.

shops that offer wheel alignment service are equipped with a computer four wheel aligner. Before performing a wheel alignment, the technician must complete a preliminary vehicle inspection. The purpose of the preliminary inspection is to locate any defective or worn components that would make wheel alignment inaccurate.

A preliminary wheel alignment inspection includes these checks:

1. Be sure the vehicle has the normal curb weight that it has when the driver is operating the vehicle. Make sure the gas tank is full, and check for excessive mud adhered to the underside of the chassis.
2. Be sure the tires are inflated to the specified tire pressure, and inspect the tires for excessive wear, bulges, cuts, and splits. Be sure the tires are all the same size.
3. Check for the specified front and rear suspension height. Because the suspension height affects many of the wheel alignment angles, this height must be corrected before performing a wheel alignment if it is not within specifications.
4. Check the steering wheel free play. If this free play is more than specified, inspect the steering linkages and tie rod ends for excessive wear. The excessive steering wheel free play must be corrected before a wheel alignment, because this problem affects front wheel toe and steering quality.
5. Be sure the shock absorbers and struts are in satisfactory condition.
6. Check the front and rear wheel bearing adjustments, and correct these adjustments as necessary. Loose wheel bearing adjustments affect some of the wheel alignment angles.
7. Check the ball joints for excessive wear. Worn ball joints affect some of the wheel alignment angles.
8. Inspect the front and rear, upper and lower control arms for damage, and inspect all the control arm bushings for wear. Bent control arms or worn control arm bushings affect wheel alignment angles.
9. Inspect the front and rear stabilizer bars and bushings. Worn stabilizer bushings affect ride quality and vehicle handling.

After the preliminary inspection is completed, and all the necessary components have been replaced or adjusted, drive the vehicle onto the wheel alignment rack.

Then follow this procedure to complete the four wheel alignment with a computer wheel aligner:

1. Follow all instructions provided in the wheel aligner operator's manual.
2. Be sure the front wheels are centered on the wheel aligner turntables.
3. Be sure the rear wheels are positioned properly on the slip plates.
4. Mount the wheel sensor units on each wheel.
5. Select the vehicle make and model year on the wheel aligner screen.
6. On the wheel aligner preliminary inspection screen, check the condition of each item. Most of these items are mentioned in the previous preliminary inspection procedure.
7. Display the ride height screen on the wheel aligner, and be sure the front and rear ride height is within specifications.
8. Display the wheel runout screen of the wheel aligner, and compensate for wheel runout as directed.
9. Display the turning angle screen on the wheel aligner. Apply the brakes with a brake pedal depressor as directed on the screen, and perform the turning angle check.
10. Display the front and rear wheel alignment angles on the screen. Most computer four wheel aligners mark the alignment angles that are not within specifications.
11. Display the adjustment screen on the wheel aligner, and perform the necessary front and rear suspension adjustments to bring all the alignment angles within specifications. Photo Sequence 2 illustrates a typical procedure for performing a four wheel alignment with a computer wheel aligner.




SERVICE TIP:

The wheel runout compensation procedure varies, depending on the make and year of the wheel aligner.

PHOTO SEQUENCE 2

TYPICAL PROCEDURE FOR PERFORMING FOUR WHEEL ALIGNMENT WITH A COMPUTER WHEEL ALIGNER



P2-1 Display the ride height screen. Check the tire condition for each tire on the tire condition screen.




P2-2 Position the vehicle on the alignment rack.




P2-3 Make sure the front tires are positioned properly on the turntables.




P2-4 Position the rear wheels on the slip plates.




P2-5 Attach the wheel units.



P2-6 Select the vehicle make and model year.



P2-7 Check the items on the screen during the preliminary inspection.




P2-8 Display the wheel runout compensation screen.



P2-9 Display the turning angle screen and perform the turning angle check.

PHOTO SEQUENCE 2 (CONTINUED)



P2-10 Display the front and rear wheel alignment angle screen.



P2-11 Display the adjustment screen.

EMPLOYER AND EMPLOYEE OBLIGATIONS

The ever increasing electronics content on today's vehicles also requires that technicians are familiar with the latest electronics technology. To be a successful automotive technician, you must be committed to lifelong training. There are many different ways to obtain this training, but it is absolutely essential.

Automotive training may be obtained by these methods:

1. Obtain bulletins, service manuals, and training information from original equipment manufacturers (OEMs); independent parts and component manufacturers; and independent suppliers of service manuals and training books. After the information is obtained, it is essential that you read and study it.
2. Join an organization dedicated to supplying information to automotive service technicians such as the International Automotive Technician's Association (IATA).
3. Join an Internet organization such as the International Automotive Technicians Network where you can communicate with other technicians and obtain answers to service problems.
4. Download information available on the Internet from automotive equipment manufacturers. Many of these manufacturers provide operator's manuals and other information on their equipment for downloading purposes.
5. Attend satellite training seminars available from some independent automotive training organizations and OEMs.
6. Attend training seminars in your location sponsored by equipment and parts manufacturers or OEMs.
7. Attend training seminars sponsored by the automotive department at your local college.
8. Attend National Institute for Automotive Service Excellence (ASE) certification classes.

Successful automotive technicians must be committed to lifelong training, but their employers must also be committed to assisting them in obtaining the necessary training. This assistance may be financial, providing time off work to attend training seminars or arranging the necessary training programs.

When you begin employment, you enter into a business agreement with your employer. A business agreement involves an exchange of goods or services that have value. Although the automotive technician may not have a written agreement with his or her employer, the technician exchanges time, skills, and effort for money paid by the employer. Both the employee and the employer have obligations.

The automotive technician's obligations include the following:

1. Productivity: As an automotive technician you have a responsibility to your employer to make the best possible use of time on the job. Each job should be done in a reasonable length of time. Employees are paid for their skills, effort, and time.

2. **Quality:** Each repair job should be a quality job! Work should never be done in a careless manner. Nothing improves customer relations like quality workmanship.
3. **Teamwork:** The shop staff are a team, and everyone including technicians and management personnel is a team member. You should cooperate with and care about other team members. Each member of the team should strive for harmonious relations with fellow workers. Cooperative teamwork helps improve shop efficiency, productivity, and customer relations. Customers may be “turned off” by bickering between shop personnel.
4. **Honesty:** Employers and customers expect and deserve honesty from automotive technicians. Honesty creates a feeling of trust among technicians, employers, and customers.
5. **Loyalty:** As an employee, you are obliged to act in the best interests of your employer, both on and off the job.
6. **Attitude:** Employees should maintain a positive attitude at all times. As in other professions, automotive technicians have days when it may be difficult to maintain a positive attitude. For example, there will be days when the technical problems on a certain vehicle are difficult to solve. However, a negative attitude certainly will not help the situation! A positive attitude has a positive effect on the job situation as well as on the customer and employer.
7. **Responsibility:** You are responsible for your conduct on the job and your work-related obligations. These obligations include always maintaining good workmanship and customer relations. Attention to details such as always placing fender, seat, and floor mat covers on customer vehicles prior to driving or working on the vehicle greatly improve customer relations.
8. **Following directions:** All of us like to do things “our way.” Such action, however, may not be in the best interests of the shop; as an employee, you have an obligation to follow the supervisor’s directions.
9. **Punctuality and regular attendance:** Employees have an obligation to be on time for work and to be regular in attendance on the job. It is very difficult for a business to operate successfully if it cannot count on its employees to be on the job at the appointed time.
10. **Regulations:** Automotive technicians should be familiar with all state and federal regulations pertaining to their job situation, such as the Occupational Safety and Health Act (OSHA) and hazardous waste disposal laws. In Canada, employees should be familiar with workplace hazardous materials information systems (WHMIS).

Employer to employee obligations include:

1. **Wages:** The employer has a responsibility to inform the employee regarding the exact amount of financial remuneration they will receive and when they will be paid.
2. **Fringe benefits:** A detailed description of all fringe benefits should be provided by the employer. These benefits may include holiday pay, pension plans, and sickness and accident insurance.
3. **Working conditions:** A clean, safe workplace must be provided by the employer. The shop must have adequate safety equipment and first-aid supplies. Employers must be certain that all shop personnel maintain the shop area and equipment to provide adequate safety and a healthy workplace atmosphere.
4. **Employee instruction:** Employers must provide employees with clear job descriptions and be sure that each worker is aware of his or her obligations.
5. **Employee supervision:** Employers should inform their workers regarding the responsibilities of their immediate supervisors and other management personnel.
6. **Employee training:** Employers must make sure that each employee is familiar with the safe operation of all the equipment that they are required to use in their job situation. Since automotive technology is changing rapidly, employers should provide regular update training for their technicians. Under the Right-to-Know Laws, employers are required to inform all employees about hazardous materials in the shop. Employees should be familiar with material safety data sheets (MSDSs), which detail the labeling and handling of hazardous waste, and the health problems if exposed to hazardous waste.

Job Responsibilities

An automotive technician has specific responsibilities regarding each job performed on a customer's vehicle.

These job responsibilities include:

1. Do every job to the best of your ability. There is no place in the automotive service industry for careless workmanship! Automotive technicians and students must realize they have a very responsible job.
2. Treat customers fairly and honestly on every repair job. Do not install parts that are unnecessary to complete the repair job.
3. Use published specifications; do not guess at adjustments.
4. Follow the service procedures in the service manual provided by the vehicle manufacturer or an independent manual publisher.
5. When the repair job is completed, always be sure the customer's complaint has been corrected.
6. Do not be too concerned with work speed when you begin working as an automotive technician. Speed comes with experience.

Liability Responsibilities

During many repair jobs you, as a student or technician working on a customer's vehicle, actually have the customer's life and the vehicle safety in your hands. For example, if you are doing a brake job and leave the nuts loose on one wheel, that wheel may fall off the vehicle at high speed. This could result in serious personal injury for the customer and others, plus extensive vehicle damage. If this type of disaster occurs, the individual who worked on the vehicle and the shop may be involved in a very expensive legal action. As a student or technician working on customer vehicles, you are responsible for the safety of every vehicle that you work on! Even when careless work does not create a safety hazard, it leads to dissatisfied customers, who often take their business to another shop. Nobody benefits when that happens.

NATIONAL INSTITUTE FOR AUTOMOTIVE SERVICE EXCELLENCE (ASE) CERTIFICATION

The National Institute for Automotive Service Excellence (ASE) has provided voluntary testing and certification of automotive technicians on a national basis for many years. The image of the automotive service industry has been enhanced by the ASE certification program. More than 415,000 technicians now have current certifications and work in a wide variety of automotive service shops.

ASE provides certification in eight areas of automotive repair:

1. Engine repair
2. Automatic transmissions/transaxles
3. Manual drivetrain and axles
4. Suspension and steering
5. Brakes
6. Electrical systems
7. Heating and air conditioning
8. Engine performance

A technician may take the ASE test and become certified in any or all of the eight areas. When a technician passes an ASE test in one of the eight areas, an Automotive Technician's shoulder patch is issued by ASE. Technicians who pass all eight tests receive a Master Technician's shoulder patch (Figure 2-51). Retesting at five-year intervals is required to



FIGURE 2-51 ASE certification shoulder patches worn by Automotive Technicians and Master Technicians.

remain certified. The certification test in each of the eight areas contains 40 to 80 multiple-choice questions. The test questions are written by a panel of automotive service experts from various areas of automotive service, including automotive instructors, service managers, automotive manufacturers' representatives, test equipment representatives, and certified technicians. The test questions are pretested and checked for quality by a national sample of technicians. On an ASE certification test, approximately 45 to 50 percent of the questions are Technician A and Technician B format, and the multiple-choice format is used in 40 to 45 percent of the questions. Less than 10 percent of ASE certification questions are an EXCEPT format in which the technician selects one incorrect answer out of four possible answers. ASE regulations demand that each technician must have two years of working experience in the automotive service industry prior to taking a certification test or tests. However, relevant formal training may be substituted for one year of working experience. Contact ASE for details regarding this substitution. The contents of the suspension and steering test are listed in Table 2-1.

ASE also provides certification tests in automotive specialty areas, such as Parts Specialist; Advanced Engine Performance Specialist; Alternate Fuels, Light Vehicle—Compressed Natural Gas; Machinist, Cylinder Head Specialist; Machinist, Cylinder Block Specialist; and Machinist, Assembly Specialist.

Shops that employ ASE-certified technicians display an official **ASE blue seal of excellence**. This blue seal increases the customer's awareness of both the shop's commitment to quality service and the competency of its certified technicians.

TABLE 2-1 SUSPENSION AND STEERING TEST SUMMARY

Content area	Questions in test	Percentage of test
A. Steering systems diagnosis and repair	10	25%
1. Steering columns and manual steering gears (3)		
2. Power-assisted steering units (4)		
3. Steering linkage (3)		
B. Suspension systems diagnosis and repair	13	33%
1. Front suspensions (6)		
2. Rear suspensions (5)		
3. Miscellaneous service (2)		
C. Wheel alignment diagnosis, adjustment, and repair	12	30%
D. Wheel and tire diagnosis and repair	5	12%
TOTAL	40	100%

Repair Orders (R.O.)

Repair orders may vary depending on the shop, but repair orders usually have this basic information:

1. Customers name, address, and phone number(s)
2. Customer's signature
3. Vehicle make, model, year, and color
4. Vehicle identification number (VIN)
5. Vehicle mileage
6. Engine displacement
7. Date and time
8. Service writers code number
9. Work order number
10. Labor rate
11. Estimate of repair costs
12. Accurate and concise description of the vehicle problem.

In many shops the repair orders are completed on a computer terminal, and the computer may automatically write the vehicle repair history on the repair order if the vehicle has a previous repair history in the shop computer system.

The repair order informs the technician regarding the problem(s) with the vehicle. In many shops the technician has to enter a starting time on the repair order. This may be done on a computer terminal or by inserting the work order into the time clock. The technician may also have to enter his code number on the work order to indicate who worked on the vehicle. The technician's code number on the work order is also used to pay the technician for the repair job. The technician must diagnose and repair the problem(s) indicated on the repair order. When the technician obtains parts from the parts department to complete the repair, the technician must present the order number. The parts personnel enter the parts and the cost on the repair order. In some shops the technician is required to enter an accurate description of the completed repairs on the work order. For example, the description of the problem on the work order may be "A/C system inoperative." If the technician replaced the A/C compressor fuse to correct the problem, he or she may enter, "Diagnosed A/C electrical defects and found a blown A/C fuse. Replaced the fuse and operated the A/C system. A/C system operation is normal." Some shops require the service writer or shop foreman to sign the work order when the repair job is successfully completed. The work order is routed back to the accountant who calculates all the charges on the work order including the appropriate taxes. Some shops add a miscellaneous charge on the work order. A typical miscellaneous charge is 10 percent of the total charges on the work order. This miscellaneous charge is to cover the cost of small items such as bolts, cotter pins, grease, lubricants, and sealers that are not entered separately on the work order.

In many shops the technicians work on a flat rate basis. In these shops the technician is paid a flat rate for each repair. In dealership the flat rate time is set by the vehicle manufacturer. Independent shops use generic flat rate manuals published by firms such as Mitchell Publications. If the flat rate time is 2 hours for completing a specific vehicle repair, the customer is charged for 2 hours, and the technician is paid for 2 hours even though he or she completed the repair in 1.5 hours. Conversely, if the technician takes 2.5 hours to complete the job, the technician is only paid for 2 hours and the customer is charged for 2 hours. The flat rate time is usually entered on the work order.

SERVICE MANUALS

The service manual is one of the most important tools for today's technician. It provides information concerning component identification, service procedures, specifications, and diagnostic information. In addition, the service manual provides information concerning




FIGURE 2-52 Uniform service manual layout.

wiring harness connections and routing, component location, and fluid capacities. Service manuals can be supplied by the vehicle manufacturer or through aftermarket suppliers.

The service manual provides an explanation of the vehicle identification number (VIN). The VIN information is essential when ordering parts. Most service manuals published by vehicle manufacturers now have a standard format (Figure 2-52). The service manual usually provides illustrations to guide the technician through the service operation (Figure 2-53). Always use the correct manual for the vehicle and system being serviced. Follow each step in the service procedure. Do not skip steps! Measurements such as torque, end play, and clearance specifications are located in or near the service manual text or procedural information. Specification tables are usually provided at the end of the procedural information or component area (Figure 2-54).

Because the service manual is divided into a number of main component and system areas, a table of contents is provided at the front of the manual to provide quick access to the desired information. Each component area or system is covered in a section of the service manual (Figure 2-55). At the beginning of each section in the service manual, a smaller table of contents guides the technician to the information regarding the specific system or component being serviced. The service manual may be divided into several volumes, because of the extensive amount of information required to service today's vehicles. Diagnostic information in each section of the service manual is usually provided in **diagnostic procedure charts** (Figure 2-56). The test results obtained in a specific diagnostic step guide the technician to the next appropriate step.


Service and parts information can also be provided through computer services (Figure 2-57). Computerized service information may be provided on computer disks or compact disks (CDs), which are easier to store and access. Computers may also be connected to a central

A diagnostic procedure chart may be called a diagnostic tree.

Ball Joint Boot Replacement

NOTE: The upper control arm ball joint, lower control arm ball joint, and knuckle upper ball joint are attached with the boot retainer to improve the sealing efficiency of the boot.

1. Remove the set ring and boot.




NOTE: Do not damage the tapered section of the ball pin with the bearing puller.

2. Remove the retainer.

NOTE: The knuckle lower ball joint does not have a retainer.


3. Pack the interior of the boot and lip with grease.



CAUTION: Do not contaminate the boot installation section with grease.

4. Wipe the grease off the sliding surface of the ball pin, and pack with fresh grease.
5. Insert the new retainer lightly into the ball joint pin.


NOTE: When installing the ball joint, press the retainer into the ball joint pin.



CAUTION:

Keep grease off the boot installation section and the tapered section of the ball pin.
Do not allow dust, dirt, or other foreign materials to enter the boot.

6. Install the boot in the groove of the boot installation section securely, then bleed air.
7. Adjust the special tool with the adjusting bolt until the end of the tool aligns with the groove on the boot.



8. Slide the set ring over the tool and into position.

CAUTION: After installing the boot, check the ball pin tapered section and threads for grease contamination and wipe them if necessary.

FIGURE 2-53 Illustrations in the service manual that guide the technician through service procedures.

		Tire size	Pressure	
			Front	Rear
Cold tire inflation pressure	For all roads including full rated loads	P195/70R14	220 kPa (2.2 kgf/cm ² , 32 psi)	240 kPa (2.4 kgf/cm ² , 34 psi)
		P205/65R15	220 kPa (2.2 kgf/cm ² , 32 psi)	240 kPa (2.4 kgf/cm ² , 34 psi)
	Optional inflation for reduced loads (1 to 4 passengers)	P195/70R14	180 kPa (1.8 kgf/cm ² , 26 psi)	180 kPa (1.8 kgf/cm ² , 26 psi)
		P205/65R15	180 kPa (1.8 kgf/cm ² , 26 psi)	180 kPa (1.8 kgf/cm ² , 26 psi)
Vehicle height	Tire size		Height	
			Front	Rear
	P195/70R14		210 mm (8.27 in.)	270 mm (10.63 in.)
	P205/65R15		213 mm (8.39 in.)	276 mm (10.87 in.)
Front wheel alignment	Toe-in (total)		0° +/- 0.2° (0 +/- 2 mm, 0 +/- 0.08 in.)	
	Wheel angle	Tire size	Inside wheel	Outside wheel
		P195/70R14	37°20' +/- 2°	32°15'
		P205/65R15	36°00' +/- 2°	31°20'
	Camber		-0°35' +/- 45'	
	Cross camber		45' or less	
	Caster		1°05' +/- 45'	
	Cross caster		45' or less	
	Steering axis inclination		13°00' +/- 45'	
Rear wheel alignment	Toe-in (total)		0.4° +/- 0.2° (4 +/- 2 mm, 0.16 +/- 0.08 in.)	
	Camber		-0°15' +/- 45'	
	Cross camber		45' or less	

FIGURE 2-54 Specification table.

database to obtain service information. Using the mouse, light pen, computer keyboard, or touch-sensitive screen, the technician selects choices from a series of menus on the computer monitor. When the desired information is accessed, it may be printed out for detailed study. Modern automotive service information is presently computer or Web-based.

Service procedures may be modified by the vehicle manufacturer at any time. Service bulletins provide up-to-date corrections for the service manuals. If a significant number of corrections are required, a second edition of the manual may be published. When service information is provided on CDs, the CDs are updated frequently to provide the latest information.

CUSTOMER CARE: When advising customers regarding when the work will be completed on their car, it is a good idea to estimate a longer time than you anticipate. For example, if you expect it will take 3 hours to repair the vehicle, advise the customer it will be ready in 4 hours. This allows extra time for diagnosing difficult problems or road testing the vehicle. It can be very frustrating for customers when they come to pick up their vehicle at the appointed time, and the vehicle is not ready.

TABLE OF CONTENTS	SECTION NUMBER
GENERAL INFO. AND LUBE General Information Maintenance and Lubrication	0A 0B
HEATING AND AIR COND. Heating and Vent. (nonA/C) Air-Conditioning System V-5 A/C Compressor Overhaul	1A 1B 1D3
BUMPERS AND FRONT BODY PANELS Bumpers (See 10-4) Fr. End Body Panels (See 10-5)	
STEERING, SUSPENSION, TIRES, AND WHEELS Diagnosis Wheel Alignment Power Steering Gear & Pump Front Suspension Rear Suspension Tires and Wheels Steering Col. On-Vehicle Service Steering Col. – Std. Unit Repair Steering Col. – Tilt, Unit Repair	3 3A 3B1 3C 3D 3E 3F 3F1 3F2
DRIVE AXLES Drive Axles	4D
BRAKES General Info. – Diagnosis and On-Car Service Compact Master Cylinder Disc Brake Caliper Drum Brake - Anchor Plate Power Brake Booster Assembly	5 5A1 5B2 5C2 5D2
ENGINES General Information 2.0 Liter I-4 Engine 3.1 Liter V6 Engine Cooling System Fuel System Engine Electrical – General Battery Cranking System Charging System Ignition System Engine Wiring Driveability & Emissions – Gen. Driveability & Emissions – TBI Driveability & Emissions – PFI Exhaust System	6 6A1 6A3 6B 6C 6D 6D1 6D2 6D3 6D4 6D5 6E 6E2 6E3 6F

TABLE OF CONTENTS	SECTION NUMBER
TRANSAXLE Auto. Transaxel On-Car Serv. Auto. Trans. – Hydraulic Diagnosis Auto. Trans. – Unit Repair Man. Trans. On-Car Service 5-Sp. 5TM40 Man. Trans. Unit Repair 5-Sp. Isuzu Man. Trans. Unit Repair Clutch	7A 3T40- HD 3T40 7B 7B1 7B2 7C
CHASSIS ELECTRICAL, INSTRUMENT PANEL & WIPER/WASHER Electrical Diagnosis Lighting and Horns Instrument Panel and Console Windshield Wiper/Washer	8A 8B 8C 8E5
ACCESSORIES Audio System Cruise Control Engine Block Heater	9A 9B 9C
BODY SERVICE General Body Service Stationary Glass Underbody Bumpers Body Front End Doors Rear Quarters Body Rear End Roof & Convertible Top Seats Safety Belts Body Wiring Unibody Collision Repair Welded Panel Replacement	10-1 10-2 10-3 10-4 10-5 10-6 10-7 10-8 10-9 10-10 10-11 10-12 11-1 11-2
INDEX Alphabetical Index	

FIGURE 2-55 The table of contents directs you to the major systems and component areas in the service manual.

EPS INDICATOR LIGHT DOES NOT COME ON

The EPS indicator light does not come on when the ignition switch is turned on (II).

Check the BACK-UP LIGHTS/ALTERNATOR (15a) fuse in the under-dash fuse box.

Is the fuse OK?

NO

Replace the fuse and recheck.

Note: reinstall the fuse if it is OK.

YES

Check for an open in the IG1 circuit:
1. Disconnect the gauge assembly 30-pin connector.
2. Turn the ignition switch ON (II).
3. Measure the voltage between the terminal No. 13 and body ground.

Is there battery voltage?

NO

Repair open in the wire between the BACK-UP LIGHTS/ALTERNATOR (15a) fuse and the gauge assembly. Replace the under-dash fuse box (open circuit inside the fuse box).

YES

Check the EPS indicator light bulb in the gauge assembly.

Is the bulb OK?

NO

Replace the EPS indicator light bulb.

YES

Check the gauge assembly:
1. Connect the gauge assembly 30-pin connector.
2. Connect the gauge assembly 30-pin connector terminal NO. 5 to body ground.

Does the EPS indicator light come on?

NO

Replace the printed circuit board in the gauge assembly.

YES

(To next page)





FIGURE 2-56 Typical diagnostic chart.



FIGURE 2-57 Computers are replacing printed service manuals in many shops.

TERMS TO KNOW

ASE blue seal of excellence
Axle puller
Ball joint removal and installation tools
Bearing puller
Brake pedal jack
Coil spring compressing tool
Computer four wheel aligner
Control arm bushing tools
Diagnostic procedure charts
Dial indicator
Electronic wheel balancer
Floor jack
Hydraulic press
International system (SI)
Machinist's rule
Magnetic wheel alignment gauge
Pitman arm puller
Plumb bob
Power steering pressure gauge
Rim clamp
Safety stands
Scan tool
Seal driver
Steering wheel locking tool
Stethoscope
Tie rod sleeve adjusting tool
Tire changer
Tie rod end and ball joint puller
Tire tread depth gauge
Toe gauge
Track gauge
Tram gauge
Turning radius gauge turntables
U.S. customary (USC) system
Vacuum hand pump
Vehicle lift

CASE STUDY

A technician was removing and replacing the alternator of a General Motors car. After installing the replacement alternator and connecting the alternator battery wire, she proceeded to install the alternator belt. The rubber boot was still removed from the alternator battery terminal. While installing this belt, her wristwatch expansion bracelet made electrical contact from the alternator battery terminal to ground on the alternator housing. Even though the alternator battery wire is protected with a fuse link, which melted, a high current flowed through the wristwatch bracelet. This heated the bracelet to a very high

temperature and severely burned the technician's arm.

The technician forgot two safety rules:

1. Never wear jewelry, such as watches and rings, while working in an automotive shop.
2. Before performing electrical work on a vehicle, disconnect the negative battery cable. If the vehicle is equipped with an air bag, wait the specified time after this cable is disconnected.

CASE STUDY

A customer brought a Cavalier into the shop with a rough idle complaint. The customer informed the service salesman that he had this problem since the car was purchased new, and the problem was always caused by an open exhaust gas recirculation (EGR) valve. The customer said the (EGR) valve had been replaced three times under warranty, and he had also paid for an EGR valve replacement, and one EGR valve cleaning, after the warranty had expired.

The technician connected a scan tool to the DLC, and verified that a diagnostic trouble code (DTC) was present indicating the EGR valve was stuck open. Next the technician checked for technical service bulletins (TSBs) related to this problem in the shop database. One TSB

indicated that the vehicle manufacturer had revised powertrain control module (PCM) software that caused the PCM to pulse the EGR valve briefly each time the PCM closed the EGR valve to remove carbon buildup on the EGR valve pintle. Using the appropriate equipment the technician installed the updated software in the PCM, and this permanently corrected the problem.

Previous technicians who serviced this vehicle had forgotten, or neglected, to check the TSB database for the cause of this problem. As a result, both the vehicle manufacturer and the customer spent a considerable amount of money for EGR valve replacements, when computer reprogramming was required to correct the problem.

CASE STUDY

A technician had just replaced the engine in a Ford vehicle and was performing final adjustments. In this shop, the cars were parked in the work bays at an angle on both sides of the shop. With the engine running at fast idle, the automatic transmission suddenly slipped into reverse. The car went backward across

the shop and collided with a car in one of the electrical repair bays. Both vehicles were damaged to a considerable extent. Fortunately, no personnel were injured.

This technician forgot to apply the parking brake while working on the vehicle!

SUMMARY

- Each unit in the metric system of measurements can be multiplied or divided by 10 to obtain larger or smaller units.
- A stethoscope amplifies sound to help the technician identify the source of abnormal noises.
- A dial indicator is a precision measuring device that measures movement or wear on various components in thousands of an inch.
- A tire changer is a pneumatically operated machine that is used to dismount and mount tires on rims.
- An electronic wheel balancer indicates static and dynamic unbalance in tire and wheel assemblies. The electronic wheel balancer also indicates the mounting location and size of wheel weight(s) required to provide a balanced tire and wheel assembly.
- A spring compressor tool compresses a coil spring so the spring and other suspension components can be safely removed.
- A power steering pressure gauge is used to test power steering pump pressure and determine the condition of the power steering system.
- Turning radius gauges are placed under the front wheels during a wheel alignment.
- A magnetic wheel alignment gauge may be attached to the outer surface of the front wheel hubs to measure certain wheel alignment angles.
- A computer four wheel aligner is used to electronically measure the alignment angles on the front and rear suspensions.
- A scan tool is connected to the data link connector (DLC) under the dash to diagnose various electronic systems.
- A vehicle lift is used to raise vehicles off the floor so under-car service may be performed.

ASE-STYLE REVIEW QUESTIONS

1. While discussing systems of weights and measures:
Technician A says the international system (SI) is called the metric system.
Technician B says every unit in the metric system can be divided or multiplied by 10.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
2. While discussing the metric system:
Technician A says that 1 inch is equal to 2.54 millimeters.
Technician B says that 1 meter is equal to 36.37 inches.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. When diagnosing a vehicle operational problem, the first step is to:
A. Think of the possible causes of the problem.
B. Perform diagnostic tests to locate the exact cause of the problem.
C. Consult TSB information to find the cause of the problem.
D. Identify the complaint.
4. When testing power steering pump pressure, the power steering gauge valve should be closed for a maximum of:
A. 10 seconds. C. 25 seconds.
B. 20 seconds. D. 35 seconds.
5. While discussing employer and employee responsibilities:
Technician A says employers are required to inform their employees about hazardous materials in the shop.
Technician B says that employers have no obligation to inform their employees about the safe operation of shop equipment.
Who is correct?
A. A only C. Both A and B

- B. B only D. Neither A nor B
6. When connecting a scan tool to diagnose a computer-controlled suspension system on a 1998 vehicle:
- A. The scan tool power cord is connected to the cigarette lighter socket.
 - B. The scan tool is connected to the DLC located under the dash.
 - C. The ignition switch should be on when disconnecting the scan tool.
 - D. On OBD II vehicles the 7-digit DTCs are displayed on the scan tool.
7. All these statements about suspension and steering tools are true EXCEPT:
- A. A plumb bob may be used for frame measurement.
 - B. A tram gauge may be used to measure front wheel alignment.
 - C. A scan tool may be used to diagnose electronically controlled suspension systems.
 - D. A brake pedal jack may be used to apply the brakes during a wheel alignment.
8. When using a vehicle lift:
- A. The lift arms may be positioned on any strong chassis member.
 - B. The safety catch must be engaged after the vehicle is raised on a lift.
 - C. The vehicle hood should be open when raising a vehicle on a lift.
 - D. The vehicle weight may exceed the maximum capacity of the lift.
9. When taking ASE certification tests:
- A. A technician must pass four of the eight ASE certification tests to receive a Master Technician's shoulder patch.
 - B. Each ASE certification test contains 35 to 45 questions.
 - C. An ASE specialty test is available in Advanced Engine Performance Specialist.
 - D. Retesting at three-year intervals is required to maintain ASE certification.
10. When taking ASE certification tests:
- A. A technician must have four years of automotive repair experience before taking an ASE certification test.
 - B. ASE may allow relevant training to be substituted for one year of work experience.
 - C. On any ASE certification test, 90 percent of the questions are Technician A and Technician B type.
 - D. Employers who employ ASE-certified technicians may display a green ASE seal of excellence.

Name _____ Date _____

RAISE A CAR WITH A FLOOR JACK AND SUPPORT IT ON SAFETY STANDS

Upon completion of this job sheet, you should be able to raise the front and rear of a vehicle with a floor jack and support the vehicle on safety stands.

Tools and Materials

A car Four safety stands
Hydraulic floor jack

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

This job sheet must be completed under the supervision of your instructor!

Procedure

Task Completed

1. Determine the proper vehicle floor jack lifting points in the car manufacturer's service manual. Proper front lifting point _____ Proper rear lifting point _____

2. Be sure the car is parked on a level shop floor surface with the parking brake applied. ☐

3. Place the floor jack under the proper lifting point on the front of the vehicle, and raise the floor jack pad until it contacts the lifting point. ☐

4. Release the parking brake and be sure the transmission is in neutral. Is the parking brake released? ☐ Yes ☐ No

Is the transmission in neutral? ☐ Yes ☐ No

Instructor check _____

5. Operate the floor jack and raise the vehicle to the desired height. Place safety stands under the proper support points on the vehicle chassis or suspension. ☐

6. Very slowly operate the release lever on the hydraulic floor jack to slowly lower the vehicle until the support points lightly contact the safety stands. Stop lowering the floor jack. ☐

7. Be sure the safety stands contact the proper support points on the vehicle, and check to be sure all the safety stand legs contact the shop floor evenly.

Are the safety stands contacting the proper support points on the vehicle?

☐ Yes ☐ No

Are all safety stand legs contacting the floor evenly? ☐ Yes ☐ No

Instructor check _____

Task Completed☐

8. If the answer to both questions in step 7 is yes, very slowly operate the release lever on the hydraulic floor jack to slowly lower the vehicle until the vehicle weight is completely supported on the safety stands. Be sure all the safety stand legs are contacting the shop floor evenly, and then remove the floor jack.

☐

9. Place the floor jack under the proper lifting point on the rear of the vehicle, and raise the floor jack pad until it contacts the lifting point.

10. Operate the floor jack, and raise the vehicle to the desired height. Place safety stands under the proper support points on the rear of the vehicle chassis or suspension.

Are the safety stands properly positioned? ☐ Yes ☐ No

Instructor check _____

☐

11. Very slowly operate the release lever on the hydraulic floor jack to slowly lower the vehicle until the rear support points lightly contact the safety stands. Stop lowering the floor jack.

12. Be sure the safety stands contact the proper rear support points on the vehicle, and check to be sure all the safety stand legs contact the shop floor evenly.

Are the safety stands contacting the proper support points on the vehicle?

☐ Yes ☐ No

Are all the safety stand legs contacting the floor evenly? ☐ Yes ☐ No

Instructor check _____

☐

13. If the answer to both questions in step 12 is yes, very slowly operate the release lever on the hydraulic floor jack to slowly lower the rear of the vehicle until the vehicle weight is completely supported on the safety stands. Be sure all the safety stand legs are contacting the shop floor evenly; then remove the floor jack.

Instructor's Response _____

Name _____ Date _____

FOLLOW THE PROPER PROCEDURE TO HOIST A CAR

Upon completion of this job sheet, you should be able to raise and lower a car on a hoist.

Tools and Materials

Car

Lift with enough capacity to hoist the car

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

1. Always be sure the lift is completely lowered before driving the car onto the lift.
2. Do not hit or run over lift arms and adaptors when driving a car onto the lift.
3. Have a coworker guide you when driving a car onto the lift.



WARNING: Do not stand in front of a lift with the car coming toward you. This action may result in personal injury.

4. Be sure the lift pads on the lift are contacting the car manufacturer's recommended lifting points shown in the service manual.

Is the vehicle properly positioned on lift? ☐ Yes ☐ No

Recommended front lifting points: ☐ Right side ☐ Left side

Recommended rear lifting points: ☐ Right side ☐ Left side

Are all four lift pads contacting the recommended lifting points? ☐ Yes ☐ No

Instructor check _____

5. Be sure the doors and hood are closed, and be sure there are no people in the car.
6. When a car is lifted a short distance off the floor, stop the lift and check the contact between the lift pads and the car chassis to be sure the lift pads are still on the recommended lifting points.
7. Be sure there is adequate clearance between the top of the vehicle and the shop ceiling or components under the ceiling.



CAUTION:

Do not raise a four-wheel-drive vehicle with a frame contact lift because this may damage axle joints.

Task Completed

☐
☐
☐
☐
☐
☐
☐

Task Completed

☐

8. When a car is raised on a lift, be sure the safety mechanism is in place to prevent the lift from dropping accidentally.

Is the lift safety mechanism in place? ☐ Yes ☐ No

Instructor check _____

List one precaution that must be observed when a front-wheel-drive vehicle is raised on a lift, and explain the reason for this precaution.

☐

9. Prior to lowering a car on a lift, always make sure there are no tools, objects, or people under the vehicle.



WARNING: Do not rock a car on a lift during a service job. This action may cause the car to fall off the lift, resulting in personal injury and vehicle damage.



WARNING: When a car is raised on a lift, removal of some heavy components may cause car imbalance on the lift, which may cause the car to fall off the lift, resulting in personal injury and vehicle damage.

☐

10. Be sure the lift is lowered completely and no lift components are contacting the vehicle before backing the vehicle off the lift.



CAUTION:

If the proper lifting points are not used, components under the vehicle such as brake lines or body parts may be damaged. Failure to use the recommended lifting points may cause the car to slip off the lift, resulting in severe vehicle damage and personal injury.

Instructor's Response _____

Name _____ Date _____

DETERMINE THE AVAILABILITY AND PURPOSE OF SUSPENSION AND STEERING TOOLS

Procedure

Locate the following tools in your shop or tool room, and explain the purpose of each tool.

1. Stethoscope: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
2. Dial indicator for measuring ball joint wear: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
3. Ball joint removal and installing tools: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
4. Coil spring compressing tool: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
5. Power steering pressure gauge: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
6. Vacuum hand pump: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
7. Turning radius gauge: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
8. Brake pedal jack: available? ☐ Yes ☐ No
 Location _____
 Purpose _____
9. Steering wheel locking tool: available? ☐ Yes ☐ No
 Location _____
 Purpose _____

10. Scan tool: available? ☐ Yes ☐ No

Location _____

Purpose _____

Instructor's Response _____

Chapter 3

WHEEL BEARING AND SEAL SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Diagnose bearing defects.
- Clean and repack wheel bearings.
- Reassemble and adjust wheel bearings.
- Remove and replace wheel bearing seals.
- Diagnose wheel bearing problems.
- Diagnose problems in wheel bearing hub units.
- Remove and replace front drive axles.
- Remove and replace wheel bearing hub units.
- Remove and replace rear-axle bearings on rear-wheel-drive cars.

Technicians must accurately diagnose wheel bearing problems to avoid repeat bearing failures, and thus provide customer satisfaction. Accurate wheel bearing service procedures are essential to maintain vehicle safety! Improper wheel bearing service may cause brake problems, steering complaints, and premature bearing failure. Improper wheel bearing service may even cause a wheel to fly off a vehicle, resulting in personal injury and vehicle damage. A knowledge of drive axle removal is necessary to service the front wheel bearings on front-wheel-drive vehicles, because the drive axle must be removed from the front hub to service the wheel bearings. Similarly, technicians must also understand rear-axle bearing service procedures on rear-wheel-drive vehicles.

DIAGNOSIS OF BEARING DEFECTS

Bearings are designed to provide long life, but there are many causes of premature bearing failure. If a bearing fails, the technician must decide if the bearing failure was caused by normal wear or if the bearing failed prematurely. For example, if a front wheel bearing fails on a car that is one year old with an original odometer reading of 15,000 miles (24,000 kilometers), experience tells us the bearing failure is premature, because front wheel bearings normally last for a much longer mileage period. Always listen to the customer's complaints, and obtain as much information as possible from the customer. Ask the customer specific questions about abnormal or unusual vehicle noises and operation. If a bearing fails prematurely, there must be some cause for the failure.

The causes of premature bearing failure are:

1. Lack of lubrication
2. Improper type of lubrication
3. Incorrect endplay adjustment (where applicable)
4. Misalignment of related components, such as shafts or housings
5. Excessive bearing load



BASIC TOOLS

Basic technician's tool set

Service manual

Inch-pound torque wrench

Foot-pound torque wrench

Fine-toothed round and flat files

Wheel bearing grease

Differential lubricant

Bearing galling refers to metal smears on the ends of the rollers.

Bearing abrasive step wear is a fine circular wear pattern on the ends of the rollers.

Bearing etching appears as a loss of material on the bearing rollers and races. Bearing surfaces are gray or grayish black.

Bearing indentations are surface depressions on the rollers and races.

Classroom Manual

Chapter 3, page 48

Bearing brinelling may be caused by the continuous vibration when transporting new vehicles by rail or truck from the factory to the dealership.



CAUTION: Never wash a sealed bearing or a bearing that is shielded on both sides because solvent may enter the bearing and destroy the lubricant in the bearing, resulting in very short bearing life.

6. Improper installation or service procedures
7. Excessive heat
8. Dirt or contamination

When a bearing fails prematurely, the technician must correct the cause of this failure to prevent the new bearing from failing. The types of bearing failures and the necessary corrective service procedures are provided in Figure 3-1 and Figure 3-2. **Bearing fatigue spalling** appears as flaking of surface metal on bearing rollers and races. **Bearing brinelling** shows up as straight-line indentations on the races and rollers. **Bearing smears** appear as metal loss in a circular, blotched pattern around the bearing races and rollers. **Bearing fretting** shows up as a fine, corrosive wear pattern around the bearing races and rollers. This wear pattern is circular on the races.

The first indication of bearing failure is usually a howling noise while the bearing is rotating. The howling noise will likely vary depending on the bearing load. A front wheel bearing usually provides a more noticeable howl when the vehicle is turning a corner, because this places additional thrust load on the bearing. A defective rear-axle bearing usually provides a howling noise that is more noticeable at lower speeds. The howling noise is more noticeable when driving on a narrow street with buildings on each side, because the noise vibrates off the nearby buildings. A rear-axle bearing noise is present during acceleration and deceleration, because the vehicle weight places a load on the bearing regardless of the operating condition. The rear-axle bearing noise may be somewhat more noticeable during deceleration because there is less engine noise at that time.

SERVICE AND ADJUSTMENT OF TAPERED ROLLER BEARING-TYPE WHEEL BEARINGS

Cleaning Bearings



WARNING: Always wear safety goggles when working in the shop.



WARNING: Do not aim compressed air directly toward any part of your body. Compressed air can penetrate human flesh and enter the blood stream with very serious consequences.



WARNING: Do not spin the bearing at high speed with compressed air. Bearing damage or disintegration may result. Bearing disintegration may cause serious personal injury.




WARNING: Never strike a bearing with a ball peen hammer. This action will damage the bearing and the bearing may shatter, causing severe personal injury.

Two separate tapered roller bearings are used in the front wheel hubs of many rear-wheel-drive cars. The rear wheel hubs on some front-wheel-drive cars have the same type of bearings. Similar service and adjustment procedures apply to these tapered roller bearings.

These bearings should be cleaned, inspected, and packed with wheel bearing grease at the vehicle manufacturer's recommended service intervals. Pry the grease seal out of the inner hub opening with a seal removal tool, and discard the seal. This seal should always be replaced when the bearings are serviced. Do not attempt to wash sealed bearings or bearings that are shielded on both sides. If a bearing is sealed on one side, it may be washed in solvent and repacked with grease.


TAPERED ROLLER BEARING DIAGNOSIS

- Consider the following factors when diagnosing bearing condition:
1. General condition of all parts during disassembly and inspection.
 2. Classify the failure with the aid of the illustrations.
 3. Determine the cause.
 4. Make all repairs following recommended procedures.




ABRASIVE STEP WEAR

Pattern on roller ends caused by fine abrasives. Clean all parts and housings, check seals and bearings, and replace if leaking, rough, or noisy.




GALLING

Metal smears on roller ends due to overheating, lubricant failure, or overload. Replace bearing, check seals, and check for proper lubrication.




BENT CAGE

Cage damaged due to improper handling or tool usage. Replace bearing.




ABRASIVE ROLLER WEAR

Pattern on races and rollers caused by fine abrasives. Clean all parts and housings, check seals and bearings, and replace if leaking, rough, or noisy.




ETCHING

Bearing surfaces appear gray or grayish black in color with related etching away of material usually at roller spacing. Replace bearings, check seals, and check for proper lubrication.




BENT CAGE

Cage damaged due to improper handling or tool usage. Replace bearing.




INDENTATIONS

Surface depressions on race and rollers caused by hard particles of foreign material. Clean all parts and housings. Check seals, and replace bearings if rough or noisy.



BRINELLING


Surface indentations in raceway caused by rollers either under impact loading or vibration while the bearing is not rotating. Replace bearing if rough or noisy.



MISALIGNMENT


Outer race misalignment due to foreign object. Clean related parts and replace bearing. Make sure races are properly sealed.

FIGURE 3-1 Bearing failures and corrective procedures.




FATIGUE SPALLING

Flaking of surface metal resulting from fatigue. Replace bearing, clean all related parts.




STAIN DISCOLORATION

Discoloration can range from light brown to black caused by incorrect lubricant or moisture. Re-use bearings if stains can be removed by light polishing or if no evidence of overheating is observed. Check seals and related parts for damage.



CAGE WEAR

Wear around outside diameter of cage and roller pockets caused by abrasive material and inefficient lubrication. Clean related parts and housings. Check seals and replace bearings.




HEAT DISCOLORATION

Heat discoloration can range from faint yellow to dark blue, resulting from overload or incorrect lubricant. Excessive heat can cause softening of races or rollers. To check for loss of temper on races or rollers, a simple file test may be made. A file drawn over a tempered part will grab and cut metal, whereas, a file drawn over a hard part will glide readily with no metal cutting. Replace bearings if overheating damage is indicated. Check seals and other parts.



FRETTAGE

Corrosion set up by small relative movement of parts with no lubrication. Replace bearings. Clean related parts. Check seals and check for proper lubrication.



CRACKED INNER RACE

Race cracked due to improper fit, cocking, or poor bearing seats. Replace bearing and correct bearing seats.



SMEARS

Smearing of metal due to slippage. Slippage can be caused by poor fits, lubrication, overheating, overloads, or handling damage. Replace bearings, clean related parts, and check for proper fit and lubrication.

FIGURE 3-2 Bearing failures and corrective procedures, continued.



FIGURE 3-3 Cleaning a bearing with solvent.



FIGURE 3-4 Wrapping a bearing in waterproof paper.

Bearings may be placed in a tray and lowered into a container of clean solvent. A brush may be used to remove old grease from the bearing (Figure 3-3). The bearings may be dried with compressed air after the cleaning operation. Be sure the shop air supply is free from moisture, which causes rust formation in the bearing. After all the old grease has been cleaned from the bearing, rinse the bearing in clean solvent and dry it thoroughly with compressed air.

When bearing cleaning is completed, bearings should be inspected for the defects illustrated in Figures 3-1 and 3-2. If any of these conditions are present on the bearing, replacement is necessary. Tapered roller bearings and their matching outer races must be replaced as a set. If the bearing installation is not done immediately, cover the bearings with a protective lubricant and wrap them in waterproof paper (Figure 3-4). Be sure to identify the bearings, or lay them in order, so you reinstall them in their original location. Do not clean bearings or races with paper towels. If you are using a shop towel for this purpose, be sure it is lint free. Lint from shop towels or paper towels may contaminate the bearing. Bearing races and the inner part of the wheel hub should be thoroughly cleaned with solvent and dried with compressed air. Inspect the seal mounting area in the hub for metal burrs. Remove any burrs with a fine round file.

Bearing races must be replaced if any of the defects described in Figures 3-1 and 3-2 are found. The proper bearing race driving tool must be used to remove the bearing races (Figure 3-5). If a driver is not available for the bearing races, a long brass punch and hammer may be used to drive the races from the hub. When a hammer and punch are used for this purpose, be careful not to damage the hub inner surface with the punch.

The new bearing races should be installed in the hub with the correct bearing race driving tool (Figure 3-6). When bearings and races are replaced, be sure they are the same

Classroom Manual

Chapter 3, page 53

The outer bearing race on a tapered roller bearing may be called a bearing cup.



SPECIAL TOOLS

Bearing driver




FIGURE 3-5 Bearing race removal.




FIGURE 3-6 Bearing race installation.

Small dirt particles left behind the outer bearing race cause race misalignment and premature bearing failure.



CAUTION:

Cleanliness is very important during wheel bearing service. Always maintain cleanliness of hands, tools, work area, and all related bearing components. One small piece of dirt in a bearing will cause bearing failure.



CAUTION:

Always keep grease containers covered when not in use. Uncovered grease containers are easily contaminated with dirt and moisture.

as the original bearings. The part numbers should be the same on the old bearings and the replacement bearings.

Inspect the bearing and seal mounting surfaces on the spindle. Small metal burrs may be removed from the spindle with a fine-toothed file. If the spindle is severely scored in the bearing or seal mounting areas, spindle replacement is necessary.

Bearing Lubrication and Assembly

After the bearings and races have been cleaned and inspected, the bearings should be packed with grease. Always use the vehicle manufacturer's specified wheel bearing grease. Vehicle manufacturers usually recommend a lithium-based wheel bearing grease. Place a lump of grease in the palm of one hand and grasp the bearing in the other hand. Force the widest edge of the bearing into the lump of grease, and squeeze the grease into the bearing. Continue this process until grease is forced into the bearing around the entire bearing circumference. Place a coating of grease around the outside of the rollers, and apply a light coating of grease to the races. A bearing packing tool may be used to force grease into the bearings rather than using the hand method. Bearing packers may be hand operated or pressure operated (Figure 3-7).

Place some grease in the wheel hub cavity and position the inner bearing in the hub (Figure 3-8). Check the fit of the new bearing seal on the spindle and in the hub. The seal lip must fit snugly on the spindle, and the seal case must fit properly in the hub opening. The part number on the old seal and the replacement seal should be the same. Be sure the seal is installed in the proper direction with the garter spring and higher part of the lip toward the lubricant in the hub. The new inner bearing seal must be installed in the hub with a suitable seal driver (Figure 3-9). Place a light coating of wheel bearing grease on the spindle and slide the hub assembly onto the spindle. Install the outer wheel bearing and be sure there is adequate lubrication on the bearing and race. Be sure the washer and nut are clean and install these components on the spindle (Figure 3-10). Tighten the nut until it is finger tight.

Photo Sequence 3 shows a typical procedure for adjusting rear wheel bearings on a front-wheel-drive car.



Hand-operated bearing packer



Pressure-operated bearing packer

FIGURE 3-7 Mechanical wheel bearing packer.




FIGURE 3-8 Wheel bearing lubrication.




FIGURE 3-9 Seal installation.




FIGURE 3-10 Installation of wheel bearings and related components.



SERVICE TIP:

When a lip seal is installed, the garter spring should always face toward the flow of lubricant.



SPECIAL TOOLS

Seal driver

Classroom
Manual

Chapter 3, page 54

Wheel Bearing Adjustment with Two Separate Tapered Roller Bearings in the Wheel Hub

Wheel bearing endplay is the amount of horizontal wheel bearing hub movement. If a bearing has a preload condition, a slight tension is placed on the bearing. Loose front wheel bearing adjustment results in lateral front wheel movement and reduced directional stability. If the

CUSTOMER CARE: Never sell a customer automotive service that is not required on his or her car. Selling preventive maintenance, however, is a sound business practice and may save a customer some future problems. An example of preventive maintenance is selling a cooling system flush when the cooling system is not leaking but the manufacturer's recommended service interval has elapsed. If customers find out they were sold some unnecessary service, they will probably never return to the shop. They will likely tell their friends about their experience, and that kind of advertising the shop can do without.

PHOTO SEQUENCE 3


TYPICAL PROCEDURE FOR ADJUSTING REAR WHEEL BEARINGS ON A FRONT-WHEEL-DRIVE CAR



P3-1 Always make sure the car is positioned safely on a lift before working on the vehicle.



P3-2 Remove the dust cap from the wheel hub.



P3-3 Remove the cotter pin and nut retainer from the bearing adjusting nut.




P3-4 Tighten the bearing adjusting nut to 17 to 25 ft-lb.



P3-5 Loosen the bearing adjusting nut one-half turn.



P3-6 Tighten the bearing adjusting nut to 10 to 15 in-lb.



P3-7 Position the adjusting nut retainer over the adjusting nut so the slots are aligned with the holes in the nut and spindle.



P3-8 Install a new cotter pin and bend the ends around the retainer flange.



P3-9 Install the dust cap and be sure the hub rotates freely.

wheel bearing adjusting nut is tightened excessively, the bearings may overheat, resulting in premature bearing failure. The bearing adjustment procedure may vary depending on the make of vehicle. Always follow the procedure in the vehicle manufacturer's service manual.

A typical bearing adjustment procedure follows:

1. With the hub and bearings assembled on the spindle, tighten the adjusting nut to 17 to 25 ft-lb. (23 to 34 Nm) while the hub is rotated in the forward direction.
2. Loosen the adjusting nut 1/2 turn and retighten it to 10 to 15 in-lb. (1.0 to 1.7 Nm). This specification varies depending on the make of vehicle. Always use the manufacturer's specifications.
3. Position the adjusting nut retainer over the nut so the retainer slots are aligned with the cotter pin hole in the spindle.
4. Install a new cotter pin, and bend the ends around the retainer flange.
5. Install the grease cap, and make sure the hub and drum rotate freely.

After a wheel bearing adjustment is performed, the hub must have an endplay of 0.001 in. to 0.005 in. (0.0254 mm to 0.127 mm). A dial indicator may be mounted with the stem positioned against the outer edge of the hub to perform this measurement. When the hub is pulled outward and pushed inward, the specified endplay must be displayed on the dial indicator. If the endplay is not correct, the wheel bearing adjustment must be repeated.

WHEEL HUB UNIT DIAGNOSIS

When wheel bearings and hubs are an integral assembly, the bearing endplay should be measured with a dial indicator stem mounted against the hub. If the endplay exceeds 0.005 in. (0.127 mm) as the hub is moved in and out, the hub and bearing assembly should be replaced. This specification is typical, but the vehicle manufacturer's specifications must be used. Hub and bearing replacement is also necessary if the bearing is rough or noisy. Integral-type bearing and hub assemblies are used on the front and rear wheels on some front-wheel-drive cars. Photo Sequence 4 shows a typical procedure for measuring front wheel hub endplay.

When removable front wheel bearings are mounted in the steering knuckle, the wheel bearings may be checked with the vehicle raised on the hoist and a dial indicator positioned against the outer wheel rim lip as shown in Figure 3-11.

When the wheel is moved in and out, the maximum bearing movement on the dial indicator should be as follows:

- 0.020 in. (0.508 mm) for 13-in. (33-cm) wheels
- 0.023 in. (0.584 mm) for 14-in. (35.5-cm) wheels
- 0.025 in. (0.635 mm) for 15-in. (38-cm) wheels



FIGURE 3-11 Wheel bearing diagnosis on vehicle.



SPECIAL TOOLS

Dial indicator

**Classroom
Manual**

Chapter 3, page 52

PHOTO SEQUENCE 4

TYPICAL PROCEDURE FOR MEASURING FRONT WHEEL HUB ENDPLAY—INTEGRAL, SEALED WHEEL BEARING HUB ASSEMBLIES




P4-1 Be sure the vehicle is properly positioned on a lift before the wheel bearing hub endplay measurement is performed. The vehicle should be properly positioned on a lift with the lift raised to a comfortable working height for performing this measurement.



P4-2 Remove the wheel cover and dust cap.



P4-3 Attach a magnetic dial indicator base securely to the inside of the fender at the lower edge of the wheel opening. Position the dial indicator stem against the vertical wheel surface as close as possible to the top wheel stud, and preload the dial indicator stem.



P4-4 Zero the dial indicator pointer.



P4-5 Grasp the top of the tire with both hands. Push and pull on the top of the tire without rotating the tire, and note the dial indicator readings with the tire pushed inward and the tire pulled outward. The difference between the two readings is the wheel hub endplay. Repeat this procedure twice to verify the endplay reading.



P4-6 Maximum wheel bearing endplay should be 0.005 in. (0.127 mm). If the endplay measurement is not correct, wheel bearing hub replacement is necessary.



P4-7 Remove the dial indicator and install the dust cap and wheel cover.




FIGURE 3-12 Chalk marking on wheel, tire, and stud.

If the bearing movement is excessive, check the hub nut torque before replacing the bearing. When this torque is correct and bearing movement is excessive, the bearing should be replaced.

When a wheel is removed to service the wheel bearings, proper balance must be maintained between the wheel and tire and the hub. Therefore, the tire, wheel, and hub stud should be chalk marked prior to removal (Figure 3-12).

FRONT DRIVE AXLE DIAGNOSIS

On many front-wheel-drive vehicles, the front drive axles must be removed before the wheel hub unit or steering knuckle and bearing can be detached. Therefore, we will discuss front drive axle diagnosis and removal. Because drive axle noises may be confused with front wheel bearing noise, a brief discussion of drive axle noises and problems may be helpful. A defective inner drive axle joint usually causes a vibration when the vehicle is decelerating at 35 to 45 miles per hour (mph), or 56 to 72 kilometers per hour (km/h). A worn inner drive axle joint may also cause vibration during acceleration. When an outer drive axle joint is worn, a clicking noise is heard during a hard turn below 20 mph (32 km/h). To determine which drive axle has the defective joint, lift the vehicle on a hoist, and allow the front wheels to drop down. This action will position the axle joints at a different angle than when the car is driven on the road. Lift the lower control arms one at a time with a floor jack, and place the transmission in drive to simulate the driving conditions that provided the vibration or noise. If the vibration or noise occurs with one lower control arm lifted, that side has the defective drive axle joint.

DRIVE AXLE REMOVAL

Many drive axles have a **circlip** on the inner joint extension that holds the inner joint into the differential side gear. Drive axle systems vary depending on the vehicle. Follow the drive axle removal procedure in the vehicle manufacturer's service manual.

A general front drive axle removal procedure follows:

1. Loosen the front wheel nuts and hub nuts.
2. Lift the vehicle on a hoist and be sure the hoist safety mechanism is in place; then remove the front wheels and tires.
3. Remove the brake calipers and rotors. Connect a piece of wire from the calipers to a suspension or chassis component. Do not allow the calipers to hang on the end of the brake line.
4. Install protective drive axle boots if these are supplied by the car manufacturer.
5. Remove the ball joint to steering knuckle clamp bolt (Figure 3-13).

A **circlip** is a split, circular clip mounted in a groove on the inner drive axle joint extension to retain the drive axle in the transaxle on some front-wheel-drive-vehicles.




FIGURE 3-13 Removal of ball joint to steering knuckle clamp bolt.




FIGURE 3-14 Removal of inner axle joint from transaxle.




FIGURE 3-15 Removal of outer axle joint from front wheel hub.



SPECIAL TOOLS

Front wheel bearing hub pulling and installing tools

6. Pry the ball joint stud from the steering knuckle.
7. Pull the inner axle from the transaxle (Figure 3-14); do not allow the axle to drop down at a severe angle.
8. Remove the hub nut and washer, and separate the outer axle joint from the wheel hub. Some outer axle joint splines are slightly spiraled. On this type of outer axle joint, a special puller is required to separate the axle joint from the wheel (Figure 3-15).
9. Remove the drive axle from the chassis.

Reverse the drive axle removal procedure for front drive axle installation.

SPECIAL PROCEDURES FOR DRIVE AXLE REMOVAL

Some car manufacturers recommend removal of the strut from the steering knuckle rather than removal of the ball joint when the drive axles are removed. This type of suspension system has a threaded nut on the ball joint stem to hold the ball joint into the steering knuckle. If an




FIGURE 3-16 Marking eccentric strut bolt before removal.

eccentric camber adjustment bolt is positioned in the strut, the bolt head position should be marked in relation to the strut before the bolt is removed (Figure 3-16).

On these suspension systems, the brake calipers and brake line clamps should be removed before the drive axles. Some car manufacturers supply a slide-hammer-type puller to remove the inner axle joints from the transaxle.

On Chrysler manual and automatic transaxles, the speedometer gear must be removed from the right differential extension housing before the right drive axle is removed (Figure 3-17).

Early model Chrysler transaxles had circlip retainers, which held the inner drive axle joints into the differential side gears. The differential cover had to be removed and these circlips had to be compressed with needle nose pliers before the drive axles could be removed from the differential side gears. The drive axles had to be rotated until a flat area on the axle and the circlip ends were visible (Figure 3-18).

The inner joint housings did not have tripod springs on early models. Later model Chrysler drive axles may be pulled from the differential side gears without collapsing the




FIGURE 3-17 Speedometer drive gear removal before right axle removal.




FIGURE 3-18 Compressible circlips in early model Chrysler transaxles.



SERVICE TIP:

Do not remove the tool until the left inner axle joint is reinstalled in the Ford ATX. If the tool is removed without installing the left inner axle joint, the side gears may fall out of place. If this action occurs, the Ford ATX may have to be disassembled to install the side gears properly.




FIGURE 3-19 Removal of left inner drive axle joint on Ford automatic transaxles.

circlips. To determine which type of circlip is used, grasp the inner joint housing and try to pull it out of the transaxle. If the inner joint housing moves outward and springs back into the transaxle, the joint has a later model circlip. When the inner joint is solid in the transaxle, the older model circlip, which requires compressing before removal, is used.

On Ford automatic transaxles (ATX), the left inner axle joint is inset into the transaxle housing. In this location, it is impossible to pry the axle joint from the transaxle. Therefore, the right axle joint must be removed first. A special tool is then used to drive the left inner axle joint from the differential side gear (Figure 3-19).

If both left and right drive axles are removed at the same time on Ford transaxles, the differential side gears may become dislocated. When this occurs, the differential must be removed to realign the side gears. The special tool for driving out the left inner axle joint may be left in place to support the side gears on ATX models. On manual transaxles (MTX), shipping plugs T81P-1177-B should be installed in each side gear when the drive axles are removed.

FRONT WHEEL BEARING HUB UNIT REMOVAL AND REPLACEMENT

The front wheel bearing removal and replacement procedure varies depending on the vehicle and the type of front wheel bearing. Always follow the front wheel bearing removal and replacement procedure in the manufacturer's service manual. The following procedure applies to front wheel bearing units that are pressed into the steering knuckle.

When front wheel bearing replacement is necessary, the steering knuckle must be removed and the wheel hub must be pressed from the bearing with a special tool (Figure 3-20).

A special puller is used to remove and replace the wheel bearing in the knuckle (Figures 3-21 and 3-22).




FIGURE 3-20 Wheel hub removal from bearing.




FIGURE 3-21 Wheel bearing removal from knuckle.




FIGURE 3-22 Wheel bearing installation in knuckle.




FIGURE 3-23 Wheel hub installation in wheel bearing.




FIGURE 3-24 Seal installation in steering knuckle.

The wheel hub must be pulled into the wheel bearing with a special tool (Figure 3-23). The proper driving tool is used to install the seal behind the bearing in the knuckle (Figure 3-24).

When two separate roller bearings are mounted in the steering knuckle, the bearing races must be driven from the knuckle with a hammer and punch. These bearings must be lubricated with wheel bearing grease prior to installation, as described earlier in this chapter. When the wheel bearings are removed, all wheel bearing seals must be replaced. A staked-type hub nut must be replaced if it is removed.

On these front-wheel-drive cars, the hub nut torque applies the correct adjustment on the front wheel bearings. Therefore, this torque is extremely important. With the brakes applied, the hub nut should be tightened to the specified torque (Figure 3-25). When the hub nut is torqued to specifications, the nut lock and cotter pin should be installed (Figure 3-26).

WARNING: Never reuse a cotter pin. A used cotter pin may break, allowing the hub nut to loosen. This may allow the wheel and hub to come off.

After the wheel is installed, the wheel nuts should be tightened in sequence to the specified torque (Figure 3-27). On cars with the front wheel bearings mounted in the steering knuckles, never move a car unless the front hub nuts are torqued to specifications. Lack of bearing preload could damage the bearings if the hub nuts are not tightened to specifications. If the car must be moved when the drive axles are removed, place a large bolt and nut with suitable washers through the front wheel bearing and tighten the nut to specifications.



CAUTION:

Never use an impact wrench to tighten a hub nut. This action may cause wheel bearing damage.



FIGURE 3-25 Hub nut torquing.




FIGURE 3-26 Nut lock and cotter pin installation.




FIGURE 3-27 Wheel nut tightening sequence.

Classroom Manual

Chapter 3, page 55



SPECIAL TOOLS

Technician's stethoscope

"C" locks are split, circular, metal rings that fit in rear axle grooves to retain the rear axles in the differential on some rear-wheel-drive vehicles.



WARNING: Use extreme caution when diagnosing problems with a vehicle raised on a hoist and the engine running with the transmission in drive. Keep away from rotating wheels, drive shafts, or drive axles.

Rear-axle bearing noise may be diagnosed with the vehicle raised on a hoist. Be sure the hoist safety mechanism is engaged after the vehicle is raised on the hoist. With the engine running and the transmission in drive, operate the vehicle at a moderate speed of 35 to 45 mph (56 to 72 km/h) and listen with a **stethoscope** placed on the rear axle housing directly over the axle bearings. If grinding or clicking noises are heard, the bearing must be replaced.

Many axle shafts in rear-wheel-drive cars have a roller bearing and seal at the outer end (Figure 3-28). These axle shafts are often retained in the differential with **"C" locks** that must be removed before the axles.

The rear-axle bearing removal and replacement procedure varies depending on the vehicle make and model year. Always follow the rear-axle bearing removal and replacement procedure in the manufacturer's service manual.




FIGURE 3-28 Rear axle roller bearing and seal, rear-wheel-drive car.




FIGURE 3-29 Rear axle "C" lock, lock bolt, and pinion gears.

A typical rear axle shaft removal and replacement procedure on a rear-wheel-drive car with "C" lock axle retainers is as follows:

1. Loosen the rear wheel nuts and chalk mark the rear wheel position in relation to the rear axle studs.
2. Raise the vehicle on a hoist and make sure the hoist safety mechanism is in place.
3. Remove the rear wheels and brake drums, or calipers and rotors.
4. Place a drain pan under the differential and remove the differential cover. Discard the old lubricant.
5. Remove the differential lock bolt, pin, pinion gears, and shaft (Figure 3-29).
6. Push the axle shaft inward and remove the axle "C" lock.
7. Pull the axle from the differential housing.

Reverse the axle removal procedure to reinstall the axle. Always use a new differential cover gasket, and fill the differential to the bottom of the filler plug opening with the manufacturer's recommended lubricant. Be sure all fasteners, including the wheel nuts, are tightened to the specified torque.

A typical axle bearing and seal removal procedure follows:

1. Remove the axle seal with a seal puller.
2. Use the proper bearing puller to remove the axle bearing (Figure 3-30).




FIGURE 3-30 Rear-axle bearing puller.



SPECIAL TOOLS

Seal puller
Bearing puller

3. Clean the axle housing seal and bearing mounting area with solvent and a brush. Clean this area with compressed air.
4. Check the seal and bearing mounting area in the housing for metal burrs and scratches. Remove any burrs or irregularities with a fine-toothed round file.
5. Wash the axle shaft with solvent and blow it dry with compressed air.
6. Check the bearing contact area on the axle for roughness, pits, and scratches. If any of these conditions are present, the axle must be replaced.
7. Be sure the new bearing fits properly on the axle and in the housing. Install the new bearing with the proper bearing driver (Figure 3-31). The bearing driver must apply pressure to the outer race that is pressed into the housing.
8. Be sure the new seal fits properly on the axle shaft and in the housing. Make sure the garter spring on the seal faces toward the differential. Use the proper seal driver to install the new seal in the housing (Figure 3-32).
9. Lubricate the bearing, seal, and bearing surface on the axle with the manufacturer's specified differential lubricant.
10. Reverse the rear axle removal procedure to reinstall the rear axle.
11. Be sure all fasteners are tightened to the specified torque.




FIGURE 3-31 Rear-axle bearing driver.




FIGURE 3-32 Installing rear axle seal.

WARNING: Never use an acetylene torch to heat axle bearings or adaptor rings during the removal and replacement procedure. The heat may cause fatigue in the steel axle and the axle may break suddenly, causing the rear wheel to fall off. This action will likely result in severe vehicle damage and personal injury.



SPECIAL TOOLS

Axle puller

Classroom Manual

Chapter 3, page 55

Some rear axles have a sealed bearing that is pressed onto the axle shaft and held in place with a retainer ring. These rear axles usually do not have “C” locks in the differential. A retainer plate is mounted on the axle between the bearing and the outer end of the axle. This plate is bolted to the outer end of the differential housing. After the axle retainer plate bolts are removed, a slide-hammer-type puller is attached to the axle studs to remove this type of axle. When this type of axle bearing is removed, the adaptor ring must be split with a hammer and chisel while the axle is held in a vise. Do not heat the adaptor ring or the bearing with an acetylene torch during the removal or installation process. After the adaptor ring is removed, the bearing must be pressed from the axle shaft, and the bearing must not be reused. A new bearing and adaptor ring must be pressed onto the axle shaft. The bearing removal and replacement procedure is shown in Figure 3-33.

DIAGNOSTIC TABLE

Problem	Symptoms	Possible causes
Noise in drive train, front-wheel-drive car.	Clicking noise while turning a corner at low speeds.	Worn outer front drive axle joint.
Vibration in front drive train, front-wheel-drive car.	Vibration while decelerating at 35 to 45 mph, 56 to 72 km/h.	Worn inner drive axle joint.
Noise in front suspension.	Growling noise in front suspension, most noticeable when turning a corner or driving at low speeds.	Worn wheel bearings.
Lack of directional stability.	Steering wanders to either side when driving straight ahead.	Excessive front wheel bearing endplay, improper wheel bearing adjustment.
Noise in drive train, rear-wheel-drive car.	Constant growling or clicking noise in rear axle, most noticeable when driving at low speeds or down a narrow street.	Worn rear-axle bearing.




FIGURE 3-33 Axle bearing and adaptor ring removal and replacement.

CASE STUDY

A customer complains of a bearing noise in the right front wheel of his Lincoln Town Car. He says the right front outer wheel bearing has been replaced twice in the last year, and this is the third failure. The technician asks the customer about the mileage intervals between bearing replacements, and the customer indicates that the wheel bearing has lasted about 8,000 miles (12,800 kilometers) each time it has been replaced. The technician finds out from the customer that no other work was done on the car each time the bearing was replaced.

When the technician removes the right front wheel and hub, the outer bearing rollers and races are badly scored. After cleaning both bearings, races, and hub, the technician closely examines the outer bearing race. It shows an uneven wear pattern, which indicates misalignment. The technician removes the outer bearing race and finds a small metal burr behind the

bearing race. This burr caused race misalignment and excessive wear on the race and rollers. The technician removes the burr with a fine-toothed file. The inner bearing and race have indentation wear because metal particles from the outer bearing contaminated the lubricant in the hub. The technician removes the inner bearing race and cleans the hub and spindle thoroughly. He replaces both bearings and the inner seal and repacks the bearings and hub with grease. After reinstalling the hub, the technician carefully adjusts the bearings to the manufacturer's specifications and tightens the wheel nuts to the specified torque. A road test indicates that the bearing noise has been eliminated.

One small metal burr caused this customer a considerable amount of unnecessary expense. This experience proves that a technician's diagnostic capability is extremely important!

TERMS TO KNOW

Bearing brinelling

Bearing fatigue spalling

Bearing fretting

Bearing indentations

Bearing smears

Circlip

"C" locks

Stethoscope

ASE-STYLE REVIEW QUESTIONS

1. While discussing defective bearings:

Technician A says brinelling appears as indentations across the bearing races.

Technician B says brinelling occurs while the bearing is rotating.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

2. While discussing bearing defects:

Technician A says misalignment wear on a front wheel bearing could be caused by a metal burr behind one of the bearing races.

Technician B says misalignment wear on a front wheel bearing could be caused by a bent front spindle.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

3. While discussing front wheel bearing service on a vehicle with the bearing hub unit pressed into the steering knuckle:

Technician A says the front wheel bearings may be damaged if this front-wheel-drive vehicle is moved without the hub nuts torqued to specifications.

Technician B says the hub nut torque supplies the correct wheel bearing adjustment.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

4. While discussing front wheel bearing service on a front-wheel-drive car with two separate tapered roller bearings mounted in the front steering knuckles:
Technician A says the hub nut torque supplies the correct bearing adjustment.
Technician B says that the brake should be applied while the front hub nuts are torqued.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
5. A front-wheel-drive vehicle has 14-in (35.5-cm) rims and front wheel bearings mounted in the steering knuckles. The vehicle is lifted on a hoist, and a dial indicator is positioned against the outer rim lip. The total inward and outward rim movement is 0.035 in (0.889 mm).
Technician A says that the wheel bearing may require replacement.
Technician B says that the hub nut torque should be checked prior to bearing replacement.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
6. When cleaning and inspecting wheel bearings:
A. Sealed bearings should be washed in solvent.
B. High-pressure air may be used to spin the bearings.
C. A bent bearing cage may be caused by improper tool use.
D. Bearing overload may cause bearing cage wear.
7. All these statements about hub seal service are true EXCEPT:
A. The garter spring must face toward the flow of lubricant.
B. A ball peen hammer should be used to install the seal.
C. Seal contact area on the spindle must be clean and free from metal burrs.
D. The outer edge of the seal case should be coated with sealant.
8. When servicing press-in rear-axle bearings on a rear-wheel-drive car:
A. These bearing may be reused after they are removed from the axle shaft.
B. The bearing adaptor ring should be removed by splitting it with a hammer and chisel.
C. A cutting torch may be used to cut the bearing off the axle shaft.
D. An acetylene torch may be used to heat the new adaptor ring prior to installation.
9. A front-wheel-drive vehicle has two tapered roller bearings in each rear wheel hub. When adjusting these wheel bearings:
A. The adjusting nut should be tightened to 17 to 25 ft-lb (23 to 24 Nm), backed off 1/2 turn, and then tightened to 10 to 15 in-lb (1.0 to 1.7 Nm).
B. The adjusting nut should be tightened to 40 ft-lb (54 Nm), backed off 1 turn, and then tightened to 10 ft-lb (13.5 Nm).
C. The adjusting nut should be tightened to 50 ft-lb (67.5 Nm), backed off 3/4 turn, and then tightened to 10 to 15 in-lb (1.0 to 1.7 Nm).
D. The wheel and hub should not be rotated while adjusting the wheel bearings.
10. A unitized front wheel bearing hub that is bolted to the steering knuckle has 0.010 in (0.254 mm) of hub endplay. The proper repair procedure is to:
A. Repack and readjust the wheel bearings in the hub.
B. Tighten the hub nut to the specified torque.
C. Inspect the drive axle and hub splines, and replace the worn components.
D. Replace the wheel bearing hub assembly.

ASE CHALLENGE QUESTIONS

1. The customer says her front-wheel-drive car makes “a moaning noise” in a turn. Which of the following could cause this problem?

A. Outer front wheel bearing.
B. Rear-axle bearing.
C. Differential gear noise.
D. Transaxle output shaft bearing.

2. The customer complains of a “whining noise” in the back of her rear-wheel-drive car when driving between 30 and 40 miles per hour.

Technician A says a good way to diagnose this problem is on a hoist with a stethoscope.

Technician B says a good way to diagnose this problem is on the road with a microphone.

Who is correct?

A. A only C. Both A and B
B. B only D. Neither A nor B

3. Upon inspecting a noisy front wheel bearing from a 4WD sport utility vehicle, brinelling damage to the outer bearing race was noticed.

Technician A says the damage was probably caused by tightening the bearing nut with an impact wrench.

Technician B says the damage was probably caused by driving the vehicle through deep, muddy water.

Who is correct?

A. A only C. Both A and B
B. B only D. Neither A nor B

4. While discussing the cause of overheating damage of a front wheel bearing:

Technician A says overheating may be caused by insufficient or incorrect bearing lubricant.

Technician B says overheating may be caused by overtightening the wheel bearing nut on installation.

Who is correct?

A. A only C. Both A and B
B. B only D. Neither A nor B

5. The customer says her front-wheel-drive car has a noise and vibration when decelerating and is most noticeable under 50 miles per hour. Which would be the most probable cause of this problem?

A. Defective outer front wheel bearing.
B. Defective inner front wheel bearing.
C. Defective outer drive axle joint.
D. Defective inner drive axle joint.

Name _____ Date _____

SERVICE INTEGRAL WHEEL BEARING HUBS

Upon completion of this job sheet, you should be able to measure integral wheel bearing hub endplay, and remove and replace integral wheel bearing hubs.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task D-2: Remove, inspect, and service or replace front and rear wheel bearings.

Tools and Materials

- A front-wheel-drive vehicle with integral-type front wheel bearing hubs
- A floor jack and safety stands, or a lift for raising the vehicle
- Dial indicator
- Integral wheel bearing hub puller
- Torque wrench

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed _____

1. Road test the vehicle and listen for any abnormal wheel bearing noises; check for steering looseness or wander that may be caused by loose wheel bearings.

Type of abnormal noise

Possible causes

- a. _____
- b. _____
- c. _____

- a. _____
- b. _____
- c. _____

Steering wander and looseness

☐ Yes ☐ No

2. Use a dial indicator to measure the endplay on the front wheel bearing hubs with the wheel installed on the hub.

Endplay left side _____ Endplay right side _____

Specified endplay _____

Necessary repairs _____

3. Loosen and remove the cotter pin, lock nut, and drive axle nut before raising the vehicle. ☐
4. Raise the vehicle on a lift and remove the front wheels. ☐

Task Completed



5. Remove the brake calipers and brake rotors. Use a length of wire to tie the calipers to the chassis.

6. Use a dial indicator to measure the endplay directly on the front wheel bearing hubs.

Endplay left side _____ Endplay right side _____

Specified endplay _____

Necessary repairs _____



7. If a wheel speed sensor for the antilock brake system (ABS) is integral in the front wheel hubs, disconnect the wheel speed sensor connectors.



8. Remove the hub-to-knuckle bolts, and place the transaxle in park.



9. Use the proper puller to remove the wheel bearing hub from the drive axle.



10. Install the new hub and bearing assembly on the drive axle splines, and install a new drive axle nut. Tighten the drive axle nut to pull the hub onto the splines. Do not tighten this nut to the specified torque at this time.

11. Place the transaxle in neutral and install the wheel bearing hub bolts. Tighten these bolts to the specified torque.

Specified wheel bearing hub bolt torque _____

Actual wheel bearing hub bolt torque _____

12. Install the wheel sensor connectors, rotors, and calipers. Tighten the caliper mounting bolts to the specified torque. Place a large punch between the rotor fins and the caliper, and tighten the drive axle nut to the specified torque.

Specified caliper bolt torque _____

Actual caliper bolt torque _____

Specified drive axle nut torque _____

Actual drive axle nut torque _____

13. Install the wheels in their original positions, and tighten the wheel nuts to the specified torque.

Specified wheel nut torque _____

Actual wheel nut torque _____

14. Lower the vehicle onto the shop floor, and tighten the drive axle nut to the specified torque. Install the lock nut and a new cotter pin.

Specified drive axle nut torque _____

Actual drive axle nut torque _____

Are the lock nut and cotter pin properly installed and tightened?

Instructor check _____

15. Road test the car and listen for abnormal wheel bearing noises.

Wheel bearing noise: ☐ Satisfactory ☐ Unsatisfactory

Instructor's Response _____

Name _____ Date _____

DIAGNOSE WHEEL BEARINGS

Upon completion of this job sheet, you should be able to diagnose wheel bearings.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task D-2: Remove, inspect, and service or replace front and rear wheel bearings.

Tools and Materials

A vehicle with wheel bearing noise or bearing noise from another source

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. Road test the vehicle, listen for any abnormal wheel noises, and check for steering looseness and wander that may be caused by loose wheel bearings.
2. Wheel bearing noise: ☐ Satisfactory ☐ Unsatisfactory
3. Is the bearing noise coming from the front or rear of the vehicle? ☐ Front ☐ Rear
4. Is this noise more noticeable when turning a corner at low speeds? ☐ Yes ☐ No
5. Is this noise more noticeable during acceleration? ☐ Yes ☐ No
6. Is this noise more noticeable during deceleration? ☐ Yes ☐ No
7. Is this noise more noticeable when driving at a steady speed? ☐ Yes ☐ No

If the answer to this question is yes, state the speed when the bearing noise is most noticeable. _____

8. Is this noise most noticeable when driving down a narrow street at a steady low speed?
☐ Yes ☐ No
9. State the exact cause of the bearing noise, and explain the reason for your diagnosis.

Instructor's Response _____

Name _____ Date _____

CLEAN, LUBRICATE, INSTALL, AND ADJUST NONSEALED WHEEL BEARINGS

Upon completion of this job sheet, you should be able to clean, lubricate, install, and adjust nonsealed wheel bearings.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task D-2: Remove, inspect, and service or replace front and rear wheel bearings.

Tools and Materials

A vehicle with tapered roller-type front wheel bearings or a front-wheel-drive car with tapered roller-type rear wheel bearings

A floor jack and safety stands, or a lift for raising the vehicle

Wheel bearing grease

Cleaning solution

Seal drivers

Torque wrench

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. Raise the vehicle on a lift with the chassis supported on the lift. ☐
2. Chalk mark the wheels in relation to the studs; remove the wheels, wheel hubs, and brake drums or rotors. ☐
3. Remove the inner hub seal and wheel bearings from the hub. ☐
4. Clean the hub and bearings with an approved cleaning solvent.

Are the hub and bearings properly cleaned? ☐ Yes ☐ No

Instructor check _____

5. Inspect the wheel bearings, bearing cones, and hubs.

Type of defects

a. _____

b. _____

c. _____

Necessary replacement parts

a. _____

b. _____

c. _____

6. Inspect all bearing-related conditions such as lubrication, alignment, spindle condition, and hub condition. State the cause(s) of the bearing defects listed in step 5.
- a. _____
- b. _____
- c. _____
7. Repack the wheel bearings and hub with the car manufacturer's specified wheel bearing grease.
- Are the wheel bearings and hub repacked with the manufacturer's recommended grease? ☐ Yes ☐ No
- Instructor check _____
8. Install a new inner hub seal with the proper seal driver. Lubricate the seal lips with a light coating of the car manufacturer's recommended wheel bearing grease.
- Is the new inner hub seal properly installed? ☐ Yes ☐ No
- Instructor check _____
9. Inspect, clean, and lubricate the spindles and seal contact area.
- Spindle and seal contact condition: ☐ Satisfactory ☐ Unsatisfactory
- If unsatisfactory, state necessary repairs. _____
- Is the spindle and seal contact area properly cleaned and lubricated? ☐ Yes ☐ No
- Instructor check _____
10. Install the wheel hubs, wheel bearings, washer, and retaining nut. Adjust the wheel bearing retaining nut to the specified initial torque.
- Specified initial wheel bearing torque _____
- Actual initial wheel bearing torque _____
11. Back off the wheel bearing retaining nut the specified amount.
- Specified portion of a turn to back off the wheel bearing retaining nut _____
- Actual portion of a turn the wheel bearing retaining nut is backed off _____
12. Tighten the wheel bearing retaining nut to the final specified torque.
- Specified final wheel bearing retaining nut torque _____
- Actual final wheel bearing retaining nut torque _____
13. Install a new cotter pin through the wheel bearing retaining nut and spindle opening.
- Is the new cotter pin properly installed? ☐ Yes ☐ No
- Instructor check _____

14. Install the wheel bearing dust covers. Install the wheels in their original position, and tighten the wheel nuts to the specified torque.

Specified wheel nut torque _____

Actual wheel nut torque _____

15. Road test the car and listen for abnormal wheel bearing noises.

Wheel bearing noise: ☐ Satisfactory ☐ Unsatisfactory

Instructor's Response _____

Chapter 4

TIRE AND WHEEL SERVICING AND BALANCING

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Diagnose tire thump and vibration problems.
- Diagnose steering pull problems related to tire condition.
- Rotate tires according to the vehicle manufacturer's recommended procedure.
- Remove and replace tire-and-wheel assemblies.
- Dismount, inspect, repair, and remount tires.
- Inspect wheel rims.
- Diagnose and service tire pressure monitoring systems.
- Measure tire and wheel radial and lateral runout.
- Diagnose problems caused by excessive radial or lateral tire-and-wheel runout.
- Measure tire tread wear.
- Perform off-car static wheel balance procedures.
- Perform off-car dynamic wheel balance procedures.
- Diagnose tire wear problems caused by tire and wheel imbalance.
- Perform on-car balance procedures.
- Diagnose comprehensive vibration problems.



BASIC TOOLS

Basic technician's tool set
Service manual
Tire repair kit
Tread depth gauge

Tire thump may be defined as a pounding noise caused by tire and wheel rotation.

Tire vibration is a fast shaking of the tire that is transferred to the chassis and passenger compartment.

Proper servicing of tires and wheels is extremely important to maintain vehicle safety and provide normal tire life. Improperly serviced and/or balanced tires and wheels cause wheel vibration and shimmy problems, resulting in excessive tire tread wear, increased wear on suspension and steering components, and decreased vehicle stability and steering control.

TIRE NOISES AND STEERING PROBLEMS

Diagnosis of Tire Noises

Uneven tread surfaces may cause tire noises that seem to originate elsewhere in the vehicle. These noises may be confused with differential noise. Differential noise usually varies with acceleration and deceleration, whereas tire noise remains more constant in relation to these forces. Tire noise is most pronounced on smooth asphalt road surfaces at speeds of 15 to 45 mph (24 to 72 km/h).

Tire Thump and Vibration

When tire thump and tire vibration are present, check these items:

1. Cupped tire treads
2. Excessive tire **radial runout**
3. Manufacturing defects such as heavy spots, weak spots, or tread chunking
4. Incorrect wheel balance




FIGURE 4-1 Tire conicity.



SERVICE TIP:

Tire noise varies with road surface conditions, whereas differential noise is not affected when various road surfaces are encountered.

Steering Pull

A vehicle should maintain the straight-ahead forward direction on smooth, straight road surfaces without excessive steering wheel correction by the driver. If the steering gradually pulls to one side on a smooth, straight road surface, a tire, steering, or suspension defect is present. Tires of different types, sizes, designs, or inflation pressures on opposite sides of a vehicle cause **steering pull**. Sometimes a tire manufacturing defect occurs in which the belts are wound off center on the tire. This condition is referred to as **tire conicity**. A cone-shaped object rolls in the direction of its smaller diameter. Similarly, a tire with conicity tends to lead, or pull, to one side, which causes the vehicle to follow the action of the tire (Figure 4-1).

Because tire conicity cannot be diagnosed by a visual inspection, it must be diagnosed by switching the two front tires and reversing the front and rear tires (Figure 4-2). Incorrect front suspension alignment angles also cause steering pull.

Radial runout refers to a tire out-of-round condition.

Steering pull is the tendency of the steering to gradually pull to the right or left when the vehicle is driven straight ahead on a reasonably smooth, straight road.




FIGURE 4-2 Tire conicity diagnosis.



SERVICE TIP:

Tire conicity is not visible. It can be diagnosed only by changing the tire and wheel position.

Classroom Manual

Chapter 4,
page 61

Some wheel balancers with force variation capabilities sense and indicate tire conicity defects. These wheel balancers have a roller that presses against the tire tread during the wheel balance procedure, and this roller senses tire conicity.

TIRE ROTATION

Driving habits determine tire life to a large extent. Severe brake applications, high-speed driving, turning at high speeds, rapid acceleration and deceleration, and striking curbs are just a few driving habits that shorten tire life. Most car manufacturers recommend **tire rotation** at specified intervals to obtain maximum tire life. The exact tire rotation procedure depends on the model year, the type of tires, and whether the vehicle has a conventional spare or a compact spare (Figure 4-3). Tire rotation procedures do not include the compact spare. The vehicle manufacturer provides tire rotation information in the owner's manual and service manual. Vehicle manufacturers usually recommend different tire rotation procedures for bias-ply tires than for radial tires (Figure 4-4).




FIGURE 4-3 Radial tire rotation procedure.




FIGURE 4-4 Bias-ply tire rotation procedure.




FIGURE 4-5 Wheel nut tightening sequence.

When tires and wheels are installed on a vehicle, it is very important that the wheel nuts are torqued to manufacturer's specifications in the proper sequence (Figure 4-5). Do not use an impact wrench when tightening wheel nuts to the specified torque.

TIRE AND WHEEL SERVICE

Tire and Wheel Removal

CUSTOMER CARE: During many automotive service operations, including tire and wheel service, the technician literally has the customer's life in his or her hands! Always perform tire and wheel service carefully and thoroughly. Watch for unsafe tire or wheel conditions, and report these problems to the customer. When you prove to the customer that you are concerned about vehicle safety, you will probably have a steady customer.

When it is necessary to remove a tire-and-wheel assembly, follow these steps:

1. Remove the wheel cover. If the vehicle is equipped with **antitheft locking wheel covers**, the lock bolt for each wheel cover is located behind the ornament in the center of the wheel cover. A special key wrench is supplied to the owner for ornament and lock bolt removal. If the customer's key wrench has been lost, a master key is available from the vehicle dealer.
2. Loosen the wheel lug nuts about one-half turn, but do not remove the wheel nuts. Some vehicles are equipped with **antitheft wheel nuts**. A special lug nut key is supplied to the vehicle owner. This lug nut key has a hex nut on the outer end and a special internal projection that fits in the wheel nut opening. Install the lug nut key on the lug nuts, and connect the lug nut wrench on the key hex nut to loosen the lug nuts.



SERVICE TIP:

On some current vehicles, such as the 2004 Cadillac SRX, the front and rear tires have dissimilar widths. For example, if one of these cars has a V8 engine, the vehicle is equipped with 18 in. wheels, and the front tire size is P235/60R18 while the rear tire size is P255/55R18. These tires must not be rotated from front to rear, but they can be rotated from side-to-side.



SERVICE TIP:

Some wheel covers have fake plastic lug nuts that must be removed to access the lug nuts. Be careful not to break the fake lug nuts.

Antitheft locking wheel covers prevent

unauthorized personnel from removing the wheel covers.

Antitheft wheel nuts prevent unau-

thorized personnel from removing the wheel nuts.



WARNING: Before the vehicle is raised on a hoist, be sure that the hoist is lifting on the car manufacturer's recommended lifting points. If the hoist is not lifting on the car manufacturer's recommended lift points, chassis components may be damaged, and the vehicle may slip off the hoist, resulting in personal injury.



CAUTION:

If heat is used to loosen a rusted wheel, the wheel and/or wheel bearings may be damaged.



WARNING: If the vehicle is lifted with a floor jack, place safety stands under the suspension or frame, and lower the vehicle onto the safety stands. Then remove the floor jack from under the vehicle. If the vehicle is not supported properly on safety stands, the vehicle may suddenly drop, resulting in personal injury.

3. Raise the vehicle on a hoist or with a floor jack to a convenient working level.
4. Chalk mark the tire, wheel, and one of the lug nuts so the tire and wheel can be reinstalled in the same position.
5. Remove the lug nuts and the tire-and-wheel assembly. If the wheel is rusted and will not come off, hit the inside of the wheel with a large rubber mallet. Do not hit the wheel with a steel hammer, because this action could damage the wheel. Do not heat the wheel.

TIRE AND WHEEL SERVICE PRECAUTIONS

There are many different types of tire changing equipment in the automotive service industry. However, specific precautions apply to the use of any tire changing equipment.

These precautions include the following:

1. Before you operate any tire changing equipment, always be absolutely certain that you are familiar with the operation of the equipment.
2. When operating tire changing equipment, always follow the equipment manufacturer's recommended procedure.
3. Always deflate a tire completely before attempting to dismount the tire.
4. Clean the bead seats on the wheel rim before mounting the tire on the wheel rim.
5. Lubricate the outer surface of the tire beads with rubber lubricant before mounting the tire on the wheel rim.
6. When the tire is mounted on the wheel rim, be sure the tire is positioned evenly on the wheel rim.
7. While inflating a tire, do not stand directly over the tire. An air hose extension allows the technician to stand back from the tire during the inflation process.
8. Do not overinflate tires.
9. When mounting tires on cast aluminum alloy wheel rims or cast magnesium alloy wheel rims, always use the tire changing equipment manufacturer's recommended tools and procedures.
10. When mounting or dismounting run-flat tires, be sure the tire changing equipment is compatible with these tires and wheels.



CAUTION:

Never use petroleum-based lubricants on tire beads. This action damages the beads.



CAUTION:

If hand tools or tire irons are used to dismount tires, tire bead and wheel rim damage may occur.

Tire Dismounting

Always use a tire changer to dismount tires. Do not use hand tools or tire irons for this purpose. Various types of tire changers are available. When servicing tires it is very important that the tire changing equipment will mount and dismount run-flat tires, low-profile tires, and tires mounted on alloy wheels without damaging the wheel rims or tires. Some




FIGURE 4-6 Tire changer.

tire changers have the features illustrated in Figure 4-6 and described in the following explanation:

1. A floating 3-point articulated arm has a polymer mount/dismount head on the end of the arm. This type of mount/dismount head goes between the tire bead and the rim when dismounting or mounting the tire (Figure 4-7). The polymer head will not damage alloy wheel rims. A mechanical bead pusher with a nylon roller facilitates handling stiff, low-profile tires.
2. A spring-loaded wheel centering support centers the wheel rim in the clamping system.
3. A rubber-pad clamping system eliminates steel-jaw clamping and wheel rim damage. The rim clamping system easily adjusts for internal or external rim clamping (Figure 4-8).
4. A multi-piston air motor in the tire changer drives the clamp assembly and wheel rim in either direction up to 15 revolutions per minute (rpm). The technician controls the clamp and wheel rim rotation by foot-operated pedals on the front of the tire changer. This type of clamping system allows the technician to rotate the wheel rim inside the tire to correct excessive wheel and tire runout conditions.




FIGURE 4-7 Articulating arm with polymer head and mechanical bead pusher.




FIGURE 4-8 Rim clamping system provides internal or external rim clamping action.

5. The technician uses two fingers to operate control switches that control the upper and lower bead rollers by air-over-hydraulic pressure.
6. The nonmetal bead rollers are placed against the tire next to the rim, and the technician uses the control switches to supply pressure to the rollers (Figure 4-9). The clamp and wheel assembly is rotated to loosen the upper and lower beads.
7. The tire changer is designed so the complete bead loosening, tire dismounting, and tire mounting operation can be performed from one position, which saves time and physical energy.




FIGURE 4-9 Bead loosening rollers.




FIGURE 4-10 Tire changer with horizontal clamping mechanism.

8. A side shovel bead-loosening tool is an optional feature that facilitates dismounting and mounting tires on special applications such as motorcycles and all-terrain vehicles (ATVs).

Other tire changers have similar features but a different tire and wheel assembly mounting (Figure 4-10). The tire and wheel assembly is mounted on a clamping bell that centers the wheel on the bell. A threaded center post is mounted in the center of the clamping bell. After the tire and wheel assembly is placed on the clamping bell, a tapered cone is threaded onto the center post to retain the tire and wheel assembly. The nonmetal bead rollers are used to loosen the upper and lower beads. On alloy wheels the polymer head on the articulating arm is used to dismount and mount the tire. On steel wheels a steel mount tool may be placed through the center post and under the tire bead, and the tire and wheel assembly is rotated to dismount or mount the tire (Figure 4-11). Many tire changers have inflation jets in the clamping mechanism to supply air pressure to the inside of the tire and inflate the tire after the tire is mounted properly.

A typical tire dismounting procedure follows:

1. Remove the valve core and be sure the tire is completely deflated.
2. Place the wheel and tire on the tire changer with the narrow bead ledge facing upward.



SPECIAL TOOLS
Tire changer

Classroom Manual

Chapter 4,
page 64



CAUTION:

The use of sealants or cord plugs when repairing PAX tires will immediately void the tire warranty.



CAUTION:

If a tire changer without PAX capabilities is used to attempt PAX tire dismounting and mounting, tire and wheel damage may occur.




FIGURE 4-11 Steel mount/demount tool for steel rims.

3. Follow the operating procedure recommended by the manufacturer of the tire changer to force the tire bead inward and separate it from the rim on both sides.
4. Push one edge of the top bead into the drop center of the rim.
5. Place the tire changer's head or lever between the bead and the rim on the opposite side of the rim from where the bead is in the drop center.
6. Operate the tire changer to rotate the head or lever and move the bead over the top of the rim.
7. Repeat steps 4, 5, and 6 to move the lower bead over the top of the rim.

PAX Tire Service

PAX tires are usually serviced at Michelin-authorized PAX tire dealers. Some car dealerships that sell cars with original equipment PAX tires may be authorized Michelin PAX dealers. Other car dealerships will only provide complete PAX tire and wheel replacements. If PAX tires are punctured in the tread area, they are repairable.

Special tire changing equipment is required to dismount and mount PAX tires. An accessory kit and a different press arm may be installed on some tire changers to upgrade the changer to PAX capabilities. A PAX accessory kit and PAX press arm are available for the Coats 9024E tire changer (Figure 4-12). This accessory kit (Figure 4-13) contains the following items:

1. Quick release hub nut
2. Centering cones
3. Removable center shaft
4. Cushioned PAX riser
5. Dual roller tool
6. Tool holders
7. PAX bead lift tool
8. Bead flip tool
9. Plain bead lock tool
10. Spring-loaded bead lock tool
11. Plastic protectors
12. Tapered roller

When dismounting and mounting PAX tires, follow the procedure specified by the tire changer manufacturer. All PAX tires have a tire pressure monitoring system (TPMS). Service precautions related to TPMS systems must be observed when servicing PAX tires and wheels.




FIGURE 4-12 Tire changer adaptable to PAX here.



FIGURE 4-13 Tire changer accessory kit for PAX tire services.

When a PAX tire is dismounted, always inspect the deflation ring mounted on the wheel. If the ring is damaged, it must be replaced.

Tire Inspection and Repair

To find a leak in a tire and wheel, inflate the tire to the pressure marked on the sidewall, and then submerge the tire and wheel in a tank of water. An alternate method of leak detection is to sponge soapy water on the tire and wheel. Bubbles will appear wherever the leak is located in the tire or wheel. Mark the leak location in the tire or wheel rim with a crayon, and mark the tire at the valve stem location so the tire can be reinstalled in the same position on the wheel to maintain proper balance.

A puncture is the most common cause of a tire leak, and many punctures can be repaired satisfactorily. Do not attempt to repair punctures over 1/4 in. in diameter. Punctures in the sidewalls or on the tire shoulders should not be repaired. The repairable area in belted bias-ply tires is approximately the width of the belts (Figure 4-14). The belts in radial tires are wider than those in bias-ply tires. The repairable area in radial tires is also the width of the belts. Because compact spare tires have thin treads, do not attempt to repair these tires.

Inspect the tire; do not repair a tire with any of the following defects, signs of damage, or excessive wear:

1. Tires with the wear indicators showing
2. Tires worn until the fabric or belts are exposed
3. Bulges or blisters
4. **Ply separation**
5. Broken or cracked beads
6. Cuts or cracks anywhere in the tire

Because most vehicles are equipped with tubeless tires, we will discuss this type of tire repair. If the cause of the puncture, such as a nail, is still in the tire, remove it from the tire.

When **ply separation** occurs, the tire plies are pulled apart. This condition often appears as a bulge on the tire surface.




FIGURE 4-14 Repairable area on bias-ply and belted bias-ply tires.




FIGURE 4-15 Plug installation procedure.



CAUTION:

Radial tire patches should have arrows that must be positioned parallel to the radial plies to provide proper adhesion.



CAUTION:

The use of abrasive cleaners, alkaline-base detergents, or caustic agents on aluminum or magnesium wheel rims may cause discoloration or damage to the protective coating.

Most punctures can be repaired from inside the tire with a service plug or vulcanized patch service kit. The instructions of the tire service kit manufacturer should be followed, but we will discuss three common tire repair procedures.

Plug Installation Procedure

1. Buff the area around the puncture with a wire brush or wire buffing wheel.
2. Select a plug slightly larger than the puncture opening, and insert the plug in the eye of the insertion tool.
3. Wet the plug and the insertion tool with vulcanizing fluid.
4. While holding and stretching the plug, pull the plug into the puncture from the inside of the tire (Figure 4-15). The head of the plug should contact the inside of the tire. If the plug pulls through the tire, repeat the procedure.
5. Cut the plug off 1/32 in. from the tread surface. Do not stretch the plug while cutting.

Cold Patch Installation Procedure

1. Buff the area around the puncture with a wire brush or buffing wheel.
2. Apply vulcanizing fluid to the buffed area and allow it to dry until it is tacky.
3. Peel the backing from the patch, and apply the patch over the puncture. Center the patch over the puncture.
4. Run a stitching tool back and forth over the patch to improve bonding.

Hot Patch Installation Procedure

1. Buff the area around the puncture with a wire brush or buffing wheel.
2. Apply vulcanizing fluid to the buffed area, if required.
3. Peel the backing from the patch and install the patch so it is centered over the puncture on the inside of the tire. Many hot patches are heated with an electric heating element clamped over the patch. This element should be clamped in place for the amount of time recommended by the equipment or patch manufacturer.
4. After the heating element is removed, allow the patch to cool for a few minutes and be sure the patch is properly bonded to the tire.

WHEEL RIM SERVICE

Steel rims should be spray cleaned with a water hose. Aluminum or magnesium wheel rims should be cleaned with a mild soap and water solution, and rinsed with clean water. The use of abrasive cleaners, alkaline-base detergents, or caustic agents may damage aluminum or

magnesium wheel rims. Clean the rim bead seats on these wheel rims thoroughly with the mild soap and water solution. The rim bead seats on steel wheel rims should be cleaned with a wire brush or coarse steel wool.

Steel wheel rims should be inspected for excessive rust and corrosion, cracks, loose rivets or welds, bent or damaged bead seats, and elongated lug nut holes. Aluminum or magnesium wheel rims should be inspected for damaged bead seats, elongated lug nut holes, cracks, and porosity. If any of these conditions are present on either type of wheel rim, replace the wheel rim.

Many shops always replace the tire valve assembly when a tire is repaired or replaced. This policy helps prevent future problems with tire valve leaks. The inner end of the valve may be cut off with a pair of diagonal pliers, and then the outer end may be pulled from the rim. Coat the new valve with rubber tire lubricant and pull it into the rim opening with a special puller screwed onto the valve threads.

Wheel Rim Leak Repair


A wheel rim leak may be repaired if the leak is not caused by excessive rust on a steel rim, and the rim is in satisfactory condition.


Follow these steps for wheel rim leak repair:

1. Use #80-grit sandpaper to thoroughly clean the area around the leak on the tire side of the rim.
2. Use a shop towel to remove any grit from the leak area.
3. Be sure the wheel rim is at room temperature, and apply a heavy coating of silicone rubber sealer over the leak area.
4. Spread the sealer over the entire sanded area with a putty knife.
5. Allow the sealer to cure for six hours before remounting the tire.

TIRE REMOUNTING PROCEDURE

1. Be sure the wheel rim bead seats are thoroughly cleaned.
2. Coat the tire beads and the wheel rim bead seats with rubber tire lubricant.
3. Secure the wheel rim on the tire changer with the narrow bead ledge facing upward, and place the tire on top of the wheel rim with the bead on the lower side of the tire in the drop center of the wheel rim.
4. Use the tire changer head or lever under the tire bead to install the tire bead over the wheel rim. Always operate the tire changer with the manufacturer's recommended procedure.
5. Repeat steps 3 and 4 to install the upper bead over the wheel rim.
6. Rotate the tire on the wheel rim until the crayon mark is aligned with the valve stem. This mark was placed on the tire prior to dismounting.

 **WARNING:** When a bead expander is installed around the tire, never exceed 10 psi (69 kPa) pressure in the tire. A higher pressure may cause the expander to break and fly off the tire, causing serious personal injury or property damage.

 **WARNING:** When a bead expander is not used, never exceed 40 psi (276 kPa) tire pressure to move the tire beads out tightly against the wheel rim. A higher pressure may blow the tire bead against the rim with excessive force, and this action could burst the rim or tire, resulting in serious personal injury or property damage.



CAUTION:

Steel wheel rims must not be welded, heated, or peened with a ball-peen hammer. These procedures may weaken the rim and create a safety hazard.



CAUTION:

Installing an inner tube to correct leaks in a tubeless tire or wheel rim is not an approved procedure.




FIGURE 4-16 The circular ring around the tire bead must be centered on the wheel rim.



WARNING: While inflating a tire, do not stand directly over the tire. In this position, serious injury could occur if the tire or wheel rim flies apart.

7. Follow the recommended procedure supplied by the manufacturer of the tire changer to inflate the tire. This procedure may involve the use of a bead expander installed around the center of the tire tread to expand the tire beads against the wheel rim. If a bead expander is used, inflate the tire to 10 psi (69 kPa) to move the beads out tightly against the wheel rim. Never exceed this pressure with a bead expander installed on the tire. Always observe the circular marking around the tire bead as the tire is inflated. This mark should be centered around the wheel rim (Figure 4-16). Always observe both beads while a tire is inflated. If the circular mark around the tire bead is not centered on the rim, deflate the tire and center it on the wheel rim. If a bead expander is not used, never exceed 40 psi (276 kPa) when moving tire beads out tightly against the rim. When either tire bead will not move out tightly against the wheel rim with 40 psi (276 kPa) tire pressure, deflate the tire and center it on the wheel rim again.

Photo Sequence 5 shows a typical procedure for dismounting and mounting a tire on a wheel assembly.

DIAGNOSING AND SERVICING TIRE PRESSURE MONITORING SYSTEMS

Visual Inspection

If the tire pressure monitoring system (TPMS) warning light is illuminated and/or a warning message is displayed in the message center, the first step in diagnosing the system is a visual inspection. During this inspection be sure each tire is inflated to the specified pressure. Make sure all fours or five tires are the size specified by the vehicle manufacturer, and that each wheel contains a tire pressure sensor. Inspect the wiring harness connection to the TPMS module for loose or corroded connections and damaged wires.

Scan Tool Diagnosis

The vehicle manufacturer's recommended diagnostic procedure varies considerably depending on the vehicle model year. Most systems are diagnosed using a scan tool with TPMS capabilities. The following is a typical scan tool diagnosis. If the visual inspection does not reveal any defects, use a scan tool to proceed with the diagnostic system check.

PHOTO SEQUENCE 5

TYPICAL PROCEDURE FOR DISMOUNTING AND MOUNTING A TIRE ON A WHEEL ASSEMBLY



P5-1 Dismounting the tire from the wheel begins with releasing the air, removing the valve stem core, and unseating the tire from its rim. The machine does the unseating. The technician merely guides the operating lever.



P5-2 Once both sides of the tire are unseated, place the tire and wheel onto the machine. Then depress the pedal that clamps the wheel to the tire machine.



P5-3 Lower the machine's arm, into position on the tire-and-wheel assembly.



P5-4 Insert the tire iron between the upper bead of the tire and the wheel. Depress the pedal that causes the wheel to rotate. Do the same with the lower bead.



P5-5 After the tire is totally free from the rim, remove the tire.



P5-6 Prepare the wheel for the mounting of the tire by using a wire brush to remove all dirt and rust from the sealing surface. Apply rubber compound to the bead area of the tire.



P5-7 Place the tire onto the wheel and lower the arm into place. As the machine rotates the wheel, the arm will force the tire over the rim. After the tire is completely over the rim, install the air ring over the tire. Activate it to seat the tire against the wheel.



P5-8 Reinstall the valve stem core and inflate the tire to the recommended inflation.

Diagnostic System Check

The diagnostic system check provides the following information:

1. Identification of the control modules in the TPMS system.
2. Indication of the ability of the system control modules to communicate through the serial data circuit.
3. Indication of any diagnostic trouble codes (DTCs) stored in the system control modules.

Follow these steps to complete the diagnostic system check.

1. Connect a scan tool to the data link connector (DLC) under the left side of the instrument panel, and turn the scan tool on.
2. Turn the ignition switch on, and do not start the engine.
3. Select antenna module on the scan tool. Check for the DTCs related to the antenna module. If there are DTCs displayed with a “U” prefix, there is a defect in the data link communications. If the scan tool cannot communicate with the antenna module, or there are DTCs related to this module or the data link communications, proceed with further diagnosis of these items.
4. Check for DTCs related to the radio/audio system. The antenna grid in the rear window receives TPMS system sensor signals. This grid shares its connector with the AM/FM antenna grid. If any radio/audio system DTCs are present, proceed with the diagnosis of the radio/audio system.
5. Check for keyless entry system DTCs displayed in the scan tool. The antenna module also controls the keyless entry system. If the scan tool displays DTCs related to the keyless entry system, proceed with the diagnosis of these DTCs.
6. Check for TPMS system DTCs on the scan tool display. If TPMS system DTCs are present, diagnose the cause of these DTCs.

TPMS System Data Display

TPMS data display may be selected on the scan tool display. The data display is very useful when diagnosing the TPMS system and sensors. The following data displays may be selected on the scan tool:

1. Battery voltage—The scan tool displays the amount of battery voltage supplied to the antennal module.
2. LF pressure sensor ID—The scan tool displays an eight-digit number or an asterisk. The eight-digit number is a unique LF sensor identification number, and this display indicates the number has been learned by the antenna module. If an asterisk is displayed, the sensor ID number has not been learned by the antenna module.
3. LF pressure sensor mode—This mode display may indicate **stationary**, **wake**, **drive**, **re-measure**, **learn**, **low bat**, or **N/A** (not available). If **stationary** is displayed, the sensor roll switch is open and the sensor has sent a stationary message that only occurs every 60 minutes from the previous stationary transmission. A **wake** display indicates the sensor has detected an initial roll switch closure, and the sensor is changing from the stationary mode to the drive mode. A **drive** display indicates the vehicle speed is above 20 mph (32 km/h), and the sensor roll switch has been closed for a minimum of 10 seconds. In this mode the sensor transmits every 60 seconds. If **re-measure** is displayed, the sensor has detected a 1.6 psi (11 kPa) pressure change. A **learn** display indicates the sensor has been activated by a low-frequency voltage signal that occurs during a sensor re-learn procedure. A **low battery** display indicates the internal sensor battery has low voltage and sensor replacement is necessary.
4. LF tire pressure—The scan tool displays the actual tire pressure between 0 and 51 psi (0 to 344 kPa).

5. LF tire pressure sensor status—In this mode the scan tool displays **valid** or **invalid**. A **valid** display indicates the specified LF tire pressure is present. If **invalid** is displayed, the LF tire pressure is not within specifications and DTC C0750 is currently set in the antenna module memory. This DTC indicates a defective LF sensor or faulty LF sensor circuit.

The same data from each wheel sensor may be displayed on the scan tool. Other DTCs include C0755 indicating a defective LR sensor, C0760 representing a faulty RF sensor, and C0765 indicating a defect in the RR sensor. A current DTC indicates the fault causing the DTC is present at the time of diagnosis. The DTCs vary depending on the vehicle make and model year. A history DTC represents a fault that occurred in the past, but it is not present at the time of diagnosis. The vehicle speed must be above 20 mph (32 km/h) for the antenna module to run the DTC check. A DTC is set in the antenna module memory if any wheel sensor does not enter the drive mode or does not transmit any data for 10 minutes or more. When a DTC is set in the antenna module memory, the following actions are taken:

1. A DTC is stored in memory.
2. The driver information center (DIC) displays a SERVICE TIRE MONITOR message.
3. The DIC indicates row of dashes in place of the suspect tire pressure display.

A current DTC is cleared from memory when the fault causing the DTC is corrected. A history DTC is cleared after 100 consecutive fault-free ignition cycles. A scan tool may be used to clear DTCs.

Senser Replacement

Vehicles with a TPMS may require a tire pressure adjustment in relation to atmospheric temperature. For example, if the atmospheric temperature decreases 30°F when a vehicle is parked outside overnight, the tire pressure decreases 3 psi. This pressure decrease may activate the TPMS warning system. Refer to the vehicle manufacturer's specifications for tire inflation pressure at various atmospheric temperatures.

Proper valve stem and sensor removal procedures must be followed to avoid damage to the sensor: To remove a valve stem and sensor, follow these steps:

1. Before removing the tire and wheel assembly from the vehicle, mark the wheel rim in relation to one of the wheel studs.
2. Position the tire and wheel assembly with the valve stem at the 6 o'clock position.
3. Remove the sensor retention nut and push the valve stem and sensor into the tire.
4. Place the wheel and tire on the turntable of the tire changer so the valve stem is positioned 270° from the mounting/demounting arm on the tire changer (Figure 4-17).
5. Loosen both tire beads away from the wheel rim.
6. Place index marks on the tire beside the valve stem opening and the wheel weight positions.
7. Lubricate the outer tire bead, and dismount the outer bead over the wheel rim.
8. Lift up on the outer tire bead, and remove the TPMS sensor and valve stem assembly.
9. Install the new sensor in the valve stem opening, and install a new grommet and retention nut.
10. Tighten the retention nut to 71 in-lbs (8 Nm).
11. Lubricate and mount the outer tire bead.
12. Inflate the tire to the specified pressure.
13. Remove the tire and wheel from the tire changer and install this assembly in the proper position on the wheel studs. Tighten the wheel retaining nuts in the proper sequence to the specified torque.



CAUTION:

Do not remove the valve stem core to relieve the tire pressure. If the valve stem core is inadvertently removed from the valve stem, a new nickel-plated valve core must be installed. Failure to use a nickel-plated valve core will result in corrosion and possible loss of tire pressure.



CAUTION:

The tire pressure sensors are not serviceable. If a sensor is defective, it must be replaced.



CAUTION:

Tire pressure sealing products may render the TPMS sensor inoperative. If this occurs, remove all of the tire sealing material and replace the sensor.



CAUTION:

Each time a TPMS sensor is removed, a new grommet, retention nut, and valve cap must be installed. Replace the valve core if it has been removed or damaged.




FIGURE 4-17 Proper tire and wheel position on a tire changer.

Sensor Learning Procedure with Magnetic Tool

If a TPMS sensor or component is serviced, a sensor learning procedure must be performed. There are a number of different sensor learning procedures depending on the vehicle make and model year. The sensor learning procedure usually involves the use of a magnetic tool or a scan tool.

Follow these steps to complete the sensor learning procedure with a magnetic tool:

1. Starting with the ignition switch off, cycle the ignition switch on and off three times, and on the third cycle leave the ignition switch in the on position. Do not wait more than two seconds between switch cycles.
2. Press and release the brake pedal.
3. Repeat the ignition switch cycling procedure as explained in step 1. Upon completion of this procedure, the horn should sound once to indicate successful entry to the learn mode.
4. After the horn sounds, a TRAIN LEFT FRONT TIRE message should appear in the instrument panel message center.
5. Place the special magnetic tool on the valve stem of the left front tire (Figure 4-18). When the TPMS module recognizes the left front sensor, the horn sounds momentarily.



SPECIAL TOOLS

Magnetic learn tool



WARNING: The special magnetic tool may adversely affect magnetically sensitive devices such as heart pacers, and this action may result in personal injury!

6. Repeat step 5 at the right front, right rear, left rear, and spare wheels.
7. If the learn procedure fails on any wheel, the horn sounds twice, and a TIRES NOT LEARNED-REPEAT message appears in the message center. If this action occurs, the learn procedure must be repeated from step 1.





FIGURE 4-18 Magnetic learning tool for TPMS sensors.

Sensor Learning Procedure with Scan Tool

Follow these steps to complete the sensor learning procedure with a scan tool:

1. Connect a scan tool to the DLC.
2. Turn on the ignition switch, and do not start the engine.
3. Apply the parking brake.
4. Select Special Functions on the scan tool.
5. Select Sensor Learn Mode on the scan tool, and press the Enter key.
6. Press the On soft key. A horn chirp should sound to indicate the sensor learn mode is enabled.
7. Starting with the LF tire, increase or decrease the tire pressure for 5–8 seconds or until a horn chirp sounds. The horn chirp may occur before the 5- to 8-second time period, or up to 30 seconds after this time period.

 **WARNING:** If you are increasing tire pressure during the learning procedure, never inflate a tire above the vehicle manufacturer's maximum specified tire pressure. This action may cause personal injury and tire damage.

8. After the horn chirp sounds, repeat step 7 on the other 3 or 4 sensors in the following order:
 - (a) RF
 - (b) RR
 - (c) LR
 - (d) Spare tire (if applicable)

If a horn chirp is not heard after 35 seconds for any of the 4 sensors, turn off the ignition switch and exit the learn mode on the scan tool. Repeat the sensor learning procedure from step 4.

9. After the learning procedure has been completed on all the sensors, a double horn chirp sounds to indicate the learning procedure is completed on all the sensors.
10. Turn off the ignition switch and disconnect the scan tool.
11. Inflate all the tires to the specified pressure.

Sensor Learning Procedure with Keyless Entry Transmitter

On some vehicles, the keyless entry remote transmitter may be used to complete the wheel sensor learning procedure without the use of any other equipment. Follow these steps to perform a sensor learning procedure using the keyless entry remote transmitter:

1. Turn on the ignition switch.
2. Apply the parking brake.
3. Use the keyless entry remote transmitter to lock and unlock the doors three times.
4. Simultaneously press the lock and unlock buttons on the keyless entry remote transmitter until a horn chirp sounds.
5. Starting with the LF tire, increase or decrease the tire pressure for 5–8 seconds, or until a horn chirp sounds. The horn chirp may sound before the 5–8 seconds is completed, or up to 35 seconds after this time period.
6. After the horn chirp sounds on the LF tire, follow the procedure in step 5 on the other 3 or 4 sensors in the following order:
 - (a) RF
 - (b) RR
 - (c) LR
 - (d) Spare (if applicable)

If a horn chirp does not sound after 35 seconds on any of the tires, turn off the ignition switch and exit the learn mode on the scan tool. Repeat the procedure starting with step 1.

7. After all the sensors have been learned, a double horn chirp sounds to indicate all the sensors have been learned.
8. Turn off the ignition switch and disconnect the scan tool.
9. Inflate all the tires to the specified tire pressure.

TIRE AND WHEEL RUNOUT MEASUREMENT

Ideally, a tire-and-wheel assembly should be perfectly round. However, this condition is rarely achieved. A tire-and-wheel assembly that is out-of-round is said to have radial runout. If the radial runout exceeds manufacturer's specifications, a vibration may occur because the radial runout causes the spindle to move up and down (Figure 4-19). A defective tire with a variation in stiffness may also cause this up-and-down spindle action.

Wheel balancers with force variation capabilities have a roller that is pressed against the tire tread during the wheel balance procedure. This roller senses and indicates stiffness variation in a tire.

A dial indicator gauge may be positioned against the center of the tire tread as the tire is rotated slowly to measure radial runout (Figure 4-20). Radial runout of more than 0.060 in. (1.5 mm) will cause vehicle shake. If the radial runout is between 0.045 in. to 0.060 in. (1.1 mm to 1.5 mm), vehicle shake may occur. These are typical radial runout specifications. Always consult the vehicle manufacturer's specifications. Mark the highest point of radial runout on the tire with chalk, and mark the valve stem position on the tire.


If the radial tire runout is excessive, dismount the tire and check the runout of the wheel rim with a dial indicator positioned against the lip of the rim while the rim is rotated (Figure 4-21). Use chalk to mark the highest point of radial runout on the wheel rim. Radial wheel runout should not exceed 0.035 in. (0.9 mm), whereas the maximum lateral wheel runout is 0.045 in. (1.1 mm). If the highest point of wheel radial runout coincides with the

Radial tire runout refers to excessive variations in the tread circumference.



SPECIAL TOOLS


Tire runout gauge



Caused by



Tire stiffness
variation



Tire out
of round



Rim bent or
out of round

FIGURE 4-19 Vertical tire and wheel vibrations caused by radial tire or wheel runout, or variation in tire stiffness.




FIGURE 4-20 Measuring tire radial runout.

chalk mark from the highest point of maximum tire radial runout, the tire may be rotated 180° on the wheel to reduce radial runout. Tires or wheels with excessive runout are usually replaced.

Lateral tire runout may be measured with a dial indicator located against the sidewall of the tire. Excessive lateral runout causes the tire to waddle as it turns, and this waddling sensation may be transmitted to the passenger compartment (Figure 4-22). A chassis waddling

Side-to-side tire and chassis movement caused by excessive lateral tire runout may be called tire or chassis waddle.





FIGURE 4-21 Measuring wheel radial and lateral runout.



Tire waddle often caused by

- Steel belt not straight within tire
- Excessive lateral runout

FIGURE 4-22 Chassis waddling action caused by lateral tire or wheel runout, or a defective tire with a belt that is not straight.

action may also be caused by a defective tire in which the belt is not straight. If the lateral runout exceeds 0.050 in. (1.27 mm) off vehicle or 0.060 in. (1.52 mm) on vehicle, wheel shake problems will occur on the vehicle. Chalk mark the tire and wheel at the highest point of lateral runout. When the tire runout is excessive, the tire should be removed from the wheel, and the wheel lateral runout should be measured with a dial indicator positioned against the edge of the wheel as the wheel is rotated. Tires or wheels with excessive lateral runout should be replaced.

TREAD WEAR MEASUREMENT

On most tires, the **tread wear indicators** appear as wide bands across the tread when tread depth is worn to 1/16 in. (1.6 mm). Most tire manufacturers recommend tire replacement when the tread wear indicators appear across two or more tread grooves at three locations around the tire (Figure 4-23). If tires do not have wear indicators, a tread depth gauge may be used to measure the tread depth (Figure 4-24). The tread depth gauge reads in 32nds of an inch. Tires with 2/32 in. of tread depth or less should be replaced.




FIGURE 4-23 Tire tread wear indicators.



FIGURE 4-24 Tread depth gauge.

PRELIMINARY WHEEL BALANCING CHECKS

These preliminary checks should be completed before a tire and wheel are balanced:

1. Check for objects in the tire tread.
2. Check for objects inside the tire.
3. Inspect the tread and sidewall.
4. Check the inflation pressure.
5. Measure the tire and wheel runout.
6. Check the wheel bearing adjustment.
7. Check for mud collected on the inside of the wheel and wash the tire and wheel assembly.
8. Inspect the wheel rim for damage and excessive rust.

**Classroom
Manual**

Chapter 4,
page 85

! WARNING: On many wheel balancers, the tire and wheel are spun at high speed during the dynamic balance procedure. Be sure that all wheel weights are attached securely, and check for other loose objects on the tire and wheel, such as stones in the tread. If loose objects are detached from the tire or wheel at high speed, they may cause serious personal injury or property damage.

! WARNING: On the type of wheel balancer that spins the tire and wheel at high speed during the dynamic balance procedure, always attach the tire-and-wheel assembly securely to the balancer. Follow the equipment manufacturer's recommended wheel mounting procedure. If the tire-and-wheel assembly becomes loose on the balancer at high speed, serious personal injury or property damage may result.

! WARNING: Prior to spinning a tire and wheel at high speed on a wheel balancer, always lower the protection shield over the tire. This shield provides protection in case anything flies off the tire or wheel.

All of the items on the preliminary check list influence wheel balance or safety. Therefore, it is extremely important that the preliminary checks be completed. Since a tire-and-wheel assembly is rotated at high speed during the dynamic balance procedure, it is very important that objects such as stones be removed from the treads. Centrifugal force may dislodge objects from the treads and cause serious personal injury. For this reason, it is also extremely important that the old wheel weights be removed from the wheel prior to balancing and the new weights attached securely to the wheel during the balance procedure.

Follow these preliminary steps before attempting to balance a wheel and tire:

1. When off-car wheel balancers are used, the tire and wheel must be removed from the vehicle and installed on the balancer. All mud, dust, and debris must be washed from the wheel after it is removed.
2. Objects inside a tire, such as balls of rubber, make balance impossible. When the tire-and-wheel assembly is mounted on the balancer, be absolutely sure that the wheel is securely tightened on the balancer. As the tire is rotated slowly, listen for objects rolling inside the tire. If such objects are present, they must be removed prior to wheel balancing.
3. The tire should be inspected for tread and sidewall defects before the balance procedure. These defects create safety hazards, and they may influence wheel balance. For example, tread chunking makes the wheel balancing difficult.

TIRE INFLATION PRESSURE

A tire depends on correct inflation pressure to maintain its correct shape and support the vehicle weight.

Excessive inflation pressure causes the following problems:

1. Excessive center tread wear (Figure 4-25)
2. Hard ride
3. Damage to tire carcass






Condition	Rapid wear at center	Rapid wear at shoulders	Cracked treads
Effect			
Cause	Over inflation or lack of rotation	Under inflation or lack of rotation	Under inflation or excessive speed
			
Correction	Adjust pressure to specifications. When tires are cool, rotate tires.		

FIGURE 4-25 Tire tread wear caused by underinflation or overinflation.

When tires are underinflated, the following problems will be evident:

1. Excessive wear on each side of the tread (Figure 4-23)
2. Hard steering
3. Wheel damage
4. Excessive heat buildup in the tire and possible severe tire damage with resultant hazardous driving

The tires should be inflated to the car manufacturer's recommended pressure prior to the balance procedure. Loose wheel bearings allow lateral wheel shaking and simulate an imbalanced wheel condition when the vehicle is in motion. Therefore, wheel bearing adjustments should be checked when wheel balance conditions are diagnosed.

STATIC AND DYNAMIC WHEEL BALANCE PROCEDURE

The off-vehicle electronic wheel balancer is presently the most common type in use (Figure 4-26). When using this type of wheel balancer, each tire and wheel assembly is removed from the vehicle and installed on the wheel balancer. A special cone centers the wheel rim on the balancer shaft, and a large nut retains the wheel and tire assembly on the balancer. Tire and wheel assemblies must always be mounted on the balancer using the service procedures recommended by the balancer manufacturer. Most electronic wheel balancers have an electric motor that spins the tire and wheel assembly at moderate speed during the balance procedure. A safety cover on the balancer must be lowered over the tire and wheel assembly when the tire and wheel assembly is spun on the balancer. This hood protects the technician from any debris that might be dislodged from the tire tread. On some electronic wheel balancers, the tire and wheel assembly is spun by hand during the balance procedure.

After the tire and wheel assembly is mounted properly on the balancer, the technician must enter the wheel diameter, wheel width, and rim offset in the balancer computer. A special caliper may be used to measure the wheel width. A special tool on the balancer may be extended so it contacts the flange on the side of the wheel rim next to the balancer.



SPECIAL TOOLS

Off-car electronic
wheel balancer



FIGURE 4-26 Electronic wheel balancer.

Static balance refers to the balance of a stationary wheel.

Dynamic wheel balance refers to proper balance of the tire and wheel assembly during tire and wheel rotation.



SERVICE TIP:

Some wheel rims such as magnesium rims require the use of stick-on wheel weights.



SERVICE TIP:

Wheel weights are rated in ounces or grams.

A **heavy spot** is a location a tire with excessive weight.


This tool provides the required wheel offset measurement that indicates the position of the wheel on the balancer shaft. An electronic wheel balancer performs **static balance** and **dynamic wheel balance** calculations simultaneously. The following is a typical wheel balance procedure:

1. Complete all the preliminary balance checks mentioned previously in this chapter.
2. Be sure the tire and wheel assembly is mounted on the balancer using the balancer manufacturer's recommended mounting procedure.
3. Use a pair of wheel weight pliers to remove all the old wheel weights from the wheel rim (Figure 4-27).
4. Enter the wheel diameter, width, and offset in the balancer computer.
5. Be sure the safety hood is lowered over the tire and wheel assembly, and activate the balancer control to spin the wheel and tire assembly.
6. Operate the balancer brake to slow and stop the wheel, and observe the balancer display screen to determine the size and location of wheel weight(s) required on the wheel rim.
7. Install the correct wheel weights in the locations indicated on the balancer screen. Use that hammer head on the wheel weight pliers to install the weights.
8. Spin the wheel again on the balancer; the balancer screen should indicate a balanced tire and wheel assembly.
9. Remove the wheel and tire assembly from the balancer, and install this assembly on the vehicle using the alignment marks placed on the tire wheel and hub stud prior to wheel removal.
10. Tighten the wheel lug nuts to the specified torque in the proper sequence.

On some pre electronic wheel balancers, a static balance procedure is performed by allowing the wheel and tire assembly to rotate by gravity on the wheel balancer. A **heavy spot** in the tire rotates the tire and wheel assembly until the heavy spot is at the bottom. The necessary wheel balance weights were then added at the top of the wheel 180° from the heavy spot. Equal wheel weights were installed on each side of the wheel (Figure 4-28). If a wheel has dynamic unbalance, and the heavy spot is on the outside edge of the tire tread, the correct size of wheel weight is installed on the rim 180° from the heavy spot (Figure 4-29). Improper static or dynamic wheel balance causes cupped tire tread wear and bald spots on the tread (Figure 4-30). Incorrect static wheel balance results in wheel tramp, and improper dynamic wheel balance causes wheel shimmy. When using an electronic wheel balancer, the



FIGURE 4-27 Wheel weights are removed and installed with special wheel weight pliers.



CORRECTIVE WEIGHTS

FIGURE 4-28 Static wheel balance procedure.




FIGURE 4-29 Dynamic wheel balance procedure with heavy spot on the outside edge of the tread.




FIGURE 4-30 Cupped tire tread wear with bald spots on the tread caused by improper static or dynamic wheel balance.

technician does not have to determine the wheel weight size or location because the balancer provides this information to the technician.

The Center for Environmental Health (CEH) in California together with Chrysler Group and three major wheel weight manufacturers reached an agreement to end the use of lead wheel weights in California by December 31, 2009. It is estimated that lead wheel weights cause 500,000 lbs of lead to be placed in the environment each year from wheel weights breaking off vehicle wheels. Lead wheel weights will be replaced with a metal or material that is more environmentally friendly. Be sure you are installing the type of wheel weights required by the legislation in your state.

Photo Sequence 6 illustrates a typical off-car wheel balance procedure.

ELECTRONIC WHEEL BALANCERS WITH LATERAL FORCE MEASUREMENT (LFM) AND RADIAL FORCE VARIATION CAPABILITIES

Improper wheel balance is only one cause of wheel vibration. Wheel vibration may also be caused by tire and/or wheel runout or stiffness variation in the tire sidewalls. Some wheel balancers now have the capability to measure wheel and tire runout and stiffness or force variation in the tire sidewalls. Tire and wheel rim runout may be measured with a dial indicator, but this operation is very time consuming. Many tires marketed today have a paint dot or mark on the sidewall that indicates either the high side or low side of the force variation in the tire. This paint dot is aligned with the valve stem when the tire is mounted on the wheel rim. Using this system, the technician is assuming the paint dot is placed at the high point of radial force, and the valve stem hole is at the low point of runout on the rim. However, this is not always true, and a tire mounted with this tire position in relation to the wheel rim may cause vibration even though it is properly balanced. Other tires may have a slight conicity problem that causes steering pull on the vehicle.

An electronic wheel balancer with radial force variation capabilities has a roller that is forced against the tire tread with considerable force during the balance procedure. This type of balancer provides wheel balance following the usual procedure. The roller forced against the tire allows the balancer to measure tire conicity that results in lateral force and steering

PHOTO SEQUENCE 6


TYPICAL OFF-CAR WHEEL BALANCING PROCEDURE



P6-1 Complete all the preliminary wheel balance checks.




P6-2 Follow the wheel balancer manufacturer's recommended procedure to mount the wheel-and-tire assembly securely on the electronic wheel balancer. Some wheel balancers have a centering check in the programming procedure. If the tire and wheel are not mounted properly, tire and wheel balance will be inaccurate.



P6-3 Use a pair of wheel weight pliers to remove all the wheel weights from the wheel rim.




P6-4 Enter the wheel diameter, width, and offset on the wheel balancer screen.




P6-5 Lower the safety hood over the wheel and tire on the wheel balancer.



P6-6 Activate the wheel balancer control to spin the wheel-and-tire assembly.



P6-7 Stop the wheel-and-tire assembly. Observe the wheel balancer display screen to determine the correct size and location of the required wheel weights.



P6-8 Install the correct size wheel weights in the location(s) indicated on the wheel balancer screen.



P6-9 Activate the wheel balancer control to spin the wheel again, and observe the wheel balancer display to confirm that it indicates a balanced wheel-and-tire assembly.



P6-10 Stop the wheel, lift the safety hood, and remove the wheel-and-tire assembly from the balancer.

pull (Figure 4-31). As each tire and wheel assembly is balanced, the balancer display indicates a number for each assembly (Figure 4-32). The balancer display also indicates the position on the vehicle where each numbered tire and wheel assembly should be installed to provide the least amount of steering pull and the best straight-ahead steering stability (Figure 4-33). The wheel balancer with LFM capabilities provides a much faster and more accurate method for diagnosing and correcting steering pull caused by tire conicity compared to the previous method of rotating tires to try and correct this problem.

The balancer also measures lateral and radial tire and wheel runout, and indicates if the runout is rim or tire related. This type of balancer also measures force variation in the tire (Figure 4-34). The balancer display indicates the amount of tire and tire and wheel assembly road force. The display also indicates the necessary tire and wheel service to correct the excessive road force. Using the balancer display, a chalk mark may be placed on the tire at the location of the high force variation, and a second chalk mark on the rim 180° away from the first chalk mark (Figure 4-35). The tire and wheel assembly may be installed on a tire changer, and the rim may be rotated in relation to the tire to correct the force variation.




FIGURE 4-31 Tire conicity sensed by the roller on the balancer causes lateral force and steering pull.




FIGURE 4-32 The balancer assigns a number to each tire-and-wheel assembly.




FIGURE 4-33 The balancer display indicates the location on the vehicle where each numbered tire should be installed.




FIGURE 4-34 The roller on the balancer senses force variation in the tire.




FIGURE 4-35 The balancer display indicates the necessary correction for excessive force variation.

ON-CAR WHEEL BALANCING

On-car wheel balancers contain a drum driven by an electric motor. This drum is positioned against the tire on the vehicle, which allows the electric motor to rotate the wheel. Many on-car balancers have a strobe light with a meter and an electronic vibration sensor. Off-car wheel balancing and on-car wheel balancing are a complementary combination for fine-tuning wheel balance. For example, a wheel vibration problem may still exist after an off-car balance procedure. If this problem occurs, the on-car balancer may be used to correct the problem. The on-car balance procedure corrects imbalance problems in all rotating components, including brake drums or rotors.



SPECIAL TOOLS

On-car wheel balancer

When a front wheel on a rear-wheel-drive car is balanced, use this procedure:

1. Perform the preliminary checks listed previously in this chapter.
2. Raise the wheel being balanced 5 in. (12 cm) off the floor and be sure the chassis is supported on safety stands so the wheel drops downward.
3. Install the electronic vibration sensor between the lower control arm and the floor.
4. Chalk mark a reference mark on the outer sidewall of the tire.
5. Spin the wheel just fast enough to produce vibration on the front bumper.
6. When vibration causes strobe light flashing, move the balancer drum away from the tire and allow the tire to spin freely.
7. Shine the strobe light around the tire sidewall and note the chalk-mark position.
8. Note the pointer position on the meter.
9. Use the balancer's brake plate to slow and stop the wheel.
10. Rotate the wheel until the chalk mark is in the exact position where it appeared under the strobe light. The heavy spot is now at the bottom of the wheel and the balancing weight should be attached 180° from the heavy spot. Install the amount of weight indicated on the meter.
11. Spin the wheel again (Figure 4-36). If the wheel balance is satisfactory, the meter pointer will read in the balanced position. When the pointer does not indicate a balanced wheel, shine the strobe light on the tire sidewall. If the installed wheel weight is at the 12 o'clock position, additional weight is required, whereas the 6 o'clock weight position indicates excessive weight. A 3 o'clock or 9 o'clock weight position may be corrected by moving the weight 1 in. (2.5 cm) toward the 12 o'clock position.

Additional on-car wheel balancer precautions include:

1. Do not spin the wheel at excessive speeds.
2. Do not spin the front wheels on a front-wheel-drive vehicle with the floor jack under the chassis and the suspension dropped downward. Under this condition, severe angles



FIGURE 4-36 On-car wheel balancer.



CAUTION:

On a rear-wheel-drive vehicle when a rear wheel is rotated with an on-car balancer, do not allow the speed indicated on the speedometer to exceed 35 mph (56 km/h), because the wheel speed is much faster than the speed indicated on the speedometer.

Classroom Manual

Chapter 4,
page 85

Classroom Manual

Chapter 4,
page 87

exist in the front drive axle joints, and these joints may be damaged if the wheels are rotated with the balancer. Place the floor jack under the lower control arm to raise the wheel.

Rear Wheel Balancing

If an on-car balancer is used on the rear wheels of a rear-wheel-drive car, the technician must determine if the vehicle has a conventional or a limited slip differential. With the transmission in park, or in gear with a manual transmission, rotate one rear wheel by hand. If the vehicle has a limited slip differential, the rear wheels will not rotate, whereas a free-turning wheel indicates a conventional differential.

When the vehicle has a conventional differential, use the same front wheel balance procedure on the rear wheels. Raise only the wheel to be balanced from the floor, and do not allow the speed indicated on the speedometer to exceed 35 mph (56 km/h). When the other rear tire is resting on the floor, the speed of the wheel being balanced is 70 mph (112 km/h).

If the vehicle has a limited slip differential, proceed as follows for on-car rear wheel balancing:

1. Raise the vehicle and place safety stands under the frame to support the vehicle weight.
2. Lift the rear axle housing with a floor jack to reduce the universal joint angles, but do not take the vehicle weight off the safety stands.
3. Remove the wheel that is not being balanced. Install and torque the wheel nuts on the brake drum to hold the drum in place.
4. Balance the opposite wheel using the same procedure as for the front wheels.
5. Leave the balanced wheel on the vehicle and install and balance the other wheel. Be sure to torque the wheel nuts properly. Do not allow rear wheel speed to exceed 55 mph (90 km/h) on the speedometer.

VIBRATION DIAGNOSIS

The technician must have a logical sequence for vibration diagnosis. This problem may be diagnosed using the same basic diagnostic procedure that is used for diagnosing defects in other parts of the vehicle.

A basic diagnostic procedure follows:

1. Question the customer regarding the vibration problem, and obtain as much information as possible from this source.
2. Be sure the complaint is identified. Road test the vehicle if necessary.
3. Think of the possible causes of the vibration.
4. Perform the necessary inspection and test procedures to locate the cause of the vibration.
5. Complete the necessary repairs to correct the problem(s) identified in the inspection and test procedures.
6. Be sure the original customer complaint is eliminated. If necessary, road test the vehicle.

When questioning the customer regarding the vibration problem, the technician should obtain the answers to these questions:

1. At what vehicle speed is the vibration most noticeable?
2. Is the vibration felt in the vehicle, and in what area of the vehicle is the vibration present? (For example, left front, right rear, under the vehicle floor.)
3. Can the customer hear the vibration?
4. Does engine load, such as hard acceleration, affect the vibration?
5. Does vehicle load, such as the number of passengers or weight in the trunk, affect the vibration?

6. Does the vibration occur in all transmission gear ranges?
7. When did the customer first notice the vibration? Did the vibration occur after some other service work was performed on the vehicle?

Basic Road Test

The purpose of a road test is to verify the vibration complaint and determine any operating conditions under which the vibration changes or is eliminated. A road test should also determine if the vibration is related to engine speed or vehicle road speed. During any road test for vibration diagnosis, if the vehicle does not have an in-dash tachometer, connect a tachometer to the ignition system, and install the leads through one of the windows so the tachometer may be placed in view of the driver. Connect the power cord from an **electronic vibration analyzer (EVA)** to the cigarette lighter socket, and attach the EVA vibration sensor to the area where the suspected vibration is located (Figure 4-37).

When it is determined that the vibration is related to engine speed or vehicle road speed, the technician has to perform special test procedures to locate the cause of the vibration in one of these areas:

1. Engine, engine or transmission mount, clutch disc and pressure plate (manual transmission), flexplate and torque converter (automatic transmission)
2. Propeller shaft, transmission output shaft, differential pinion flange (rear-wheel-drive vehicles), front drive axles (front-wheel-drive vehicles)
3. Tires, wheels, hubs, and brake rotors

The **electronic vibration analyzer (EVA)** is a tester that helps to locate the source of a vibration.

Special Road Tests

Slow Acceleration Test. All of the special road tests help the technician to locate the cause of the vibration. A tire and wheel inspection should be completed before any road test. Defects discovered during the tire inspection may explain the cause of the vibration that occurs during a road test.




FIGURE 4-37 Electronic vibration analyzer (EVA).

Inspect the tires and wheel for these defects:

1. Check the inflation pressure in each tire.
2. Check for unusual tire wear such as cupping, excessive tread wear, and flat or bald spots. Inspect the tire sidewalls and tread area for bulges and ply separation. These tire defects may cause vibration, slapping noise, and tire growl or howl.
3. Inspect the rims for bends, damage, and excessive corrosion.

Perform the **slow acceleration test** on a smooth level road. During this test, accelerate the vehicle from a stop to legal highway speed. Check for any vibration that matches the customer's description. If any vibration is present, record the frequency vehicle speed and engine speed when the vibration occurred.

Neutral Coast-Down Test. Perform the **neutral coast-down** test on a smooth, level road. Accelerate the vehicle to a speed slightly higher than the speed at which the vibration occurs. Shift the transmission into neutral and allow the vehicle to coast down through the speed range at which the vibration occurs. If the vibration still occurs in neutral, the vibration is vehicle-speed sensitive, and the engine, propeller shaft, flexplate, and torque converter have been eliminated as causes of the vibration. When the vibration occurs with the transmission in neutral, the vibration diagnosis should concentrate on the drive axle assemblies and the tire-and-wheel assemblies. Off-car or on-car balance procedures are performed to correct balance problems in brake drums or rotors and tires and wheels.

Downshift Test. To complete the **downshift test**, drive the vehicle on a smooth, level road at the speed when the vibration is present. Note the engine rpm. Decelerate and reduce the vehicle speed until the vibration is no longer present. Manually downshift the transmission into the next lowest gear, and accelerate the vehicle until the engine is running at the previously recorded rpm. If the vibration returns at the same engine rpm, the engine, propeller shaft, flexplate and torque converter (automatic transmission) or clutch disc and pressure plate (manual transmission) are the most likely causes of the vibration.

Neutral Run-Up Test. Perform the **neutral run-up test** when the customer complains about vibration at idle speed or as a follow-up to the downshift test. To perform the neutral run-up test, slowly increase the engine rpm from idle. Note the engine rpm and frequency at which vibration occurs. If vibration occurs, the cause of the vibration is related to the engine, flexplate and torque converter (automatic transmission) or clutch disc and pressure plate (manual transmission).

Brake Torque Test. The **brake torque test** may be used to identify engine vibrations that were not present during the downshift and neutral run-up tests. This test may also be used when diagnosing vibrations that are sensitive to engine load.

To perform the brake torque test, follow this procedure:

1. Firmly apply the parking brake.
2. Block the front wheels.
3. Firmly apply the brake pedal.
4. Shift transmission into drive.
5. Slowly increase the engine speed to 1,200 rpm and check for vibrations.
6. Note the engine rpm when vibration occurred.



CAUTION:

Do not increase the engine rpm above 1,200, and limit this test to 10 seconds to protect the transmission from overheating.

If engine vibrations occur during the brake torque test, but they did not occur during the downshift and neutral run-up tests, the engine and/or transmission mounts are a prime suspect for the cause of the vibration.

Steering Input Test. The **steering input test** may be performed to diagnose vibrations in suspension components. To perform this test, drive the vehicle through sweeping turns at the speed when the vibration occurs. Drive the vehicle when turning in one direction and then perform some turns in the opposite direction. If the vibration changes during these turns, the vibration is likely caused by defective wheel bearings, tire tread, or front drive axle shafts and joints.

Standing Acceleration Test. The **standing acceleration test** is used to diagnosis a vibration that may be called a launch shudder. To perform the standing acceleration test bring the vehicle to a complete stop. Place the transmission in drive and remove your foot from the brake pedal. Accelerate the vehicle to 30 to 40 mph (48 to 64 km/h), and check for vibrations that match the customer's complaint. If a shudder-type vibration occurs during the test, the cause of this vibration could be incorrect curb riding height, defective front drive axle joints, defective engine or transmission mounts, or faulty exhaust hangers or mounts.

Vibration Diagnosis with the Electronic Vibration Analyzer (EVA)

The EVA is helpful in locating the source of vibration problems.


Follow these steps to connect the EVA:

1. Be sure the correct software cartridge is securely installed in the bottom of the EVA.
2. Connect the vibration sensor cord to input A or B on the EVA. Position the release button facing downward on the lower side of this connector. Push the connector into the input port until the connector clicks and locks in place.
3. Follow these steps to perform the sensor calibration procedure:
 - a. Lay the sensor on a flat stationary surface, and be sure the side of the sensor marked UP is facing upward.
 - b. Plug the EVA power cord into a 12 V power supply, such as the cigarette lighter.
 - c. Press the "up" arrow key.
 - d. Press number 2 on the key pad three times until the word BURNING appears, followed by a request to turn the sensor over.
 - e. Turn the sensor over and press any key on the keypad to begin calibration. The calibration procedure takes approximately 20 seconds, and the display returns to the active mode when calibration is completed.
4. Two vibration sensors can be connected to ports A and B on the EVA at the same time, and the A/B button on the tester can be used to switch from one sensor to the other. Place the sensor(s) on any component that is suspected of being a vibration source. Each sensor has a 20-ft. cord, so it may be placed anywhere on the vehicle. Each sensor contains a magnet for attachment to metal surfaces. For attachment to nonmagnetic surfaces, use putty or a hook and loop fastener. Vibrations are usually felt in an up-and-down direction. Because the vibration sensor is directionally sensitive, this sensor must be mounted on the lower part of the suspected component with the marking on the sensor facing upward (Figure 4-38). When repeating a vibration test on the same component, always be sure the vibration sensor is mounted in the exact same location.



CAUTION:

When installing the sensor connector in the EVA input terminal, do not twist the sensor connector. Do not remove this connector when the EVA is in use. This action may damage the EVA.



NOTE:
Sensor is directionally sensitive, marking on sensor must be facing upward.

FIGURE 4-38 Vibration sensor mounting.




FIGURE 4-39 Electronic vibration analyzer (EVA) display and keypad.

the top of the left column on the display. A bar graph of the suspected source of the vibration is shown in the center of the display. When the AUTO mode is selected, the suspected vibration source is shown in the display. If the AUTO mode is not in use, the bar graph is indicated in the center of the display (Figure 4-39). The amplitude of each frequency indicated on the left of the screen is displayed on the right side of the screen. These amplitudes are displayed in Gs of acceleration force. Higher amplitudes indicate stronger vibration forces. The EVA displays up to three of the most dominant input frequencies in descending order of amplitude strength.

The technician may press the averaging (AVG) button to select this mode. In the AVG mode, the EVA displays the average of multiple vibration readings taken over a period of time. The EVA is usually operated in the AVG mode to minimize distractions caused by a sudden vibration that is not related to the main vibration source. These distractions could be caused by the vehicle wheels striking road irregularities. When the EVA is operating in the AVG mode and the Auto Mode, "A" is displayed along the top of the screen. The AUTO mode is designed to be used with the vibration diagnosis tables in the appropriate service manual. If the EVA is operating in the AVG mode and the MANUAL mode, AVG is shown at the top of the screen. When the EVA is operating in the non-AVG mode and the AUTO mode, "I" is indicated at the top of the display. The top row on the display also indicates "A" or "B," representing the vibration sensor input port.

When the FREEZE button is pressed, the EVA displays FRZ on the top line of the display. In this mode the EVA will store data for a short time period when the RECORD button is pressed during various vibration tests. The technician may press the PLAY BACK button to display the recorded data. The technician presses the EXIT button to return the EVA to normal operation.

The EVA has a strobe light trigger wire that may be used with an inductive pickup timing light to balance rotating components such as propeller shafts.

Calculating Vibration Frequencies of Various Components

Calculating Tire/Wheel Frequency. The first step in calculating tire/wheel frequency is to divide the vehicle speed by five-mile-per-hour increments. There are 12 increments of 5 miles per hour, if the vehicle speed is 60 mph. The next step is to use the chart in Figure 4-40 to determine how many times a wheel and tire rotate per second at 5 mph. As indicated in this chart, if the tire size is 195/70/14, the tires revolve at 1.17 times per second for every 5 mph of vehicle speed. To calculate the tire/wheel frequency at 60 mph, multiply the number of five-mile-per-hour increments, 12, by the number of times the tire and wheel revolve in one second per 5 mph increment, 1.17. Therefore we have the calculation $12 \times 1.17 = 14.04$, and this

Tire Size	Tire Frequency at 5 mph	Tire Size	Tire Frequency at 5 mph
P145/80/13	1.31	215/70/15	1.08
155/80/13	1.27	215/75/15	1.05
175/65/14	1.26	215/75/16	1.01
185/65/14	1.23	215/85/16	0.95
185/70/14	1.20	220/75/15	1.03
185/75/14	1.16	225/45/17	1.16
195/60/15	1.20	225/55/17	1.08
195/65/15	1.16	225/60/16	1.09
195/70/14	1.17	225/70/15	1.06
195/75/14	1.13	225/70/16	1.02
195/75/15	1.09	225/75/15	1.02
205/55/15	1.21	225/75/16	0.99
205/55/16	1.16	235/70/15	1.04
205/60/14	1.22	235/75/15	1.00
205/60/15	1.17	235/75/16	0.97
205/65/15	1.14	245/70/15	1.02
205/70/14	1.14	245/70/16	0.98
205/70/15	1.10	245/75/16	0.95
205/75/14	1.11	275/40/17	1.13
205/75/15	1.07	295/40/20	0.99
215/50/17	1.14	335/35/17	1.10
215/55/16	1.14	30X9.5/15	0.98
215/65/15	1.11	31X10.5/15	0.95
215/65/16	1.07		

FIGURE 4-40 Tire/wheel frequencies.

size of tire and wheel on a vehicle traveling at 60 mph produces a vibration of approximately 14 hertz (Hz). With a vibration sensor attached to the lower control arm, if the EVA displays a vibration of 14 Hz, the tire and wheel mounted on the knuckle attached to the control arm has a vibration problem. This vibration problem could also be caused by a rotor or hub.

With a vibration of 14 Hz, a second-order vibration is 28 Hz, a third-order vibration is 42 Hz, and a fourth-order vibration is 56 Hz. On a front-wheel-drive vehicle, a worn constant velocity drive axle joint may cause a vibration in the fifth order of the tire/wheel vibration, and a defective tripod drive axle joint may result in a vibration of the third order of the tire/wheel vibration. On a rear-wheel-drive-vehicle if the tire/wheel frequency is 14 and the rear axle ratio is 3.42:1, the frequency of the drive shaft is $14 \times 3.42 = 47.88$.

Calculating Engine and Engine Firing Frequency. To calculate the engine frequency, divide the engine rpm by 60 seconds per minute. For example, if the engine rpm is 3,000, the engine frequency is $3,000 \div 60 = 50$ revolutions per second, or 50 Hz. To determine the engine firing frequency, divide the number of engine cylinders by two, and multiply the answer by the engine frequency. Let us assume we are working on a V6 engine running at 3,000 rpm. Divide the number of cylinders by two, and so $6 \div 2 = 3$. Then multiply this answer by the engine frequency of 50 to calculate the firing frequency. Therefore, $3 \times 50 = 150$ engine firing frequency. Because a cylinder in a four-cycle engine expels exhaust only once every two revolutions, a single cylinder frequency is one-half the engine frequency. Therefore, in our example if the engine frequency is 50, a single cylinder frequency is 25. This is the frequency of exhaust pulses in a single cylinder and also the frequency of the camshaft that turns at one-half the engine speed.

Calculating Accessory Drive Frequencies. To calculate the frequency of the belt-driven accessories, divide the diameter of the crankshaft pulley by the diameter of the pulley on the

TERMS TO KNOW

Antitheft locking
 wheel covers
 Antitheft wheel nuts
 Brake torque test
 Downshift test
 Dynamic wheel
 balance
 Heavy spot
 Lateral tire runout
 Neutral coast down
 Neutral run-up test
 Ply separation
 Radial runout
 Slow acceleration
 test
 Standing
 acceleration test
 Static balance
 Steering input test
 Steering pull
 Tire conicity
 Tire rotation
 Tire thump
 Tire vibration
 Tread wear
 indicators

belt-driven accessory and multiply the answer by the engine frequency. Let us assume the we are still working on the engine in our previous example which is a V6 engine with a frequency of 50 running at 3,000 rpm. With a vibration sensor mounted on the engine the EVA displays a vibration of 160 Hz. The diameter of the crankshaft pulley is 8 inches, the diameter of the power steering pulley is 5 inches, the diameter of the A/C compressor pulley is 4.5 inches, and the diameter of the alternator pulley is 2.5 inches.

Therefore, we have the following calculations:

Power steering pump frequency: $8 \div 5 = 1.6 \times 50 = 80$

A/C compressor frequency: $8 \div 4.5 = 1.7 \times 50 = 85$

Alternator frequency: $8 \div 2.5 = 3.2 \times 50 = 160$

When we compare the vibration frequency displayed on the EVA to the belt-driven accessory frequencies, the alternator frequency matches the frequency on the EVA, indicating the alternator is the source of the vibration.

TABLE 4-1 Tire and Wheel Diagnosis

Problem	Symptoms	Possible Causes
Tire thump	Thumping noise while driving	Cupped tire treads Excessive radial tire or wheel runout Tire defects Improper wheel balance Variation in tire stiffness
Chassis waddling	Lateral rear chassis oscillations while driving	Excessive rear tire or wheel lateral runout
Steering pull	Steering pulls to one side while driving straight ahead	Tire conicity Unmatched tires side-to-side Improper wheel alignment angles
Wheel vibration	A vibration that occurs at certain speeds and may be felt on the steering wheel or throughout the chassis	Improper wheel balance Excessive lateral tire runout Variation in tire stiffness Tire defects
Excessive wear on tire treads	Cupped tire treads Wear on tread center Equal wear on tread edges	Improper wheel balance Overinflation Underinflation

CASE STUDY

A customer complains about severe front end waddling on a 2009 Cadillac STS equipped with steel-belted radial tires. The technician questions the customer further regarding this problem and learns that the problem occurs only after the car has sat overnight, and it lasts only for approximately six blocks when the customer starts driving the car.

The technician carefully checks all steering and suspension components, wheel bearing adjustment, and tire runout. No problems are found during these checks, and the technician asks the customer to leave the car in the shop overnight. The technician installs

the front tires on the rear of the car and rotates the rear tires to the front, and the car is left in the shop overnight. A road test the next morning indicates rear end waddling, which proves the problem must be caused by a tire problem such as an improperly installed steel belt, since the tires were the only thing changed on the car. The technician installs and balances two new tires on the rear wheel rims, and installs these tires and wheels on the front of the car. The front tires and wheels were moved to the rear wheels. The customer reports later that the problem has been completely corrected.

ASE-STYLE REVIEW QUESTIONS

1. While discussing a tire thumping problem:
Technician A says this problem may be caused by cupped tire treads.
Technician B says a heavy spot in the tire may cause this complaint.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
2. While discussing a vehicle that pulls to one side:
Technician A says that excessive radial runout on the right front tire may cause this problem.
Technician B says that tire conicity may be the cause of this complaint.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. While discussing tire noise:
Technician A says that tire noise varies with road surface conditions.
Technician B says that tire noise remains constant when the vehicle is accelerated and decelerated.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
4. While discussing tire wear:
Technician A says that static imbalance causes feathered tread wear.
Technician B says that dynamic imbalance causes cupped wear and bald spots on the tire tread.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
5. While discussing on-car wheel balancing:
Technician A says that during an on-car wheel balancing procedure on a rear wheel of a rear-wheel-drive car, the speed indicated on the speedometer should not exceed 65 mph (105 km/h).
Technician B says that the speed indicated on the speedometer on this car must not exceed 35 mph (56 km/h).
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
6. A front tire has excessive wear on both edges of the tire tread. The most likely cause of this problem is:
A. Overinflation.
B. Underinflation.
C. Improper static balance.
D. Improper dynamic balance.
7. When measuring radial tire and wheel runout, the maximum runout on most automotive tire-and-wheel assemblies should be:
A. 0.015 in. (0.038 mm). C. 0.045 in. (1.143 mm).
B. 0.025 in. (0.635 mm). D. 0.070 in. (1.77 mm).
8. When measuring lateral wheel runout with the tire demounted from the wheel, the maximum runout on most automotive wheels is:
A. 0.020 in. (0.508 mm). C. 0.045 in. (1.143 mm).
B. 0.030 in. (0.762 mm). D. 0.055 in. (1.397 mm).
9. All of these statements about improper wheel balance are true EXCEPT:
A. Dynamic imbalance may cause wheel shimmy.
B. Dynamic imbalance may cause steering pull in either direction.
C. Static imbalance causes wheel tramp.
D. Static imbalance causes rapid wear on suspension components.
10. When diagnosing wheel balance problems:
A. Balls of rubber inside the tire have no effect on wheel balance.
B. Loose wheel bearing adjustment may simulate improper static wheel balance.
C. Improper dynamic wheel balance may be caused by a heavy spot in the center of the tire tread.
D. After a tire patch is installed, the tire and wheel may be improperly balanced.

ASE CHALLENGE QUESTIONS

1. The owner of a rear-wheel-drive car with after-market alloy wheels says he has replaced the wheel bearings three times in the past two years. He wants to know why the bearings fail.

Technician A says excessive radial runout of the wheel may be the cause of the problem.

Technician B says excessive offset of the wheel may be the cause of the problem.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

2. A customer returns with recently purchased radial tires saying that the rear of the car feels like “it’s riding on Jello™.” All of the following could cause this problem EXCEPT:

- A. The radial belt of a rear tire is not straight.
B. The wheel is improperly mounted.
C. Excessive lateral wheel runout.
D. Excessive radial tire runout.

3. A customer says the new tires he just purchased vibrate. The installer says he balanced the wheels and tires with a conventional electronic balancer before placing them on the car.

Technician A says one of the tires may have a conicity problem.

Technician B says one of the tires may have a force variation problem.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

4. After a set of radial tires is rotated, the customer returns saying he feels vibration and steering shimmy. To correct this problem, you should:

- A. Measure the lateral run out on each tire.
B. Return the tires and wheels to their original positions.
C. Check the wheel bearings.
D. Balance the tires and wheels with an on-car balancer.

5. A customer says there is a “thumping” vibration in the wheels and an inspection of the tires shows the two front wheels have flat spots on the tire treads.

Technician A says heavy spots in the tires may have caused this condition.

Technician B says locking the wheels and skidding on pavement caused this condition.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

Name _____ Date _____

TIRE DISMOUNTING AND MOUNTING

Upon completion of this job sheet, you should be able to demount and mount tires.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task F-6: Dismount, inspect, and remount tire on wheel: Balance wheel and tire assembly (static and dynamic).

Tools and Materials

Tire changer

Tire-and-wheel assembly

Procedure

1. Remove the valve core to release all the air pressure from the tire. Chalk mark the tire at the valve stem opening in the wheel so the tire may be re-installed in the same position to maintain proper wheel balance.

Is all the air pressure released from the tire? ☐ Yes ☐ No

Is the tire chalk marked at the valve stem location in the wheel?

Instructor check _____

2. Guide the operating lever on the tire changer to unseat both tire beads. Are both tire beads unseated? Yes _____ No _____

3. Place the tire-and-wheel assembly properly on the tire changer. Is the tire-and-wheel assembly positioned properly on the tire changer? Yes _____ No _____

! WARNING: Do not proceed to dismount the tire unless the tire-and-wheel assembly is securely attached to the tire changer. This action may cause personal injury.

4. Press the pedal on the tire changer that clamps the wheel to the changer. Is the wheel clamped properly to the tire changer? Yes _____ No _____

5. Lower the arm on the tire changer into position on the tire-and-wheel assembly. Is the tire changer arm positioned properly on the tire-and-wheel assembly?
Yes _____ No _____

6. Insert the tire iron properly between the upper tire bead and the wheel. Be sure the tire iron is properly positioned. Depress the tire changer pedal that causes the wheel to rotate. This rotation moves the top bead out over the wheel. Is the top tire bead above the wheel rim? Yes _____ No _____



SERVICE TIP:

The following is a generic tire demounting and mounting procedure.

Task Completed



SERVICE TIP:

Different makes of tire changers have various ways of tire bead seating on the wheel. Some tire changers have an air inflation ring that is positioned on top of the wheel and tire. Other tire changers have air jets in each clamping jaw that hold the wheel on the tire changer. Air pressure from these jets helps force the tire beads against the wheel sealing surfaces.

☐



SERVICE TIP:

Some tire changers have an air hose and air pressure gauge designed into the tire changer. On other tire changers a shop air hose must be used to inflate the tire.

7. Lift the tire up and install the tire iron between the lower bead and the wheel. Be sure the tire iron is properly positioned. Depress the tire changer pedal that causes the wheel to rotate. This rotation moves the lower bead out over the wheel. Is the lower bead above the wheel rim? Yes _____ No _____
8. Remove the tire from the wheel.
9. Use a wire brush to remove rust and debris from the tire bead sealing areas on the wheel rim. Are the tire bead sealing areas on the wheel properly cleaned? Yes _____ No _____
10. Apply rubber lubricant to both tire beads. Are both tire beads lubricated? Yes _____ No _____
11. Place the tire onto the wheel, and lower the tire changer arm into position. Depress the tire changer lever that causes the wheel to rotate. This action causes the lower tire bead over the wheel. Repeat this process to install the upper bead over the wheel. Is the tire properly installed on the wheel? Yes _____ No _____



WARNING: Do not proceed to mount the tire unless the wheel is securely attached to the tire changer. This action may cause personal injury.

12. Rotate the tire on the wheel so the chalk mark placed on the tire in step 8 is aligned with the valve stem opening in the wheel.
Is the chalk mark on the tire aligned with the valve stem position?
☐ Yes ☐ No

13. Install and tighten the valve core in the valve stem.



WARNING: When inflating a tire, do not stand or lean over the tire and wheel. If the tire bead comes off the rim or the rim cracks, personal injury may occur. When using a shop air hose to inflate the tire, install an extension on the air hose.

14. Supply air to the air ring or air jets on the tire changer to move the tire beads outward against the wheel. Are the tire beads moved outward against the wheel?
☐ Yes ☐ No
15. Connect an air supply hose to the tire valve stem. When using a shop air hose, connect an extension to the air hose. Inflate the tire to the specified pressure.
Specified tire pressure _____
Actual tire pressure _____

Instructor's Response _____

Name _____ Date _____

TIRE AND WHEEL RUNOUT MEASUREMENT

Upon completion of this job sheet, you should be able to measure radial and lateral tire and wheel runout.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task F-4: Measure wheel, tire, axle flange, and hub runout: determine necessary action.

Tools and Materials

Dial indicator

Wheel balancer

Tire-and-wheel assembly

Wheel diameter _____

Manufacturer and type of tire _____

Procedure

1. Mount the tire-and-wheel assembly properly on the wheel balancer and position a dial indicator against the center of the tire tread as the tire is rotated slowly to measure radial runout.

Radial runout _____

Specified radial runout _____

2. Mark the highest point of radial runout on the tire with chalk, and mark the valve stem position on the tire.

☐

3. If the radial tire runout is excessive, demount the tire, and check the runout of the wheel rim with a dial indicator positioned against the lip of the rim while the rim is rotated.

Wheel radial runout _____

Specified wheel radial runout _____

4. Use chalk to mark the highest point of radial runout on the wheel rim.

☐

5. If the highest point of wheel radial runout coincides with the chalk mark from the highest point of maximum tire radial runout, the tire may be rotated 180° on the wheel to reduce radial runout. Tires or wheels with excessive runout are usually replaced.

Does the highest point of tire radial runout coincide with the highest point of wheel radial runout? ☐ Yes ☐ No

Instructor's Response _____

State the required action to correct excessive radial runout and the reason for this action.



SERVICE TIP:

The tire and wheel may be installed on an off-car wheel balancer to measure tire and wheel runout.

Task Completed

Task Completed

☐

6. Position a dial indicator located against the sidewall of the tire to measure lateral runout.

Tire lateral runout _____

Specified tire lateral runout _____

☐

7. Chalk mark the tire and wheel at the highest point of lateral runout.

8. If the tire runout is excessive, the tire should be demounted from the wheel and the wheel lateral runout measured.

9. If the tire runout was excessive, measure the wheel lateral runout with a dial indicator positioned against the edge of the wheel as the wheel is rotated.

Wheel lateral runout _____

Specified wheel lateral runout _____

State the required action to correct excessive wheel lateral runout and the reason for this action. _____

Instructor's Response _____

OFF-CAR WHEEL BALANCING

7. Inspect the tread and sidewall.

List defective tread and sidewall conditions. _____

List the types of tire tread wear and state the causes of this wear.

Based on your inspection of the tire, list the required tire service.

8. Check tire inflation pressure.

Tire inflation pressure _____

Specified tire inflation pressure _____

9. Measure tire and wheel runout.

Radial tire and wheel runout _____

Specified tire and wheel radial runout _____

Lateral tire and wheel runout _____

Specified lateral tire and lateral wheel runout _____

Recommended tire and wheel service. _____

10. Lower the safety hood on the wheel balancer.

Is the safety hood lowered? ☐ Yes ☐ No

11. Enter the required information on wheel balancer keypad, such as wheel diameter, wheel width, and wheel offset or distance.

Is the required wheel information entered in the wheel balancer? ☐ Yes ☐ No

Instructor check _____

12. If the wheel balancer has a mode selector, select the desired balance mode.

Balance mode selected _____

13. Spin the wheel on the balancer, then apply the balancer brake to stop the wheel.

☐

14. Observe the balancer display indicating the necessary amount of wheel weights and the required location of these weights. Install the required wheel weights in the locations indicated on the balancer. Be sure the wheel weights are securely attached to the rim.

Are the wheel weight(s) securely attached to the rim at the locations indicated by the wheel balancer? ☐ Yes ☐ No

Instructor check _____

15. Spin the tire-and-wheel assembly on the the balancer again to be sure this assembly is properly balanced.

Does the wheel balancer indicate proper wheel balance? ☐ Yes ☐ No

If the answer to this question is no, repeat the balance procedure.

Instructor's Response _____

Name _____ Date _____

ON-CAR WHEEL BALANCING

Upon completion of this job sheet, you should be able to perform on-car wheel balancing procedures.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task F-6: Dismount, inspect, and remount tire on wheel. Balance wheel and tire assembly (static and dynamic).

Tools and Materials

On-car wheel balancer
Car
Wheel weights

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

1. Wash mud and debris from the wheel and tire.
2. Raise the wheel being balanced 5 in. (12 cm) off the floor; be sure the chassis is securely supported on safety stands.
3. Remove stones and other objects from the tire tread.

Are all objects removed from the tire tread? ☐ Yes ☐ No

Instructor check _____

4. Inspect the tire tread and sidewall condition.

Tread and sidewall condition _____

Types of tire tread wear _____

Causes of tire tread wear _____

Based on your inspection of the tire tread and sidewall, state the necessary tire service.

5. Check the wheel bearing adjustment and adjust to specifications if necessary.

Wheel bearing adjustment: ☐ Satisfactory ☐ Unsatisfactory

Task Completed

☐
☐


CAUTION:

Do not spin the front wheels on a front-wheel-drive vehicle with the floor jack under the chassis and the suspension dropped downward. Under this condition, severe angles exist in the front drive axle joints, and these joints may be damaged if the wheels are rotated with the balancer. Place the floor jack under the lower control arm to raise the wheel.



CAUTION:

To obtain proper wheel balance, spin the wheel only to the speed where the vibration occurs. Do not spin the wheel at excessive speeds.

6. Install the electronic vibration sensor between the lower control arm and the floor.
Is the vibration sensor properly installed? ☐ Yes ☐ No
Instructor check _____
7. Chalk mark a reference mark on the outer sidewall of the tire.
8. Spin the wheel just fast enough to produce vibration on the front bumper.
9. When vibration causes strobe light flashing, move the balancer drum away from the tire and allow the tire to spin freely.
10. Shine the strobe light around the tire sidewall and note the chalk-mark position.
Chalk-mark clock position _____
11. Note the pointer position on the meter.
Meter pointer position _____
12. Use the balancer's brake plate to slow and stop the wheel.
13. Rotate the wheel until the chalk mark is in the exact position where it appeared under the strobe light. The heavy spot is now at the bottom of the wheel and the balancing weight should be attached 180° from the heavy spot. Install the amount of weight indicated on the meter.
Amount of wheel weight installed _____
14. Spin the wheel again. If the wheel balance is satisfactory, the meter pointer will read in the balanced position. If the pointer does not indicate a balanced wheel, shine the strobe light on the tire sidewall. If the installed wheel weight is at the 12 o'clock position, additional weight is required. A 6 o'clock weight position indicates excessive weight. A 3 o'clock or 9 o'clock weight position may be corrected by moving the weight 1 in. (2.5 cm) toward the 12 o'clock position.
Tire and Wheel balance: ☐ Satisfactory ☐ Unsatisfactory
If the wheel balance is unsatisfactory, state the action required to balance tire and wheel.

Instructor's Response _____

Name _____ Date _____

DIAGNOSE TIRE AND WHEEL VIBRATION, STEERING PULL, AND CHASSIS WADDLE

Upon completion of this job sheet, you should be able to diagnose tire and wheel vibration problems, steering pull, and chassis waddle.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task F-2: Diagnose wheel/tire vibration, shimmy, and noise, determine necessary action.

Tools and Materials

Late model vehicle

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

1. Drive the vehicle at 10 mph (16 kmh), 20 mph (32 kmh), 30 mph (48 kmh), 40 mph (64 kmh), 50 mph (80 kmh), 60 mph (96.5 kmh). Maintain each vehicle speed long enough to diagnose tire, steering, and chassis problems. Do not exceed the legal speed limit. Did the vehicle indicate any of the following problems at these various speeds?

2. Chassis waddle. Speed at which waddle occurred _____.
Did the waddle occur at the front or the rear of the vehicle? _____
List the possible causes of waddle and the necessary diagnostic steps and service procedures to correct the problem.

3. Tire thump and vibration. Speed at which tire thump or vibration occurred _____. At which corner of the vehicle did the thump and vibration occur. _____
List the possible causes of tire thump and vibration and the necessary diagnostic steps and service procedures to correct the problem.

4. Wheel shimmy. Speed at which wheel shimmy occurred. _____

List the possible cause of wheel shimmy, and the necessary diagnostic steps and service procedures to correct the problem.

5. Steering pull. Speed at which steering pull occurred. _____
Direction of steering pull. _____

List the possible causes of steering pull, and the necessary diagnostic steps and service procedures to correct the problem.

Instructor's Response _____

Name _____ Date _____

INSPECT, DIAGNOSE, AND CALIBRATE TIRE PRESSURE MONITORING SYSTEMS

Upon completion of this job, you should be able to inspect, diagnose, and calibrate tire pressure monitoring systems (TPMSs).

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task F-11: Inspect, diagnose, and calibrate TPMSs.

Tools and Materials

Late model vehicle
Scan tool

Describe the vehicle being worked on:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

1. Connect a scan tool to the data link connector (DLC) under the left side of the instrument panel, and turn the scan tool on.
2. Turn the ignition switch on, and do not start the engine.
3. Select antenna module on the scan tool. Check for the DTCs related to the antenna module. If there are DTCs displayed with a "U" prefix, there is a defect in the data link communications. If the scan tool cannot communicate with the antenna module, or there are DTCs related to this module or the data link communications, proceed with further diagnosis of these items.
4. Check for DTCs related to the radio/audio system. The antenna grid in the rear window receives TPMS sensor signals. This grid shares its connector with the AM/FM antenna grid. If any radio/audio system DTCs are present, proceed with the diagnosis of the radio/audio system.
5. Check for keyless entry system DTCs displayed in the scan tool. The antenna module also controls the keyless entry system. If the scan tool displays DTCs related to the keyless entry system, proceed with the diagnosis of these DTCs.
6. Check for TPMS DTCs on the scan tool display. If TPMS DTCs are present, diagnose the cause of these DTCs.

List and interpret the DTCs displayed on the scan tool _____

TPMS Learning Procedure

1. Connect a scan tool to the DLC.
2. Turn on the ignition switch, and do not start the engine.
3. Apply the parking brake.
4. Select Special Functions on the scan tool.
5. Select Sensor Learn Mode on the scan tool, and press the Enter key.
6. Press the On soft key. A horn chirp should sound to indicate the sensor learn mode is enabled.
7. Starting with the LF tire, increase or decrease the tire pressure for 5–8 seconds or until a horn chirp sounds. The horn chirp may occur before the 5- to 8-second time period, or up to 30 seconds after this time period.



WARNING: If you are increasing tire pressure during the learning procedure, never inflate a tire above the vehicle manufacturer's maximum specified tire pressure. This action may cause personal injury and tire damage.

8. After the horn chirp sounds, repeat step 7 on the other 3 or 4 sensors in the following order:
 - (a) RF
 - (b) RR
 - (c) LR
 - (d) Spare tire (if applicable)

If a horn chirp is not heard after 35 seconds for any of the 4 sensors, turn off the ignition switch and exit the learn mode on the scan tool. Repeat the sensor learning procedure from step 4.

9. After the learning procedure has been completed on all the sensors, a double horn chirp sounds to indicate the learning procedure is completed on all the sensors.
10. Turn off the ignition switch and disconnect the scan tool.
11. Inflate all the tires to the specified pressure.

Learning procedure completed Yes _____ No _____. If the answer is no, state the reason for the test not being completed _____

Instructor's Response _____

Chapter 5

SHOCK ABSORBER AND STRUT DIAGNOSIS AND SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Perform a visual shock absorber inspection.
- Perform a shock absorber bounce test, and determine shock absorber condition.
- Determine shock absorber condition from a manual shock absorber test.
- Remove and replace shock absorbers.
- Diagnose shock absorber and strut noise complaints.
- Remove and replace front and rear struts.
- Remove struts from coil springs.
- Install coil springs on struts.
- Follow the vehicle manufacturer's recommended strut disposal procedure.
- Perform off-car strut cartridge replacement procedures.
- Perform on-car strut cartridge replacement procedures.
- Diagnose electrically controlled shock absorbers.

Shock absorbers and struts must be in good condition to provide satisfactory ride quality and maintain vehicle safety. Worn-out shock absorbers and struts may cause excessive chassis oscillations and harsh ride quality with resulting passenger discomfort. On a severely rough road surface, the chassis oscillations caused by worn-out shock absorbers and struts may contribute to a loss of steering control, resulting in a vehicle collision. Therefore, technicians must be familiar with shock absorber and strut diagnosis and service procedures.

SHOCK ABSORBER VISUAL INSPECTION

Bolt Mounting

Shock absorbers should be inspected for loose mounting bolts and worn mounting bushings. If these components are loose, rattling noise is evident, and replacement of the bushings and bolts is necessary.

Bushing Condition

In some shock absorbers, the bushing is permanently mounted in the shock, and the complete unit must be replaced if the bushing is worn. When the mounting bushings are worn, the shock absorber will not provide proper spring control.

Oil Leakage

Shock absorbers and **struts** should be inspected for oil leakage. A slight oil film on the lower oil chamber is acceptable. Any indication of oil dripping is not acceptable, and unit replacement is necessary (Figure 5-1).



BASIC TOOLS

Basic technician's tool set
Service manual
Hydraulic floor jack
Jack stands
Center punch



SERVICE TIP:

During a visual shock absorber inspection, check the rebound, or strikeout, bumpers on the control arms or chassis. If the rebound bumpers are severely worn, the shock absorbers may be worn out.

Struts are similar internally to shock absorbers, but struts also support the steering knuckle. In many applications, the coil spring is mounted on the strut.

A shock absorber may be called a shock.



SERVICE TIP:

A road test should be completed to test for shock absorber noise. If the gas leaks out of a shock absorber, oil will leak past the piston and the shock valve may knock (slap) against the oil. This knocking noise is heard when driving the vehicle over small bumps. This noise cannot be duplicated during a bounce test.



SERVICE TIP:

On twin I-beam front suspension systems, front wheel camber may be noticeably different after a bounce test.




FIGURE 5-1 Shock absorber and strut oil leak diagnosis.




FIGURE 5-2 Damaged shock absorber inspection.

Shock absorbers and struts should be inspected visually for physical damage, such as a bent condition and severe dents or punctures. When any of these conditions are present, unit replacement is required (Figure 5-2).

SHOCK ABSORBER OR STRUT BOUNCE TEST

CUSTOMER CARE: Always be willing to spend a few minutes explaining problems, including safety concerns, regarding the customer's vehicle. When customers understand why certain repairs are necessary, they feel better about spending the money. For example, if you explain that worn-out shock absorbers cause excessive chassis oscillations and may result in loss of steering control on irregular road surfaces, the customer is more receptive to spending the money for shock absorber replacement.

When the **bounce test** is performed, the bumper is pushed downward with considerable weight applied on each corner of the vehicle. The bumper is released after this action, and one free upward bounce should stop the vertical chassis movement if the shock absorber or strut provides proper spring control. Shock absorber replacement is required if more than one free upward bounce occurs. The shock absorber bounce test is illustrated in Photo Sequence 7.

SHOCK ABSORBER MANUAL TEST

A **manual test** may be performed on shock absorbers. When this test is performed, disconnect the lower end of the shock, and move the shock up and down as rapidly as possible. A satisfactory shock absorber should offer a strong, steady resistance to movement on the entire compression and rebound strokes. The amount of resistance may be different on the compression stroke compared with the rebound stroke. If a loss of resistance is experienced during either stroke, shock replacement is essential.

REAR SHOCK ABSORBER VISUAL INSPECTION AND BOUNCE TEST



P7-1 Raise the vehicle on a lift.



P7-2 Inspect the rear shock absorbers for oil leaks and damage such as dents and punctures.




P7-3 Grasp the lower shock absorber tube and attempt to move the shock absorber vertically and horizontally to check for looseness and wear on the shock absorber bushing and mounting bolt.



P7-4 Grasp the upper shock absorber cover and attempt to move it vertically and horizontally to check for looseness and wear on the shock absorber mounting bushing and mounting bolt.



P7-5 Disconnect the lower shock absorber mounting and grasp the lower end of the shock absorber. Pull the shock absorber downward on the extension stroke and push the lower end of the shock absorber upward on the compression stroke. The shock absorber should offer resistance to movement in relation to the shock absorber ratio.



P7-6 Install the lower shock absorber mounting and tighten the mounting bolt to the specified torque.



P7-7 Lower the vehicle onto the shop floor, and move the vehicle off the lift.



P7-8 Using your knee press down on the rear bumper with considerable weight, and suddenly remove your knee from the bumper. Count the number of free chassis oscillations before the chassis stops bouncing upward and downward.



CAUTION:

Gas-filled shock absorbers will extend when disconnected.

Upward wheel movement is referred to as wheel jounce, and downward wheel movement is called rebound.

Some defective shock absorbers or struts may have internal clunking, clicking, and squawking noises, or binding conditions. When these shock absorber noises or conditions are experienced, shock absorber or strut replacement is necessary.

AIR SHOCK ABSORBER DIAGNOSIS AND REPLACEMENT

Air shock absorbers are similar to conventional shocks except they have air pressure applied to them to control chassis curb height. Some air shock absorbers must be pressurized with the shop air hose. This type of unit contains a valve for inflation purposes. Other air shock absorbers are inflated by an onboard compressor with interconnecting plastic lines between the compressor and the shocks. Shock absorber lines must be inspected for breaks, cracks, and sharp bends. If any of these defects are present, the line must be replaced. The shock absorber lines must be secured to the chassis, and they must not rub against other components.

When air shock absorbers slowly lose their air pressure and reduce the curb riding height, shock replacement is required. Before removing an air shock, relieve the air pressure in the shock.

SHOCK ABSORBER REPLACEMENT



WARNING: Never apply heat to the lower shock absorber or strut chamber with an acetylene torch. Excessive heat may cause a shock absorber or strut explosion, which could result in personal injury.

When shock absorber replacement is necessary, follow this procedure:

1. Before replacing rear shock absorbers, lift the vehicle on a hoist and support the rear axle on safety stands so the shock absorbers are not fully extended.
2. When a front shock absorber must be changed, lift the front end on the vehicle with a floor jack, then place safety stands under the lower control arms. Lower the vehicle onto the safety stands and remove the floor jack.
3. Disconnect the upper shock mounting nut and grommet.
4. Remove the lower shock mounting nut or bolts, and remove the shock absorber.
5. Reverse steps 1 through 4 to install the new shock absorber and grommets.
6. With the full vehicle weight supported on the suspension, tighten the shock mounting nuts to the specified torque.

DIAGNOSIS OF FRONT SPRING AND STRUT NOISE

Strut chatter may be heard when the steering wheel is turned with the vehicle not moving or moving at low speed. To verify the location of this chattering noise, place one hand on a front coil spring while someone turns the steering wheel. If strut chatter is present, the spring binds and releases as it turns. This condition is caused by the upper spring seat binding against the strut bearing mount. A revised spring seat is available to correct this problem on some models.

A noise that occurs on sharp turns or during front suspension jounce may be caused by one of the following problems:

1. Interference between the upper strut rebound stop and the upper mount or **strut tower**
2. Interference between the coil spring and the tower (Figure 5-3)
3. Interference between the coil spring and the upper mount (Figure 5-4)

On some models, these coil spring interference problems may be corrected by installing upper coil spring spacers on top of the coil spring. Spring removal from the strut is required to install these spacers.

Classroom Manual

Chapter 5, page 96

A **strut tower** is a raised, circular, reinforced area inboard of the front fenders, which supports the upper end of the strut and coil spring assembly.




FIGURE 5-3 Coil spring to upper strut tower interference.




FIGURE 5-4 Coil spring to upper mount interference.

On many front suspension systems the strut is bolted to the upper end of the knuckle. When the front wheels are turned, the strut and coil spring rotate together and pivot on the upper strut mount bearing. In this type of suspension, a defective upper strut mount may cause strut chatter and noise.

On other front suspension systems, the strut extends downward and the lower ball joint retains the lower end of the strut to the lower control arm (Figure 5-5). The front hub is bolted to a flange on the knuckle. A bearing assembly is mounted in the lower spring seat. When the front wheels are turned, the strut rotates on the bearing in the lower spring seat, but the spring and upper strut mount do not rotate. Therefore, in this type of suspension system, strut chatter may be caused by a worn or defective lower spring seat bearing.




FIGURE 5-5 Strut assembly with bearing mounted in the lower spring seat.

An **eccentric camber bolt** has an oblong head, which provides inward or outward steering knuckle movement in relation to the strut as this bolt is rotated.

Classroom Manual

Chapter 5, page 100

If the lateral movement of the strut rod and nut above the strut tower exceeds $\frac{3}{16}$ in (4.76 mm), the upper strut bearing and mount assembly should be replaced.

Worn **spring insulators** or broken coil springs cause a rattling noise on road irregularities. Broken coil springs result in reduced curb riding height and harsh riding.

STRUT REMOVAL AND REPLACEMENT

Before a front strut-and-spring assembly is removed, the strut must be removed from the steering knuckle, and the top strut mount bolts must be removed from the strut tower. If an **eccentric camber bolt** is used to attach the strut to the knuckle, always mark the bolt head in relation to the strut and reinstall the bolt in the same position (Figure 5-6).

Always follow the vehicle manufacturer's recommended procedure in the service manual for removal of the strut-and-spring assembly.

A typical procedure for strut-and-spring assembly removal follows:

1. Raise the vehicle on a hoist or floor jack. If a floor jack is used to raise the vehicle, lower the vehicle onto safety stands placed under the chassis so the lower control arms and front wheels drop downward. Remove the floor jack from under the vehicle.
2. Remove the brake line and antilock brake system (ABS) wheel-speed sensor wire from clamps on the strut (Figure 5-7). In some cases, the clamps may also have to be removed from the strut.




FIGURE 5-6 Camber bolt marking for strut removal.




FIGURE 5-7 Brake line and ABS wheel-speed sensor wire removed from the strut.




FIGURE 5-8 Removing strut-to-steering knuckle retaining bolts.




FIGURE 5-9 Removing upper strut mounting bolts on top of strut tower.

3. Remove the strut-to-steering knuckle retaining bolts, and remove the strut from the knuckle (Figure 5-8).
4. Remove the upper strut mounting bolts on top of the strut tower, and remove the strut-and-spring assembly (Figure 5-9).

REMOVAL OF STRUT FROM COIL SPRING

WARNING: Always use a coil spring compressing tool according to the tool or vehicle manufacturer's recommended service procedure. Be sure the tool is properly installed on the spring. If a coil spring slips off the tool when the spring is compressed, severe personal injury or property damage may occur.

WARNING: Never loosen the upper strut mount retaining nut on the end of the strut rod unless the spring is compressed enough to remove all spring tension from the upper strut mount. If this nut is loosened with spring tension on the upper mount, this mount becomes a very dangerous projectile that may cause serious personal injury or property damage.

The coil spring must be compressed with a special tool before the strut can be removed. All the tension must be removed from the upper spring seat before the upper strut piston rod nut is loosened. Many different **spring compressing tools** are available, and they must always be used according to the manufacturer's recommended procedure. *If the coil spring has an enamel-type coating, tape the spring where the compressing tool contacts the spring.* The spring may break prematurely if this coating is chipped.

A typical procedure for removing a strut from a coil spring follows:

1. Install the coil spring and strut assembly in the spring compressing tool according to the tool or vehicle manufacturer's recommended procedure.
2. Adjust the compressing arms on the spring compressing tool so the arms contact the coils farthest away from the center of the spring (Figure 5-10).
3. Turn the handle on top of the compressing tool until all the spring tension is removed from the upper strut mount (Figure 5-10).
4. Loosen and remove the nut on the upper strut rod (Figure 5-11). Be sure all the spring tension is removed from the upper strut mount before loosening this nut.

Classroom Manual

Chapter 5, page 102



SPECIAL TOOLS

Coil spring compressing tool



CAUTION:

Never clamp the lower shock absorber or strut chamber in a vise with excessive force. This action may distort the lower chamber and affect piston movement in the shock absorber or strut.




FIGURE 5-10 Coil spring and strut assembly mounted in a spring compressing tool.




FIGURE 5-11 After the compressing tool is operated to remove all the spring tension, remove the strut rod nut.



SERVICE TIP:

Because of high labor costs, it is often more economical for the customer if the technician replaces a strut and coil spring as a complete assembly rather than replacing these components individually. Many automotive parts suppliers market struts and coil spring as complete assemblies.




FIGURE 5-12 Removal of the upper strut mount, bearing, upper spring seat, and insulator.




FIGURE 5-13 Removal of the dust shield, jounce bumper, and lower spring insulator.

Spring

compressing

tools are used to compress a coil spring and relieve the spring tension on the upper strut mount to allow spring removal from the strut.

5. Remove the upper strut mount assembly and mount bearing, and then remove the upper spring seat and insulator (Figure 5-12).
6. Rotate the handle on the spring compressing tool to release all the tension on the coil spring, and then remove the spring.
7. Remove the dust shield and jounce bumper from the strut rod, and then remove the lower spring insulator (Figure 5-13).




FIGURE 5-14 Strut drilling location.

STRUT DISPOSAL PROCEDURE

WARNING: Always follow the vehicle manufacturer's recommended procedure for strut disposal. Do not throw gas-filled shock absorbers or struts in a fire of any kind or in a dumpster. If the vehicle manufacturer recommends drilling the strut to release the gas charge, drill the strut at the manufacturer's recommended location.

The following is a typical strut drilling procedure that is performed prior to strut disposal:

1. Fully extend the strut rod.
2. Center punch the strut at the manufacturer's recommended drilling location (Figure 5-14).
3. Drill a small hole at the center-punched position.

INSTALLATION OF COIL SPRING ON STRUT

A typical procedure for installing a coil spring on a strut follows:

1. Install the lower insulator on the lower strut spring seat, and be sure the insulator is properly seated (Figure 5-15).
2. Install the spring bumper on the strut rod (Figure 5-16).
3. With the coil spring compressed in the spring compressing tool, install the strut in the spring (Figure 5-17). Be sure the spring is properly seated on the lower insulator spring seat.
4. Be sure the strut piston rod is fully extended and install the upper insulator on top of the coil spring.
5. Install the upper strut mount on the upper insulator (Figure 5-18).
6. Be sure the spring, upper insulator, and upper strut mount are properly positioned and seated on the coil spring and strut piston rod (Figure 5-19).
7. Install the strut rod nut, and tighten this nut to the specified torque (Figure 5-20).




FIGURE 5-15 Insulator installation on lower spring seat.




FIGURE 5-16 Spring bumper installation on strut piston rod.




FIGURE 5-17 Installing strut in coil spring with proper lower spring seat alignment.




FIGURE 5-18 Upper insulator and upper strut mount installed on coil spring.




FIGURE 5-19 Upper strut mount properly positioned on strut piston rod.




FIGURE 5-20 Installing strut rod nut.




FIGURE 5-21 Aligning lowest bolt on upper strut mount with tab on lower spring seat.

8. Rotate the upper strut mount until the lowest bolt in this mount is aligned with the tab on the lower spring seat (Figure 5-21).
9. Gradually loosen the handle on the compressing tool until all the spring tension is released from the tool, and remove the strut and spring assembly from the tool.

INSTALLATION OF STRUT-AND-SPRING ASSEMBLY IN VEHICLE

A typical installation procedure for a strut-and-spring assembly follows:

1. Install the strut-and-spring assembly with the upper strut mounting bolts extending through the bolt holes in the strut tower. Tighten the nuts on the upper strut mounting bolts to the specified torque (Figure 5-22).
2. Install the lower end of the strut in the steering knuckle to the proper depth, and tighten the strut-to-knuckle retaining bolts to the specified torque (Figure 5-23). If one of the strut-to-knuckle bolts is an eccentric camber bolt, be sure the eccentric is aligned with the mark placed on the strut during the removal procedure.
3. Install the brake hose in the clamp on the strut. Place the ABS wheel-speed sensor wire in the strut clamp if the vehicle is equipped with ABS (Figure 5-24).

Photo Sequence 8 shows a typical procedure for removing and replacing a MacPherson strut.




FIGURE 5-22 Nuts installed on upper strut mount bolts.




FIGURE 5-23 Lower end of strut installed in steering knuckle.





FIGURE 5-24 Brake hose and ABS wire installed in strut clamps.

PHOTO SEQUENCE 8

TYPICAL PROCEDURE FOR REMOVING AND REPLACING A MACPHERSON STRUT



P8-1 The top of the strut assembly is mounted directly to the chassis of the car. Prior to loosening the strut-to chassis bolts, scribe alignment marks on the strut bolts and the chassis.




P8-2 With the top strut bolts or nuts removed, raise the car to a working height. It is important that the car be supported on its frame and not on its suspension components.




P8-3 Remove the wheel assembly. The strut is accessible from the wheel well after the wheel is removed.




P8-4 Remove the bolt that fastens the brake line or hose to the strut assembly.



P8-5 Remove the strut-to-steering knuckle bolts.




P8-6 Support the steering knuckle with wire and remove the strut assembly from the car.



P8-7 Install the strut assembly into the proper type spring compressor. Then compress the spring until all spring tension is removed from the upper strut mount. Loosen and remove the strut rod nut.



P8-8 Remove the old strut assembly from the spring and install the new strut. Compress the spring to allow for reassembly and tighten the strut rod nut.



P8-9 Reinstall the strut assembly into the car. Make sure all bolts are properly tightened and in the correct locations.

REAR STRUT REPLACEMENT

The rear strut replacement procedure varies depending on the type of rear suspension. Always follow the vehicle manufacturer's recommended procedure outlined in the appropriate service manual.

A typical rear strut replacement procedure follows:

1. Lift the vehicle with a floor jack and lower the vehicle onto safety stands placed under the chassis to support the vehicle weight.
2. Place the floor jack under the lower control arm and operate the jack to support some of the spring tension.
3. Remove the tire-and-wheel assembly.
4. Remove the strut-to-spindle bolts.
5. Pull upward on the strut to remove the strut from the spindle. If necessary, lower the floor jack slightly to remove the strut from the spindle.
6. Disconnect the upper strut mount from the chassis, and remove the strut.
7. When the new strut and/or mount is installed, reverse steps 1 through 6. Tighten all the bolts to the specified torque.
8. Check vehicle alignment.

The rear coil springs may be removed from the rear struts using the same basic procedure for spring removal from the front struts.

INSTALLING STRUT CARTRIDGE, OFF-CAR

CUSTOMER CARE: Check the cost of the strut cartridges versus the price of new struts. Give customers the best value for their repair dollar!

Many struts are a sealed unit, and thus rebuilding is impossible. However, some manufacturers supply a replacement cartridge that may be installed in the strut housing after the strut has been removed from the vehicle. Always follow the **strut cartridge** manufacturer's recommended installation procedure.

The following is a typical off-car strut cartridge installation procedure:

1. Install a bolt and two nuts in the upper strut-to-knuckle mounting bolt hole. Place a nut on the inside and outside of the strut flange.
2. Clamp this bolt in a vise to hold the strut.
3. Locate the line groove near the top of the strut body, and use a pipe cutter installed in this groove to cut the top of the strut body.
4. After the cutting procedure, remove the strut piston assembly from the strut (Figure 5-25).
5. Remove the strut from the vise and dump the oil from the strut.
6. Place the special tool supplied by the vehicle manufacturer or cartridge manufacturer on top of the strut body. Strike the tool with a plastic hammer until the tool shoulder contacts the top of the strut body. This action removes burrs from the strut body and places a slight flare on the body.
7. Remove the tool from the strut body.
8. Install the required amount of oil in the strut, place the new cartridge in the strut body, and turn the cartridge until it settles into indentations in the bottom of the strut body.

A **strut cartridge** contains the inner working part of the strut, which may be installed in the outer housing of the old strut.



SPECIAL TOOLS

Pipe cutter




FIGURE 5-25 Installation of strut cartridge.

9. Place the new nut over the cartridge.
10. Using a special tool supplied by the vehicle or cartridge manufacturer, tighten the nut to the specified torque.
11. Move the strut piston rod in and out several times to check for proper strut operation.

INSTALLING STRUT CARTRIDGE, ON-CAR



WARNING: If a vehicle is hoisted or lifted in any way during an on-car strut cartridge replacement, the coil spring may fly off the strut, causing vehicle damage and personal injury.




FIGURE 5-26 Removing upper strut mount nuts and cover.




FIGURE 5-27 Removing nut from strut piston rod.

On some vehicles, the front strut cartridge may be removed and replaced with the strut installed in the vehicle. Always consult the vehicle manufacturer's service manual for the proper strut service procedure.

A typical on-car strut cartridge installation procedure follows:

1. Remove the nuts from the upper strut mount and remove the strut mount cover (Figure 5-26).
2. Use the special tool supplied by the vehicle manufacturer and a number 50 torx bit to remove the nut from the strut piston rod (Figure 5-27). Never lift or hoist the vehicle once this nut is removed.
3. Remove the bushing from the upper strut mount (Figure 5-28).
4. Thread the special tool supplied by the vehicle manufacturer onto the top of the strut piston rod, and push this rod downward into the strut (Figure 5-29). Remove this tool and then remove the jounce bumper retainer (Figure 5-30).
5. Remove the jounce bumper (Figure 5-31).




FIGURE 5-28 Removing upper strut mount bushing.




FIGURE 5-29 Pushing strut piston rod downward.




FIGURE 5-30 Removing jounce bumper retainer.




FIGURE 5-31 Removing jounce bumper.




FIGURE 5-32 Re-extending strut piston rod.




FIGURE 5-33 Removing strut closure nut.

6. Thread the special tool onto the strut piston rod, and re-extend this rod (Figure 5-32). Use the special tool supplied by the vehicle manufacturer to remove the closure nut on top of the strut (Figure 5-33).
7. Grasp the top of the strut piston rod and remove the strut valve mechanism (Figure 5-34).
8. Remove the oil from the strut tube with a hand-operated suction pump.
9. Install the new strut cartridge in the strut, and tighten the closure nut to the specified torque (Figure 5-35). Reverse steps 1 through 6 to complete the strut cartridge replacement. Place a light coating of the vehicle manufacturer's recommended engine oil on the upper strut mount bushing prior to bushing installation.




FIGURE 5-34 Removing strut valve mechanism.




FIGURE 5-35 Installing new strut cartridge.

DIAGNOSIS OF ELECTRONICALLY CONTROLLED SHOCK ABSORBERS

The actuators on electronically controlled shock absorbers can be removed by pushing inward simultaneously on the two actuator retaining tabs and lifting the actuator off the top of the strut (Figure 5-36).

An actuator may be called a solenoid.

! WARNING: If the strut piston rod nut and actuator mounting bracket are removed, do not move or raise the vehicle. This action releases the coil spring tension and may result in personal injury and vehicle damage.

Follow these steps to diagnose the electronic actuator:

1. With the actuator removed from the strut and the actuator wiring harness connected, turn the ignition switch on. Move the ride control switch to the auto position and wait 5 seconds.




FIGURE 5-36 Electronically controlled strut actuator.



SERVICE TIP:

Wiring harness colors vary depending on the vehicle make and model year. The wiring colors in the following steps are based on Ford vehicles. If you are working on a different make of vehicle, refer to the wire colors in the vehicle manufacturer's service information.

2. Move the ride control switch to the firm position, and wait 5 seconds. If the actuator control tube on the bottom of the actuator rotated, the actuator is operating. If the actuator control tube did not rotate, proceed with the actuator tests.
3. With the ride control switch in the firm position, place matching H's beside the control tube and the actuator.
4. With the ride control switch in the auto position, place matching S's beside the control tube and the actuator.
5. Turn the ignition switch off and disconnect the actuator electrical connector. The actuator control tube may be rotated with a small screwdriver.
6. Connect a pair of ohmmeter leads to the position sense wire and the signal return wire. The position sense wire is white or white with a colored tracer, and the signal return wire is yellow with a black tracer. With the actuator in the S position, the position sense should be closed and the ohmmeter should indicate less than 10 ohms.
7. Rotate the actuator to the H position. Under this condition, the position sense switch should be open and the ohmmeter should indicate over 1,000 ohms. If the ohmmeter readings are not within specifications, replace the actuator.
8. Connect the ohmmeter leads to the position sense wire and soft power terminal in the actuator electrical connector. The position sense wire is white or white with a colored tracer, and the soft power wire is tan with a red tracer. If the ohmmeter indicates over 1,000 ohms, the actuator is satisfactory. If the ohmmeter reading is below 10 ohms, replace the actuator.
9. Connect the ohmmeter leads from the signal return terminal in the wiring harness side of the actuator connector to a chassis ground. The ohmmeter should indicate less than 10 ohms. If the ohmmeter reading is higher than specified, check the signal return wire and the programmed ride control (PRC) module.

TABLE 5-1 SHOCK ABSORBER AND STRUT DIAGNOSIS

Problem	Symptoms	Possible Causes
Harsh ride quality	Excessive chassis bouncing Excessive vertical wheel oscillations	Worn out shock absorbers or struts
Shock absorber or strut oil leaks	Oil dripping from shock absorber or strut	Worn out seal in shock absorber or strut, damaged lower shock absorber or strut housing
Rattling noise	Rattling noise in chassis when driving	Worn out shock absorber or strut mountings
Chattering noise	Chattering noise when turning the front wheels to the right or left	Worn out upper strut mount and bearing assembly
Worn, damaged rebound bumpers	Chassis bottoming out	Worn out shock absorbers or struts, low ride height

CASE STUDY

A customer complained about a squeaking noise in the rear suspension of a 2009 Dodge Caravan. The customer said the noise occurred during normal driving at lower speeds. The technician lifted the car on a hoist and made a check of all rear suspension bushings in shock absorbers, track bar, and trailing arms.

The spring insulators and all suspension bolts were checked visually. All of these items were in good condition, and there was no evidence of a squeaking noise as the chassis was bounced gently. Since the exact source of chassis noise can sometimes be difficult to locate, the technician performed a visual check of

bushings, insulators, and fasteners in the front suspension. No problems were found in the front suspension.

One of the first requirements for successful automotive diagnosis is to obtain as much information as possible from the customer. The customer with the squeaking rear suspension in a Dodge Caravan lived in a part of the country where cold temperatures occur in the winter. This complaint occurred in January. The technician questioned the customer further about the conditions when the squeaking suspension noise was heard, and the customer revealed that the noise occurred when the temperature was severely cold. The customer also indicated that the noise disappeared at warmer temperatures.

The technician informed the customer that the only way to find the exact cause of this annoying squeak

was to leave the car on the lot at the shop all night and check it first thing in the morning when it was colder. The customer complied with this suggestion, and the technician drove the car into the shop immediately the next morning. The squeaking noise occurred as the car was driven across the parking lot. The technician lifted the car on a hoist and listened with a stethoscope at each rear suspension bushing as a coworker gently bounced the rear suspension. No squeaking noise was heard at any of the rear suspension bushings. However, when the stethoscope pickup was placed on the left rear shock absorber, the squeaking noise was loud and clear. The shock absorber was quickly removed, and the squeaking noise was gone when the rear chassis was bounced gently. Replacement of the left rear shock absorber corrected this complaint and made the customer happy.

TERMS TO KNOW

Bounce test

Eccentric camber bolt

Manual test

Spring compressing tools

Spring insulators

Struts

Strut cartridge

Strut chatter

Strut tower

ASE-STYLE REVIEW QUESTIONS

1. A slight oil film appears on the lower shock absorber oil chamber, and the shock absorber performs satisfactorily in a bounce test:

Technician A says the shock absorber is satisfactory.

Technician B says the shock absorber may contain excessive pressure.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

2. While discussing a shock absorber and strut bounce test:

Technician A says the shock absorber is satisfactory if the bumper makes two free upward bounces.

Technician B says the bumper must be pushed downward with considerable force.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

3. While discussing a shock absorber manual test:

Technician A says the shock absorber's resistance to movement should be jerky and erratic.

Technician B says the shock absorber's resistance to movement may be greater on the rebound stroke compared with the compression stroke.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

4. When the front wheels are turned on a vehicle equipped with front struts, the left front coil spring provides a chattering action and noise:

Technician A says the strut has internal defects, and strut replacement is necessary.

Technician B says the upper strut bearing and mount is defective.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

5. While discussing enamel-coated coil springs:

Technician A says if the enamel-type coating on a coil spring is chipped, the spring may break prematurely.

Technician B says coil springs should be taped in the compressing tool contact areas to prevent chipping of the enamel-type coating.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

6. During service procedures, gas-filled shock absorbers may:

- A. Be heated with an acetylene torch.
B. Be thrown in an incinerator.
C. Extend when disconnected.
D. Retract when disconnected and extended.

7. During wheel jounce, a thumping noise is heard in the right front suspension, but the strut bounce test is satisfactory. All of these defects could cause the problem EXCEPT:
 - A. A worn upper strut mount.
 - B. Worn spring insulators.
 - C. A broken coil spring.
 - D. A fluid leak in the strut.
8. When removing and replacing a front strut on a MacPherson strut suspension:
 - A. The cam-type strut-to-knuckle bolt should be marked in relation to the strut.
 - B. The strut rod nut may be loosened with spring tension applied to the upper strut mount.
 - C. The lower strut chamber may be clamped in a vise to support the strut.
 - D. The spring compressor must be installed before the strut is removed from the vehicle.
9. When assembling and installing a strut and coil spring in a MacPherson strut front suspension:
 - A. The upper spring insulator should be installed between the upper strut mount and the strut tower.
 - B. The lower spring insulator should be installed between the coil spring and the spring bumper.
 - C. On some vehicles, the upper strut mount must be properly aligned in relation to the lower spring seat on the strut.
 - D. Final compressing of the coil spring may be done by tightening the nut on the strut rod.
10. During an on-car strut cartridge replacement:
 - A. Oil must be removed from the strut with a hand-operated suction pump.
 - B. The front suspension may be lifted with a floor jack.
 - C. The strut rod must be pulled upward before removing the jounce bumper.
 - D. The new strut cartridge must be filled with the manufacturer's specified fluid.

ASE CHALLENGE QUESTIONS

1. A customer says his MacPherson strut front suspension is making a chattering noise when the steering wheel is turned hard to the left. He says he also feels a "kind of vibration" in the steering wheel when the chatter is heard. To correct this problem, you should:
 - A. Replace the front struts.
 - B. Check the lower strut spring seating.
 - C. Check the stabilizer links.
 - D. Check the upper bearing and strut mounting.
2. When performing a bounce test on a twin I-beam front suspension, the front tires noticeably flex as the front end of the vehicle is vigorously exercised. When the vehicle is released, the front end rebounds once then settles, but the front wheel now has a slight but obvious negative camber.

Technician A says the shock absorbers are worn and should be replaced.

Technician B says the twin I-beam suspension can change camber during a bounce and rebound.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
3. The front rebound bumpers on a coil spring suspension system are badly worn and damaged.

Technician A says the shock absorbers may be worn out.

Technician B says the coil springs may be weak.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
4. A manual test of a shock absorber shows a stronger resistance to rebound than compression.

Technician A says the shock is defective.

Technician B says the shock has a 50/50 ratio.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
5. *Technician A* says any visible presence of oil on a strut or shock requires replacement.

Technician B says a slight film of oil on a strut or shock is OK if it performs satisfactorily in a bounce test.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B

Name _____ Date _____

REMOVE STRUT-AND-SPRING ASSEMBLY AND DISASSEMBLE STRUT AND SPRING

Upon completion of this job sheet, you should be able to remove a strut-and-spring assembly from a car and disassemble the strut and spring.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task C-10. Remove, inspect, and install strut cartridge or assembly, strut coil spring, insulators (silencers), and upper strut bearing mount.

Tools and Materials

Front-wheel-drive car

Floor jack

Safety stands

Coil spring compressor

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed _____

1. With the vehicle parked on the shop floor, perform a strut bounce test.

Based on the bounce test results, state the strut condition, and give the reason for your diagnosis.

2. Raise the vehicle on a hoist or with a floor jack. If a floor jack is used to raise the vehicle, lower the vehicle onto safety stands placed under the chassis so the lower control arms and front wheels drop downward. Remove the floor jack from under the vehicle.

Is the vehicle securely supported on safety stands? ☐ Yes ☐ No

Instructor check _____

3. Remove the brake line and antilock brake system (ABS) wheel-speed sensor wire from clamps on the strut. In some cases, these clamps may have to be removed from the strut.

Is the brake line and ABS wheel-speed sensor wire disconnected? ☐ Yes ☐ No

Instructor check _____

Task Completed

4. Punch mark the cam bolt in relation to the strut, remove the strut-to-steering knuckle retaining bolts, and remove the strut from the knuckle.

Is the cam bolt marked in relation to the strut? ☐ Yes ☐ No

Is the strut removed from the knuckle? ☐ Yes ☐ No

Instructor check _____

State the reason for marking the cam bolt in relation to the strut.

☐

5. Remove the upper strut mounting bolts on top of the strut tower; remove the strut-and-spring assembly.



WARNING: Always use a coil spring compressing tool according to the tool or vehicle manufacturer's recommended service procedure. Be sure the tool is properly installed on the spring. If a coil spring slips off the tool when the spring is compressed, severe personal injury or property damage may occur.



WARNING: Never loosen the upper strut mount retaining nut on the end of the strut rod unless the spring is compressed enough to remove all spring tension from the upper strut mount. If this nut is loosened with spring tension on the upper mount, this mount becomes a very dangerous projectile that may cause serious personal injury or property damage.

6. Install the spring compressing tool on the coil spring according to the tool or vehicle manufacturer's recommended procedure.

Is the compressing tool properly installed on the strut-and-spring assembly?

☐ Yes ☐ No

Instructor check _____

7. Turn the nut on top of the compressing tool until all the spring tension is removed from the upper strut mount.

Is all the spring tension removed from the upper strut mount? ☐ Yes ☐ No

Instructor check _____

8. Install a bolt and two nuts in the upper strut to knuckle mounting bolt holes. Install a nut on each side of the strut flange. Clamp this bolt securely in a vise to hold the strut-and-spring assembly and the compressing tool.

9. Use the bar on the spring compressing tool to hold the strut-and-spring assembly from turning, and loosen the nut on the upper strut mount. Be sure all the spring tension is removed from the upper strut mount before loosening this nut.

Is all the spring tension removed from the upper strut mount? ☐ Yes ☐ No

Is the upper strut mount retaining nut loosened? ☐ Yes ☐ No

Instructor check _____



CAUTION:

Never clamp the lower shock absorber or strut chamber in a vise with excessive force. This action may distort the lower chamber and affect piston movement in the shock absorber or strut.

☐



☐

CAUTION:

If the coil spring has an enamel-type coating and the compressing tool contacts the coil spring, tape the spring where the compressing tool contacts the spring.

10. Remove the nut, upper strut mount, upper insulator, coil spring, spring bumper, and lower insulator.

Task Completed



11. Inspect the strut, upper strut mount, coil spring, spring insulators, and spring bumper. On the basis of this inspection, list the necessary strut-and-spring service, and give the reasons for your diagnosis.

Instructor's Response

Name _____ Date _____

ASSEMBLE STRUT AND SPRING AND INSTALL STRUT-AND-SPRING ASSEMBLY

Upon completion of this job sheet, you should be able to assemble a strut and spring and install a strut-and-spring assembly in a car.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task C-10: Remove, inspect, and install strut cartridge on assembly, strut coil spring, insulators (silencers), and upper strut bearing mount.

Tools and Materials

Front-wheel-drive car
Floor jack
Safety stands
Coil spring compressor

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

☐

1. Install a bolt in the upper strut-to-knuckle retaining bolt, and clamp this bolt in a vise to hold the strut, spring, and compressing tool as in the disassembly procedure.
2. Install the lower insulator on the lower strut spring seat and be sure the insulator is properly seated.

Is the lower insulator properly seated? ☐ Yes ☐ No

Instructor check _____

3. Install the spring bumper on the strut rod.

Is the spring bumper properly installed? ☐ Yes ☐ No

Instructor check _____

4. With the coil spring compressed in the spring compressing tool, install the spring on the strut. Be sure the spring is properly seated on the lower insulator spring seat.

Is the coil spring properly seated on the lower insulator? ☐ Yes ☐ No

Instructor check _____

Task Completed

5. Be sure the strut piston rod is fully extended and install the upper insulator on top of the coil spring.

Is the strut rod fully extended? ☐ Yes ☐ No

Is the upper insulator properly installed? ☐ Yes ☐ No

Instructor check _____

6. Install the upper strut mount on the upper insulator.
7. Be sure the spring, upper insulator, and upper strut mount are properly positioned and seated on the coil spring and strut piston rod.

Are the spring, upper insulator, and upper strut mount properly positioned?

☐ Yes ☐ No

Instructor check _____

8. Use the compressing tool bar to hold the strut and spring from turning, then tighten the strut piston rod nut to the specified torque.

Specified strut piston rod nut torque _____

Actual strut piston rod nut torque _____

9. Rotate the upper strut mount until the lowest bolt in this mount is aligned with the tab on the lower spring seat.

Is the upper strut mount properly aligned? ☐ Yes ☐ No

Instructor check _____



10. Gradually loosen the nut on the compressing tool until all the spring tension is released from the tool, and remove the tool from the spring.
11. Install the strut-and-spring assembly with the upper strut mounting bolts extending through the bolt holes in the strut tower. Tighten the nuts on the upper strut mounting bolts to the specified torque.

Specified upper strut mount nut torque _____

Actual upper strut mount nut torque _____

12. Install the lower end of the strut in the steering knuckle to the proper depth. Align the punch marks on the cam bolt and strut that were placed on these components during disassembly, and tighten the strut-to-knuckle retaining bolts to the specified torque.

Is the cam bolt properly positioned? ☐ Yes ☐ No

Specified strut-to-knuckle bolt torque _____

Actual strut-to-knuckle bolt torque _____

Instructor check _____

- 13.** Install the brake hose in the clamp on the strut. Place the ABS wheel-speed sensor wire in the strut clamp if the vehicle is equipped with ABS.

Task Completed

Is the brake hose properly installed and tightened? ☐ Yes ☐ No

Is the ABS wheel-speed sensor properly installed and tightened? ☐ Yes ☐ No

Instructor check _____

- 14.** Raise the vehicle with a floor jack, remove the safety stands, and lower the vehicle onto the shop floor.

☐

Instructor's Response _____

Name _____ Date _____

INSTALL STRUT CARTRIDGE OFF-CAR

Upon completion of this job sheet, you should be able to remove and replace a strut cartridge with the strut removed from the car.

NATEF Correlation

This job sheet is related to the NATEF Suspension and Steering Task C-10. Remove, inspect, and install strut cartridge on assembly, strut coil spring, insulators (silencers), and upper strut bearing mount.

Tools and Materials

Front strut removed from car

Pipe cutter

Torque wrench

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. List the strut conditions and suspension operating conditions that indicate a strut should be serviced or replaced.

2. Install a bolt and two nuts in the upper strut to knuckle mounting bolt hole. Place a nut on the inside and outside of the strut flange.

☐

3. Clamp this bolt in a vise to hold the strut.

4. Locate the line groove near the top of the strut body, and use a pipe cutter installed in this groove to cut the top of the strut body.

☐

5. After the cutting procedure, remove the strut piston assembly from the strut.

Is the strut piston assembly removed from the strut? ☐ Yes ☐ No

Instructor check _____

6. Remove the strut from the vise and dump the oil from the strut.

☐

Task Completed

7. Place the special tool supplied by the vehicle manufacturer or cartridge manufacturer on top of the strut body and strike the tool with a plastic hammer until the tool shoulder contacts the top of the strut body. This action removes burrs from the strut body and places a slight flare on the body.

Is the strut body properly flared? ☐ Yes ☐ No

Instructor check _____

☐

8. Remove the tool from the strut body.

9. Place the new cartridge in the strut body and turn the cartridge until it settles into indentations in the bottom of the strut body.

Is the new strut cartridge properly seated in strut body indentations? ☐ Yes ☐ No

Instructor check _____

☐

10. Place the new nut over the cartridge.

11. Using a special tool supplied by the vehicle or cartridge manufacturer, tighten the nut to the specified torque.

Specified strut nut torque _____

Actual strut nut torque _____

12. Move the strut piston rod in and out several times to check for proper strut operation.

Strut operation: ☐ Satisfactory ☐ Unsatisfactory

Instructor's Response _____

Chapter 6

FRONT SUSPENSION SYSTEM SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Measure curb riding height.
- Diagnose and correct curb riding height problems.
- Adjust torsion bars.
- Diagnose front suspension noise and body sway.
- Remove and replace ball joints, and check ball joint condition.
- Remove and replace steering knuckles, and check knuckle condition.
- Remove and replace lower control arms, and check control arm and bushing condition.
- Remove and replace coil springs, and check spring and insulator condition.
- Remove and replace upper control arms, and check control arm and bushing condition.
- Remove and replace control arm bushings.
- Inspect and replace rebound bumpers.
- Diagnose, remove, and replace stabilizer bars.
- Diagnose, remove, and replace strut rods.
- Diagnose, remove, and replace leaf springs.
- Replace torsion bars, and check torsion bar condition.

Proper front suspension system service is extremely important to provide adequate vehicle safety and to maintain ride comfort and normal tire life. If worn or loose front suspension system components are ignored, steering control may be adversely affected, which may result in loss of steering control and an expensive collision. Defective front suspension components, such as worn out shock absorbers or broken springs, may cause rough riding that results in driver and passenger discomfort. Other worn front suspension components, such as worn ball joints and control arm bushings, cause improper alignment angles that causes excessive front tire wear. Therefore, technicians must be familiar with front suspension service.

CURB RIDING HEIGHT MEASUREMENT

Regular inspection and proper maintenance of suspension systems is extremely important for maintaining vehicle safety. The **curb riding height** is determined mainly by spring condition. Other suspension components, such as control arm bushings, affect curb riding height if they are worn. Since incorrect curb riding height affects most of the other suspension angles, this measurement is critical.

Reduced curb riding height on the front suspension may cause decreased **directional stability**. If the curb riding height is reduced on one side of the front suspension, the steering may pull to one side. Reduced rear suspension height increases **steering effort** and causes rapid steering wheel return after turning a corner. Harsh riding occurs when the curb riding



BASIC TOOLS

Basic technician's tool set
Service manual
Floor jack
Safety stands
Pry bar
3/8" electric drill
and drill bits

Curb riding height is the distance from specific chassis locations to the road surface.

Directional stability refers to the tendency of the vehicle steering to remain in the straight-ahead position when driven straight ahead on a reasonably smooth, level road surface.

Steering effort is the amount of effort required to turn the steering wheel.




FIGURE 6-1 Curb riding height measurement, front suspension.




FIGURE 6-2 Curb riding height measurement, rear suspension.

height is less than specified. The curb riding height must be measured at the vehicle manufacturer's specified location, which varies depending on the type of suspension system.

When the vehicle is on a level floor or on an alignment rack, measure the curb riding height from the floor to the center of the lower control arm mounting bolt on both sides of the front suspension (Figure 6-1). On the rear suspension system, measure the curb riding height from the floor to the center of the strut rod mounting bolt (Figure 6-2).

If the curb riding height is less than specified, the control arms and bushings should be inspected and replaced as necessary. When the control arms and bushings are in normal condition, the reduced curb riding height may be caused by sagged springs that require replacement.

FRONT SUSPENSION DIAGNOSIS AND SERVICE

Torsion Bar Adjustment

CUSTOMER CARE: Each time under-car service is performed, make a quick inspection of suspension and steering components. Advise the customer regarding any necessary repairs. This procedure often obtains additional work for the shop, and the customer will be impressed that you are interested in his or her car and personal safety.



SPECIAL TOOLS

Machinist's rule

On torsion bar front suspension systems, the torsion bars may be adjusted to correct the curb riding height. The curb riding height must be measured at the location specified by the vehicle manufacturer. On some torsion bar front suspension systems, the curb riding height is measured with the vehicle on a lift and the tires supported on the lift. Measure the distance from the center of the front lower control arm bushing to the lift. Then measure the distance from the lower end of the front spindle to the lift (Figure 6-3). The difference between these two readings is the curb riding height.




FIGURE 6-3 Curb riding height measurement, torsion bar front suspension.




FIGURE 6-4 Curb riding height adjustment, torsion bar front suspension.

If the curb riding height is not correct on a torsion bar front suspension, the torsion bar anchor adjusting bolts must be rotated until the curb riding height equals the vehicle manufacturer's specifications (Figure 6-4).

Inspecting Ball Joints

CUSTOMER CARE: Regular chassis lubrication at the vehicle manufacturer's recommended service interval is one of the keys to long ball joint life. Always advise the customer of this fact.

Classroom Manual
Chapter 6, page 116

Wear Indicators. Some ball joints have a grease fitting installed in a floating retainer. The grease fitting and retainer may be used as a **ball joint wear indicator**. With the vehicle weight resting on the wheels, grasp the grease fitting and check for movement (Figure 6-5).

Some car manufacturers recommend ball joint replacement if any grease fitting movement is present. In some other ball joints, the grease fitting retainer extends a short distance through the ball joint surface (Figure 6-6). On this type of joint, replacement is necessary if the grease fitting shoulder is flush with or inside the ball joint cover.

A **ball joint wear indicator** allows the technician to check ball joint wear by visibly inspecting the ball joint.




FIGURE 6-5 Ball joint grease fitting wear indicator.




FIGURE 6-6 Ball joint wear indicator with grease fitting extending from ball joint surface.




FIGURE 6-7 Floor jack position to check ball joint wear with spring between the lower control arm and the chassis.




FIGURE 6-8 Floor jack position to check ball joint wear with spring between the upper control arm and the chassis.

Ball Joint Unloading

On many suspension systems, ball joint looseness is not apparent until the weight has been removed from the joint. When the coil spring is positioned between the lower control arm and the chassis, place a floor jack near the outer end of the lower control arm and raise the tire off the floor (Figure 6-7). Be sure the rebound bumper is not in contact with the control arm or frame.

When the coil springs are positioned between the upper control arm and the chassis, place a steel block between the upper control arm and the frame. With this block in place, raise the tire off the floor with a floor jack under the front crossmember (Figure 6-8).

Ball Joint Vertical Measurement

The vehicle manufacturer may provide ball joint vertical and horizontal tolerances. A dial indicator is one of the most accurate ball joint measuring devices (Figure 6-9). Always install the dial indicator at the vehicle manufacturer's recommended location for ball joint measurement. When measuring the **ball joint vertical movement** in a compression-loaded ball joint, attach the dial indicator to the lower control arm and position the dial indicator stem on the lower side of the steering knuckle beside the ball joint stud (Figure 6-10). Depress the dial



SPECIAL TOOLS

Dial indicator for ball joint measurement

Ball joint vertical movement refers to up and down movement in a ball joint.




FIGURE 6-9 Dial indicator designed for ball joint measurement.



FIGURE 6-10 Dial indicator installed to measure vertical ball joint movement on a compression-loaded ball joint.

indicator stem approximately 0.250 in. (6.35 mm) and zero the dial indicator. Place a pry bar under the tire and pry straight upward while observing the vertical ball joint movement on the dial indicator. If this movement is more than specified, ball joint replacement is necessary. Photo Sequence 9 illustrates the vertical ball joint measurement procedure.

On a tension-loaded ball joint, clean the top end of the lower ball joint stud, and position the dial indicator stem against the top end of this stud. Depress the dial indicator plunger approximately 0.250 in. (6.35 mm) and zero the dial indicator. Lift upward with a pry bar under the tire and observe the dial indicator reading. If the vertical ball joint movement exceeds the manufacturer's specifications, ball joint replacement is required.

Ball Joint Horizontal Measurement

Worn ball joints cause improper **camber angles** and **caster angles**, which result in reduced directional stability and tire tread wear. Connect the dial indicator to the lower control arm of the ball joint being checked and position the dial indicator stem against the edge of the wheel rim (Figure 6-11).

Be sure the front wheel bearings are adjusted properly prior to the ball joint horizontal measurement. While an assistant grasps the top and bottom of the raised tire and attempts to move the tire and wheel horizontally in and out, observe the reading on the dial indicator (Figure 6-12).

Diagnosis of Ride Harshness

When diagnosing a ride harshness condition, check these measurements and components:

1. Curb riding height—insufficient curb riding height causes ride harshness
2. Excessive vehicle load
3. Worn shock absorbers or struts
4. Broken or weak springs
5. Worn suspension bushings, such as strut mounts, control arm bushings, and shock absorber mounting bushings
6. Wheel alignment—excessive positive caster on front wheels causes ride harshness

Noise Diagnosis

A squeaking noise in the rear suspension may be caused by a suspension bushing or a defective strut or shock absorber.

Camber angles are an imaginary line through the centerline of the tire and wheel in relation to the true vertical centerline of the tire.

Caster angles are an imaginary line through the upper and lower ball joint centers in relation to the true vertical tire centerline viewed from the side.



FIGURE 6-11 Dial indicator installed to measure radial ball joint movement.




FIGURE 6-12 Measuring radial ball joint movement.

PHOTO SEQUENCE 9

VERTICAL BALL JOINT MEASUREMENT



P9-1 Place a floor jack under a front, lower control arm, and raise the lower control arm until the front tire is approximately 4 in. (10 cm) off the floor.



P9-2 Lower the lower control arm until it is securely supported on a safety stand, and remove the floor jack.



P9-3 Attach the magnetic base of a dial indicator for measuring ball joints to the safety stand.



P9-4 Position the dial indicator stem against the steering knuckle beside the ball joint stud.



P9-5 Preload the dial indicator stem approximately 0.250 in. (6.35 mm), and zero the dial indicator scale.



P9-6 Position a pry bar under the tire and lift on the tire-and-wheel assembly while a coworker observes the dial indicator. Record the ball joint vertical movement indicated on the dial indicator.



P9-7 Repeat step 6 several times to confirm an accurate dial indicator reading.



P9-8 Compare the ball joint vertical movement indicated on the dial indicator to the vehicle manufacturer's specifications for ball joint wear. If the ball joint vertical movement exceeds specifications, ball joint replacement is necessary.




FIGURE 6-13 Ball joint wear measurement on MacPherson strut front suspension.

The lower ball joint on a MacPherson strut front suspension should be checked for radial movement with a dial indicator when the tire is lifted off the floor (Figure 6-13). Since the spring load is carried by the upper and lower spring seats when the tire is lifted off the floor, it is not necessary to unload this type of ball joint. Photo Sequence 10 shows a typical procedure for measuring the lower ball joint radial movement on a MacPherson strut front suspension.

Checking Ball Joints, Twin I-Beam Axles

Follow these steps to check the ball joints on a twin I-beam axle:

1. Lift the front end of the vehicle with a floor jack and place safety stands near the outer end of the I-beams.
2. Lower the vehicle onto the safety stands.
3. While an assistant grasps the wheel at the bottom and moves the wheel in and out, watch for movement between the lower part of the axle jaw and the spindle lower arm. If this movement exceeds 1/32 in., replace the lower ball joint.
4. As an assistant grasps the top of the wheel and moves the wheel in and out, watch for movement between the upper axle jaw and the spindle upper arm. If this movement exceeds 1/32 in., replace the upper ball joint.

**Classroom
Manual**

Chapter 6, page 121

Front Steering Knuckle Diagnosis and Service, Front-Wheel-Drive Vehicle

Front Steering Knuckle Diagnosis. Steering looseness may be caused by a worn tie-rod end opening or ball joint opening in the steering knuckle. If these knuckle openings are worn, reduced directional stability may be experienced. Since a bent steering knuckle affects front suspension alignment angles, this problem may cause reduced directional stability and tire tread wear. Many steering arm and knuckle assemblies must be replaced as a unit. If the steering arms are bent, knuckle replacement is required.

Steering Knuckle Removal and Replacement. The steering knuckle replacement procedure varies depending on the type of front suspension. Always follow the vehicle manufacturer's steering knuckle replacement procedure in the service manual.

PHOTO SEQUENCE 10


TYPICAL PROCEDURE FOR MEASURING THE LOWER BALL JOINT HORIZONTAL MOVEMENT ON A MACPHERSON STRUT FRONT SUSPENSION




P10-1 Raise the front suspension with a floor jack and place safety stands under the chassis at the vehicle manufacturer's recommended lifting points.




P10-2 Grasp the front tire at the top and bottom and rock the tire inward and outward while a coworker visually checks for movement in the front wheel bearing. If there is movement in the front wheel bearing, adjust or replace the bearing.



P10-3 Position a dial indicator against the inner edge of the rim at the bottom. Preload and zero the dial indicator.



P10-4 Grasp the bottom of the tire and pull outward.



P10-5 With the tire held outward, read the dial indicator.




P10-6 Push the bottom of the tire inward and be sure the dial indicator reading is zero. Adjust the dial indicator as required.



P10-7 Grasp the bottom of the tire and pull outward.



P10-8 With the tire held in this position, read the dial indicator.



P10-9 If the dial indicator reading is more than specified, replace the lower ball joint.

Follow these steps to replace the steering knuckle on a front-wheel-drive vehicle with a MacPherson strut front suspension system:

1. Remove the wheel cover and loosen the front wheel nuts and the drive axle nut.
2. Lift the vehicle chassis on a hoist and allow the front suspension to drop downward. Remove the front wheel, brake caliper, brake rotor, and drive axle nut. Tie the brake caliper to a suspension component. Do not allow the caliper to hang on the end of the brake hose.
3. Remove the inner end of the drive axle from the transaxle with a pulling or prying action. On some Chrysler products, the differential cover must be removed and axle circlips compressed before the drive axle is removed from the transaxle.
4. Remove the outer end of the drive axle from the steering knuckle. On some early model Ford Escorts and Lynx, a puller is required for this operation.
5. Be sure the vehicle weight is supported on the hoist with the front suspension dropped downward. Disconnect the lower ball joint nuts from the mounting bolts in the lower control arm (Figure 6-14).
6. Remove the cotter pin from the outer tie-rod nut (Figure 6-15). Remove the outer tie-rod nut, and then use a puller to disconnect the tie-rod end from the steering knuckle (Figure 6-16).
7. If an eccentric cam is used on one of the strut-to-knuckle bolts, mark the cam and bolt position in relation to the strut, and remove the strut-to-knuckle bolts.
8. Remove the knuckle from the strut, and lift the knuckle out of the chassis (Figure 6-17).




FIGURE 6-14 Removing nuts from lower ball joint mounting bolts under the lower control arm.




FIGURE 6-15 Removing the cotter pin and nut from the outer tie-rod end.




FIGURE 6-16 Removing the outer tie-rod end from the steering knuckle.




FIGURE 6-17 Removing the steering knuckle from the lower control arm.




FIGURE 6-18 Removing dust deflector from the steering knuckle.




FIGURE 6-19 Removing ball joint from the steering knuckle.




FIGURE 6-20 Installing dust deflector in the steering knuckle.



SPECIAL TOOLS

Ball joint puller

9. Pry the dust deflector from the steering knuckle with a large flat-blade screwdriver (Figure 6-18).
10. Use a puller to remove the ball joint from the steering knuckle (Figure 6-19). Check the ball joint and tie-rod end openings in the knuckle for wear and out-of-round. Replace the knuckle if these openings are worn or out-of-round.
11. Use the proper driving tool to reinstall the dust deflector in the steering knuckle (Figure 6-20).
12. Reverse steps 1 through 10 to reinstall the knuckle. Service or replace the wheel bearing as required. (Refer to Chapter 3 for wheel bearing service.) Torque all nuts to specifications and install cotter pins as required.

Front Steering Knuckle Replacement, Rear-Wheel-Drive Vehicle

Proceed as follows for steering knuckle replacement on short-and-long arm front suspension systems with the coil spring positioned between the lower control arm and the frame:

1. Remove the wheel cover and loosen the wheel nuts.
2. Lift the vehicle with a floor jack and place safety stands under the chassis so the front suspension drops downward. Lower the vehicle onto the safety stands and remove the floor jack.
3. Remove the front wheel, brake caliper, and the brake rotor and hub with the wheel bearings. Attach the brake caliper to a chassis component with a piece of wire. Do not allow the caliper to hang on the end of the brake hose.
4. Remove the outer tie-rod cotter pin and nut, and remove the outer tie-rod end from the steering arm.
5. Remove the cotter pins from the upper and lower ball joint nuts and loosen, but do not remove the nuts.



WARNING: During the knuckle replacement procedure, the floor jack supports the spring tension when the ball joints are disconnected from the knuckle. Do not lower the floor jack. Chain the coil spring to the lower control arm as a safety precaution.



SPECIAL TOOLS

Ball joint spreader tool

6. Support the lower control arm with a floor jack, and raise the floor jack until the spring tension is supported by the jack.




FIGURE 6-21 Removing the lower ball joint from the steering knuckle.




FIGURE 6-22 Removing the upper ball joint from the steering knuckle.

7. Remove both ball joint nuts, and remove the ball joint studs from the steering knuckle. A threaded spreader tool may be used to push the upper and lower ball joints from the knuckle (Figures 6-21 and 6-22).
8. Pull upward on the upper control arm to remove the upper ball joint stud from the knuckle. Remove the knuckle from the lower ball joint stud. Check the ball joint and tie-rod end openings in the knuckle for wear and out-of-round. Replace the knuckle if these conditions are present.
9. Reverse steps 1 through 8 to install the steering knuckle. Tighten the ball joint nuts and the outer tie-rod nut to the specified torque, and install the cotter pins in these nuts. Adjust the front wheel bearings, and tighten the wheel nuts to the specified torque.

Ball Joint Replacement

Results of Ball Joint Wear. Worn ball joints affect steering angles and cause reduced directional stability and excessive tire tread wear.

Ball Joint Removal and Replacement. Ball joints may be pressed, bolted (or riveted), or threaded into the control arms (Figure 6-23). The ball joint replacement procedure varies depending on the type of suspension and the method of ball joint attachment. Always follow the vehicle manufacturer's recommended ball joint replacement procedure in the service manual.




FIGURE 6-23 Methods of ball joint attachment.



SERVICE TIP:

Some ball joints have a tapered stud, and a nut is threaded onto the top of this stud to retain the ball joint in the steering knuckle. Other ball joints have a straight stud, and a pinch bolt extends through the steering knuckle and a notch in the side of the ball joint stud to hold the ball joint in the steering knuckle.




SPECIAL TOOLS


Ball joint pressing tools

The following are typical steps that apply to all three methods of ball joint attachment:


1. Remove the wheel cover and loosen the wheel nuts.
2. Lift the vehicle with a floor jack and place safety stands under the chassis so the front suspension is allowed to drop downward. Lower the vehicle onto the safety stands and remove the floor jack.
3. Remove the wheel and place a floor jack under the outer end of the lower control arm. Operate the floor jack and raise the lower control arm until the ball joints are unloaded. Remove other components, such as the brake caliper, rotor, and drive axle, as required to gain access to the ball joints.
4. Remove the cotter pin in the ball joint or joints that requires replacement, and loosen, but do not remove the ball joint stud nuts.
5. Loosen the ball joint stud tapers in the steering knuckle. A threaded expansion tool is available for this purpose.
6. Remove the ball joint nut and lift the knuckle off the ball joint stud. Block or tie up the knuckle and hub assembly to access the ball joint.
7. If the ball joint is riveted to the control arm, drill and punch out the rivets, and bolt the new ball joint to the control arm (Figure 6-24).
8. If the ball joint is pressed into the lower control arm, remove the ball joint dust boot, and use a pressing tool to remove and replace the ball joint (Figures 6-25 and 6-26).
9. If the ball joint housing is threaded into the control arm, use the proper size socket to remove and install the ball joint. The replacement ball joint must be torqued to the manufacturer's specifications. If a minimum of 125 ft.-lbs. of torque cannot be obtained, the control arm threads are damaged and control arm replacement is necessary.
10. If the ball joint is bolted to the lower control arm, install the new ball joint and tighten the bolt and nuts to the specified torque (Figure 6-27).
11. Clean and inspect the ball joint stud tapered opening in the steering knuckle. If this opening is out-of-round or damaged, the knuckle must be replaced.
12. Check the fit of the ball joint stud in the steering knuckle opening. This stud should fit snugly in the opening and only the threads on the stud should extend through the knuckle. If the ball joint stud fits loosely in the knuckle tapered opening, either this opening is worn or the wrong ball joint has been supplied.



Using a 1/8" drill, drill rivets approximately 1/4" deep in center of rivet.



Remove rivets with punch.



Install new ball joint.

Using a 1/2" drill, drill just deep enough to remove rivet head.

FIGURE 6-24 Replacing the riveted ball joint.




FIGURE 6-25 Removing the pressed-in ball joint from the lower control arm.




FIGURE 6-26 Installing the pressed-in ball joint in the lower control arm.




FIGURE 6-27 Installing the ball joint retaining bolts and nuts in the lower control arm.

13. Install the ball joint stud in the steering knuckle opening, making sure the stud is straight and centered. Install the stud nut and tighten this nut to the specified torque. Install a new cotter pin through the stud and nut. Do not loosen the nut to align the nut and stud openings.
14. Reassemble the components that were removed in step 3. Make sure the wheel nuts are tightened to the specified torque.
15. After ball joint replacement, the front suspension alignment should be checked.

CONTROL ARM DIAGNOSIS AND SERVICE

Control Arm Diagnosis and Replacement

Upper and lower control arms should be inspected for cracks, bent conditions, and worn bushings. If the control arm bushings are worn, steering is erratic, especially on irregular road surfaces. Worn control arm bushings may cause a rattling noise while driving on irregular road surfaces. Dry or worn control arm bushings may cause a squeaking noise on irregular road surfaces. Caster and camber angles on the front suspension are altered by worn upper and lower control arm bushings. Incorrect caster or camber angles may cause the vehicle to pull to one side. Tire wear may be excessive when the camber angle is not within specifications.

Lower Control Arm Replacement, MacPherson Strut Suspension

The upper or lower control arm removal and replacement procedure varies depending on the type of suspension. Always follow the recommended procedure in the vehicle manufacturer's service manual.



CAUTION:

Never back off a ball joint stud nut to align the cotter pin openings in the nut and stud. This action may cause the ball joint stud to become loose in the opening where it is mounted. Always tighten the nut to the next hole to install the cotter pin.



SPECIAL TOOLS

Tie-rod end puller

The following is a lower control arm replacement procedure for a MacPherson strut front suspension:

1. Remove the wheel cover and loosen the wheel nuts and drive axle nut.
2. Lift the front of the vehicle with a floor jack and place jack stands under the chassis. Lower the vehicle onto the safety stands and allow the front suspension to drop downward.
3. Remove the front wheel and the front fender apron seal (Figure 6-28). Remove the drive axle nut (Figure 6-29).
4. Remove the cotter pin and nut from the outer tie-rod end, and use a puller to remove this tie-rod end from the steering arm (Figure 6-30).
5. Remove the stabilizer brackets from the lower control arm (Figure 6-31).
6. Remove the lower ball joint nuts and bolts from the lower control arm (Figure 6-32).
7. Remove the drive axle from the axle hub (Figure 6-33), and secure the drive axle to a suspension component with a piece of wire (Figure 6-34). Do not allow the drive axle to hang downward.
8. Remove the two attaching bolts at the front side of the lower control arm (Figure 6-35).
9. Remove the bolt and nut on the rear side of the lower control arm (Figure 6-36), and remove the lower arm bushing stopper from the lower arm shaft.

Reverse steps 1 through 9 to install the replacement control arm. Tighten all bolts and nuts to the specified torque, and install cotter pins as required.

Classroom Manual

Chapter 6, page 120




FIGURE 6-28 Removing the front fender apron seal.




FIGURE 6-29 Removing the drive axle cotter pin, lock, cap, and nut.



FIGURE 6-30 Removing the outer tie-rod end.




FIGURE 6-31 Removing stabilizer brackets from the lower control arm.




FIGURE 6-32 Removing the lower ball joint bolts and nuts from the lower control arm.



FIGURE 6-33 Removing the drive axle from the axle hub.




FIGURE 6-34 Securing the drive axle with a piece of wire.




FIGURE 6-35 Removing the bolts from the front side of the lower control arm.




FIGURE 6-36 Removing the bolt and nut from the rear side of the lower control arm.

Lower Control Arm and Spring Replacement, Short-and-Long Arm Suspension



WARNING: During control arm and spring replacement, the coil spring tension is supported by a compressing tool or floor jack. Always follow the vehicle manufacturer's recommended control arm and spring replacement procedures very carefully. Serious personal injury or property damage may occur if the spring tension is released suddenly.

Broken coil springs may cause a rattling noise while driving on irregular road surfaces. Weak or broken coil springs also reduce curb riding height. A rattling noise while driving on road irregularities may also be caused by worn or broken spring insulators. Since weak or broken coil springs affect front suspension alignment angles, this problem may cause reduced directional stability, excessive tire wear, and harsh riding.

Follow this procedure when a lower control arm and/or spring is replaced on a vehicle with a short-and-long arm suspension system with the coil springs positioned between the lower control arm and the frame:

1. Lift the vehicle on a hoist until the tires are a short distance off the floor, and allow the front suspension to drop downward. An alternate method is to lift the vehicle with a floor jack, and then support the chassis securely on safety stands so the front suspension drops downward.
2. Disconnect the lower end of the shock absorber. On some applications, the shock absorber must be removed.
3. Disconnect the stabilizer bar from the lower control arm.
4. Install a spring compressor and turn the spring compressor bolt until the spring is compressed (Figure 6-37). Make sure all the spring tension is supported by the compressing tool.
5. Place a floor jack under the lower control arm, and raise the jack until the control arm is raised and the rebound bumper is not making contact.
6. Remove the lower ball joint cotter pin and nut, and use a threaded expansion tool to loosen the lower ball joint stud.
7. Lower the floor jack very slowly to lower the control arm and coil spring.



SPECIAL TOOLS

Spring compressing tool, short-and-long arm suspension




FIGURE 6-37 Spring compressing tool installed on a spring in a short-and-long arm suspension system.

8. Disconnect the lower control arm inner mounting bolts, and remove the lower control arm.
9. Rotate the compressing tool bolt to release the spring tension, and remove the spring from the control arm.
10. Inspect the lower control arm for a bent condition or cracks. If either of these conditions is present, replace the control arm. Visually inspect all control arm bushings. Loose or worn bushings must be replaced. Visually inspect upper and lower spring insulators for cracks and wear, and inspect the spring seat areas in the chassis and lower control arm. Worn or cracked spring insulators must be replaced.
11. Reverse steps 1 through 9 to install the lower control arm. Be sure the coil spring and insulators are properly seated in the lower control arm and in the upper spring seat.

Note: See Chapter 5 for strut and spring service.

Upper Control Arm Removal and Replacement, Short-and-Long Arm Suspension System

Proceed as follows when replacing an upper control arm on a short-and-long arm suspension system with the front coil springs located between the lower control arm and the frame:

1. Remove the wheel cover and loosen the wheel nuts.
2. Lift the vehicle with a floor jack and install safety stands under the chassis. Lower the vehicle onto the safety stands so the front suspension drops downward.
3. Remove the front wheel and tire.
4. Place a floor jack under the lower control arm and raise this arm. Make sure the rebound bumper is not making contact.
5. Remove the cotter pin and loosen, but do not remove the upper ball joint nut.
6. Use a threaded expansion tool to loosen the ball joint stud in the control arm. Make sure the floor jack is supporting the spring tension.
7. Remove the ball joint nut and the inner control arm mounting bolts. If shims are located on the inner control arm mounting bolts, note the shim position.
8. Remove the control arm from the chassis.
9. Visually inspect the upper control arm for a bent or cracked condition. Inspect the control arm bushing openings for wear, and replace the control arm if it is bent, cracked, or worn in the bushing areas. Inspect the control arm shaft and bushings for wear, and replace all worn parts (Figure 6-38).
10. Install the control arm and place the original number of shims on the inner mounting bolts. Tighten these bolts to the manufacturer's specifications.



CAUTION:

Since the floor jack is supporting the spring tension, do not lower the floor jack until the ball joint is reconnected and the ball joint nut is tightened to the specified torque.




FIGURE 6-38 Upper control arm components.



SERVICE TIP:

Excessively worn rebound bumpers indicate worn-out shock absorbers, reduced curb riding height, or driving continually on irregular road surfaces.

Rebound bumpers limit the maximum lower control arm movement to prevent coil spring bottoming. Rebound bumpers may be called strikeout bumpers.



SPECIAL TOOLS

Control arm bushing removal, replacement, and flaring tools




FIGURE 6-39 Rebound bumper.

11. Install the ball joint stud in the steering knuckle, and tighten the stud nut to the specified torque.
12. Install the upper ball joint cotter pin and the front wheel. Tighten the wheel nuts to the specified torque.

The front suspension alignment angles should be checked after upper control arm replacement.

Rebound Bumpers

Rebound bumpers are usually bolted to the lower control arm or to the chassis. Inspect the rebound bumpers for cracks, wear, and flattened conditions (Figure 6-39). Damaged rebound bumpers may be caused by sagged springs and insufficient curb riding height or worn-out shock absorbers and struts. If the rebound bumpers must be replaced, remove the mounting bolts and the bumper. Install the new bumper and tighten the mounting bolts to the specified torque.

Front Lower Control Arm Bushing Removal and Replacement

All suspension bushings should be checked periodically for wear, looseness, and deterioration. These bushings are important for providing quiet suspension operation and preventing the transmission of suspension vibration to the chassis and passenger compartment. When a bushing is contained in a steel sleeve, press only on the outer sleeve during the removal and replacement procedure. The control arm bushing removal and replacement procedure varies depending on the type of suspension system. Always follow the vehicle manufacturer's recommended procedure in the service manual. Special bushing removal and replacement tools are required for control arm bushing replacement. A front control arm bushing removal tool and spacer is used to remove the control arm bushing (Figure 6-40). The spacer is installed between the bushing support lugs to prevent distorting these lugs during the bushing removal process.




FIGURE 6-40 Removing the front control arm bushing.

A different tool is required to install the new front control arm bushing (Figure 6-41). The same spacer that is used during the bushing removal is installed between the bushing lugs during bushing installation.

After the front control arm bushing is installed, a bushing flaring tool is used to flare the bushing (Figure 6-42). Notice that a spacer is installed between the bushing lugs during the flaring process. Flaring retains the bushing securely (Figure 6-43).

The rear control arm bushing is replaced with the same procedure as the front control arm bushing. Some of the same special tools are used for rear control arm bushing replacement (Figures 6-44 and 6-45).




FIGURE 6-41 Installing the front control arm bushing.




FIGURE 6-42 Flaring the front control arm bushing.




FIGURE 6-43 Front control arm bushing after flaring.




FIGURE 6-44 Removing the rear control arm bushing.




FIGURE 6-45 Installing the rear control arm bushing.

A **stabilizer bar** may be referred to as a sway bar. It reduces body sway when one wheel strikes a road irregularity.

Classroom Manual

Chapter 6, page 125

Stabilizer Bar Diagnosis and Replacement

Worn **stabilizer bar** mounting bushings, grommets, or mounting bolts cause a rattling noise as the vehicle is driven on irregular road surfaces. A weak stabilizer bar or worn bushings and grommets cause harsh riding and excessive body sway while driving on irregular road surfaces. Worn or very dry stabilizer bar bushings may cause a squeaking noise on irregular road surfaces. All stabilizer bar components should be visually inspected for wear. Stabilizer bar removal and replacement procedures vary depending on the vehicle. Always follow the vehicle manufacturer's recommended procedure in the service manual.

The following is a typical stabilizer bar removal and replacement procedure:

1. Lift the vehicle on a hoist and allow both sides of the front suspension to drop downward as the vehicle chassis is supported on the hoist.
2. Remove the mounting bolts at the outer ends of the stabilizer bar and remove the bushings, grommets, brackets, or spacers (Figure 6-46).
3. Remove the mounting bolts in the center area of the stabilizer bar.
4. Remove the stabilizer bar from the chassis.
5. Visually inspect all stabilizer bar components, such as bushings, bolts, and spacer sleeves. Replace the stabilizer bar, grommets, bushings, brackets, or spacers as required. Split bushings may be removed over the stabilizer bar. Bushings that are not split must be pulled from the bar.
6. Reverse steps 2 through 4 to install the stabilizer bar. Make sure all stabilizer bar components are installed in the original position, and tighten all fasteners to the specified torque.

Some vehicle manufacturers specify that stabilizer bars must have equal distances between the outer bar ends and the lower control arms. Always refer to the manufacturer's recommended measurement procedure. If this measurement is required, adjust the nut on the outer stabilizer bar mounting bolt until equal distances are obtained between the outer bar ends and the lower control arms. Worn grommets cause these distances to be unequal.

Strut Rod Diagnosis and Replacement

A **strut rod** prevents fore-and-aft lower control arm movement.

Some front suspension systems have a **strut rod** connected from the lower control arm to the frame. Rubber grommets isolate the rod from the chassis components. Worn strut rod grommets may allow the lower control arm to move rearward or forward. This movement changes the caster angle, which may affect steering quality and cause the vehicle to pull to one side. A bent strut rod also causes steering pull. Worn strut rod grommets or loose mounting bolts cause a rattling noise while driving on irregular road surfaces. Inspect the strut rod grommets




FIGURE 6-46 Stabilizer bar components.




FIGURE 6-47 Strut rod.

visually for wear and deterioration. With the vehicle lifted on a hoist, grasp the strut rod firmly and apply vertical and horizontal force to check the rod and grommets for movement. Worn grommets must be replaced. If a strut rod is bent, replace the rod.

Follow these steps for strut rod replacement:

1. Lift the vehicle on a hoist.
2. Remove the strut rod nut from the front end of the rod.
3. Remove the strut rod bolts from the lower control arm.
4. Pull the strut rod rearward to remove the rod (Figure 6-47).
5. Remove the bushings from the opening in the chassis.
6. Visually inspect the strut rod, bushings, washers, and retaining bolts. Replace all worn parts. Reverse steps 1 through 5 to reinstall the strut rod. Tighten the strut rod nut and bolts to the specified torque.

Since strut rod and bushing conditions affect front suspension alignment, check front suspension alignment after strut rod service.

Front Leaf Spring Inspection and Replacement

Front leaf springs are used in some truck suspension systems. These springs are mounted longitudinally with a spring on each side of the suspension. Many leaf springs have plastic silencers between the spring leaves. If these silencers are worn out, creaking and squawking noises will be heard when the vehicle is driven over road irregularities at low speeds.

When the silencers require checking or replacement, lift the vehicle with a floor jack and support the frame on safety stands so the suspension hangs downward. With the vehicle weight no longer applied to the springs, the spring leaves may be pried apart with a pry bar to remove and replace the silencers. On some leaf springs, the clamps must be removed to replace the silencers.

Leaf springs should be inspected for a sagged condition, which causes the curb riding height to be less than specified. Leaf springs should also be visually inspected for broken leaves, broken center bolts, and worn shackles or bushings. Weak or broken leaf springs affect front suspension alignment angles and cause excessive tire tread wear, reduced directional stability, and harsh riding. A rattling noise while driving on irregular road surfaces may be caused by worn shackles or bushings. A broken center bolt usually allows one side of the front suspension to move rearward in relation to the other side. This action may cause steering pull to one side. Worn shackles and bushings lower curb riding height and cause a rattling noise on road irregularities.




FIGURE 6-48 Front leaf spring.

The following is a typical front leaf spring replacement procedure:

1. Lift the front end of the vehicle with a floor jack under the front axle and place safety stands under the frame. Lower the vehicle weight onto the safety stands, but leave the floor jack under the front axle to support some of the front suspension weight.
2. Remove the nuts from the spring U-bolts, and remove the U-bolts and lower spring plate. If the spring plate is attached to the shock absorber, this plate may be left on the shock absorber and moved out of the way. If shims are positioned between the spring plate and the front axle, be sure to note the position and the number of shims. These shims must be reinstalled in their original position because they set the front wheel caster angle.
3. Be sure the floor jack is lowered enough to relieve the vehicle weight from the springs.
4. Remove the front shackle assembly.
5. Remove the rear spring mounting bolt, and remove the spring from the chassis (Figure 6-48).
6. Check all the spring hangers, bolts, bushings, and shackle plates for wear, and replace as required. Springs with broken or sagged leaves are usually sent to a spring rebuilding shop for repair.
7. Check the spring center bolt to be sure it is not broken.
8. Reverse steps 1 through 5 to install the front springs. Tighten all bolts to the manufacturer's specifications.

REMOVING AND REPLACING LONGITUDINALLY MOUNTED TORSION BARS

Worn torsion bar components, such as pivot cushion bushings and control arm bushings, result in harsh riding and suspension noise when driving on road irregularities. A worn torsion bar hex and anchor may cause a rattling noise while driving on irregular road surfaces. Weak torsion bars or those with worn bushings or anchors cause reduced curb riding height, which may result in reduced directional stability and excessive tire tread wear. Always follow the vehicle manufacturer's recommended procedure in the service manual for torsion bar removal and replacement.

The following is a typical torsion bar removal and replacement procedure:



WARNING: Some torsion bar front suspension systems on sport utility vehicles (SUVs) are combined with an air suspension system. When servicing these systems, the air suspension switch in the rear jack storage area must be shut off before performing any suspension service or hoisting, jacking, or towing the vehicle. If this procedure is not followed, personal injury and vehicle damage may occur.




FIGURE 6-49 Torsion bar cover plate.




FIGURE 6-50 Measuring the torsion bar adjusting bolt position.




FIGURE 6-51 Torsion bar tool and adapters.

1. Raise the vehicle on a lift with the tires supported on the lift.
2. Remove the torsion bar cover plate bolts and the cover plate (Figure 6-49).
3. Measure and record the distance from the lip on the head of the torsion bar adjusting bolt to the casting surface this bolt is threaded into (Figure 6-50). When reinstalled, this bolt must be adjusted to this same measurement.
4. Install the torsion bar tool and adapters (Figure 6-51). Tighten this tool until the torsion bar adjuster lifts off the adjustment bolt.
5. Remove the torsion bar adjustment bolt and nut.
6. Loosen the torsion bar tool to remove all the tension from the torsion bar (Figure 6-52).
7. Use the end of a screwdriver to place matching alignment marks on the torsion bar and the adjuster so these components may be reassembled in the same position. Remove the torsion bar insulator. Pull the torsion bar to the rear to remove this bar from the lower control arm.
8. Position the torsion bar in the lower control arm.
9. Install the torsion bar adjuster on the torsion bar with the alignment marks properly aligned (Figure 6-53).



CAUTION:

The torsion bar adjusting bolt is coated with a dry adhesive. This bolt must be replaced if it is backed off or removed. Failure to follow this procedure may cause the bolt to loosen during operation, resulting in improper wheel alignment, reduced steering control, increased tire wear, and reduced ride quality.




FIGURE 6-52 Loosening the torsion bar tool.



FIGURE 6-53 Alignment marks placed on the torsion bar and adjuster.

10. Install the torsion bar tool and adapters. Tighten the torsion bar tool until a new adjustment bolt can be installed. Tighten this bolt until the measurement obtained in step 3 is obtained between the head of the bolt and the casting the bolt is threaded into.
11. Install the torsion bar cover plate, and tighten the plate retaining bolts to the specified torque.
12. Measure the suspension riding height as explained previously this chapter. If the suspension riding height is not within specifications, adjust the torsion bar adjusting bolt to obtain the specified riding height.

TABLE 6-1 FRONT SUSPENSION DIAGNOSIS

Problem	Symptoms	Possible Causes
Low riding height	Harsh ride quality, worn strikeout bumpers	Weak springs, worn control arm bushings, bent control arms, improper torsion bar adjustment
Steering wander, excessive edge wear on front tires	Erratic steering control when driving straight ahead	Worn ball joints, worn suspension or steering components, improper wheel alignment
Suspension noise	Rattling or squeaking noise when driving on road irregularities	Worn or dry stabilizer bar links and bushings, worn shock absorber or strut rod bushings
Improper steering control	Steering pull to the left or right when driving straight ahead	Improper wheel alignment, worn control arm bushings, bent control arms
Improper steering control while braking	Steering pull to the left or right only when braking	Worn strut rod bushings, loose strut rod mounting, worn lower control arm bushings
Leaf spring noise	Squeaking noise when driving on road irregularities	Worn silencers between the spring leaves

TERMS TO KNOW

Ball joint vertical movement
 Ball joint wear indicator
 Camber angles
 Caster angles
 Curb riding height
 Directional stability
 Rebound bumpers
 Stabilizer bar
 Steering effort
 Strut rod

CASE STUDY

A customer complained about steering pull to the left while braking on a 2009 Chrysler 300. The technician questioned the customer about other symptoms, but the customer stated that the steering did not pull while driving, and the car had no other problems. Further questioning of the customer revealed that extensive brake work had been done in an attempt to correct the problem. The front brake pads had been replaced and the front brake rotors had been turned.

While performing a road test, the technician discovered the car had a definite pull to the left while braking, but the steering was normal while driving. During the road test, no other problems were evident. The technician removed the front wheels and brake rotors. A careful examination of the brake

linings and rotor surfaces indicated these components were in excellent condition. The technician checked the rotor surfaces to be sure they were both in the same condition. The pistons in both front calipers moved freely. An inspection of the brake lines and hoses did not reveal any visible problems, and a pressure check at each front brake caliper indicated equal pressures at both front wheels during a brake application.

Next, the technician made a visual inspection of the steering and suspension components and discovered a worn, loose left front tension rod bushing. This tension rod was replaced, and the strut rod nut tightened to the specified torque. A road test of the car indicated no steering pull during brake application.

ASE-STYLE REVIEW QUESTIONS

1. While discussing curb riding height:
Technician A says worn control arm bushings reduce curb riding height.
Technician B says incorrect curb riding height affects most other front suspension angles.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
2. The shoulder on the ball joint grease fitting is inside the ball joint cover:
Technician A says the ball joint should be replaced.
Technician B says a longer grease fitting should be installed.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
3. While discussing ball joint unloading on a short-and-long arm suspension system with the coil springs between the lower control arm and the chassis:
Technician A says a steel spacer should be installed under the upper control arm.
Technician B says a floor jack should be placed under the lower control arm to unload the ball joints.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
4. While discussing ball joint radial measurement:
Technician A says the dial indicator should be positioned against the top of the ball joint stud.
Technician B says the front wheel bearing adjustment does not affect the ball joint radial measurement.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
5. While discussing ball joint installation:
Technician A says the ball joint nut may be backed off to install the cotter pin.
Technician B says only the ball joint threads should extend above the opening in the steering knuckle.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
6. When installing a new threaded ball joint in a lower control arm, the technician can only torque the ball joint to 90 ft.-lbs. The necessary repair for this problem is to:
A. Weld the ball joint into the control arm.
B. Place Loctite on the ball joint threads.
C. Replace the lower control arm.
D. Install a larger diameter ball joint.
7. All of these defects could result in worn-out rebound bumpers EXCEPT:
A. Sagged springs.
B. Worn-out shock absorbers.
C. Continual driving on rough roads.
D. Curb riding height more than specified.
8. When removing and replacing control arm bushings:
A. If the bushing is contained in a steel sleeve, press on the rubber bushing.
B. A spacer should be installed between the control arm support lugs during bushing removal and installation.
C. The same tool is used for bushing removal and replacement.
D. Bushing flaring is necessary to expand the bushing.
9. A car experiences excessive body sway when cornering, but there is no abnormal noise in the suspension. The most likely cause of this problem is:
A. Stabilizer bar bushing is missing.
B. A weak stabilizer bar.
C. Stabilizer bar grommets are worn out.
D. A broken stabilizer bar.
10. The steering on a vehicle pulls to the left while driving straight ahead. The most likely cause of this problem is:
A. The left front strut rod is bent.
B. The left lower ball joint is worn.
C. Worn front stabilizer bushings on the left side.
D. Reduced curb riding height on both sides of the front suspension.

ASE CHALLENGE QUESTIONS

1. The customer says her 2009 Silverado truck with front torsion bar suspension pulls to the left. A cursory check of the vehicle shows that the right front tire height is too low. The next step to diagnose the condition would be:
A. Check the ball joints.
B. Check the torsion bar.
C. Check the strut rod bushings.
D. Check the stabilizer bar bushings.
2. A customer says her front-wheel-drive car has a steering wander problem on irregular road surfaces. All of the following could cause this problem EXCEPT:
A. Worn stabilizer bar bushings.
B. Worn ball joints.
C. Worn strut rod bushings.
D. Worn tie-rod ends.
3. While diagnosing a customer's complaint of steering instability on a MacPherson strut front suspension with wear indicator-type ball joints, an inspection of the ball joints shows the grease fittings to be solid.
Technician A says no movement of the fitting means the ball joint is good.

Technician B says ball joint wear may not be apparent with the weight on the joint.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

4. A customer says her rear-wheel-drive car has excessive body sway while cornering. In diagnosing this problem, which of the following components should you check first?
A. Control arm bushings.
B. Strut rod bushings.
C. Stabilizer bar bushings.
D. Shock absorber bushings.
5. *Technician A* says a bent strut rod can cause a car to pull to one side.
Technician B says a deteriorated strut rod bushing can cause steering and braking problems.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

Name _____ Date _____

MEASURE LOWER BALL JOINT VERTICAL AND HORIZONTAL MOVEMENT, SHORT-AND-LONG ARM SUSPENSION SYSTEMS

Upon completion of this job sheet, you should be able to measure ball joint wear and determine the necessary ball joint service.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task C-5. Remove, inspect, and install upper and/or lower ball joints.

Tools and Materials

Ball joint dial indicator
Floor jack
Safety stands

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Raise the front of the vehicle with a floor jack lift pad positioned on the specified lifting point. ☐
2. Install safety stands near the outer ends of the lower control arms. Lower the floor jack so the control arms are supported on the safety stands. Remove the floor jack. ☐
3. Attach a dial indicator for ball joint measurement to the lower control arm, and position the dial indicator stem against the lower end of the steering knuckle next to the ball joint retaining nut if the suspension has a lower compression-loaded ball joint. When the suspension has a tension-loaded ball joint, place the indicator stem against the top of the ball joint stud.

Type of ball joint _____

Dial indicator stem position _____

4. Preload the dial indicator stem 0.250 in. (6.35 mm), and zero the dial indicator.

Is the dial indicator preloaded and placed in the zero position? ☐ Yes ☐ No

Instructor check _____

5. Place a pry bar under the front tire and lift straight upward on the pry bar while a coworker observes the dial indicator. ☐
6. Compare the reading on the dial indicator with the vehicle manufacturer's specifications. If the vertical ball joint movement exceeds specifications, replace the ball joint. ☐

Task Completed

Specified ball joint vertical movement

Actual ball joint vertical movement

Necessary ball joint service

☐**7.** Be sure the front wheel bearings are properly adjusted.**8.** Attach the dial indicator to the lower control arm, and position the dial indicator against the inner edge of the wheel rim. Preload the dial indicator 0.250 in. (6.35 mm) and place the dial in the zero position.Is the dial indicator preloaded and placed in the zero position? ☐ Yes ☐ No

Instructor check _____

☐**9.** Grasp the tire at the top and bottom, and try to rock the tire inward and outward while a coworker observes the dial indicator.☐**10.** Compare the reading on the dial indicator to the vehicle manufacturer's specifications. If the horizontal ball joint movement exceeds specifications, replace the ball joint.

Specified ball joint horizontal movement

Actual ball joint horizontal movement

☐**11.** Repeat the measurements in steps 3 through 10 on the opposite side of the front suspension.**12.** Based on your ball joint measurements, state all the necessary ball joint service and explain the reasons for your diagnosis.

Instructor's Response _____

Name _____ Date _____

BALL JOINT REPLACEMENT

Upon completion of this job sheet, you should be able to remove and replace ball joints.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task C-5. Remove, inspect, and install upper and/or lower ball joints.

Tools and Materials

Floor jack Ball joint loosening tool
Safety stands Torque wrench

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Remove the wheel cover and loosen the wheel nuts.
2. Lift the vehicle with a floor jack and place safety stands under the chassis so the front suspension is allowed to drop downward. Lower the vehicle onto the safety stands and remove the floor jack.
3. Remove the wheel and place a floor jack under the outer end of the lower control arm. Operate the floor jack and raise the lower control arm until the ball joints are unloaded.

☐
☐

Are the ball joints properly unloaded? ☐ Yes ☐ No

Instructor check _____

4. Remove other components, such as the brake caliper, rotor, and drive axle, as required to gain access to the ball joints.
5. Remove the cotter pin in the ball joint or joints that require replacement, and loosen, but do not remove, the ball joint stud nuts.

☐

Is the ball joint stud nut loosened? ☐ Yes ☐ No

Instructor check _____

6. Loosen the ball joint stud tapers in the steering knuckle. A threaded expansion tool is available for this purpose.

Are the ball joint stud tapers loosened? ☐ Yes ☐ No

Instructor check _____

7. Remove the ball joint nut and lift the knuckle off the ball joint stud. Block or tie up the knuckle and hub assembly to access the ball joint.

☐

Task Completed

☐☐

8. If the ball joint is riveted to the control arm, drill and punch out the rivets and bolt the new ball joint to the control arm.
9. If the ball joint is pressed into the lower control arm, remove the ball joint dust boot and use a pressing tool to remove and replace the ball joint.
10. If the ball joint housing is threaded into the control arm, use the proper size socket to remove and install the ball joint. The replacement ball joint must be torqued to the manufacturer's specifications. If a minimum of 125 ft.-lbs. of torque cannot be obtained, the control arm threads are damaged and control arm replacement is necessary.

Ball joint torque, threaded ball joint _____

Control arm condition, threaded ball joint: ☐ Satisfactory ☐ Unsatisfactory

11. If the ball joint is bolted to the lower control arm, install the new ball joint and tighten the bolt and nuts to the specified torque.

Ball joint bolt torque _____

☐

12. Clean and inspect the ball joint stud tapered opening in the steering knuckle. If this opening is out-of-round or damaged, the knuckle must be replaced.

Condition of ball joint stud opening in the steering knuckle:

☐ Satisfactory ☐ Unsatisfactory

13. Check the fit of the ball joint stud in the steering knuckle opening. This stud should fit snugly in the opening and only the threads on the stud should extend through the knuckle. If the ball joint stud fits loosely in the knuckle tapered opening, either this opening is worn or the wrong ball joint has been supplied.

Ball joint stud smooth tapered area appearing above steering knuckle surface:

☐ Yes ☐ No

If the answer to this question is yes, state the necessary repairs and explain the reason for your diagnosis.

Ball joint stud fit in the steering knuckle opening:

☐ Satisfactory ☐ Unsatisfactory

If the ball joint stud fit in the steering knuckle opening is unsatisfactory, state the necessary repairs and explain the reason for your diagnosis.

14. Install the ball joint stud in the steering knuckle opening, making sure the stud is straight and centered. Install the stud nut and tighten this nut to the specified torque. Install a new cotter pin through the stud and nut. Do not loosen the nut to align the nut and stud openings.



CAUTION:

Never back off a ball joint stud to align the cotter pin openings in the nut and stud. This may cause the ball joint stud to loosen, resulting in a suspension failure. Always tighten the nut to the next hole to install the cotter pin.

Specified ball joint nut torque _____

Actual ball joint nut torque _____

Is a new cotter pin properly installed? ☐ Yes ☐ No

Instructor check _____

- 15.** Reassemble the components that were removed in step 4. Make sure the wheel nuts are tightened to the specified torque.

Specified wheel nut torque _____

Actual wheel nut torque _____

Instructor's Response _____

Name _____ Date _____

STEERING KNUCKLE REMOVAL, MACPHERSON STRUT FRONT SUSPENSION

Upon completion of this job sheet, you should be able to remove the steering knuckle and determine knuckle condition on McPherson strut front suspension systems.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task C-6. Remove, inspect, and install steering Knuckle assemblies.

Tools and Materials

Floor jack Torque wrench
Safety stands Driving tools
Tire-rod end puller

Procedure

Task Completed
☐

1. Remove the wheel cover and loosen the front wheel nuts and the drive axle nut.
2. Lift the vehicle chassis on a hoist and allow the front suspension to drop downward. Remove the front wheel, brake caliper, brake rotor, and drive axle nut. Tie the brake caliper to a suspension component; do not allow the caliper to hang on the end of the brake hose.

Is the vehicle weight supported on hoist with front suspension dropped downward?
☐ Yes ☐ No

Instructor check _____

3. Remove the inner end of the drive axle from the transaxle with a pulling or prying action. On some Chrysler products, the differential cover must be removed and axle circlips compressed prior to drive axle removal from the transaxle.

Is the inner end of drive axle removed from transaxle? ☐ Yes ☐ No

Instructor check _____

4. Remove the outer end of the drive axle from the steering knuckle and hub. On some early model Ford Escorts and Lynx, a puller is required for this operation.

Is the outer end of drive axle removed from steering knuckle and hub?
☐ Yes ☐ No

Instructor check _____

5. Be sure the vehicle weight is supported on the hoist with the front suspension dropped downward. Remove the ball joint retaining nuts in the lower control arm.

Are the lower ball joint retaining nuts removed? ☐ Yes ☐ No

Instructor check _____

Task Completed

6. Remove the cotter pin from the tie-rod nut. Remove the outer tie-rod nut and use a puller to disconnect the tie-rod end from the steering knuckle.

Is the outer tie-rod end removed? ☐ Yes ☐ No

Instructor check _____

7. If an eccentric cam is used on one of the strut-to-knuckle bolts, mark the cam and bolt position in relation to the strut and remove the strut-to-knuckle bolts.

Is the eccentric camber marked in relation to the strut? ☐ Yes ☐ No

Instructor check _____

- ☐ 8. Remove the knuckle from the strut and lift the knuckle out of the chassis.

- ☐ 9. Pry the dust deflector from the steering knuckle with a large flat-blade screwdriver.

10. Use a puller to remove the ball joint from the steering knuckle. Check the ball joint and tie-rod end openings in the knuckle for wear and out-of-round. Replace the knuckle if these openings are worn or out-of-round.

Condition of ball joint opening in the knuckle:

☐ Satisfactory ☐ Unsatisfactory

Condition of tie-rod end opening in the knuckle:

☐ Satisfactory ☐ Unsatisfactory

State the necessary steering knuckle and related repairs, and explain the reason for your diagnosis.

- ☐ 11. Use the proper driving tool to reinstall the dust deflector in the steering knuckle.

Instructor's Response _____

Chapter 7

REAR SUSPENSION SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Diagnose rear suspension noises.
- Diagnose rear suspension sway and lateral movement.
- Measure and correct rear suspension curb riding height.
- Remove and replace rear coil springs.
- Inspect rear springs, insulators, and seats.
- Inspect strut or shock absorber bushings and upper mount, and replace strut cartridge.
- Remove, inspect, and replace lower control arms.
- Inspect, remove, and replace rear ball joints.
- Inspect, remove, and replace suspension adjustment links.
- Diagnose, remove, and replace rear leaf springs.
- Diagnose, remove, and replace stabilizer bars.
- Diagnose, remove, and replace track bars.
- Inspect, remove, and replace tie-rods.

Rear suspension system diagnosis and service is extremely important to maintain vehicle safety, ride quality, and tire life. Many rear suspension components may create a safety hazard if they are not serviced properly. For example, if wheel nuts or spindle nuts are not tightened properly, a wheel assembly may come off the vehicle with disastrous results. Improper rear suspension curb riding height, worn struts or shock absorbers, and sagged or broken springs will result in harsh ride quality. Rear wheel toe and camber must be adjusted to specifications to provide normal tire tread life.

Diagnosis of Ride Harshness

When diagnosing a ride harshness condition, check these measurements and components:

1. Curb riding height—insufficient curb riding height causes ride harshness
2. Excessive vehicle load
3. Worn shock absorbers or struts
4. Broken or weak springs
5. Worn suspension bushings, such as strut mounts, control arm bushings, and shock absorber mounting bushings
6. Wheel alignment—excessive positive caster on front wheels causes ride harshness

Noise Diagnosis

A squeaking noise in the rear suspension may be caused by a suspension bushing or a defective strut or shock absorber.



BASIC TOOLS

Basic technician's tool set

Service manual

Machinist's rule

Floor jack

Safety stands

Transmission jack

Foot-pound torque wrench

Pry bar

Body sway is leaning of the chassis to one side.



SERVICE TIP:

Proper curb riding height must be maintained to provide normal steering quality and tire wear.

Classroom Manual

Chapter 7, page 162

If a rattling noise occurs in the rear suspension, check these components:

1. Worn or missing suspension bushings, such as control arm bushings, track bar bushings, stabilizer bar bushings, trailing arm bushings, and strut rod bushings
2. Worn strut or shock absorber bushings or mounts
3. Defective struts or shock absorbers
4. Broken springs or worn spring insulators
5. Broken exhaust system hangers or improperly positioned exhaust system components

Special tools can be used to locate noises at any location on the vehicle. A ChassisEar tool has six clamp-on sensors that are miniature microphones (Figure 7-1). These six sensors are connected to a switchbox that is also connected to a headset worn by the technician. The technician can rotate the switch on the switchbox to connect any sensor to the headset. The sensors can be mounted on various suspected noise sources. When the control on the switchbox is rotated, the technician can determine which sensor is connected to the noise source.

An electronic stethoscope can be used to locate the source of a noise. This tool has one pickup that is placed on or near a suspected noise source. The pickup is connected to an amplifier box, and the headset is also connected to this box (Figure 7-2). When the pickup is placed on the source of a noise, the noise is amplified in the headset.

Sway and Lateral Movement Diagnosis

Excessive **body sway**, or roll, on road irregularities may be caused by a weak stabilizer bar or loose stabilizer bar bushings. If lateral movement is experienced on the rear of the chassis, the track bar or track bar bushings may be defective. Lateral movement is sideways movement.

Curb Riding Height Measurement

Regular inspection and proper maintenance of suspension systems are extremely important to maintaining vehicle safety. The curb riding height is determined mainly by spring condition. Other suspension components, such as control arm bushings, affect curb riding height if they are worn. *Since incorrect curb riding height affects most of the other suspension angles, this measurement is critical.* Reduced rear suspension height increases steering effort and causes rapid steering wheel return after turning a corner. Harsh riding occurs when the curb riding height is less than specified. The curb riding height must be measured at the vehicle



FIGURE 7-1 ChassisEar tool for locating noise sources.



FIGURE 7-2 Electronic stethoscope.




FIGURE 7-3 Curb riding height measurement, rear suspension.

manufacturer's specified location, which varies depending on the type of vehicle and suspension system. On some vehicles, the curb riding height on the rear suspension is measured from the floor to the center of the strut rod mounting bolt when the vehicle is on a level floor or an alignment rack (Figure 7-3). Photo Sequence 11 shows a typical procedure for measuring front and rear curb riding height.

Rear Strut, Coil Spring, and Upper Mount Diagnosis and Service

WARNING: When the rear coil springs are mounted on the struts, never loosen the upper strut nut until all the spring tension is removed from the upper support with a spring compressor. If this nut is removed with spring tension on the upper support, the spring tension turns the spring and the upper support into a dangerous projectile, which may cause serious personal injury and/or property damage.

Weak springs cause harsh riding and reduced curb riding height. Broken springs or spring insulators cause a rattling noise while driving on road irregularities. Worn-out struts or shock absorbers cause excessive chassis oscillations and harsh riding. (Refer to Chapter 5 for strut and shock absorber service.) Loose or worn strut or shock absorber bushings cause a rattling noise on road irregularities. The rear coil spring removal and replacement procedure varies depending on the type of rear suspension system. Always follow the vehicle manufacturer's recommended procedure in the service manual.

The following is a typical rear strut and spring removal and replacement procedure on a MacPherson strut independent rear suspension system with the coil springs mounted on the struts:

1. Remove the rear seat and the package trim tray (Figure 7-4).
2. Remove the wheel cover, and loosen the wheel nuts.
3. Lift the vehicle with a floor jack, and lower the chassis onto safety stands so the rear suspension is allowed to drop downward.
4. Place a floor jack lift pad under the rear spindle on the side where the strut and spring removal is taking place. Raise the floor jack to support some of the suspension system weight (Figure 7-5).
5. Remove the rear wheel, disconnect the nut from the small spring in the lower arm (Figure 7-6), and remove the brake hose and antilock brake system (ABS) wire from the strut (Figure 7-7).
6. Remove the stabilizer bar link from the strut (Figure 7-8), and loosen the strut-to-spindle mounting bolts (Figure 7-9).
7. Remove the three upper support nuts under the package tray trim (Figure 7-10), and lower the floor jack to remove the strut from the knuckle (Figure 7-11). Remove the strut from the chassis.




SERVICE TIP:

If the plastic coating on a coil spring is chipped, the spring may break prematurely. The spring may be taped in the compressing tool contact areas to prevent chipping.

PHOTO SEQUENCE 11

TYPICAL PROCEDURE FOR MEASURING FRONT AND REAR CURB RIDING HEIGHT



P11-1 Check the trunk for extra weight.



P11-2 Check the tires for normal inflation pressure.



P11-3 Park the car on a level shop floor or alignment rack.



P11-4 Find the vehicle manufacturer's specified curb riding height measurement locations in the service manual.



P11-5 Measure and record the right front curb riding height.



P11-6 Measure and record the left front curb riding height.



P11-7 Measure and record the right rear curb riding height.



P11-8 Measure and record the left rear curb riding height.



P11-9 Compare the measurement results to the specified curb riding height in the service manual.




FIGURE 7-4 Rear suspension with rear seat and package trim tray.




FIGURE 7-6 Disconnecting nut from small spring in the lower arm.

FIGURE 7-5 Floor jack supporting some of the rear suspension weight.

8. Following the vehicle or equipment manufacturer's recommended procedure, install a spring compressing tool on the coil spring, and tighten the tool until all the spring tension is removed from the upper support (Figure 7-12).
9. Operate the compressing tool to remove all the spring tension from the upper strut mount and then remove the strut rod nut (Figure 7-13).
10. Remove the strut rod nut, upper support, and upper insulator.
11. Remove the strut from the lower end of the spring.
12. If the spring is to be replaced, rotate the compressing tool handle until all the spring tension is removed from the compressing tool, and then remove the spring from the tool.



SPECIAL TOOLS

Coil-spring
compressor




FIGURE 7-7 Disconnecting brake hose and ABS wire from the rear strut.




FIGURE 7-8 Removing stabilizer bar from the rear strut.




FIGURE 7-9 Loosening strut-to-rear spindle bolts.




FIGURE 7-10 Removing upper mount nuts.

Classroom Manual

Chapter 7, page 151

13. Inspect the lower insulator and spring seat on the strut (Figure 7-14). If the spring seat is warped or damaged, replace the strut. A new cartridge may be installed in some rear struts. (The strut cartridge replacement procedure is explained in Chapter 5.)
14. Visually inspect the upper mount, insulator, and spring bumper. If any of these components are damaged, worn, or distorted, replacement is necessary. Worn upper mounts and insulators or damaged spring seats cause suspension noise while driving on road irregularities. Assemble the spring bumper, upper mount, and insulator (Figure 7-15), and then compress the coil spring in the compressing tool. Assemble the strut and related components into the spring (Figure 7-16). Tighten all fasteners to the specified torque. Photo sequence 12 illustrates the proper procedure for removing a rear strut and spring.




FIGURE 7-11 Removing the strut from the rear spindle.




FIGURE 7-12 A spring compressing tool is used to compress the coil spring.




FIGURE 7-13 After the compressing tool is operated to remove all the spring tension, remove the strut rod nut.




FIGURE 7-14 Inspecting lower spring seat and insulator.



FIGURE 7-15 Assembly of rear strut, spring bumper, spring, upper mount, and insulator.




FIGURE 7-16 Compressing the coil spring in the compressing tool prior to strut-and-spring assembly.

CUSTOMER CARE: When talking to customers, always remember the two Ps, pleasant and polite. There may be many days when we do not feel like being pleasant and polite. Perhaps we have several problem vehicles in the shop with symptoms that are difficult to diagnose and correct. Some service work may be behind schedule, and customers may be irate because their vehicles are not ready on time. However, we should always remain pleasant and polite with customers. Our attitude does much to make the customer feel better and realize their business is appreciated. A customer may not feel very happy about an expensive repair bill, but a pleasant attitude on our part may help improve the customer's feelings. When the two Ps are remembered by service personnel, customer relations are enhanced, and the customer will return to the shop. Conversely, if service personnel have a grouchy, indifferent attitude, the customer may be turned off and take his or her business to another shop.

LOWER CONTROL ARM AND BALL JOINT DIAGNOSIS AND REPLACEMENT

Worn bushings on the lower control arms may cause incorrect rear wheel camber or toe, which results in rear tire wear and steering pull. Bent lower control arms must be replaced. When ball joints with **wear indicators** are in normal condition, there is 0.050 in. (1.27 mm) between the grease nipple shoulder and the cover. If the ball joint is worn, the grease nipple shoulder is flush with or inside the cover (Figure 7-17). A worn ball joint causes improper rear wheel toe and/or camber, which may result in tire tread wear or steering pull.

The lower control arm removal and replacement procedure varies depending on the vehicle and the type of suspension. Always follow the vehicle manufacturer's recommended procedure in the service manual.

The following is a typical lower control arm removal procedure:

1. Lift the vehicle on a hoist with the chassis supported on the hoist and the control arms dropped downward. The vehicle may be lifted with a floor jack, and the chassis supported on safety stands.
2. Remove the tire-and-wheel assembly.

Wear indicators show ball joint wear by the position of the grease fitting in the ball joint.

PHOTO SEQUENCE 12


TYPICAL PROCEDURE FOR REMOVING A REAR STRUT-AND-SPRING ASSEMBLY ON A FRONT-WHEEL-DRIVE CAR



P12-1 Remove the left rear wheel cover, and loosen the wheel nuts on the left rear wheel.



P12-2 Raise the vehicle on a frame-contact lift and chalk mark one of the left rear wheel studs in relation to the wheel, and remove the wheel nuts followed by the wheel-and-tire assembly.



P12-3 Remove the left rear brake caliper, and use a piece of wire to suspend the caliper from a chassis member. Do not allow the caliper to hang from the flexible brake hose.



P12-4 If the vehicle is equipped with antilock brakes, remove the left rear speed sensor wire, routing tube, and bracket from the trailing arm.



P12-5 Remove both forward and rearward lateral lower link-to-spindle attaching bolts by installing a thin open-end wrench on the hex of the attaching link stud to prevent the stud from turning and then remove the lateral link-to-spindle attaching bolts.



P12-6 Use an open-end wrench to hold the left rear stabilizer bar attaching link stud from turning, and remove the stabilizer bar attaching link nut. Disconnect the stabilizer bar from the attaching link stud.



P12-7 Remove the nut from the strut-to-spindle pinch bolt, and remove the pinch bolt.




P12-8 Tap a center punch into the slot in the lower end of the strut to spread the strut opening slightly. Be sure the inner end of the punch does not contact and puncture the strut.



P12-9 Use a hammer to tap the top of the spindle and drive it downward off the end of the strut. Allow the left rear spindle and assembled components to hang from the trailing arm.

PHOTO SEQUENCE 12 (CONTINUED)

TYPICAL PROCEDURE FOR REMOVING A REAR STRUT-AND-SPRING ASSEMBLY ON A FRONT-WHEEL-DRIVE CAR



P12-10 Lower the vehicle on the lift so the disconnected components on the left rear suspension and the other tires are a short distance off the shop floor. Open the trunk and remove the dust cap on top of the left rear strut opening. Loosen the left rear strut mounting nuts.



P12-11 Have a coworker hold the left rear strut-and-spring assembly and remove the strut mounting nuts. Remove the left rear strut from the vehicle.

Classroom Manual

Chapter 7, page 153



SPECIAL TOOLS

Lower control arm support tool

3. Remove the stabilizer bar from the knuckle bracket.
4. Remove the parking brake cable retaining clip from the lower control arm.
5. If the car has electronic level control (ELC), disconnect the height sensor link from the control arm.
6. Install a special tool to support the lower control arm in the bushing areas (Figure 7-18).
7. Place a transmission jack under the special tool and raise the jack enough to remove the tension from the control arm bushing retaining bolts. If the car was lifted with a floor jack and supported on safety stands, place a floor jack under the special tool.
8. Place a safety chain through the coil spring and around the lower control arm.
9. Remove the bolt from the rear control arm bushing.
10. Be sure the jack is raised enough to relieve the tension on the front bolt in the lower control arm and remove this bolt.
11. Lower the jack slowly and allow the control arm to pivot downward. When all the tension is released from the coil spring, remove the safety chain, coil spring, and insulators.

Check the coil spring for distortion and proper free length. If the spring has a vinyl coating, check this coating for scratches and nicks. Check the spring insulators for cracks and wear.




FIGURE 7-17 Ball joint wear indicator.




FIGURE 7-18 Special tool installed to support the inner end of the lower control arm.




FIGURE 7-19 Removing the suspension adjustment link from the lower control arm.

After the coil spring is removed, follow these steps to remove the lower control arm:

1. Remove the nut on the inner end of the **suspension adjustment link**, and disconnect this link from the lower control arm (Figure 7-19).
2. Remove the cotter pin from the ball joint nut, and loosen, but do not remove, the nut from the ball joint stud.
3. Use a special ball joint removal tool to loosen the ball joint in the knuckle.
4. Remove the ball joint nut and the lower control arm (Figure 7-20).

Check the lower control arm for bends, distortion, and worn bushings. A special ball joint pressing tool is used to press the ball joint from the lower control arm (Figure 7-21), and the same pressing tool with different adapters is used to press the new ball joint into the control arm (Figure 7-22).

Remove the nut and cotter pin on the outer end of the suspension adjustment link, and use a special puller to remove this link from the knuckle (Figure 7-23). Remove the suspension adjustment link and inspect the joints. If the joints are loose or the seals are damaged, joint replacement is necessary. The joint studs must fit snugly in the knuckle and lower

A **suspension adjustment link** may be connected from the rear knuckle to the lower control arm to adjust rear wheel toe.



CAUTION:

When disconnecting a linkage joint, such as the ends of the suspension adjustment link, do not use a wedge-type tool between the joint and the attached part. This method of joint removal may damage the joint seal.




FIGURE 7-20 Removing the lower control arm and ball joint.



FIGURE 7-21 Removing the ball joint from the lower control arm.




FIGURE 7-22 Installing the ball joint in the lower control arm.




FIGURE 7-23 Removing the suspension adjustment link from the knuckle.

control arm openings. When the joint studs are worn, joint replacement is necessary, and worn stud openings in the knuckle or lower control arm require component replacement.

Follow this procedure to install the lower control arm and spring:

1. Install the ball joint stud in the knuckle and install the nut on the ball joint stud. Tighten the ball joint nut to the specified torque, and then tighten the nut an additional 2/3 turn. If necessary, tighten the nut slightly to align the nut castellations with the cotter pin hole in the ball joint stud, and install the cotter pin.
2. Snap the upper insulator on the coil spring. Install the lower spring insulator and the spring in the lower control arm (Figure 7-24).
3. Be sure the top of the coil spring is properly positioned in relation to the front of the vehicle (Figure 7-25).



SPECIAL TOOLS

Ball joint stud
removal tool
Ball joint pressing
tool




FIGURE 7-24 Installing the spring and insulators.




FIGURE 7-25 Proper location of upper coil spring ends in relation to the front of the vehicle.

4. Install the special tool on the inner ends of the control arm, and place the transmission jack under the special tool.
5. Slowly raise the transmission jack until the control arm bushing openings are aligned with the openings in the chassis.
6. Install the bolts and nuts in the inner ends of the control arm. Do not torque these bolts and nuts at this time.
7. Install the stabilizer-bar-to-knuckle bracket and tighten the fasteners to the specified torque.
8. Install the parking brake retaining clip.
9. If the vehicle has ELC, install the height sensor link, and tighten the fastener to the specified torque.
10. Install the suspension adjustment link and tighten the retaining nuts to the specified torque. Install cotter pins as required.
11. Remove the transmission jack and install the tire-and-wheel assembly.
12. Lower the vehicle onto the floor and tighten the wheel hub nuts and lower control arm bolts and nuts to the specified torque.



SPECIAL TOOLS

Suspension
adjustment link
removal tool



CAUTION:

Never loosen a ball joint nut to install a cotter pin, because this action causes improper torquing of the nut.



CAUTION:

The pivot bolts and nuts in the inner ends of the lower control arm must be tightened to the specified torque with the vehicle weight supported on the wheels and the suspension at normal curb height. Failure to follow this procedure may adversely affect ride quality and steering characteristics.

REAR LEAF-SPRING DIAGNOSIS AND REPLACEMENT

This leaf-spring discussion applies to multiple-leaf springs on rear suspension systems that have two springs mounted longitudinally in relation to the chassis. Many leaf springs have plastic **spring silencers** between the spring leaves. If these silencers are worn out, creaking and squawking noises are heard when the vehicle is driven over road irregularities at low speeds.

When the silencers require checking or replacement, lift the vehicle with a floor jack and support the frame on safety stands so the rear suspension moves downward. With the vehicle weight no longer applied to the springs, the spring leaves may be pried apart with a pry bar to remove and replace the silencers.

Worn shackle bushings, brackets, and mounts cause excessive chassis lateral movement and rattling noises. With the normal vehicle weight resting on the springs, insert a pry bar between the rear outer end of the spring and the frame. Apply downward pressure on the bar and observe the rear shackle for movement. Shackle bushings, brackets, or mounts must be replaced if there is movement in the shackle. The same procedure may be followed to check the front bushing in the main leaf. A broken spring center bolt may allow the rear axle assembly to move rearward on one side. This movement changes rear wheel tracking, which results in handling problems, tire wear, and reduced directional stability. Sagged rear springs reduce the curb riding height. Spring replacement is necessary if the springs are sagged.

Spring silencers are plastic spacers mounted between the spring leaves to reduce spring noise.

Directional stability refers to the tendency of the vehicle steering to remain in the straight-ahead position when driven straight ahead on a reasonably smooth, level road surface.

Lateral chassis movement refers to sideways movement.

A stabilizer bar may be referred to as a sway bar.




FIGURE 7-26 Leaf-spring rear suspension.

When rear leaf-spring replacement is necessary, proceed as follows:

1. Lift the vehicle with a floor jack and place safety stands under the frame. Lower the vehicle weight onto the safety stands, and leave the floor jack under the differential housing to support the rear suspension weight.
2. Remove the nuts from the spring U-bolts, and remove the U-bolts and lower spring plate (Figure 7-26). The spring plate may be left on the rear shock absorber and moved out of the way.
3. Be sure the floor jack is lowered sufficiently to relieve the vehicle weight from the rear springs.
4. Remove the rear shackle nuts, plate, shackle, and bushings.
5. Remove the front spring mounting bolt and remove the spring from the chassis. Check the spring center bolt to be sure it is not broken.
6. Check the front hanger, bushing, and bolt, and replace as necessary.
7. Check the rear shackle, bushings, plate, and mount; replace the worn components.
8. Reverse steps 1 through 5 to install the spring. Tighten all bolts and nuts to the specified torque.

TRACK BAR DIAGNOSIS AND REPLACEMENT

Some rear suspension systems have a track bar to control **lateral chassis movement**. Rubber mounting bushings insulate the track bar from the chassis components. Worn track bar mounts and bushings may cause rattling and excessive lateral chassis movement.

When the track bar is inspected, lift the vehicle on a hoist or floor jack with the rear suspension in the normal riding height position. If the vehicle is lifted with a floor jack, place safety stands under the rear axle to support the vehicle weight. Grasp the track bar firmly and apply vertical and horizontal force. If there is movement in the track bar mountings, track bar, or bushing, replacement is essential (Figure 7-27).

Another track bar checking method is to leave the vehicle on the shop floor and observe the track bar mounts as an assistant applies side force to the chassis or rear bumper. If there is lateral movement in the track bar bushings or brackets, replace the bushings and check the bracket bolts. Bent track bars must be replaced.

When the track bar is replaced, remove the mounting bolts, bushings, grommets, and track bar. Inspect the mounting bolt holes in the chassis for wear. After the track bar is installed with the proper grommets and bushings, tighten the mounting bolts to the specified torque.

STABILIZER BAR DIAGNOSIS AND SERVICE

Worn stabilizer bar mounting bushings, grommets, or mounting bolts cause a rattling noise as the vehicle is driven on irregular road surfaces. A weak stabilizer bar or worn bushings and grommets cause harsh riding and excessive body sway while driving on irregular road




FIGURE 7-27 Checking track bar bushings.

surfaces. Worn or very dry stabilizer bar bushings may cause a squeaking noise on irregular road surfaces. All stabilizer bar components should be visually inspected for wear. Stabilizer bar removal and replacement procedures vary depending on the vehicle. Always follow the vehicle manufacturer's recommended procedure in the service manual.

Following is a typical rear stabilizer bar removal and replacement procedure:

1. Lift the vehicle on a hoist and allow both sides of the rear suspension to drop downward as the vehicle chassis is supported on the hoist.
2. Remove the mounting bolts at the outer ends of the stabilizer bar and remove the bushings, grommets, brackets, or spacers (Figure 7-28).
3. Remove the mounting bolts in the center area of the stabilizer bar.
4. Remove the stabilizer bar from the chassis.
5. Visually inspect all stabilizer bar components, such as bushings, bolts, and spacer sleeves. Replace the stabilizer bar, grommets, bushings, brackets, or spacers as required. Split bushings may be removed over the stabilizer bar. Bushings that are not split must be pulled from the bar.
6. Reverse steps 2 through 4 to install the stabilizer bar. Make sure all stabilizer bar components are installed in the original position, and tighten all fasteners to the specified torque.



SERVICE TIP:

On rear suspension systems with an inverted U-channel, the stabilizer bar inside the U-channel sometimes breaks away where it is welded to the end plate in the U-channel. This results in a rattling, scraping noise when the car is driven over road irregularities.




FIGURE 7-28 Stabilizer bar, bushings, grommets, and brackets.

REAR SUSPENSION TIE ROD INSPECTION AND REPLACEMENT

Rear tie-rods should be inspected for worn grommets, loose mountings, and bent conditions. Loose tie-rod bushings or a bent tie-rod will change the rear wheel tracking and result in reduced directional stability. Worn tie-rod bushings also cause a rattling noise on road irregularities. When the rear tie-rod is replaced, remove the front and rear rod mounting nuts. The lower control arm or rear axle may have to be pried rearward to remove the tie-rod. Inspect the tie-rod grommets and mountings for wear, and replace parts as required. When the tie-rod is reinstalled, tighten the mounting bolts to specifications, and measure the rear wheel toe.

TABLE 7-1 REAR SUSPENSION DIAGNOSIS

Problem	Symptoms	Possible Causes
Low riding height	Harsh ride quality, worn strikeout bumpers	Weak springs, worn control arm bushings, bent trailing arms or control arms
Steering pull	Steering pulls to the right or left when driving straight ahead	Improper rear wheel toe
Rear tire wear	Excessive rear tire tread wear	Improper rear wheel toe or camber
Rear chassis vibration	Rear chassis vibration when driving at a certain speed	Improper rear wheel, rotor, or drum balance; improper drive shaft balance or angles on rear-wheel-drive vehicles
Rear suspension noise	Rattling or squeaking noise when driving on road irregularities	Worn or dry stabilizer bar links and bushings, worn shock absorber or strut rod bushings, broken tubular rod in the rear axle inverted U-channel
Excessive rear suspension vertical oscillations	Excessive rear suspension bouncing when driving on road irregularities	Worn out shock absorbers or struts
Excessive rear chassis waddle	Excessive rear chassis lateral oscillations	Worn track bar bushings, loose track bar or brace

TERMS TO KNOW

Body sway
Brake torque test
Downshift test
Electronic vibration analyzer (EVA)
Lateral chassis movement
Neutral coast-down test
Neutral run-up test
Slow acceleration test
Spring silencers
Standing acceleration test
Steering input test
Suspension adjustment link
Wear indicators

CASE STUDY

A customer complained about steering pull to the left on a Chevrolet Impala. The customer also said the problem had just occurred in the last few days. The technician road tested the car and found the customer's description of the complaint to be accurate. A careful inspection of the tires indicated there was no abnormal tire wear on the front or rear tires. The vehicle was inspected for recent collision damage, but there was no evidence of this type of damage. After lifting the vehicle on a hoist, the technician checked all the front suspension components, including ball joints, control arms, control arm bushings, and wheel bearings. However, none of these front suspension components indicated any sign of wear or looseness.

Realizing that improper rear wheel tracking causes steering pull, the technician inspected the rear suspension. A pry bar was used to apply downward and rearward force to the trailing arms on the rear suspension. When this action was taken on the right rear trailing arm, the technician discovered the trailing arm bushing was very loose. This defect had allowed the right side of the rear axle to move rearward a considerable amount, which explained why the steering pulled to the left.

After installing a new trailing arm bushing, the alignment was checked on all four wheels, and the wheel alignment was within specifications. A road test indicated no evidence of steering pull or other steering problems.

ASE-STYLE REVIEW QUESTIONS

1. While discussing lateral movement of the rear chassis:
Technician A says this problem may be caused by loose stabilizer bar bushings.
Technician B says this problem may be caused by loose track bar bushings.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
2. While discussing excessive rear body sway or roll when driving on road irregularities:
Technician A says this problem may be caused by worn spring insulators.
Technician B says this problem may be the result of sagged rear springs.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. While discussing rear suspension curb riding height:
Technician A says reduced rear curb riding height causes harsh riding.
Technician B says reduced rear curb riding height increases steering effort.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
4. While discussing curb riding height:
Technician A says the curb riding height is measured at the same location on each vehicle.
Technician B says the curb riding height has no effect on other alignment angles.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
5. While discussing spring removal on a MacPherson strut rear suspension:
Technician A says all the spring tension must be removed from the upper mount before the upper strut nut is loosened.
Technician B says a vinyl-coated spring should be taped in the compressing tool contact area.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
6. The most likely cause of excessive rear chassis lateral movement is (are):
A. A weak stabilizer bar.
B. Worn track bar bushings.
C. Worn-out struts.
D. Sagged rear coil springs.
7. All these statements about rear suspension systems with lower control arms and ball joints are true EXCEPT:
A. Worn lower control arm bushings do not affect tire tread wear.
B. Some rear suspension ball joints have wear indicators.
C. On some rear suspensions, the ball joint is pressed into the lower control arm.
D. On some vehicles, the vehicle weight must be resting on the tires when the inner, lower control arm bolts are tightened.
8. Rear suspension adjustment links:
A. May be lengthened or shortened to adjust rear wheel camber.
B. Are connected from the lower control arm to the knuckle.
C. May be loosened on each end with a wedge-type tool.
D. Prevent fore-and-aft control arm and wheel movement.
9. On a rear suspension system with longitudinally mounted leaf springs:
A. Improper vehicle tracking may be caused by a broken spring center bolt.
B. Worn spring silencers may cause reduced curb riding height.
C. A shackle is mounted between the front of the spring and the chassis.
D. Longitudinal rear leaf springs are usually installed on independent rear suspension systems.
10. While diagnosing improper rear wheel tracking:
A. Improper rear wheel tracking may be caused when both rear springs are sagged the same amount.
B. A bent rear suspension tie-rod does not affect rear wheel tracking.
C. Improper rear wheel tracking may result in steering pull when driving straight ahead.
D. Improper rear wheel tracking may cause front wheel shimmy.

ASE CHALLENGE QUESTIONS

1. A squeak in the rear suspension could be caused by all of the following EXCEPT:
 - A. The suspension bushing.
 - B. Weak spring leaves.
 - C. Worn spring antifriction pads.
 - D. A defective shock absorber.
2. A vehicle with a live-axle coil spring rear suspension has become hard to steer with harsh ride quality. Which of the following could be the cause of this problem?
 - A. Worn lateral link bushings.
 - B. Weak rear coil springs.
 - C. Bent rear shock rod.
 - D. Worn stabilizer bar bushings.
3. A customer says his 1993 Isuzu Trooper has become “real antsy” on a curve. An initial check of the rear suspension by pushing sideways against the bumper with the truck on the floor indicates wear.

Technician A says worn sway bar bushings could be the problem.

Technician B says a worn shock mount could be the problem.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
4. A car with independent rear suspension has excessive rear tire wear. An inspection of the rear tires shows they are worn on the inside edge and the tread is feathered.

Technician A says the problem could be the tires are toeing out during acceleration.

Technician B says worn control arm bushings could be the cause of the problem.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
5. The steering on a front-wheel-drive car pulls to the right.

Technician A says the strut on the right rear suspension assembly could be the problem.

Technician B says worn bushings of the left rear lower arm assembly could be the problem.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B

Name _____ Date _____

REMOVE AND SERVICE REAR SUSPENSION STRUT AND COIL SPRING ASSEMBLY

Upon completion of this job sheet, you should be able to remove and service rear suspension strut and coil spring assemblies.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Tasks C-10: Remove inspect, and install strut cartridge or assembly, strut coil spring, insulators (silencers), and upper strut bearing mount.

Tools and Materials

Floor jack Hoist
Safety stands Coil spring compressing tool

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Remove the rear seat and the package trim tray. ☐
2. Remove the wheel cover, and loosen the wheel nuts. ☐
3. Lift the vehicle with a floor jack, and lower the chassis onto safety stands so the rear suspension is allowed to drop downward.
Is the rear suspension properly supported on the safety stands? ☐ Yes ☐ No
Instructor check _____
4. Place the floor jack lift pad under the rear spindle on the side where the strut and spring removal is taking place. Raise the floor jack to support some of the suspension system weight.
Is the floor jack placed under the rear spindle and supporting some of the vehicle weight? ☐ Yes ☐ No
Instructor check _____
5. Remove the rear wheel, disconnect the nut from the small spring in the lower arm, and remove the brake hose and antilock brake system (ABS) wire from the strut. ☐
6. Remove the stabilizer bar link from the strut, and loosen the strut-to-spindle mounting bolts. ☐
7. Remove the three upper support nuts under the package tray trim, and lower the floor jack to remove the strut from the knuckle. Remove the strut from the chassis. ☐
8. Following the vehicle and equipment manufacturers' recommended procedures, install a spring compressor on the coil spring, and tighten the spring compressor until all the spring tension is removed from the upper support.

Task Completed

☐

Is the spring compressor properly installed on the coil spring? ☐ Yes ☐ No
Is the spring compressor tightened so all tension is removed from the upper support?
Instructor check _____

9. Install a bolt in the upper strut-to-spindle bolt hole and tighten the two nuts on the end of this bolt. One nut must be on each side of the strut bracket.
Clamp this bolt in a vise to hold the strut, coil spring, and spring compressor.

10. Using the special tool to hold the spring and strut from turning, loosen the nut from the strut rod nut.
Is all the coil spring tension removed from the upper strut mount by the spring compressor? ☐ Yes ☐ No
Is the strut rod nut loosened? ☐ Yes ☐ No
Instructor check _____

☐

11. Remove the strut rod nut, upper support, and upper insulator.

☐

12. Remove the strut from the lower end of the spring.

☐

13. If the spring is to be replaced, rotate the compressor bolt until all the spring tension is removed from the compressing tool, then remove the spring from the tool.

14. Inspect the lower insulator and spring seat on the strut. If the spring seat is warped or damaged, replace the strut. A new cartridge may be installed in some rear struts.

Lower insulator condition: ☐ Satisfactory ☐ Unsatisfactory

Spring seat condition: ☐ Satisfactory ☐ Unsatisfactory

Strut condition: ☐ Satisfactory ☐ Unsatisfactory

List all the components that require replacement and explain the reasons for your diagnosis.



SERVICE TIP:

If the plastic coating on a coil spring is chipped, the spring may break prematurely. The spring may be taped in the compressing tool contact areas to prevent chipping.

15. Visually inspect the coil spring, upper mount, insulator, and spring bumper. If any of these components are damaged, worn, or distorted, replacement is necessary.

Coil spring condition: ☐ Satisfactory ☐ Unsatisfactory

Upper mount condition: ☐ Satisfactory ☐ Unsatisfactory

Insulator condition: ☐ Satisfactory ☐ Unsatisfactory

Spring bumper condition: ☐ Satisfactory ☐ Unsatisfactory

List all the components that require replacement and explain the reasons for your diagnosis.

Instructor's Response _____

Name _____ Date _____

REMOVE REAR SUSPENSION LOWER CONTROL ARM AND BALL JOINT ASSEMBLY

Upon completion of this job sheet, you should be able to remove rear suspension lower control arm and ball joint assemblies.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Tasks C-3, C-5: Remove inspect, and install upper and lower control arms, bushings, shafts, and rebound bumpers. Remove, inspect, and install upper and/or lower ball joints.

Tools and Materials

Floor jack	Control arm removing tool
Safety stands	Transmission jack
Hoist	Ball joint removal and replacement tools

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Lift the vehicle on a hoist with the chassis supported in the hoist and control arms dropped downward. The vehicle may be lifted with a floor jack and the chassis supported on safety stands. ☐
2. Remove the tire-and-wheel assembly. ☐
3. Remove the stabilizer bar from the knuckle bracket. ☐
4. Remove the parking brake cable retaining clip from the lower control arm. ☐
5. If the car has electronic level control (ELC), disconnect the height sensor link from the control arm. ☐
6. Install a special tool to support the lower control arm in the bushing areas. ☐
7. Place a transmission jack under the special tool and raise the jack enough to remove the tension from the control arm bushing retaining bolts. If the car was lifted with a floor jack and supported on safety stands, place a floor jack under the special tool. Is the special control arm support tool properly installed and supported?
☐ Yes ☐ No
Instructor check _____
8. Place a safety chain through the coil spring and around the lower control arm. Is the safety chain properly installed? ☐ Yes ☐ No
Instructor check _____
9. Remove the bolt from the rear control arm bushing. ☐

Task Completed☐

10. Be sure the jack is raised enough to relieve the tension on the front bolt in the lower control arm and remove this bolt.

☐

11. Lower the jack slowly and allow the control arm to pivot downward. When all the tension is released from the coil spring, remove the safety chain, coil spring, and insulators.

12. Inspect the coil spring for distortion and proper free length. If the spring has a vinyl coating, check this coating for scratches or nicks. Check the spring insulators for cracks and wear.

Coil spring condition:: ☐ Satisfactory ☐ Unsatisfactory

List all the components that require replacement and explain the reasons for your diagnosis.

☐

13. Remove the nut on the inner end of the suspension adjustment link and disconnect this link from the lower control arm.

14. Remove the cotter pin from the ball joint nut, and loosen, but do not remove, the nut from the ball joint stud.

Is the ball joint nut loosened? ☐ Yes ☐ No

Instructor check _____

☐

15. Use a special ball joint removal tool to loosen the ball joint in the knuckle.

☐

16. Remove the ball joint nut and the control arm.

17. Inspect the lower control arm for bends, distortion, and worn bushings.

Lower control arm condition: ☐ Satisfactory ☐ Unsatisfactory

List the control arm and related parts that require replacement and explain the reasons for your diagnosis.

Instructor check _____

☐

18. Use a special ball joint pressing tool to press the ball joint from the lower control arm.

☐

19. Use the same pressing tool with different adapters to press the new ball joint into the control arm.

Instructor's Response _____

Name _____ Date _____

INSTALL REAR SUSPENSION LOWER CONTROL ARM AND BALL JOINT ASSEMBLY

Upon completion of this job sheet, you should be able to install rear suspension lower control arm and ball joint assemblies.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task C-3, C-5: Remove, inspect, and install upper and lower control arms, bushings, shafts, and rebound bumpers. Remove, inspect, and install upper and/or lower ball joints.

Tools and Materials

Floor jack Control arm removing tool
Safety stands Transmission jack
Hoist

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Install the ball joint stud in the knuckle and install the nut on the ball joint stud.
Tighten the ball joint nut to the specified torque, and then tighten the nut an additional 2/3 turn. If necessary, tighten the nut slightly to align the nut castellations with the cotter pin hole in the ball joint stud, and install the cotter pin.
Specified ball joint stud nut torque _____
Actual ball joint stud nut torque _____
2. Snap the upper insulator on the coil spring. Install the lower spring insulator and the spring in the lower control arm.
Is the coil spring and insulator properly installed in lower control arm?
☐ Yes ☐ No
Instructor check _____
3. Be sure the top of the coil spring is properly positioned in relation to the front of the vehicle.
Is the top of the spring properly positioned? ☐ Yes ☐ No
Instructor check _____
4. Install the special tool on the inner ends of the control arm, and place the transmission jack or floor jack under the special tool. ☐
Is the special tool properly supported on the control arm? ☐ Yes ☐ No
Instructor check _____
Is the special tool properly supported on the transmission or floor jack?
Instructor check _____

Task Completed

☐

5. Slowly raise the transmission jack until the control arm bushing openings are aligned with the openings in the chassis.

6. Install the bolts and nuts in the inner ends of the control arm. Do not torque these bolts and nuts at this time.

7. Install the stabilizer-bar-to-knuckle bracket fasteners to the specified torque.

Specified torque on stabilizer-bar-to-knuckle bracket fasteners _____

Actual torque on stabilizer-bar-to-knuckle bracket fasteners _____

☐

8. Install the parking brake retaining clip.

☐

9. If the vehicle has ELC, install the height sensor link, and tighten the fastener to the specified torque.

10. Install the suspension adjustment link and tighten the fastener to the specified torque.

Install cotter pins as required.

Specified adjustment link retaining nut torque _____

Actual adjustment link retaining nut torque _____

Are the cotter pins properly installed in adjustment link retaining nuts?

☐ Yes ☐ No

Instructor check _____

☐

11. Remove the transmission jack or floor jack, and install the tire-and-wheel assembly.

12. Lower the vehicle onto the floor. Tighten the wheel hub nuts and lower control arm bolts and nuts to the specified torque.

Specified wheel nut torque _____

Actual wheel nut torque _____

Specified control arm retaining nut torque _____

Actual control arm retaining nut torque _____



CAUTION:

The pivot bolts and nuts in the inner ends of the lower control arm must be tightened to the specified torque with the vehicle supported on the wheels and the suspension at normal curb height. Failure to follow this procedure may adversely affect ride quality and steering characteristics.

Instructor's Response _____

Chapter 8

COMPUTER-CONTROLLED SUSPENSION SYSTEM SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Diagnose programmed ride control (PRC) systems.
- Diagnose electronic air suspension systems.
- Remove, replace, and inflate air springs.
- Adjust front and rear trim height on electronic air suspension systems.
- Service and repair nylon air lines.
- Diagnose vehicle dynamic suspension (VDS) systems.
- Remove and replace air springs on VDS systems.
- Perform an on-demand self-test on VDS systems.
- Diagnose electronic suspension control (ESC) systems.
- Display and interpret scan tool data on ESC systems.
- Use the output controls function to diagnose ESC systems.
- Diagnose vehicle networks.

Each year more vehicles are equipped with computer-controlled suspension systems, and these systems are becoming increasingly complex. Therefore, technicians must understand the correct procedures for diagnosing and servicing these systems. When a technician understands computer-controlled suspension systems and the proper diagnostic procedures for these systems, diagnosis becomes faster and more accurate.

PRELIMINARY INSPECTION OF COMPUTER-CONTROLLED SUSPENSION SYSTEMS

Prior to diagnosing a computer-controlled suspension system, a preliminary inspection should be performed. The preliminary inspection may locate a minor defect that is the cause of the problem. If the preliminary inspection is not performed, a lot of time may be wasted performing advanced diagnosis when the problem is a minor defect. When the preliminary diagnosis does not locate any minor problems, further diagnosis is required.

Follow these steps to complete the preliminary diagnosis:

1. Talk to the customer and find out the exact complaint regarding vehicle operation.
2. If necessary, road test the vehicle to determine the exact symptoms.
3. Inspect the vehicle for any work that was completed recently, including body work. Wires or air lines may have been damaged by a collision.
4. Check all electrical connections and wiring in the computer-controlled suspension system.



BASIC TOOLS

Basic technician's tool set

Service manual

Floor jack

Safety stands

Utility knife

Machinist's ruler or tape measure

5. If the vehicle has a computer-controlled air suspension system, listen for air leaks in the system.
6. If the vehicle has a computer-controlled air suspension system, check all the air lines for cracks, breaks, damage, and kinks.
7. Measure the vehicle curb (trim) height.
8. Check the operation of the suspension warning light or observe the message center in the instrument panel for displayed suspension messages.

PROGRAMMED RIDE CONTROL SYSTEM DIAGNOSIS

General Diagnosis

The **programmed ride control (PRC)** module monitors the complete system while the vehicle is driven. If a defect occurs in the PRC system, the mode indicator light starts flashing. When the mode selector switch is moved to the opposite position and returned to the same position, erroneous codes are cleared from the control module memory. If the mode indicator light continues flashing, the self-test should be performed.

Self-Test

The self-test connector is located under the ash tray (Figure 8-1). This connector has two terminals that must be connected during the self-test. A jumper tool should be fabricated to connect these terminals, and this tool should be soldered to the end of a 7-inch slotted screwdriver blade to access the self-test terminals (Figure 8-2).

Follow this procedure to perform the self-test:

1. Turn the ignition switch off and be sure the headlights and parking lights are off. These lights must remain off during the self-test.
2. Position the mode select switch in the Auto position.
3. Remove the ash tray and insert the fabricated tool in the self-test connector terminals.




FIGURE 8-1 Self-test terminals, programmed ride control system.




FIGURE 8-2 Fabricated tool to connect the self-test terminals.




FIGURE 8-3 Mode indicator in tachometer flashes trouble codes.

PRC System Diagnostic Trouble Codes (DTCs)

Code	Defect
6	No problem
1	Left rear actuator circuit
2	Right rear actuator circuit
3	Right front actuator circuit
4	Left front actuator circuit
5	Soft relay control circuit shorted
7	PRC control module
13	Firm relay control circuit shorted
14	Relay control circuit

FIGURE 8-4 PRC system diagnostic trouble codes (DTCs).

4. Start the engine and leave the mode select switch in the Auto position.
5. When the engine has been running for 20 seconds or more, remove the tool from the self-test connector.
6. Count the mode indicator light flashes to obtain the trouble codes. For example, if the light flashes six times, code 6 has been provided. The light flashes each code four times at nine-second intervals. The mode indicator light is in the tachometer (Figure 8-3).

Diagnostic Trouble Codes (DTCs)

Several DTCs are available on the PRC system (Figure 8-4). The DTCs vary depending on the vehicle make and year. Always use the DTC list in the manufacturer's service manual. A trouble code indicates a defect in a specific area. For example, if DTC 2 is received, the defect may be in the right rear actuator or in the connecting wires.

After a PRC system defect has been corrected, the DTCs should be cleared. The system should be checked for DTCs again to make sure there are no other faults in the system.

ELECTRONIC AIR SUSPENSION DIAGNOSIS AND SERVICE

Air Spring Removal and Installation

WARNING: The system control switch must be in the Off position when system components are serviced to prevent personal injury and damage to system components.

WARNING: The system control switch must be turned off prior to hoisting, jacking, or towing the vehicle. If the front of the chassis is lifted with a bumper jack, the rear suspension moves downward. The electronic air suspension system will attempt to restore the rear trim height to normal, and this action may cause the front of the chassis to fall off the bumper jack, resulting in personal injury or vehicle damage.

WARNING: When air spring valves are being removed, always rotate the valve to the first stage until all the air escapes from the air spring. Never turn the valve to the second (release) stage until all the air is released from the spring. If this action is taken, the valve may be blown out of the air spring with considerable force, and this may cause personal injury.



SERVICE TIP: Diagnostic trouble codes (DTCs)

together with the vehicle manufacturer's service manual diagnostic procedures will usually locate the problem in a PRC system.

Diagnostic trouble codes (DTCs)

indicate defects in specific areas of computer-controlled systems.

Classroom Manual

Chapter 8, page 167



WARNING: When removing and replacing many suspension components such as lower control arms in an air spring suspension system, air must be exhausted from the air spring to relieve tension on the components before the removal procedure. Failure to observe this precaution may result in personal injury.

**Classroom
Manual**

Chapter 8, page 171

Many components in an electronic air suspension system, such as control arms, shock absorbers, and stabilizer bars, are diagnosed and serviced in the same way as the components in a conventional suspension system. However, the air spring service procedures are different compared to coil-spring service procedures on a conventional suspension system.

The air spring removal and replacement procedure varies depending on the vehicle make and model year. For example, a different air spring removal and replacement procedure is required on vehicles with integral air springs and struts, and vehicles with the air springs mounted separately from the shock absorbers. Front and rear air spring removal and replacement procedures may vary. Always follow the exact air spring removal and replacement procedure in the vehicle manufacturer's service manual. The following is a typical air spring removal and replacement procedure for some vehicles with the air springs mounted separately from the shock absorbers:

Follow these steps for air spring removal:


1. Turn off the electronic air suspension switch in the trunk.
2. Hoist the vehicle and allow the suspension to drop downward, or lift the vehicle with a floor jack and place safety stands under the chassis. Lower the vehicle onto the safety stands and allow the suspension to drop downward.
3. Disconnect the nylon air line from the spring solenoid valve, and rotate the valve to the first stage to allow the air to escape from the spring. Never turn the valve to the second stage until all the air is exhausted from the spring.
4. Disconnect the lower spring retainer and remove the spring from the chassis.
5. Before an air spring is installed, it must be properly folded over the piston at the bottom of the membrane (Figure 8-5).
6. Install the spring in the chassis and connect the lower spring retainer. Be sure the top of the spring is properly seated in the spring seat. When an air spring is installed in the front or rear suspension, the spring must be properly positioned to eliminate folds and creases in the membrane (Figure 8-6)

Removal and Replacement of Air Springs with Integral Struts


Front or rear air springs with integral struts are sold only as an assembly. Do not attempt to service these components. The following is typical front air spring removal and replacement procedure on an automatic air suspension system with air springs containing integral struts:

1. Turn off the air suspension switch.
2. Raise the vehicle on a frame-contact lift and allow the suspension to drop downward.
3. Remove the wheel and tire assembly on the corner of the vehicle that requires air spring and strut removal.
4. Release the metal clip at the top height sensor mount, then remove the height sensor off the ball stud.
5. Remove the air spring solenoid retainer, loosen the air spring solenoid valve to the first position, and allow all the air pressure to be relieved from the air spring.


1. Spring membrane unrolled



2. Remove solenoid to expand membrane, then reinstall solenoid to trap air



3. Re-rolling membrane



4. Release air to trap membrane, then reinstall solenoid




FIGURE 8-5 Air spring folding.


6. Push the air solenoid line retainer toward the center of the solenoid, and pull the rubber hose and nylon tube out of the solenoid (Figure 8-7). Remove the electrical connector from the solenoid.
7. Remove the air spring solenoid valve.
8. Remove the top strut cover, and remove three strut-to-strut tower retaining nuts (Figure 8-8).
9. Remove the strut-to-suspension arm retaining nut and bolt.
10. Remove the strut and spring assembly from the vehicle.



CAUTION:

Loosening the large center nut on the top of the strut rod may cause a permanent leak through the top of the air spring.

Air spring appearance
prior to vehicle installation



Height approximately 2" front

Height approximately 3" rear

FIGURE 8-6 When an air spring is installed in the front or rear suspension, the spring must be properly positioned to eliminate folds and creases in the membrane.




FIGURE 8-7 Air line removal from the air spring solenoid valve.




FIGURE 8-8 Removing the upper strut mount retaining nuts.

Follow these steps to install a replacement front air spring and integral strut:

1. Install the air spring and strut assembly into the front suspension until the upper strut mount retaining bolts extend through the bolt holes in the strut tower.
2. Install the upper strut mount retaining nuts and tighten these nuts to the specified torque.
3. Install the lower strut-to-suspension retaining bolt and nut, and tighten the nut until it is snug. The nut on this bolt must be tightened to the specified torque after the vehicle weight is applied to the suspension.
4. Install the air spring solenoid valve fully into the air spring, and install the valve retainer.
5. Install the air line and electrical connector into the solenoid valve.
6. Install the wheel and tire assembly and tighten the wheel nuts to the specified torque.
7. Perform an air spring fill procedure described in the next section.

Air Spring Inflation

If an air spring has been replaced, or the air has been completely exhausted from an air spring, a spring fill procedure is required to inflate the air spring. The air spring fill procedure varies depending on the vehicle make and model year. Always follow the air spring fill procedure in the vehicle manufacturer's service manual. The following air spring fill procedure is for a vehicle with the air springs separate from the shock absorbers.

The weight of the vehicle must not be allowed to compress an uninflated air spring.

When an air spring is being inflated, use this procedure:

1. With the vehicle chassis supported on a hoist, lower the hoist until a slight load is placed on the suspension. Do not lower the hoist until the suspension is heavily loaded.
2. Turn on the air suspension system switch.



CAUTION:

Do not allow the suspension to compress an air spring until the air spring is inflated. This action may damage the air spring.

3. Turn the ignition switch from Off to Run for 5 seconds with the driver's door open and the other doors shut. Turn the ignition switch off.
4. Ground the diagnostic lead.
5. Apply the brake pedal and turn the ignition to the Run position. The warning lamp will flash every 2 seconds to indicate the fill mode.
6. To fill a rear spring or springs, close and open the driver's door once. After a 6-second delay, the rear spring will fill for 60 seconds.
7. To fill a front spring or springs, close and open the driver's door twice. After a 6-second delay, the front spring will fill for 60 seconds.
8. When front and rear springs require filling, fill the rear springs first. Once the rear springs are filled, close and open the driver's door once to begin filling the front springs.
9. The spring fill mode is terminated if the diagnostic lead is disconnected from ground. Termination also occurs if the ignition switch is turned off or the brake pedal is applied.

Scan Tool Procedure for Air Spring Inflation

On some air suspension systems the **scan tool** is used to activate the air compressor and energize the appropriate air spring solenoid valve to inflate an air spring. The following is a typical spring fill procedure using a scan tool on an automatic air suspension system:

1. Turn off the air suspension switch.
2. Be sure the proper module is installed in the scan tool for suspension diagnosis and service on the vehicle being serviced.
3. Connect the scan tool to the **data link connector (DLC)** on the vehicle.
4. Be sure the vehicle is positioned on a frame-contact lift with the suspension dropped downward and no load on the suspension.
5. Connect a battery charger to the battery terminals with the correct polarity, and set the charger at a low charging rate.
6. Select Function Test on the scan tool, and select the desired function test number for the air spring being filled as follows: test number 212 – LH front air spring, test number 214 – RH front air spring, test number 216 – LH rear air spring, and test number 218 – RH rear air spring. When the proper function test number is selected, the scan tool commands the compressor and the appropriate air spring solenoid valve on, to allow air spring inflation.
7. When the compressor shuts off, the air spring inflation is complete, and any further air spring inflation or deflation is done during normal operation of the air suspension system.
8. Lower the vehicle onto the shop floor and completely lower the lift. Be sure the lift arms are not contacting the vehicle.
9. Inspect the air spring(s) that were completely deflated, and be sure there are no folds and creases in these springs.
10. Turn on the suspension switch.
11. If the lower front strut-to-control arm bolt and nut were removed and reinstalled during the suspension service procedure, use your knee to push downward and release the front bumper. Repeat this procedure three times.
12. Tighten the lower front strut-to-control arm nut and bolt to the specified torque.
13. Road test the vehicle and verify proper air suspension operation and trim height.

Photo sequence 13 shows the proper procedure for air spring inflation with a scan tool.

Trim Height Mechanical Adjustment

On some vehicles with air suspension, the trim height is adjusted by lengthening or shortening the front or rear height sensors. On other vehicles the manufacturer recommends using the scan tool to adjust the trim height. Always follow the trim height adjustment procedure in the vehicle manufacturer's service manual.

A **scan tool** is a digital tester that can be used to diagnose various on-board computer systems.

The **data link connector (DLC)** is a 16-terminal connector positioned under the left side of the instrument panel. A scan tool is connected to the DLC to diagnose various on-board electronic systems.

OBD II computer systems became mandatory on cars and light trucks in the 1996 model year. Some vehicles prior to 1996 were equipped with OBD II systems. OBD II systems have some standardized features such as a 16-terminal DLC under the left side of the dash. OBD II systems have increased monitoring capabilities in the PCM. Many engine control systems are monitored, and if any engine system is defective so it allows the exhaust emissions to increase more than 1.5 times the normal limit for that vehicle, the malfunction indicator light (MIL) illuminates in the instrument panel.

PHOTO SEQUENCE 13

INFLATE L/H FRONT AIR SPRING USING A SCAN TOOL




P13-1 Turn off the air suspension switch.




P13-2 Connect the scan tool to the data link connector (DLC) on the vehicle.



P13-3 Be sure the vehicle is positioned on a frame-contact lift with the suspension dropped downward and no load on the suspension.



P13-4 Connect a battery charger to the battery terminals with the correct polarity, and set the charger at a low charging rate.




P13-5 Select Function Test on the scan tool, and select the desired Function Test number 212 - LH front air spring. When the proper function test number is selected, the scan tool commands the compressor and the appropriate air spring solenoid valve on, to allow air spring inflation.



P13-6 When the compressor shuts off, the air spring inflation is complete. Inspect the L/H front air spring and be sure there are no folds and creases in the spring.



P13-7 Shut the battery charger off and disconnect the charger cables. Lower the vehicle onto the shop floor and completely lower the lift. Be sure the lift arms are not contacting the vehicle.



P13-8 Disconnect the scan tool, and turn on the suspension switch.



P13-9 If the lower front strut-to-control arm bolt and nut were removed and reinstalled during the suspension service procedure, use your knee to push downward and release the front bumper. Repeat this procedure three times. Tighten the lower front strut-to-control arm nut and bolt to the specified torque.



P13-10 Road test the vehicle and verify proper air suspension operation and trim height.

The **trim height** should be measured on the front and rear suspension at the locations specified by the vehicle manufacturer (Figure 8-10).

If the rear suspension trim height is not within specifications, it may be adjusted by loosening the attaching bolt on the top height sensor bracket (Figure 8-11). When the bracket is moved one index mark up or down, the ride height is lowered or raised 0.25 in. (6.35 mm).

The front suspension trim height may be adjusted by loosening the lower height sensor attaching bolt. Three adjustment positions are located in the lower front height sensor bracket (Figure 8-12). If the height sensor attaching bolt is moved one position up or down, the front suspension height is lowered or raised 0.5 in. (12.7 mm).

Line Service

Nylon lines on the electronic air suspension system have quick disconnect fittings. These fittings should be released by pushing downward and holding the plastic release ring, and then pulling outward on the nylon line (Figure 8-13). Simply push the nylon line into the fitting until it seats to reconnect an air line.



SERVICE TIP:

Some on-board diagnostic I (OBD I) vehicles have a separate suspension DLC positioned on the right-front strut tower. Other OBD I vehicles have the suspension DLC in the trunk. **OBD II computer systems** have a universal 16-terminal DLC mounted under the left side of the dash near the steering column (Figure 8-9). Data links are connected from various on-board computers including the suspension computer to the DLC to allow the on-board computers to communicate with the scan tool and vice versa.





FIGURE 8-9 Data link connector (DLC), on-board diagnostic II (OBD-II) system.



622–635 mm
(24.50–25 in.)

FIGURE 8-10 Trim height measurement location.




FIGURE 8-11 Rear trim height adjustment.




FIGURE 8-12 Front trim height adjustment.




FIGURE 8-13 Air line removed from the air spring valve or compressor outlets.

Front and rear **trim height** is the distance between the vehicle chassis and the road surface measured at locations specified by the vehicle manufacturer.

If a line fitting is damaged, it may be removed by looping the line around your fingers and pulling on the line without pushing on the release ring (Figure 8-14). When a new collet and release ring are installed, the O-ring under the collet must be replaced. If a leak occurs in a nylon line, a sharp knife may be used to cut the defective area out of the line. A service fitting containing a collet fitting in each end is available for line repairs. After the defective area is cut out of the line, push the two ends of the line into the service fitting (Figure 8-14).




FIGURE 8-14 Removing the quick disconnect fittings and air line repairs procedure.

SERVICING AND DIAGNOSING VEHICLE DYNAMIC SUSPENSION SYSTEMS

On some vehicles the air suspension is referred to as a **vehicle dynamic suspension (VDS)**. Proper diagnosis of the VDS is extremely important to locate the exact root cause of the customer's complaint. Improper diagnosis may lead to wasted time and unnecessary replacement of expensive electronic components. The first step in VDS diagnosis is to visually inspect the system.

VDS Inspection and Verification

Follow these steps to inspect the VDS system and verify the symptoms:

1. Be sure the customer complaint is identified; road test the vehicle if necessary.
2. Be sure none of the DOOR AJAR indicators are illuminated.
3. Inspect the suspension system for anything that could result in restricted suspension movement.
4. Inspect the vehicle trunk for excessive loading.
5. Check the front and rear height sensors for loose or worn mountings.
6. Inspect the front and rear air springs for damage such as punctures and tears.
7. Check the suspension air lines for cuts, splits, or a crimped condition.
8. Check fuses 102, 30, 27, and 111 in the central junction box.
9. Inspect all VDS electrical connections for looseness and corrosion.
10. Be sure the air suspension switch is on.
11. Inspect the solenoid valves in the air springs for damage.

If the VDS inspection reveals an obvious problem, this defect must be corrected before proceeding with the electronic diagnosis. When the inspection and verification does not indicate any defects, proceed with the pneumatic test and the on-demand self-test.

Ride Height Adjustment or Calibration

The ride height adjustment procedure with a scan tool may vary depending on the vehicle make and model year. The following is a typical ride height adjustment procedure with a

The **vehicle dynamic suspension** is an air suspension system used on some current model vehicles.




SERVICE TIP:

If a door ajar indicator is illuminated even when all the doors, liftgate, and liftgate glass are closed, the VDS will not operate properly. The problem with the door ajar indicator must be repaired before proceeding with the VDS diagnosis.


Classroom Manual

Chapter 8, page 184



Item	Description
1	Distance between the ground and the lower knuckle surface near the ball joint
2	Ride height = 3 - 1
3	Distance between the ground and the center of the lower arm rearward mounting bolt

FIGURE 8-15 Front ride height measurement.



Item	Description
1	Distance between the ground and lower edge of arm below the shock absorber mounting bolt
2	Ride height = 3 - 1
3	Distance between the ground and the center of the lower arm mounting bolt

FIGURE 8-16 Rear ride height measurement.

scan tool for a 2005 Ford Expedition or Lincoln Navigator equipped with a vehicle dynamic suspension:

1. Be sure the air suspension switch is in the On position.
2. Be sure the battery is fully charged.
3. Turn off the ignition switch and exit the vehicle. Close all doors and wait 45 seconds for the air suspension system to vent down to the Kneel position.
4. Open the driver's door, and turn on the ignition switch.
5. Shift the transmission into drive and back into park.
6. Exit the vehicle, close all the doors, and wait 45 seconds for the suspension system to pump up to the trim height.
7. Use a tape measure to measure the ride height at the locations specified by the vehicle manufacturer (Figures 8-15 and 8-16).
8. If the ride height does not equal the manufacturer's specifications, open the left-front door, and connect the scan tool to the DLC. Be sure the scan tool contains the proper module for the vehicle being tested.
9. Select the correct vehicle year, model, and engine type on the scan tool, and then select *Vehicle Dynamic Module* (VDM).
10. Use the active command mode in the scan tool to vent or lift the vehicle to achieve the specified trim height.
11. When a tape measure indicates the specified front and rear ride height, select *Save Calibration Values* on the scan tool to calibrate the VDM to the specified trim height.
12. Road test the vehicle and verify the proper suspension height.

Pneumatic Test

The pneumatic test verifies the air lines are connected and the air compressor, air compressor vent solenoid, and air spring solenoid valves are functioning properly. Follow these steps to complete the pneumatic test:

1. Close all doors, liftgate, and liftgate glass.
2. Place the transmission selector in park.
3. Be sure the air suspension switch is on.
4. Connect the scan tool to the DLC. Be sure the correct module is installed in the scan tool.
5. Turn on the ignition switch and select *Vehicle Dynamic Module* followed by *Pneumatic Test* on the scan tool.



SERVICE TIP:

The ride height adjustment procedure must be completed before a wheel alignment is performed.



SERVICE TIP:

The ride height adjustment must be performed after a VDM is replaced.

6. This scan tool selection causes the VDM to operate the VDS compressor, spring solenoid valves, and vent valve. While operating the system the VDM checks for proper response from the height sensors. If the VDM does not perform normal air spring fill and vent operations in the required time, the VDM sets diagnostic trouble codes (DTCs) in memory and displays appropriate messages in the message center or in the instrument panel if the vehicle does not have a message center. The results of the pneumatic test are also displayed on the scan tool.

On-Demand Self-Test

When the inspection, verification, and pneumatic tests do not indicate any defects, the on-demand self-test should be performed to locate the problem area in the VDS system.

Complete the following steps to perform the on-demand self-test:

1. Be sure the transmission is in park.
2. Be sure the battery is fully charged. A battery charger may be installed to maintain a fully charged battery.
3. Connect the scan tool to the DLC.
4. Lower the driver's window and close all doors, liftgate, and liftgate glass.
5. Be sure the 4L mode is not selected on four-wheel-drive models.
6. Turn on the ignition switch.
7. Select *Vehicle Dynamic Module* and *On-Demand Self-Test* on the scan tool.
8. Record all DTCs displayed on the scan tool.
9. Turn off the ignition switch.

When DTCs are displayed on the scan tool, interpret the meaning of the DTC and diagnose the root cause of the problem. Possible DTCs on the VDS system are these:

1. B1317 – high battery voltage
2. B1318 – low battery voltage
3. B1342 – VDM is defective
4. B2477 – variable assist power steering (VAPS) steering assist curve not complete
5. C1445 – vehicle speed sensor circuit defect
6. C1724 – air suspension height sensor power circuit failure
7. C1725 – air suspension front pneumatic failure
8. C1726 – air suspension rear pneumatic failure
9. C1760 – failure in rear height sensor signal circuit
10. C1770 – failure in vent solenoid output circuit
11. C1790 – L/R air spring solenoid valve output circuit failure
12. C1795 – R/R air spring solenoid valve output circuit failure
13. C1830 – failure in compressor relay circuit
14. C1840 – failure in air suspension On/Off switch
15. C1873 – R/F air spring solenoid valve output circuit failure
16. C1877 – L/F air spring solenoid valve output circuit failure
17. C1881 – failure in R/F height sensor circuit
18. C1889 – failure in L/F height sensor circuit
19. C1897 – failure in VAPS circuit loop
20. C1964 – compressor run time longer than specified
21. C1990 – VDM initialization required on replacement VDM
22. C1991 – factory trim height setting and/or tests not completed
23. U1900 – missing controller area network (CAN) messages
24. U2023 – improper CAN messages

If DTCs are displayed on the scan tool, detailed pinpoint tests are provided in the vehicle manufacturer's service manual to locate the exact cause of the problem. These pinpoint tests



CAUTION:

When removing and replacing components on the VDS, the vehicle manufacturer recommends replacing all the self-locking nuts. Failure to observe this service procedure may cause loose suspension components and component failure.



SERVICE TIP:

If the retainer tabs on the lower end of the air spring are broken, air spring replacement is necessary.

usually include voltmeter and ohmmeter tests. A DTC indicates the area in which a problem is present, but the pinpoint tests are used to locate the root cause of the defect. When DTC C1990 is displayed, perform the pneumatic test and ride height calibration procedure to initialize the VDM.

Removal and Disassembly of Combined Air Springs and Shock Absorbers on VDS Systems

The removal and disassembly procedures are similar for front and rear air springs. Follow these steps to remove and disassemble a combined air spring and shock absorber:

1. Position the vehicle on a lift and place the lift arms under the specified lift points on the vehicle.
2. Be sure the ignition switch and the VDS switch are turned off.
3. Connect the scan tool to the DLC, and use the scan tool to vent the air spring being removed.



WARNING: Never remove an air spring or a component attached to the air spring without completely deflating the air spring. This action may cause personal injury.

4. Remove the upper strut mount retaining nuts on the air spring to be removed (Figure 8-17). Discard the nuts.
5. Raise the vehicle to a comfortable working height. Disconnect the electrical connector from the air spring solenoid valve (Figure 8-18).
6. Compress the orange quick-disconnect connector on the air line connected to the air spring, and pull downward to disconnect the air line (Figure 8-19).
7. Use the appropriate socket and ratchet to remove the nut from the lower shock absorber mounting bolt, and remove this bolt (Figure 8-20).
8. Remove the air spring and shock absorber from the chassis.
9. Place a wrench on the hex on top of the shock absorber rod, and hold this rod from turning while loosening and removing the nut on the top of the shock absorber rod (Figure 8-21).
10. Place index marks on the lower end of the air spring and shock absorber so these components may be reassembled in the original position. Depress the retainer tabs on the bottom end of the air spring, and remove the air spring from the shock absorber (Figure 8-22).
11. Remove and discard the seal and washer on the upper end of the shock absorber rod (Figure 8-23).




FIGURE 8-17 Removing the upper mount retaining nuts.




FIGURE 8-18 Disconnecting the electrical connector from the air spring solenoid valve.




FIGURE 8-19 Disconnecting the air line from the air spring solenoid valve.




FIGURE 8-20 Removing the lower shock absorber retaining bolt and nut.




FIGURE 8-21 Removing the nut from the upper end of the shock absorber rod.




FIGURE 8-22 Depressing the retaining tabs on the bottom end of the air spring.




FIGURE 8-23 Seal and washer on the upper end of the shock absorber rod.



CAUTION:

Never remove or install the wiring connector on a computer or computer system component with the ignition switch on. This action may result in computer damage.



CAUTION:

Do not supply voltage to or ground any circuit or component in a computer system unless instructed to do so in the vehicle manufacturer's service manual. This action may damage computer system components.



CAUTION:

During computer system diagnosis, use only the test equipment recommended in the vehicle manufacturer's service manual to prevent damage to computer system components.




FIGURE 8-24 O-ring seals on the lower sealing area on the shock absorber.




FIGURE 8-25 Retaining pins on the upper air spring mount.




FIGURE 8-26 O-ring seals on the upper spring mount.

12. Remove and discard the O-ring seals on the lower sealing area between the shock absorber and the air spring (Figure 8-24).
13. Remove and discard the retainer pins that hold the upper mount onto the air spring (Figure 8-25).
14. Remove and discard the O-ring seals on the upper mount area that provides a seal between the mount and the air spring (Figure 8-26).

When reassembling the air spring and shock absorber, replace all the O-rings and self-locking nuts, and place a light coating of chassis lubricant on all the O-rings.

DIAGNOSIS OF ELECTRONIC SUSPENSION CONTROL SYSTEMS

Diagnostic Trouble Code (DTC) Display

Vehicles equipped with the **electronic suspension control (ESC)** system may have a digital or an analog instrument panel cluster (IPC). If the vehicle has a digital IPC, the air-conditioning (A/C) control panel is contained in the IPC (Figure 8-27). A driver message center is located in the center of the IPC underneath the speedometer. This message center is a vacuum fluorescent (VF) display with twenty characters. The same message center is mounted in an analog IPC (Figure 8-28). If the car has an analog IPC, the A/C controls are mounted in a separate display (Figure 8-29).




FIGURE 8-27 Digital instrument panel cluster.




FIGURE 8-28 Analog instrument panel cluster.




FIGURE 8-29 A/C controls used with the analog instrument panel cluster.

Early versions of the ESC system may be called **continuously variable road sensing suspension (CVRSS)** systems.

When the information (INFO) button is pressed in the IPC, the driver message center cycles through a series of status messages: RANGE, AVG MPG, MPG INST, FUEL USED, OIL LIFE LEFT, ENGINE RPM, BATTERY VOLTS, COOLANT TEMP, ENGLISH/METRIC RESET. The parameters related to fuel usage are not displayed in the message center on a digital IPC, because these readings are displayed in the fuel data center that is contained in the IPC.

If an electrical defect occurs in the ESC system, a SERVICE RIDE CONTROL message is displayed in the driver information center, and a diagnostic trouble code (DTC) is usually stored in the ESC module. The first step in diagnosing the ESC system should be a thorough visual inspection of the system. Inspect the wiring harness for damaged wires and loose or corroded connectors. Be sure the battery is fully charged and all the fuses are in good condition.



SERVICE TIP:

When removing, replacing, or servicing an electronic component on a vehicle, always disconnect the negative battery cable before starting the service procedure. If the vehicle is equipped with an air bag or bags, wait one minute after the battery negative cable is removed to prevent accidental air bag deployment. Many air bag computers have a backup power supply capable of deploying the air bag for a specific length of time after the battery is disconnected.

If the SERVICE RIDE CONTROL message is displayed, the technician enters the diagnostic mode by pressing the OFF and WARMER buttons simultaneously on the A/C controls with the ignition switch on. When these buttons are pressed, the IPC performs a segment check in which all segments in the IPC and climate control panel (CCP) are illuminated for a brief period of time. Press the low fan speed button to display the abbreviation for the on-board computers, such as PCM and IPC, one after the other. Continue pressing the low fan speed button until ESC appears in the driver message center. When ESC is displayed, press the increase fan speed button to select this parameter. When this action is taken, the ESC DTCs are displayed in the driver message center. Each DTC is designated as CURRENT or HISTORY, and each DTC has a C prefix followed by four digits. If there are no DTCs in the ESC module, NO ESC CODES is displayed. When NO ESC DATA is displayed, there is an electrical defect in the data link, the module ground connection, or in the ESC module battery or ignition inputs. A DTC represents a fault in a certain area of the ESC system. For example, if a C1711 is displayed, there is a short to ground in the left front (LF) damper actuator. The technician has to perform voltmeter or ohmmeter test procedures provided in the appropriate service manual to test the LF damper actuator and the related sensor wiring to locate the exact cause of the defect. When the ohmmeter leads are connected to the damper actuator terminals on the strut, the ohmmeter should indicate 9.5 to 15.5 ohms. The DTCs and ESC system specifications may vary depending on the vehicle make, model, and year. If the ohmmeter reading is infinite, the damper actuator has an open circuit. An ohmmeter reading below this value indicates a shorted damper actuator. If the ohmmeter leads are connected from one of the damper actuator terminals to ground, the ohmmeter should provide an infinite reading indicating this actuator is not grounded. When the ohmmeter indicates a low reading, the damper actuator is shorted to ground. Ohmmeter tests for shorts-to-ground and open circuits must also be performed on the wires from the damper actuator to the ESC module. The DTCs are displayed in the driver message center. The DTCs may be cleared from the ESC module by pressing the increase fan speed button when CLEAR DTCS is displayed in the driver message center. A scan tool may also be used to clear the DTCs. Disconnecting the battery or the ESC module connector will not clear the DTCs.

A scan tool also displays the DTCs and diagnoses the ESC system. The scan tool displays the voltage data from the wheel position sensors, steering sensor, vehicle speed sensor, and battery.

SCAN TOOL DIAGNOSIS OF ELECTRONIC SUSPENSION CONTROL

When diagnosing an ESC system, the first step is to identify the complaint. Listen to the customer's complaint, and road test the car if necessary to determine the exact problem. The next step in the diagnostic procedure is to visually inspect all ESC components. Check all the ESC wiring connections and wiring harnesses. Be sure all the ESC fuses are satisfactory. Check the shock absorbers, struts, and other suspension components for loose mountings and damage. Inspect the shock absorbers and struts for fluid leaks. Be sure the battery is fully charged.

Observe the message center for displayed messages related to the ESC system. ESC systems with computer-controlled solenoids in the shock absorbers or struts display SERVICE SUSPENSION SYSTEM or SPEED LIMITED TO XXX if a defect occurs in the ESC. If the vehicle has an ESC system with magneto-rheological fluid in the shock absorbers or struts, the ESC system displays SHOCKS INOPERATIVE, SERVICE RIDE CONTROL, OR MAXIMUM SPEED 129 km/h (80 mph) if a defect occurs in the system. The messages indicating a limited maximum vehicle speed are displayed only when the ESC module has detected a defect and shut down the electronic control of all shock absorbers or struts.

To locate a defect in an ESC system the next step is to perform a diagnostic system check. This check identifies the control modules in the system, and tests the ability of the control

modules to communicate through the data link system. The diagnostic system check also displays all DTCs in the various modules related to ESC.

Follow these steps to complete a diagnostic system check:

1. Be sure the ignition switch is off, and connect a scan tool to the DLC.
2. Turn on the ignition switch.
3. Use the scan tool to select the various modules related to ESC control. These modules include the **powertrain control module (PCM)**, ESC module, and the electronic brake control module (EBCM).
4. Use the scan tool to display all the DTCs stored in each of the modules in step 3. Record all DTCs.
5. If a DTC is displayed that begins with a U, there is a problem with communications through the data links. When one or more of the displayed DTCs begins with a U, a lack of communication between the scan tool and one or more of the modules likely occurred in step 3.
6. The cause of the DTC beginning with a U must be corrected before proceeding with any further diagnosis. After the cause of the data link DTC is corrected, diagnose the cause of all other DTCs.

The **powertrain control module (PCM)** controls engine functions.

The following DTCs represent ESC defects:

1. C0550 – ESC module malfunction.
2. C0563 – ESC module calibration defect.
3. C0577, C0579, C0582, C0584, C0587, C0589, C0592, C0594 – the voltage is out of the normal range in one of the strut solenoids or electromagnets. Detailed DTC explanations and diagnostic procedures are provided in the vehicle manufacturer's service manual.
4. C0578, C0583, C0588, C0593 – ESC fault in one of the internal ESC module drivers that operate the strut solenoids or electromagnets.
5. C0615, C0620, C0625, C0630 – a fault exists in one of the position sensors that causes the sensor voltage to be below or above the normal range of 0.35 V to 4.75 V for more than 1 second.
6. C0635, C0638, C0640, C0643, C01252, C01253 – a defect in the two normal force signal circuits between the ESC module and the electronic brake control module (EBCM). The ESC module controls each shock absorber or strut actuator with a pulse width modulated (PWM) duty cycle or 10% to 90% depending on road surface conditions. The ESC module relays this PWM information through a normal force signal circuit to the EBCM, and the EBCM uses this information to provide improved braking on irregular road surfaces.
7. C0665 – the ESC module did not detect a low-to-high change in the lift/dive circuit within 31 seconds after it received the ignition switch on signal.
8. C0690, C0691, C0693 – a defect in the damper control relay circuit that is integral in the ESC module. If one or more of these DTCs is displayed, ESC module replacement is necessary.
9. C0696 – the 5 V reference voltage sent from the ESC module to each position sensor is out of the normal range of 3.75 V to 5.6 V.
10. C0710 – the ESC module does not detect a valid steering position signal from the EBCM for 5 seconds. The EBCM controls the ABS and the variable assist steering.
11. C0896 – the battery voltage is not within the normal range of 9 V to 15.5 V.
12. P1652 – the output driver module (ODM) in the PCM that controls suspension lift/dive has detected an improper circuit condition.

To set most DTCs in the ESC module, the module must sense a defect on three consecutive ignition cycles, or during the same ignition cycle after clearing the DTC with a scan tool.

Scan Tool Data Display

Select *Special Functions* on the scan tool to access the ESC system data. The ESC data is very helpful to pinpoint the exact cause of DTCs. The following ESC data may be displayed on the scan tool with the ignition switch on, the engine off, and the front wheels straight ahead:

1. Battery voltage signal – typical data 12.6 V.
2. DSP software version ID – numerical value.
3. EEPROM calibration ID – numerical value.
4. GM part number ESC module – numerical value.
5. ESC module software version – numerical value.
6. L/F damper actuator command – 0% to 100% – this percentage indicates the commanded on-time of the damper actuator. If the ESC module commands the damper actuator On, the percentage increases.
7. L/F position sensor – 0 V to 5 V – this voltage is the signal voltage sent from the position sensor to the ESC module. If downward force is supplied to the L/F of the chassis, the voltage reading should change. When the position sensor voltage does not change, the sensor and connecting wires must be tested to locate the exact cause of the problem. After repairs have been completed to correct a problem causing a DTC, the scan tool must be used to clear the DTC from the ESC module.
8. L/F normal force – 20% to 80% – this percentage indicates a measured level of the road surface condition sent from the ESC module to the EBCM, and the EBCM uses this information to improve antilock braking on irregular road surfaces.
9. The damper actuator command and position sensor data are displayed on the scan tool for the other three corners of the chassis. The normal force data is available only on the front wheels.
10. Lift/Dive status – active, inactive – if there is no change in chassis pitch, the scan tool displays Inactive. When a change in chassis pitch occurs, the scan tool displays Active.
11. Lift/Dive change – changed, unchanged – if there is no change in chassis pitch, Unchanged is displayed on the scan tool. A change in chassis pitch causes the scan tool to display Changed.
12. Steering position PWM – 0 to 10 ms – this PWM signal is sent from the EBCM to the ESC module when the steering wheel is turned while cornering. The ESC module commands a firmer shock absorber state when the vehicle is turning a corner.
13. Vehicle speed – 0 to 159 mph (0 to 255 km/h) – the vehicle speed sensor signal is relayed on the data links from the PCM to the ESC module.

Scan Tool Output Controls

The Output Controls are accessed on the scan tool under the Special Functions menu. When Output Controls are selected on the scan tool, followed by an individual damper solenoid selection, the solenoid is cycled on and off. When an individual damper solenoid actuator is cycled on and off, the technician may perform voltage tests to check the damper actuator and related circuit. The scan tool may also be used to cycle all the damper solenoids simultaneously.


In the Output Controls mode, the scan tool may be used to command the ESC module to send the L/F and R/F normal force percentage readings to be sent to the EBCM, and this percentage is displayed on the scan tool.

ESC Module Recalibration may also be selected on the scan tool in the Output Controls mode. This recalibration is necessary after a module replacement.


Photo Sequence 14 illustrates the procedure for reading scan tool data on an electronic suspension control system.

PHOTO SEQUENCE 14


READING SCAN TOOL DATA ON AN ELECTRONIC SUSPENSION CONTROL SYSTEM




P14-1 Connect the scan tool to the DLC under the dash.




P14-2 Turn on the ignition switch, and select Special Functions in the ESC menu on the scan tool.




P14-3 Display and record the DSP software version ID, EEPROM Calibration ID, GM part number ESC module, and ESC module software version on the scan tool.




P14-4 Select the damper actuator command on each damper actuator. This percentage indicates the commanded on-time of the damper actuator.




P14-5 Select the wheel position sensor voltage on each wheel position sensor. This voltage is the signal voltage sent from the position sensor to the ESC module.




P14-6 Select the normal force display on the scan tool. This percentage indicates a measured level of the road surface condition sent from the ESC module to the EBCM, and the EBCM uses this information to improve antilock braking on irregular road surfaces.



P14-7 Select the Lift/Dive status on the scan tool.



P14-8 Select Steering Position PWM on the scan tool.



P14-9 Select Vehicle Speed on the scan tool.

The **antilock brake system (ABS)** prevents wheel lockup during a brake application.

The **Stabilitrak®** system is a type of vehicle stability control.

The **electronic brake and traction control module (EBTCM)** controls ABS, TCS, and Stabilitrak® functions.

The **brake pressure modulator valve (BPMV)** controls brake fluid pressure to the wheel calipers or cylinders.

Diagnosis of Stability Control System

The stability control system module is combined with the **antilock brake system (ABS)** and traction control system (TCS) modules. Therefore, it is not possible to completely separate the diagnosis of these systems. However, our discussion is mostly concerned with the stability control system, and this diagnostic information pertains to the **Stabilitrak®** system. The Stabilitrak® system may be called a vehicle stability enhancement system (VSES).

The **electronic brake and traction control module (EBTCM)** performs an initialization test each time the vehicle is started and the EBTCM does not receive a brake switch input. During the initialization test, the EBTCM cycles each solenoid valve and the pump motor in the **brake pressure modulator valve (BPMV)** for 1.5 seconds. If the EBTCM detects an electrical fault during the initialization test, a DTC is set in the EBTCM, and the amber ABS light and the red brake light may be illuminated in the instrument panel, depending on the severity of the defect. During the initialization test, the customer may hear the solenoids clicking and the pump motor turning in the BPMV.

The first step in diagnosing the stability control system is a visual inspection of all system components, such as the module connectors, fuses, relays, wiring harness, and sensor mounting and wiring connector.

If the visual inspection did not reveal any problems, the next step is to perform a Stabilitrak® diagnostic test drive as follows:

1. Turn the ignition switch off.
2. Connect a scan tool to the data link connector (DLC) under the instrument panel. Be sure the correct module for the system being tested is securely installed in the bottom of the scan tool.
3. Start the engine.
4. Monitor the “steering wheel centered” parameter on the scan tool, and be sure the scan tool displays “Yes” while driving the vehicle straight ahead above 15 mph (24 km/h).
5. Drive the vehicle for at least 10 minutes under a variety of driving conditions: highway driving, rough road driving, and turning maneuvers, including freeway ramps and sharp turns on parking lots.
6. Perform any driving maneuvers under which the customer complaint(s) occurred.
7. With the engine still running, observe and record any DTCs displayed on the scan tool.

If there is a defect in the Stabilitrak® system, “Stability Reduced” may be displayed in the driver information center. When “Display ABS/TCM/ICCS DTCs” is selected on the scan tool, any of the following DTCs may be displayed as indicated in Figures 8-30 and 8-31. The technician usually has to perform voltmeter or ohmmeter tests to locate the exact cause of a problem in the area indicated by the DTC.

Automated Test

An automated test may be selected on the scan tool. During this test, the EBTCM cycles all the solenoid valves and the pump motor in the BPMV, and DTCs are set in the EBTCM if there are defects in these components. This test is the same as the initialization test performed by the EBTCM when the engine is started. The scan tool also performs solenoid tests.

Valve Solenoid/Pressure Hold Test

To perform the valve solenoid/pressure hold test, follow this procedure:

1. Be sure the scan tool is properly connected to the DLC.
2. Turn on the ignition switch.

DTC	DESCRIPTION
C1211	ABS Indicator Lamp Circuit Malfunction
C1214	Solenoid Valve Relay Contact or Coil Circuit Open
C1217	BPMV Pump Motor Relay Contact Circuit Open
C1221	LF Wheel Speed Sensor Input Signal - 0
C1222	RF Wheel Speed Sensor Input Signal - 0
C1223	LR Wheel Speed Sensor Input Signal - 0
C1224	RR Wheel Speed Sensor Input Signal - 0
C1225	LF - Excessive Wheel Speed Variation
C1226	RF - Excessive Wheel Speed Variation
C1227	LR - Excessive Wheel Speed Variation
C1228	RR - Excessive Wheel Speed Variation
C1232	LF Wheel Speed Sensor Circuit Open or Shorted
C1233	RF Wheel Speed Sensor Circuit Open or Shorted
C1234	LR Wheel Speed Sensor Circuit Open or Shorted
C1235	RR Wheel Speed Sensor Circuit Open or Shorted
C1236	Low System Voltage
C1237	High System Voltage
C1238	Brake Thermal Model Limit Exceeded
C1241	Magna Steer® Circuit Malfunction
C1242	BPMV Pump Motor Ground Circuit Open
C1243	BPMV Pump Motor Stalled
C1251	RSS Steering Sensor Data Malfunction
C1252	ICCS2 Data Link Left Malfunction
C1253	ICCS2 Data Link Right Malfunction
C1255 xx	EBTCM Internal Malfunction (ABS/TCS/ICCS Disabled)
C1256 xx	EBTCM Internal Malfunction
C1261	LF Hold Valve Solenoid Malfunction

FIGURE 8-30 DTCs for ABS/TCS/ICCS systems.

3. Raise the vehicle on a lift so all four wheels are at least 6 in. (15 cm) off the floor.
4. Select Valve Solenoid Test on the scan tool followed by Hold Pressure on a specific wheel.
5. Hold the brake pedal in the applied position.
6. Have a co-worker try to turn the wheel being tested. If the hold pressure solenoid is operating properly, the co-worker should be able to turn the wheel.
7. Repeat steps 4 through 6 on the other wheels.

CUSTOMER CARE: While discussing computer-controlled suspension systems with customers, remember that the average customer is not familiar with automotive electronics terminology. Always use basic terms that customers can understand when explaining electronic suspension problems. Most customers appreciate a few minutes spent by service personnel to explain their automotive electronic problems. It is not necessary to provide customers with a lesson in electronics, but it is important that customers understand the basic cause of the problem with their vehicle so they feel satisfied the repair expenditures are necessary. A satisfied customer is usually a repeat customer.

DTC	DESCRIPTION
C1262	LF Release Valve Solenoid Malfunction
C1263	RF Hold Valve Solenoid Malfunction
C1264	RF Release Valve Solenoid Malfunction
C1265	LR Hold Valve Solenoid Malfunction
C1266	LR Release Valve Solenoid Malfunction
C1267	RR Hold Valve Solenoid Malfunction
C1268	RR Release Valve Solenoid Malfunction
C1271	LF TCS Master Cylinder Isolation Valve Malfunction
C1272	LF TCS Prime Valve Malfunction
C1273	RF TCS Master Cylinder Isolation Valve Malfunction
C1274	RF TCS Prime Valve Malfunction
C1276	Delivered Torque Signal Circuit Malfunction
C1277	Requested Torque Signal Circuit Malfunction
C1278	TCS Temporarily Inhibited By PCM
C1281	Stabilitrak® Sensors Uncorrelated
C1282	Yaw Rate Sensor Bias Circuit Malfunction
C1283	Excessive Time to Center Steering
C1284	Lateral Accelerometer Sensor Self-Test Malfunction
C1285	Lateral Accelerometer Sensor Circuit Malfunction
C1286	Steering/Lateral Accelerometer Sensor Bias Malfunction
C1287	Steering Sensor Rate Malfunction
C1288	Steering Sensor Circuit Malfunction
C1291	Open Brake Lamp Switch During Deceleration
C1293	DTC C1291 Set In Current or Previous Ignition Cycle
C1294	Brake Lamp Switch Circuit Always Active
C1295	Brake Lamp Switch Circuit Open
C1297	PCM Indicated Brake Extended Travel Switch Failure
C1298	PCM Indicated Class 2 Serial Data Link Malfunction
U1016	Loss of PCM Communications
U1056	Loss of CVRSS Communications
U1255	Generic Loss of Communications
U1300	Class 2 Circuit Shorted to Ground
U1301	Class 2 Circuit Shorted to Battery +

FIGURE 8-31 DTCs for ABS/TCS/ICCS systems. (continued)

Valve Solenoid/Pressure Release Test

To perform a valve solenoid/pressure release test, follow this procedure:

1. Be sure the scan tool is properly connected to the DLC.
2. Turn on the ignition switch.
3. Raise the vehicle on a lift so all four wheels are at least 6 in. (15 cm) off the floor.
4. Hold the brake pedal in the applied position.
5. Select Valve Solenoid Test on the scan tool followed by Release Pressure on a specific wheel.
6. Have a co-worker try to turn the wheel being tested. If the release pressure solenoid is operating properly, the co-worker should be able to turn the wheel.
7. Repeat steps 4 through 6 on the other wheels.

If any of the hold or release solenoids do not operate properly, the BPMV requires replacement. The solenoids in the BPMV are not serviceable.

Diagnosis of Vehicle Networks

Vehicle networks have various voltages and operating characteristics. Therefore, the vehicle manufacturer's specific diagnostic procedure must be followed for each vehicle network. The most common equipment for diagnosing vehicle networks are a scan tool, a digital volt ohm meter (DVOM), and a lab scope. If a defect occurs in most networks, a DTC(s) is displayed on a scan tool connected to the DLC. The technician must follow the vehicle manufacturer's specified procedure to diagnose the cause of the DTC(s). When using a lab scope to diagnose vehicle networks, the technician must be familiar with the normal lab scope pattern for each network. We will discuss the lab scope patterns for two common networks and provide several case studies of network diagnosis.

A Class 2 network is a single-wire system. When the system is at rest with no communication taking place, the system voltage is 0 V. When communication takes place on this network, the data are transmitted by a variable pulse width signal of 0–7 V. The Class 2 network is connected to terminal 2 in the DLC, and it also interconnects with various computers depending on the electronic equipment on the vehicle. To diagnose a Class 2 network with a lab scope, connect the Channel 1 positive lead of the scope to pin 2 in the DLC, and connect the ground lead on the scope to pin 4 in the DLC or to a good chassis ground. Adjust the scope voltage setting to 5 V and set the time base setting to 100 milliseconds (ms). With the ignition switch on, a normal network should display a voltage pattern as illustrated in Figure 8-32. A **splice pack** is used in the network on some vehicles. A parts locator manual will help the technician to locate the splice pack. This splice pack may be disconnected to isolate the PCM and truck body computer (TBC) from the rest of the network so the network cannot affect these computers. If the vehicle has a no-start condition, and the engine starts after the splice pack is disconnected, the defect is located in the network. Under this condition, the network may be shorted to ground, the network may be shorted to a 12 V source, or a module connected to the network may be shorted internally. The network modules may be disconnected one at a time. If the defect is corrected when one module is disconnected, the network problem is in that module. When none of the modules are causing the network problem, voltage and/or ohmmeter tests must be performed on the network wires to locate the shorted condition.

The Standard Corporate Protocol (SCP) network is used on many vehicles. The two wires in the SCP system are designated as Bus+ and Bus-. Bus+ is connected to pin 2 in the DLC, and Bus- is connected to pin 10 in the DLC. The network voltages at rest with no communication are 5 V on Bus+, and 0 V–.2 V on Bus-. A DVOM may be used to read these voltages. To read the SCP voltages on a lab scope, connect the Channel 1 lead on the lab scope to pin 2 on the DLC, and connect the Channel 2 lead on the lab scope to pin 10 on the DLC. Connect the ground lead to pin 4 on the DLC or a good chassis ground. When the ignition switch is turned on, the normal SCP pattern shown in Figure 8-33 should be displayed. If one network signal is displayed as a flat line, communication has failed between some of the computers




FIGURE 8-32 Class 2 network voltage signal.

A **splice pack** is a special connector that may be disconnected to isolate specific components when diagnosing vehicle networks.




FIGURE 8-33 SCP network voltage signal.

and part of the network (Figure 8-34). When both network signals are displayed as a flat line, no communication is taking place through the network. Some networks remain functional with the ignition switch off, because certain module(s) require information under this condition. Always consult the vehicle manufacturer's specific diagnostic information when diagnosing networks.




FIGURE 8-34 SCP network defective voltage signal.

CASE STUDY

A 2002 GM 1500 series truck was towed into the shop with a no-start condition. During a preliminary diagnosis, the technician discovered there was 12V on the Class 2 vehicle network with the ignition switched on. The technician used a parts locator manual to locate the splice pack behind the radio. When the splice pack was disconnected, the engine started and ran normally. This proved that the PCM and TBC were not causing the problem, because disconnecting the splice pack isolated these computers from the network. Therefore, the defect must be in the Class 2 network or computers connected in the

network. The technician decided to disconnect each computer in the network beginning with the radio/CD player. When the splice pack was reconnected, and the radio disconnected, network voltage was normal, and the engine started and ran normally. Closer internal examination of the radio/CD player indicated a dime lodged between the radio/CD player circuit board and the case. When the dime was removed and the radio reconnected, network voltage and engine operation were normal. The technician used a scan tool to erase all DTCs in the computer memories.

CASE STUDY

A customer brought a 2004 Silverado into the shop with multiple electric problems. The cruise control would cancel when the turn signals were turned on. This only occurred at night when the headlights were on. The customer said several instrument panel readings were randomly intermittent. When a scan tool was connected to the DLC, a U1041 was displayed indicating loss of electronic brake control module (EBCM) data on the network. The technician checked for service bulletins related to this problem and discovered this problem was detailed in a service bulletin. The bulletin indicated this problem was caused by high resistance in ground connection G110 on the vehicle frame below the driver's door. The ground connection was cleaned and tightened and the DTC erased, but the DTC reset again in a short time.

The technician considered the possibility of a defective EBCM. Prior to EBCM replacement, the technician

checked the EBCM voltage supply and ground. The EBCM voltage supply was 12V. When a pair of voltmeter leads was connected from the EBCM ground terminal to the battery ground, the voltmeter indicated 3V. The technician inspected all the wiring from the EBCM module to the battery, and discovered that the battery ground cable was connected to the radiator support rather than being connected to the specified location on the left front corner of the vehicle frame. The battery ground cable and the vehicle frame attaching location were thoroughly cleaned, and the ground cable was properly tightened. Now the voltage reading from the EBCM ground terminal to the battery ground was .2 V. All DTCs were erased with a scan tool, and after driving the vehicle on a road test the DTCs did not reset. All electronic systems operated normally during the road test.

TERMS TO KNOW

Antilock brake system (ABS)
Brake pressure modulator valve (BPMV)
Continuously variable road sensing suspension (CVRSS)
Data link connector (DLC)
Diagnostic trouble codes (DTCs)
Electronic brake and traction control module (EBTCM)
Electronic suspension control (ESC)
OBD II computer systems
Programmed ride control (PRC)
Powertrain control module (PCM)
Scan tool
Splice pack
Stabilitrak®
Trim height
Vehicle dynamic suspension (VDS)

CASE STUDY

A customer complained about the SERVICE RIDE CONTROL light being illuminated on his 2009 Cadillac XLR. When the technician visually inspected the ESC system, no defects were evident. During a diagnostic system check, the scan tool displayed DTC C0577. The detailed DTC explanation in the vehicle manufacturer's service manual indicated this DTC represented a short to ground in the L/F shock absorber damper solenoid circuit.

When the technician disconnected the wiring connector from the L/F damper solenoid and measured the solenoid resistance with an ohmmeter, he discovered the solenoid had the specified resistance of 2.0 ohms.

The technician disconnected the wiring connectors from the ESC module and identified the L/F damper solenoid wires connected to the module. When the technician connected a pair of ohmmeter leads across the wires from the ESC module terminals to the L/F damper solenoid terminals, each wire had very low resistance. Next the technician connected

the ohmmeter leads from each terminal in the L/F damper solenoid connector to the ground. When connected to one of the damper solenoid terminals, the ohmmeter displayed an infinite reading indicating the wire was not grounded. However, when the ohmmeter leads were connected from the other damper solenoid terminal to the ground, the ohmmeter indicated a very low reading indicating contact between this wire and the chassis.

A closer examination of the L/F damper solenoid wires indicated these wires were jammed against the chassis about 2 ft. from the damper solenoid. The insulation was worn on the wires, and one wire was contacting the chassis. The technician repaired the wiring insulation and re-positioned the harness so the wires were not jammed against the chassis. The technician used the scan tool to clear the DTC from the ESC module, and road tested the car to be sure the DTC did not reset and illuminate the SERVICE RIDE CONTROL light.

ASE-STYLE REVIEW QUESTIONS

1. When performing a self-test on a programmed ride control system:
 - A. The mode select switch must be in the Auto position.
 - B. One of the wires in the self-test connector must be grounded.
 - C. The engine must be off and the ignition switch turned on.
 - D. The headlights must be on during the self-test.
2. When servicing a vehicle with an air suspension system, the air suspension switch must be turned off:
 - A. When changing the engine oil and filter.
 - B. When changing the spark plugs.
 - C. When jacking the vehicle to change a tire.
 - D. During any of the above service procedures.
3. To deflate an air spring prior to removal of the spring:
 - A. Disconnect the air line from the air spring.
 - B. Turn the air spring solenoid valve to the first stage.
 - C. Turn the air spring solenoid valve to the second stage.
 - D. Energize the vent solenoid in the air compressor.
4. When using the scan tool to inflate an air spring:
 - A. The vehicle must be raised on a tire-contact lift.
 - B. The scan tool commands the air compressor on.
 - C. The air suspension switch must be on.
 - D. The scan tool commands the vent solenoid on.
5. When using a scan tool to perform a ride height adjustment on a vehicle dynamic suspension (VDS),

Technician A says the VDS switch must be in the Off position.

Technician B says if the ride height does not equal the manufacturer's specifications, the scan tool is used to command the VDS to lower or lift the vehicle to obtain the specified ride height.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
6. All of these statements about performing an on-demand self-test on a VDS system are true EXCEPT:
 - A. The battery must be fully charged.
 - B. The ignition switch must be on.
 - C. The vehicle must be raised on a lift.
 - D. The 4L mode must not be selected on four-wheel-drive vehicles.
7. When diagnosing a VDS system, a U1900 DTC is obtained. This DTC indicates a defect in the:
 - A. Controller area network (CAN).
 - B. L/R air spring solenoid.
 - C. Vent solenoid.
 - D. R/F height sensor.
8. When diagnosing an electronic suspension control (ESC) system,

Technician A says defects represented by a DTC with a U prefix must be repaired before proceeding with further diagnosis or service.

Technician B says ESC system operation may be affected by low battery voltage.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
9. On an ESC system a normal voltage signal from a wheel position sensor is:
 - A. 2.5 V.
 - B. 5.5 V.
 - C. 6.1 V.
 - D. 6.8 V.
10. While discussing ESC system diagnosis,

Technician A says the normal force signal on a scan tool indicates a measured level of road surface condition sent from the ESC module to the EBCM.

Technician B says the normal force data is sent from the front and rear wheels.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B

ASE CHALLENGE QUESTIONS

1. *Technician A* says during air spring inflation the vehicle weight must be applied to the suspension system.

Technician B says during air spring inflation the vehicle should be positioned on a lift so the wheels are dropped downward.

Who is correct?

- A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
2. All of these statements about a programmed ride control system are true EXCEPT:
- A. An air spring is mounted at each corner of the vehicle.
 - B. An electric actuator is located in each strut.
 - C. A mode indicator light is positioned in the tachometer.
 - D. The PRC module provides a firm ride during severe braking.

3. *Technician A* says the suspension switch must be turned off before raising any corner of a car with an electronic air suspension.

Technician B says the ignition switch must not be turned on while any corner of a car with electronic air suspension is raised.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

4. A vehicle with an electronic air suspension system with mechanical trim height adjustment requires front and rear trim height adjustment.

Technician A says to adjust the front trim height, rotate the threaded mounting bolt in the upper end of the height sensor.

Technician B says to adjust the rear trim height, loosen the attaching bolt(s) on the upper height sensor bracket and move the bracket upward or downward.

Who is correct?

- A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
5. When removing and replacing an air spring and shock absorber assembly on a VDS:
- A. The self-locking nuts on the upper strut mount can be reused.
 - B. Retainer tabs on the lower end of the spring must be depressed to separate the spring and the shock absorber.
 - C. The spring must be vented by loosening the spring solenoid valve to the first stage.
 - D. The VDS switch and the ignition switch must be in the On position.

Name _____ Date _____

INSPECTION AND PRELIMINARY DIAGNOSIS OF COMPUTER-CONTROLLED SUSPENSION SYSTEM

Upon completion of this job sheet, you should be able to inspect computer-controlled suspension systems.

NATEF Correlation

This job sheet is correlated with NATEF Automotive Suspension and Steering Task D-3: Test and diagnose components of electronically controlled suspension systems using a scan tool; determine necessary action.

Tools and Materials

Modern vehicle with electronically controlled suspension system.

Describe the Vehicle Being Worked On

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. Discuss the vehicle complaint with the customer.

Describe the customer complaint(s). _____

2. Road test the vehicle and verify the vehicle complaint.

☐

Describe the vehicle complaint experienced during the road test.

3. Inspect the vehicle for collision damage or other damage that could affect the computer-controlled suspension system.

☐

Describe any collision or other vehicle damage that could affect the computer-controlled suspension system _____

4. Inspect all electrical connections and wiring harness in the suspension system.

☐

Wiring connection and harness condition, Satisfactory ☐ Unsatisfactory ☐

Task Completed

If the wiring connection and harness condition are unsatisfactory, explain the wiring connection and/or harness defects.

5. If the vehicle has an air suspension system, listen for air leaks near the air-operated components and air lines, and inspect all the air lines for cracks, breaks, damage, and kinks.

Air line condition, Satisfactory ☐ Unsatisfactory ☐

If the air line condition is unsatisfactory, explain the air line defects.

6. Measure the vehicle ride (trim) height.

Ride height, L/F _____, R/F _____, L/R _____, R/R _____

Specified ride height, Front _____ Rear _____

7. Observe the operation of the suspension warning light or message display in the instrument panel.

8. Suspension warning light or message display operation,
Normal ☐ Abnormal ☐

9. Based on your inspection and preliminary diagnosis of the computer-controlled suspension system, list the problems in the system and explain the required further diagnostic and service procedures.

Instructor's Response _____

Name _____ Date _____

ADJUST VEHICLE RIDE (TRIM) HEIGHT WITH A SCAN TOOL

Upon completion of this job sheet, you should be able to adjust the vehicle ride height with a scan tool on computer-controlled suspension systems.

NATEF Correlation

This job sheet is correlated with NATEF Automotive Suspension and Steering Task D-3: Test and diagnose components of electronically controlled suspension systems using a scan tool; determine necessary action.

Tools and Materials

Modern vehicle with a vehicle dynamic suspension (VDS) system.

Scan Tool

Tape Measure

Describe the Vehicle Being Worked On

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. Be sure the air suspension switch is in the On position.

Air suspension switch On, ☐ Yes ☐ No

2. Be sure the battery is fully charged.

Battery fully charged, ☐ Yes ☐ No

3. Turn off the ignition switch and exit the vehicle. Close all doors and wait 45 seconds for the air suspension system to vent down to the kneel position.

VDS suspension in the kneel position, ☐ Yes ☐ No

4. Open the driver's door, and turn on the ignition switch.

Ignition switch on, ☐ Yes ☐ No

5. Shift the transmission into Drive and back into Park.

Transmission shifted into Drive and back into Park, ☐ Yes ☐ No

6. Exit the vehicle, close all the doors, and wait 45 seconds for the suspension system to pump up to the trim height.

VDS system in the trim height position, ☐ Yes ☐ No

Task Completed

7. Use a tape measure to measure the ride height at the locations specified by the vehicle manufacturer.

Specified ride height, Front _____ Rear _____

Actual ride height, L/F _____, R/F _____, L/R _____ R/R _____

8. If the ride height does not equal the manufacturer's specifications, open the left-front door, and connect the scan tool to the DLC.

Scan tool properly connected to the DLC, ☐ Yes ☐ No

9. Select the correct vehicle year, model, and engine type on the scan tool, and then select *Vehicle Dynamic Module* (VDM).

Scan tool selections, Vehicle year _____ Model _____

Engine Size _____

Vehicle Dynamic Module (VDM) selected on scan tool,

☐ Yes ☐ No

10. Use the active command mode in the scan tool to vent or lift the vehicle to achieve the specified trim height.

Active command mode on scan tool used to lift or vent VDS system to specified trim height, ☐ Yes ☐ No

11. When a tape measure indicates the specified front and rear ride height, select *Save Calibration Values* on the scan tool to calibrate the VDM to the specified trim height.

Actual ride height, L/F _____, R/F _____, L/R _____ R/R _____

Instructor's Response _____

Name _____ Date _____

PERFORM AN ON-DEMAND SELF-TEST ON A VEHICLE DYNAMIC SUSPENSION (VDS) SYSTEM

Upon completion of this job sheet, you should be able to perform an On-Demand Self-Test on a vehicle dynamic suspension (VDS) system.

NATEF Correlation

This job sheet is correlated with NATEF Automotive Suspension and Steering Task D-3: Test and diagnose components of electronically controlled suspension systems using a scan tool; determine necessary action.

Tools and Materials

Modern vehicle with a vehicle dynamic suspension (VDS) system.
Scan tool

Describe the Vehicle Being Worked On

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Be sure the transmission is in Park.

Transmission in Park, ☐ Yes ☐ No

2. Be sure the battery is fully charged.

Battery fully charged, ☐ Yes ☐ No

3. Connect the scan tool to the DLC.

Scan tool properly connected to the DLC, ☐ Yes ☐ No

4. Lower the driver's window and close all doors, liftgate, and liftgate glass.

Driver's window down, ☐ Yes ☐ No

All doors, liftgate, and liftglass closed, ☐ Yes ☐ No

5. Be sure the 4L mode is not selected on four-wheel-drive models.

4L switch off, ☐ Yes ☐ No

6. Turn on the ignition switch.

Ignition switch on, ☐ Yes ☐ No

7. Select *Vehicle Dynamic Module* and *On-Demand Self-Test* on the scan tool.

Vehicle Dynamic Module selected on scan tool, ☐ Yes ☐ No

On-Demand Self-Test selected on scan tool, ☐ Yes ☐ No

Task Completed

8. Record all the DTCs displayed on the scan tool.

9. Use the vehicle manufacturer's service information to interpret the meaning of each DTC, and list the meaning of each DTC in the spaces below.

10. Turn off the ignition switch, and disconnect the scan tool.

Ignition switch OFF, ☐ Yes ☐ No

Scan tool disconnected, ☐ Yes ☐ No

Instructor's Response

Chapter 9

STEERING COLUMN AND LINKAGE DIAGNOSIS AND SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Diagnose steering columns.
- Remove and replace steering wheels on air-bag-equipped vehicles and non-air-bag-equipped vehicles.
- Remove and replace air bag deployment modules and clock spring electrical connectors.
- Remove and replace steering columns.
- Inspect collapsible steering columns for damage.
- Disassemble steering columns.
- Inspect steering column components and replace necessary parts.
- Assemble steering columns.
- Diagnose and service flexible couplings and universal joints.
- Diagnose steering linkage mechanisms.
- Diagnose, remove, and replace tie-rod ends.
- Diagnose, remove, and replace pitman arms.
- Diagnose, remove, and replace center links.
- Diagnose, remove, and replace idler arms.
- Diagnose, remove, and replace steering dampers.
- Diagnose steering arms.

When servicing or replacing steering wheels, columns, and linkages, technicians actually have the customer's life in their hands. If steering components are not serviced properly and not tightened to the specified torque, the steering may become disconnected, resulting in a complete loss of steering control. This condition may cause a collision, resulting in vehicle damage, personal injury, and an expensive lawsuit for the technician and the shop where he or she is employed. Therefore, when performing any automotive service, always be sure the vehicle manufacturer's recommended service procedures and torque specifications are followed.

AIR BAG DEPLOYMENT MODULE, STEERING WHEEL, AND CLOCK SPRING ELECTRICAL CONNECTOR REMOVAL AND REPLACEMENT

Prior to working on an air bag system, always disconnect the negative battery cable and wait one minute before proceeding with the diagnostic or service work. Many air bag systems have a **backup power supply** circuit designed into the air bag computer or located in a separate

CUSTOMER CARE: Before disconnecting the negative battery cable, note how the customer has the radio stations programmed, and reset the radio and clock after the negative battery cable is reconnected.



BASIC TOOLS

Basic technician's tool set

Service manual

Steering wheel puller

Foot-pound torque wrench

Machinist's rule

1/4" Electric drill

Set of drill bits

Screw extractors



CAUTION:

Always disconnect the negative battery terminal and wait one minute before diagnosing or servicing any air bag system component. Failure to observe this precaution may result in accidental air bag deployment. Air bag service precautions vary depending on the vehicle. Always follow the vehicle manufacturer's air bag service precautions in the service manual.

Classroom Manual

Chapter 9,
page 213

An air bag deployment module may be referred to as a steering wheel pad.

module. This backup power supply provides power to deploy the air bag for a specific length of time after the battery power is disconnected in a collision. One minute after the negative battery terminal is disconnected, this backup power supply is powered down, and no power is available to deploy the air bag while the battery remains disconnected.

An air bag warning light in the instrument panel indicates the status of the air bag system. On some vehicles, this warning light should be illuminated for a few seconds when the ignition switch is turned on. The warning light should remain off while cranking the engine, and it should be on for a few seconds after the engine starts. After the engine has been running for a few seconds, the air bag warning light should remain off. On other vehicles, the air bag warning light flashes 7 to 9 times when the ignition switch is turned on and after the engine is started. The air bag warning light operation varies depending on the make and model year of the vehicle. Always check the vehicle manufacturer's service manual for the exact air bag warning light operation. When the air bag warning light does not operate as specified by the vehicle manufacturer, the air bag system is defective, and the air bag or bags will probably not deploy if the vehicle is involved in a collision.

Air bag module and steering wheel removal and replacement procedures vary depending on the vehicle. Always follow the vehicle manufacturer's recommended procedure in the service manual.

The following is a typical air bag module and steering wheel removal and replacement procedure:

1. Turn the ignition switch to the Lock position and place the front wheels facing straight ahead.
2. Remove the negative battery terminal and wait for the specified time period.
3. Loosen the three air-bag-retaining Torx screws under the steering wheel (Figure 9-1).
4. Loosen the other two air-bag-retaining Torx screws under the steering wheel (Figure 9-2). Loosen all five Torx screws until the groove along the screw circumference catches on the screw case. Some air bag deployment modules are retained on top of the steering wheel with a spring-loaded clip. To release this clip, insert a flat-tipped screw driver into the slot at the lower edge of the steering wheel and turn the screw driver 1/4 turn to release the clip.



WARNING: When an air bag deployment module is temporarily stored on the workbench, always place this module face upward. If the air bag deployment module accidentally deployed when facing downward, the module would become a projectile, and personal injury might result.




FIGURE 9-1 Three air-bag-retaining Torx screws.




FIGURE 9-2 Two air-bag-retaining Torx screws.



FIGURE 9-3 Disconnecting the air bag module electrical connector.




FIGURE 9-4 Disconnecting the air bag wiring retainer.

5. Pull the **air bag deployment module** from the steering wheel and disconnect the air bag module electrical connector (Figure 9-3). Do not pull on the air bag wires in the steering column. Place the air bag deployment module face upward on the workbench.
6. Disconnect the air bag wiring retainer in the steering wheel (Figure 9-4).
7. Use the proper size socket and a ratchet to remove the steering wheel retaining nut.
8. Observe the matching alignment marks on the steering wheel and the steering shaft. If these alignment marks are not present, place alignment marks on the steering wheel and steering shaft with a center punch and a hammer.

! WARNING: Photo Sequence 15 shows a typical procedure for removing a steering wheel. Do not pull on the steering wheel in an attempt to remove it from the steering shaft. The steering wheel may suddenly come off, resulting in personal injury, or the steering wheel may be damaged by the pulling force.

9. Install a steering wheel puller with the puller bolts threaded into the bolt holes in the steering wheel. On some vehicles, the steering wheel has slots for the pulley adapters to fit into rather than threaded bolt holes. This design prevents the possibility of the technician turning the bolts too far into the steering wheel and damaging components below the steering wheel. Tighten the puller nut to remove the steering wheel (Figure 9-5). Visually check the steering wheel condition. If the steering wheel is bent or cracked, replace the wheel.




FIGURE 9-5 Removing steering wheel with the proper steering wheel puller.

The **air bag deployment module** contains the air bag, inflation chemicals, and an igniting device.



CAUTION: On an air-bag-equipped vehicle, the wait time prior to servicing electrical components after the negative battery terminal is disconnected varies depending on the vehicle make and model year. Always follow the wait time and all other service precautions recommended in the vehicle manufacturer's service manual.

PHOTO SEQUENCE 15

TYPICAL PROCEDURE FOR REMOVING A STEERING WHEEL



P15-1 Check and record the radio stations programmed in the stereo system.



P15-2 Look up the car manufacturer's steering wheel removal procedure in the service manual.



P15-3 Disconnect the negative battery cable, and wait for the car manufacturer's specified length of time.



P15-4 Remove the air bag deployment module retaining screws under the steering wheel.



P15-5 Lift the air bag deployment module upward from the steering wheel, and disconnect the module wiring connector.



P15-6 Set the air bag deployment module face upward on the workbench.



P15-7 Loosen and remove the steering wheel retaining nut.



P15-8 Observe the alignment marks on the steering wheel and shaft.



P15-9 Connect the proper steering wheel puller to the steering wheel.

PHOTO SEQUENCE 15 (CONTINUED)



P15-10 Turn the puller screw to loosen the steering wheel on the shaft.



P15-11 Remove the puller from the steering wheel.



P15-12 Lift the steering wheel off the shaft.

10. Disconnect the four retaining screws and remove the **clock spring electrical connector** (Figure 9-6).
11. Be sure the front wheels are facing straight ahead. Turn the clock spring electrical connector counterclockwise by hand until it becomes harder to turn as it becomes fully wound in that direction.
12. Turn the clock spring electrical connector clockwise three turns and align the red mark on the center part of the spring face with the notch in the cable circumference (Figure 9-7). This action centers the clock spring electrical connector.
13. Install the clock spring electrical connector and tighten the four retaining screws to the specified torque.
14. Align the marks on the steering wheel and the steering shaft, and install the steering wheel on the shaft.
15. Install the steering wheel retaining nut and tighten this nut to the specified torque.
16. Install the air bag wiring retainer in the steering wheel.
17. Hold the air bag deployment module near the top of the steering wheel and connect the air bag module connector.
18. Install the air bag deployment module in the top of the steering wheel and tighten the five retaining Torx screws.
19. Reconnect the negative battery cable.
20. Reset the clock and radio.



CAUTION:

Always use the vehicle manufacturer's recommended tools when diagnosing or servicing an air bag system or the electrical system on an air-bag-equipped vehicle. Do not use a 12-V test light or a self-powered test light to diagnose air bag systems or electrical systems on air-bag-equipped vehicles. **Accidental air bag deployment** may result from improper use of tools.




FIGURE 9-6 Removing clock spring electrical connector.




FIGURE 9-7 Centering clock spring electrical connector.

A **clock spring electrical connector** may be called a coil, spiral cable, or cable reel. The clock spring electrical connector connects the air bag electrical system to the air bag deployment module and allows steering wheel rotation.



SERVICE TIP:

When servicing air bag components on some recent model vehicles, the vehicle manufacturer recommends disconnecting the air bag components only in the zone or area on the vehicle where service work is required rather than disconnecting the negative battery cable.

If the vehicle is not equipped with an air bag, the steering wheel removal and replacement procedure is basically the same, but all steps pertaining to the air bag module and clock spring are not required. On a non-air-bag-equipped vehicle, the center steering wheel cover must be removed to access the steering wheel retaining nut.

CUSTOMER CARE: While servicing a vehicle, always inspect the operation of the indicator lights or gauges in the instrument panel. These lights or gauges may indicate a problem that the customer has been ignoring. For example, if the air bag warning light is not operating properly, the air bag or bags may not deploy in a collision, resulting in serious injury to the driver and/or passenger. If the air bag warning light is not working properly, always advise the customer that he or she will not be protected by the air bag in a collision, and the vehicle should not be driven under this condition.

STEERING COLUMN SERVICE

Some steering column service can be performed with the column installed in the vehicle. In some steering columns removal and replacement of the various switches in the column is possible with the column installed in the vehicle. Always follow the recommended service procedure in the vehicle manufacturer's service manual.

STEERING COLUMN REMOVAL AND REPLACEMENT

Steering column removal and replacement procedures vary depending on the vehicle make, type of steering column, and gearshift lever position. Always follow the vehicle manufacturer's recommended procedure in the service manual.

The following is a typical steering column removal and replacement procedure:

1. Disconnect the negative battery cable. If the vehicle is equipped with an air bag, wait one minute.
2. Install a seat cover on the front seat.
3. Place the front wheels in the straight-ahead position and remove the ignition key from the switch to lock the steering column.
4. Remove the cover under the steering column and remove the lower finish panel if necessary.
5. Disconnect all wiring connectors from the steering column.
6. If the vehicle has a column-mounted gearshift lever, disconnect the gearshift linkage at the lower end of the steering column. If the vehicle has a floor-mount gearshift, disconnect the shift interlock.
7. Remove the retaining bolt or bolts in the lower universal joint or flexible coupling.
8. Remove the steering-column-to-instrument-panel mounting bolts.
9. Carefully remove the steering column from the vehicle. Be careful not to damage the upholstery or paint.
10. Install the steering column under the instrument panel and insert the steering shaft into the lower universal joint.
11. Install the steering-column-to-instrument-panel mounting bolts. Be sure the steering column is properly positioned, and tighten these bolts to the specified torque.
12. Install the retaining bolt or bolts in the lower universal joint or flexible coupling, and tighten the bolts to the specified torque.
13. Connect the gearshift linkage if the vehicle has a column-mounted gearshift.
14. Connect all the wiring harness connectors to the steering column connectors.

Classroom Manual

Chapter 9,
page 214



CAUTION:

Do not hammer on the top of the steering shaft to remove the steering wheel. This action may damage the shaft.

15. Install the steering column cover and the lower finish panel.
16. Reconnect the negative battery cable.
17. Road test the vehicle and check for proper steering column operation.

COLLAPSIBLE STEERING COLUMN INSPECTION

Since steering column design varies depending on the vehicle, the **collapsible steering column** inspection procedure should be followed in the vehicle manufacturer's service manual.

The following is a typical collapsible steering column inspection procedure:

1. Measure the clearance between the capsules and the slots in the steering column bracket (Figure 9-8). If this measurement is not within specifications, replace the bracket.
2. Inspect the contact between the bolt head and the bracket (Figure 9-9). If the bolt head contacts the bracket, the shear load is too high, and the bracket must be replaced.
3. Inspect the steering column jacket for **sheared injected plastic** in the openings on the side of the jacket (Figure 9-10). If sheared plastic is present, the column is collapsed. Measure the distance from the end of the bearing assembly to the lower edge of the upper steering column jacket (Figure 9-11). If this distance is not within the vehicle manufacturer's specification, a new jacket must be installed.
4. Visually inspect the gearshift tube for sheared injected plastic. If the gearshift tube indicates sheared plastic, replace the tube.
5. Remove the intermediate steering shaft between the column and the steering gear. Position a dial indicator stem against the lower end of the steering shaft, and rotate the steering wheel. If the runout on the dial indicator exceeds the vehicle manufacturer's specification, the steering shaft is bent and must be replaced.
6. If the steering shaft is not bent but shows sheared injected plastic (Figure 9-12), this shaft may be repaired with a service repair package.



CAUTION:

If the steering wheel puller bolts are too long, they will extend through the steering wheel and damage the clock spring.



CAUTION:

Failure to center a clock spring prior to installation may cause a broken conductive tape in the clock spring.

A **collapsible steering column** allows the column to move away from the driver if the driver impacts the column during a collision.




FIGURE 9-8 Capsules in steering column bracket.




FIGURE 9-9 Bolt head to bracket clearance.




FIGURE 9-10 Inspecting for sheared plastic in jacket openings.




FIGURE 9-11 Measuring distance from the end of the bearing assembly to the upper steering column jacket.

Classroom Manual

Chapter 9,
page 217

Classroom Manual

Chapter 9,
page 219

Tapered-head bolts have a tapered head with no provision for connecting any type of wrench to the bolt.




FIGURE 9-12 Inspecting for sheared injected plastic in steering shaft.

TILT STEERING COLUMN DISASSEMBLY

Since there are many variations in steering column design, always follow the vehicle manufacturer's recommended steering column disassembly procedure in the service manual.

The following is a typical tilt steering column disassembly procedure:

1. Remove the air bag deployment module, steering wheel, and spiral cable, as mentioned previously in this chapter.
2. Remove the ignition key cylinder illumination mounted on top of the ignition switch cylinder (Figure 9-13).
3. Remove the universal joint from the lower end of the steering shaft.
4. Remove the steering column protector and the wiring harness clamp mounted under the steering column.
5. Remove the steering damper mounted near the top of the column.
6. Remove the retaining screw and the combination switch with the wiring harness (Figure 9-14).
7. Mark the center of the **tapered-head bolts** on the steering column with a center punch. Use a 0.120 to 0.160 in. (3 to 4 mm) drill bit to drill into the tapered-head bolts (Figure 9-15).
8. Remove the tapered-head bolts with a screw extractor, and separate the upper bracket and column tube (Figure 9-16).




FIGURE 9-13 Ignition key cylinder illumination mounted above ignition switch cylinder.




FIGURE 9-14 Removing combination switch and wiring harness.




FIGURE 9-15 Drilling tapered-head bolts.




FIGURE 9-16 Removing tapered-head bolts with a screw extractor.




FIGURE 9-17 Removing compression spring, seat, and bushing.




FIGURE 9-18 Removing tension spring.




FIGURE 9-19 Removing snapring from upper column tube.




FIGURE 9-20 Loosening staked parts in upper column tube.

9. Grasp the compression spring seat with a pair of pliers and turn the seat to release the seat, compression spring, and bushing (Figure 9-17).
10. Grasp the tension spring with a pair of pliers and extend this spring to remove it from the column (Figure 9-18).
11. Remove the snapring from the upper column tube with snapring pliers (Figure 9-19).
12. Use a soft hammer and a screwdriver to loosen the staked parts of the upper column tube (Figure 9-20).




FIGURE 9-21 Removing nuts on upper column pivot bolts.




FIGURE 9-22 Removing pivot bolts from steering column.




FIGURE 9-23 Removing upper column tube, tilt lever assembly, and plate washers.




FIGURE 9-24 Removing steering shaft from the steering column.




FIGURE 9-25 Removing snapring above steering shaft bushing.

- 13.** Remove the two nuts on the upper column pivot bolts (Figure 9-21).
- 14.** Use a plastic hammer to tap the pivot bolts out of the column (Figure 9-22).
- 15.** Remove the upper column tube, tilt lever assembly, and plate washers (Figure 9-23).
- 16.** Remove the steering shaft from the column (Figure 9-24).
- 17.** Use snapring pliers to remove the snapring above the steering shaft bushing (Figure 9-25). Remove the steering shaft bushing.

TILT STEERING COLUMN INSPECTION AND PARTS REPLACEMENT

- 1.** Place the ignition key in the switch and move the key through all the switch positions. Be sure the operating pin moves properly in the switch mechanism (Figure 9-26). If the ignition key cylinder must be replaced, turn the key to the accessory (ACC) position. Use a small steel rod to push down on the stop pin near the bottom of the key cylinder




FIGURE 9-26 Inspecting ignition switch operation.




FIGURE 9-27 Depressing stop pin in release ignition switch cylinder.




FIGURE 9-28 Inspecting upper steering shaft bearing.




FIGURE 9-29 Inspecting lower steering shaft bearing.




FIGURE 9-30 Inspecting ignition key interlock solenoid.

(Figure 9-27) and pull the cylinder out of the housing. Install the new key cylinder with the key in the ACC position.

2. Rotate the upper steering shaft bearing and inspect for noise, looseness, and wear (Figure 9-28). If any of these conditions are present, replace the upper tube.
3. Inspect the lower steering shaft bearing for noise, looseness, and wear (Figure 9-29). Replace this bearing if necessary.
4. Inspect the ignition key interlock solenoid for damaged wires and loose mounting screws (Figure 9-30). Repair or replace this solenoid as required.

TILT STEERING COLUMN ASSEMBLY

1. Coat all rubbing parts with **molybdenum disulphide lithium-based grease**. Install the steering shaft bushing and the bushing snapping (Figure 9-31).

Molybdenum disulphide lithium-based grease is a special grease that is applied to contacting parts in a tilt steering column.




FIGURE 9-31 Installing steering shaft bushing and snapping.




FIGURE 9-32 Installing the steering shaft in the lower tube.




FIGURE 9-33 Installing upper column tube, tilt lever mechanism, and two plate washers.




FIGURE 9-34 Tightening pivot bolt nuts.




FIGURE 9-35 Tapping steering shaft into upper column tube.




FIGURE 9-36 Staking upper column tube.

2. Install the steering shaft in the lower tube (Figure 9-32).
3. Install the upper column tube, tilt lever mechanism, and two plate washers (Figure 9-33). Install the two pivot bolts.
4. Install the pivot bolt nuts and tighten these nuts to the specified torque (Figure 9-34).
5. Use a brass bar and a hammer to tap the steering shaft into the upper column tube (Figure 9-35).
6. Stake the upper column tube with a pin punch and a hammer (Figure 9-36).
7. Install the snapping in the top of the upper column tube (Figure 9-37).
8. Install the tension spring (Figure 9-38). Assemble the compression spring, bushing, plate, and seat. Use a vise to install the compression spring and related components (Figure 9-39).
9. Install the upper bracket with two new tapered-head bolts. Tighten the tapered-head bolts until the tapered head breaks off (Figure 9-40).




FIGURE 9-37 Installing snapping in upper column tube.




FIGURE 9-38 Installing tension spring.




FIGURE 9-39 Installing compression spring.




FIGURE 9-40 Tightening tapered-head bolts in upper bracket.

10. Install the protector and wiring harness clamp.
11. Install the steering damper and ignition key illumination.
12. Install the universal joint on the bottom of the steering shaft and tighten the retaining bolt to the specified torque.
13. Install the combination switch and wiring harness and tighten the retaining screw to the specified torque.
14. Install the spiral cable, steering wheel, and air bag deployment module as mentioned earlier in this chapter.

STEERING COLUMN FLEXIBLE COUPLING AND UNIVERSAL JOINT DIAGNOSIS AND SERVICE

Checking Steering Wheel Free Play

With the engine stopped and the front wheels in the straight-ahead position, move the steering wheel in each direction with light finger pressure. Measure the amount of steering wheel movement before the front wheels begin to turn (Figure 9-41). This movement is referred to as **steering wheel free play**. On some vehicles, this measurement should not exceed 1.18 in. (30 mm). Always refer to the vehicle manufacturer's specifications. Excessive steering wheel free play is caused by worn steering shaft universal joints or flexible coupling. Other causes of excessive steering wheel free play include worn steering linkage mechanisms and a worn or out of adjustment steering gear.

Steering wheel free play is the amount of steering wheel movement before the front wheels start to turn.




FIGURE 9-41 Measuring steering wheel free play.

A worn universal joint or flexible coupling in the steering column may also cause rattling noises. The rattling noises may occur while driving the vehicle straight ahead on irregular road surfaces. With the normal vehicle weight resting on the front suspension, observe the flexible coupling or universal joint as an assistant turns the steering wheel 1/2 turn in each direction. If the vehicle has power steering, the engine should be running with the gear selector in Park. The flexible coupling or universal joint must be replaced if there is free play in this component.

Flexible Coupling Replacement

If the flexible coupling must be replaced, loosen the coupling-to-steering-gear-stub-shaft bolt. Disconnect the steering column from the instrument panel, and move the column rearward until the flexible coupling can be removed from the steering column shaft. Remove the coupling-to-steering-shaft bolts, and disconnect the coupling from the shaft. When the new coupling and the steering column are installed on some vehicles, the clearance between the coupling clamp and the steering gear adjusting plug should be 1/16 in. (1.5 mm) (Figure 9-42). This specification may vary depending on the vehicle. Always use the vehicle manufacturer's specifications in the service manual.




FIGURE 9-42 Flexible coupling installation.

STEERING COLUMN DIAGNOSIS

There are variations in steering columns depending on the vehicle, type of transmission, and the transmission gear selector position. Thus different column diagnostic procedures may be required. See Table 9-1, Table 9-2, and Table 9-3 for a typical steering column diagnosis.

TABLE 9-1 AUTOMATIC TRANSMISSION—STEERING COLUMN DIAGNOSIS

Condition	Possible Cause	Correction
Lock system—will not unlock	<ol style="list-style-type: none"> 1. Lock bolt damaged 2. Defective lock cylinder 3. Damaged housing 4. Damaged or collapsed sector 5. Damaged rack 6. Shear flange on sector shaft collapsed 	<ol style="list-style-type: none"> 1. Replace lock bolt. 2. Replace or repair lock cylinder. 3. Replace housing. 4. Replace sector. 5. Replace rack. 6. Replace.
Lock system—will not lock	<ol style="list-style-type: none"> 1. Lock bolt spring broken or defective 2. Damaged sector tooth, or sector installed incorrectly 3. Defective lock cylinder 4. Burr on lock bolt or housing 5. Damaged housing 6. Transmission linkage adjustment incorrect 7. Damaged rack 8. Interference between bowl and coupling (tilt) 9. Ignition switch stuck 10. Actuator rod restricted or bent 	<ol style="list-style-type: none"> 1. Replace spring. 2. Replace, or install correctly. 3. Replace lock cylinder. 4. Remove burr. 5. Replace housing. 6. Readjust. 7. Replace rack. 8. Adjust or replace as necessary. 9. Readjust or replace. 10. Readjust or replace.
Lock system—high effort	<ol style="list-style-type: none"> 1. Lock cylinder defective 2. Ignition switch defective 3. Rack preload spring broken or deformed 4. Burr on sector, rack, housing, support, tang of shift gate, or actuator rod coupling 5. Bent sector shaft 6. Distorted rack 7. Misalignment of housing to cover (tilt) 8. Distorted coupling slot in rack (tilt) 9. Bent or restricted actuator rod 10. Ignition switch mounting bracket bent 	<ol style="list-style-type: none"> 1. Replace lock cylinder. 2. Replace switch. 3. Replace spring. 4. Remove burr. 5. Replace shaft. 6. Replace rack. 7. Replace either or both. 8. Replace rack. 9. Straighten, remove restriction, or replace. 10. Straighten or replace.
Lock cylinder—high effort between Off and Off-lock positions	<ol style="list-style-type: none"> 1. Burr on tang of shift gate 2. Distorted rack 	<ol style="list-style-type: none"> 1. Remove burr. 2. Replace rack.

(Continued)

TABLE 9-1 (Continued)

Condition	Possible Cause	Correction
Sticks in Start position	1. Actuator rod deformed 2. Any high effort condition	1. Straighten or replace. 2. Check items under high effort section.
Key cannot be removed in Off-lock position	1. Ignition switch not set correctly 2. Defective lock cylinder	1. Readjust ignition switch. 2. Replace lock cylinder.
Lock cylinder can be removed without depressing retainer	1. Lock cylinder with defective retainer 2. Lock cylinder without retainer 3. Burr over retainer slot in housing cover	1. Replace lock cylinder. 2. Replace lock cylinder. 3. Remove burr.
Lock bolt hits shaft lock in Off and Park positions	Ignition switch not set correctly	Readjust ignition switch.
Ignition system—electrical system does not function	1. Defective fuse in "accessory" circuit 2. Connector body loose or defective 3. Defective wiring 4. Defective ignition switch 5. Ignition switch not adjusted properly	1. Replace fuse. 2. Tighten or replace. 3. Repair or replace. 4. Replace ignition switch. 5. Readjust ignition switch.
Switch does not actuate mechanically	Defective ignition switch	Replace ignition switch.
Switch cannot be set correctly	1. Switch actuator rod deformed 2. Sector to rack engaged in wrong tooth (tilt)	1. Repair or replace switch actuator rod. 2. Engage sector to rack correctly.
Noise in column	1. Coupling bolts loose 2. Column not correctly aligned 3. Coupling pulled apart 4. Sheared intermediate shaft plastic joint 5. Horn contact ring not lubricated 6. Lack of grease on bearings or bearing surfaces 7. Lower shaft bearing tight or frozen 8. Upper shaft tight or frozen 9. Shaft lock plate cover loose 10. Lock plate snapping not seated	1. Tighten pinch bolts to specified torque. 2. Realign column. 3. Replace coupling and realign column. 4. Replace or repair steering shaft and realign column. 5. Lubricate with Lubriplate. 6. Lubricate bearings. 7. Replace bearing. Check shaft and replace if scored. 8. Replace housing assembly. 9. Tighten three screws or, if missing, replace. CAUTION: Use specified screws (15 inch-pounds). 10. Replace snapping. Check for proper seating in groove.

	11. Defective buzzer dog cam on lock cylinder 12. One click when in Off-lock position and the steering wheel is moved	11. Replace lock cylinder. 12. Normal condition: lock bolt is seating.
Steering shaft—high effort	1. Column assembly misaligned in vehicle 2. Improperly installed or deformed dust seal 3. Tight or frozen, upper or lower bearing 4. Flash on ID of shift tube from plastic joint	1. Realign. 2. Remove and replace. 3. Replace affected bearing or bearings. 4. Replace shift tube.
High shift effort	1. Column not aligned correctly in car 2. Improperly installed dust seal 3. Lack of grease on seal or bearing areas 4. Burr on upper or lower end of shift tube 5. Lower bowl bearing not assembled properly (tilt) 6. Wave washer with burrs (tilt)	1. Realign. 2. Remove and replace. 3. Lubricate bearings and seals. 4. Remove burr. 5. Reassemble properly. 6. Replace wave washer.
Improper transmission shifting	1. Sheared shift tube joint 2. Improper transmission linkage adjustment 3. Loose lower shift lever 4. Improper gate plate 5. Sheared lower shift lever weld	1. Replace shift tube assembly. 2. Readjust linkage. 3. Replace shift tube assembly. 4. Replace with correct part. 5. Replace tube assembly.
Lash in mounted column assembly	1. Instrument panel mounting bolts loose 2. Broken weld nuts on jacket 3. Instrument panel bracket capsule sheared 4. Instrument panel to jacket mounting bolts loose 5. Loose shoes in housing (tilt) 6. Loose tilt head pivot pins (tilt) 7. Loose shoe lock pin in support (tilt)	1. Tighten to specifications (20 foot-pounds). 2. Replace jacket assembly. 3. Replace bracket assembly. 4. Tighten to specifications (15 foot-pounds). 5. Replace. 6. Replace. 7. Replace.
Miscellaneous	1. Housing loose on jacket noticed with ignition in Off-lock position and a torque applied to the steering wheel 2. Shroud loose on shift bowl	1. Tighten four mounting screws (60 inch-pounds). 2. Bend tabs on shroud over lugs on bowl.

TABLE 9-2 MANUAL TRANSMISSION—STEERING COLUMN DIAGNOSIS

Condition	Possible Cause	Correction
Shift lever sticking	<ol style="list-style-type: none"> 1. Defective upper shift lever 2. Defective shift lever gate 3. Loose relay lever on shift tube 4. Wrong shift lever 	<ol style="list-style-type: none"> 1. Replace shift lever. 2. Replace shift lever gate. 3. Replace shift tube assembly. 4. Replace with current lever.
High shift effort	<ol style="list-style-type: none"> 1. Column not aligned correctly 2. Lower bowl bearing not assembled correctly 3. Improperly installed seal 4. Wave washer in lower bowl bearing defective 5. Improper adjustment of lower shift levers 6. Lack of grease on seal, bearing areas, or levers 7. Damaged shift tube in bearing areas 	<ol style="list-style-type: none"> 1. Realign column. 2. Reassemble correctly. 3. Remove and replace. 4. Replace wave washer. 5. Readjust. 6. Lubricate seal, levers, and bearings. 7. Replace shift tube assembly.
Improper transmission shifting	Loose relay lever on shift tube	Replace shift tube assembly.

TABLE 9-3 MANUAL TRANSMISSION—TILT COLUMN DIAGNOSIS

Condition	Possible Cause	Correction
Housing scraping on bowl	Bowl bent or not concentric with hub	Replace bowl.
Steering wheel loose	<ol style="list-style-type: none"> 1. Excessive clearance between holes in support or housing and pivot pin diameters 2. Defective or missing antilash spring in spheres 3. Upper bearing seat not seating in bearing 4. Upper bearing inner race seat missing 5. Loose support screws 6. Bearing preload spring missing or broken 	<ol style="list-style-type: none"> 1. Replace either or both. 2. Add spring or replace both. 3. Replace both. 4. Install seat. 5. Tighten to 60 inch-pounds. 6. Replace preload spring.
Steering wheel loose every other tilt position	Loose fit between shoe and shoe pivot pin	Replace both.
Noise when tilting column	<ol style="list-style-type: none"> 1. Upper tilt bumper worn 2. Tilt spring rubbing in housing or dirt 	<ol style="list-style-type: none"> 1. Replace tilt bumper. 2. Lubricate.
Steering column not locking in any tilt position	<ol style="list-style-type: none"> 1. Shoe seized on its pivot pin 2. Shoe grooves might have burrs 3. Shoe lock spring weak or broken 	<ol style="list-style-type: none"> 1. Replace shoe and pivot pin. 2. Replace shoe. 3. Replace lock spring.
Steering wheel fails to return to top tilt position	<ol style="list-style-type: none"> 1. Pivot pins bound up 2. Wheel tilt spring defective 3. Turn signal switch wires too tight 	<ol style="list-style-type: none"> 1. Replace pivot pins. 2. Replace tilt spring. 3. Reposition wires.

STEERING LINKAGE DIAGNOSIS AND SERVICE

Diagnosis of Center Link, Pitman Arm, and Tie-Rod Ends

The vehicle should be raised and safety stands positioned under the lower control arms to support the vehicle weight. Use vertical hand force to check for looseness in all the pivots on the tie-rod ends and the center link. Inspect the seals on each tie-rod end and pivot on the center link or pitman arm for damage and cracks. Cracked seals allow dirt to enter the pivoted joints, which results in rapid wear. If looseness or damaged seals are found on any pivoted joint on the tie-rods and center link, these components must be replaced.

The second part of this diagnosis is done with the front wheels resting on the shop floor. If the vehicle is equipped with power steering, start the engine and allow the engine to idle with the transmission in Park and the parking brake applied. While someone turns the steering wheel one-quarter turn in each direction from the straight-ahead position, observe all the pivoted joints on the tie-rod ends and center link. This test allows the technician to check the steering linkage pivots under load. If any of the pivoted joints show a slight amount of play, they must be replaced.

Tie-Rod End Replacement

Worn tie-rod ends result in these problems:

1. Excessive steering wheel free play
2. Incorrect front wheel toe setting
3. Tire squeal on turns
4. Tread wear on front tires
5. Front wheel shimmy
6. Rattling noise on road irregularities

The cotter pin and nut must be removed prior to tie-rod end replacement. A puller is used to remove the tie-rod end from the steering arm (Figure 9-43). Tie-rod ends with rubber-encapsulated ball studs require special inspection and diagnostic procedures (Figure 9-44). On this type of tie-rod end, inspect for looseness of the ball stud in the rubber capsule and looseness of the stud and rubber capsule in the outer housing. If any looseness is present, replace the tie-rod end. Tie-rod end replacement is also necessary if there is any indication of the rubber capsule starting to come out of the outer housing.

**Classroom
Manual**

Chapter 9,
page 222

Front wheel shimmy may be defined as a consistent, fast, side-to-side movement of the front wheels and steering wheel. This movement is usually experienced at speeds above 40 mph (25 km/h), and it may occur more frequently while driving on irregular road surfaces.



SPECIAL TOOLS

Tie-rod end puller




FIGURE 9-43 Removing tie-rod end.




FIGURE 9-44 Tie-rod end with rubber encapsulated ball stud.




FIGURE 9-45 Measuring turning torque on a rubber-encapsulated tie-rod end.




FIGURE 9-46 Tie-rod nut and cotter pin installation.

After the tie-rod end is removed from the steering arm, install two nuts on the stud threads and tighten these nuts against each other. Use the proper size of socket and a torque wrench to rotate the ball stud through a 40° arc (Figure 9-45). If the ball stud turning torque is less than 20 ft-lb. (27 Nm), replace the tie-rod end.

The tie-rod clamp must be loosened before the tie-rod end is removed from the sleeve. Count the number of turns required to remove the tie-rod end from the sleeve, and install the new tie-rod with the same number of turns. Even when this procedure is followed, the toe must be checked after the steering linkage components are replaced. Before the new tie-rod end is installed, center the stud in the tie-rod end. When the tie-rod end stud is installed in the steering arm opening, only the threads should be visible above the steering arm surface. If the machined surface of the tie-rod end stud is visible above the steering arm surface, or if the stud fits loosely in the steering arm opening, this opening is worn or the tie-rod end is not correct for that application. The tie-rod end nut must be torqued to the manufacturer's specifications, and the cotter pin must be installed through the tie-rod end and nut openings (Figure 9-46). Photo Sequence 16 illustrates the procedure for removing and replacing an outer tie-rod end.

The tie-rod end nut must never be loosened from the specified torque to install the cotter pin. Another method of positioning replacement tie-rod ends is to measure the distance from the center of the tie-rod stud to the end of the sleeve prior to removal. When the new tie-rod end is installed, be sure this measurement is the same. The slots in the tie-rod sleeve must be positioned away from the opening in the sleeve clamps (Figure 9-47). Leave the sleeve clamps loose until the front wheel toe is checked, and then tighten the sleeve clamp bolts to the specified torque. A special tool is available to rotate the tie-rod sleeves and set the front wheel toe (Figure 9-48).

When rubber-encapsulated tie-rod ends are installed and tightened to the specified torque, the front wheels must be straight ahead. Tightening this type of tie-rod end with the front wheels in any other position but straight ahead may cause steering pull or wander. After rubber-encapsulated tie-rod ends are tightened to the specified torque, it is acceptable for the tie-rod end housing to be tilted to one side (Figure 9-49).



CAUTION:

If rubber-encapsulated tie-rod ends are tightened with the front wheels in any position but straight ahead, steering pull and wander may occur.




FIGURE 9-47 Proper slot and clamp position on tie-rod sleeves.




FIGURE 9-48 Tie-rod sleeve adjusting tool.




FIGURE 9-49 Rubber-encapsulated tie-rod end housing may be tilted to one side after it is installed and tightened.

Pitman Arm Diagnosis and Replacement

Some pitman arms contain a ball socket joint on the outer end. The threaded extension on this ball socket fits into the center link. On other steering linkages, the ball socket joint is in the center link, and the threaded extension fits into the pitman arm opening. If the pitman arm is bent, it must be replaced because the tie-rod is not parallel to the lower control arm. Under this condition, excessive front wheel toe change occurs on road irregularities, and front tire wear may be excessive.

The following is a typical pitman arm replacement procedure:

1. Position the front wheels straight ahead, and remove the cotter pin and nut from the ball socket joint on the outer end of the pitman arm.
2. Remove the ball socket extension from the pitman arm or center link with a tie-rod end puller.
3. Loosen the pitman-arm-to-pitman-shaft nut.
4. Use a puller to pull the pitman arm loose on the shaft.
5. Remove the nut, lock washer, and pitman arm.
6. Check the pitman shaft splines. If the splines are damaged or twisted, the shaft must be replaced.
7. Reverse steps 1 through 5 to install the pitman arm. The pitman arm-to-shaft nut and the ball socket extension nut must be tightened to the manufacturer's specified torque. Be sure the pitman arm is installed in the correct position on the shaft splines. Install the cotter pin in the ball socket extension.



SPECIAL TOOLS
Pitman arm puller

PHOTO SEQUENCE 16

DIAGNOSING, REMOVING, AND REPLACING AN OUTER TIE-ROD END ON A VEHICLE WITH A PARALLELOGRAM STEERING LINKAGE



P16-1 Raise the vehicle on a lift and check for excessive vertical movement in the left outer tie-rod end.



P16-2 Check for lateral movement in the left outer tie-rod end.



P16-3 Visually inspect the left outer tie-rod end seal for cracks and damage.



P16-4 Loosen the nut on the outer bolt in the left tie-rod sleeve.



P16-5 Use a pair of side cutters to remove the cotter pin in the left outer tie-rod end retaining nut.



P16-6 Use the proper size socket and ratchet to remove the retaining nut on the outer tie-rod end.



P16-7 Use a tape measure to carefully measure the distance from the outer edge of the left tie-rod sleeve to the outer edge of the tie-rod end, and record this distance.



P16-8 Install a tie-rod end puller on the left outer tie-rod end and tighten the puller bolt to remove the tie-rod end from the steering arm.



P16-9 After the tie-rod end is removed from the steering arm, rotate the outer tie-rod end to remove it from the tie-rod sleeve.


PHOTO SEQUENCE 16 (CONTINUED)



P16-10 Inspect the outer tie-rod sleeve for thread damage.



P16-11 Thread the new tie-rod end into the outer tie-rod sleeve until the distance from the outer edge of the sleeve to the outer edge of the tie-rod end is exactly the same as the original distance measured and recorded previously.




P16-12 Be sure the seal is properly installed on the new tie-rod end, and install the outer tie-rod end in the steering arm opening and install the nut to retain the tie-rod end.



P16-13 Use a torque wrench and the proper size socket to tighten the left outer tie-rod nut to the specified torque. Be sure the serrated openings in the nut are aligned with the hole in the tie-rod stud.



P16-14 Install the cotter pin in the left outer tie-rod nut and bend the ends of this cotter pin around the nut.



P16-15 Position the outer tie-rod sleeve clamp so the clamp opening is positioned away from the slots in the tie-rod sleeve, and tighten the clamp bolt nut to the specified torque.



P16-16 Inflate all the vehicle tires to the specified pressure, and position the vehicle properly on a wheel alignment ramp. Use the wheel aligner to check the front wheel toe. Adjust the front wheel toe if necessary.



SERVICE TIP:

Never attempt to straighten steering linkage components. This action may weaken the metal and cause sudden component failure, vehicle damage, and personal injury.

Center Link Diagnosis and Replacement

A bent center link must be replaced. Do not attempt to straighten this rod. If the ball socket joints are loose on either end of the rod, center link assembly replacement is necessary. If the ball stud openings in the center link are worn, replace the center link.

Follow these steps for a typical center link replacement:

1. Remove the cotter pins from the tie-rod-to-center-link nuts, and the idler arm and pitman-arm-to-center-link nuts.
2. Remove the nuts on the tie-rod inner ends, idler-arm-to-center-link ball socket extension, and the pitman-arm-to-center-link ball socket extension.
3. Use a tie-rod end puller to pull the inner tie-rods from the center link. Follow the same procedure to remove the center-link-to-pitman-arm ball socket extension.
4. Remove the idler arm from the center link; then remove the center link.
5. Reverse steps 1 through 4 to install the center link. Tighten all the ball socket nuts to the manufacturer's specified torque, and install cotter pins in all the nuts. If the ball sockets have grease fittings, lubricate the ball sockets with a grease gun and chassis lubricant.

Idler Arm Diagnosis

To measure idler arm vertical movement, attach the magnetic base of a dial indicator to the frame near the idler arm. Position the dial indicator stem against the upper side on the outer end of the idler arm. Preload the dial indicator stem and zero the dial. Use a pull scale to apply 25 lbs. (11.34 kg) of force downward and upward on the idler arm (Figure 9-50). Observe the total vertical idler arm movement on the dial indicator. If this vertical movement exceeds the vehicle manufacturer's specifications, replace the idler arm. Typical maximum vertical idler arm movement from the downward to the upward position is 0.250 in. (63.5 mm). If idler arm vertical movement is excessive, the tie-rod is not parallel to the lower control arm.




FIGURE 9-50 Measuring idler arm vertical movement.




FIGURE 9-51 Specified clearance between center of lower bracket bolt hole and upper idler arm surface.

Excessive idler arm vertical movement causes these steering problems:

1. Excessive toe change and front tire tread wear
2. Excessive steering wheel free play and reduced steering control
3. Front end shimmy

Binding idler arm bushings result in these complaints:

1. Hard steering
2. Squawking noise when the front wheels are turned
3. Poor steering wheel returnability

Some idler arms contain steel bushings, whereas others are equipped with rubber bushings.

The following is a typical idler arm removal and replacement procedure:

1. Remove the idler-arm-to-center-link cotter pin and nut.
2. Remove the center link from the idler arm.
3. Remove the idler arm bracket mounting bolts, and remove the idler arm.
4. If the idler arm has a steel bushing, thread the bracket into the idler arm bushing until the specified clearance is obtained between the center of the lower bracket bolt hole and the upper idler arm surface (Figure 9-51).
5. Install the idler arm bracket to frame bolts, and tighten the bolts to the specified torque. Be sure that lock washers are installed on the bolts.
6. Install the center link into the idler arm, and tighten the mounting nut to the specified torque. Install the cotter pin in the nut.
7. If the idler arm contains a grease fitting, lubricate as required.

The idler arm adjustment is very important. If this adjustment is incorrect, front wheel toe is affected. After idler arm replacement, the front wheel toe should be checked.

Steering Damper Diagnosis and Replacement

Some steering systems have a damper connected between the center link and the chassis. A damper is similar to a small shock absorber. The purpose of the damper is to prevent the transfer of steering shock and vibrations to the steering wheel. A worn-out steering damper may cause excessive steering shock and vibration on the steering wheel, especially on irregular road surfaces. A rattling noise occurs if the damper mounting bolts or brackets are loose.

The following is a typical steering damper checking and replacement procedure:

1. Lift the vehicle on a hoist, and grasp the damper firmly. Apply vertical and horizontal pressure to the damper, and check for movement in the damper mounts. If movement exists, tighten or replace the damper mounting bushings or brackets.



SERVICE TIP:

A binding idler arm may suddenly break off and cause complete loss of steering control, vehicle damage, and personal injury.

2. Visually inspect the damper for oil leaks. A slight film of oil on the damper body near the shaft seal is acceptable. If there is any indication of oil dripping from the damper, the unit must be replaced.
3. Disconnect one end of the damper, and pull the damper back and forth horizontally. The damper should offer a slight equal resistance to movement in either direction. When this resistance is not felt in one or both directions, replace the damper.
4. To replace the damper, remove the mounting bolts from the chassis and the center link.
5. When the new damper is installed, tighten the mounting bolts to the specified torque. Turn the steering wheel fully in each direction, and be sure the damper does not restrict linkage movement.

Steering Arm Diagnosis

If the front rims have been damaged, the steering arms should be checked for a bent condition. Measure the distance from the center of the tie-rod end stud to the edge of the rim on each side. Unequal readings may indicate a bent steering arm. Bent steering arms must be replaced. Steering linkage diagnosis is summarized in Table 9-4.

TABLE 9-4 STEERING LINKAGE DIAGNOSIS

Condition	Possible Cause	Correction
Excessive play or looseness in steering system	<ol style="list-style-type: none"> 1. Front wheel bearings loosely adjusted 2. Worn steering shaft couplings 3. Worn upper ball joints 4. Steering wheel loose on shaft or loose pitman arm, tie-rods, steering arms, or steering linkage ball studs 5. Steering gear thrust bearings loosely adjusted 6. Excessive over-center lash in steering gear 7. Worn intermediate rod or tie-rod sockets 	<ol style="list-style-type: none"> 1. Adjust bearings to obtain proper endplay. 2. Replace part. 3. Check and replace if necessary. 4. Tighten to specified torque, or replace if necessary. 5. Adjust preload to specifications. 6. Adjust preload to specifications per shop manual. 7. Replace worn part.
Excessive looseness in tie-rod or intermediate rod pivots, or excessive vertical lash in idler support	Seal damage and leakage resulting in loss of lubricant, corrosion, and excessive wear	Replace damaged parts as necessary. Properly position upon reassembly.
Hard steering—excessive effort required at steering wheel	<ol style="list-style-type: none"> 1. Low or uneven tire pressure 2. Steering linkage or bolt joints need lubrication 3. Tight or frozen intermediate rod, tie-rod, or idler socket 4. Steering gear-to-column misalignment 5. Steering gear adjusted too tightly 6. Front wheel alignment incorrect (manual gear) 	<ol style="list-style-type: none"> 1. Inflate to specified pressures. 2. Lube with specified lubricant. 3. Lube, replace, or reposition as necessary. 4. Align column. 5. Adjust over-center and thrust bearing preload to specification. 6. Check alignment and correct as necessary.

(Continued)

TABLE 9-4 (Continued)

Condition	Possible Cause	Correction
Poor returnability	1. Steering linkage or ball joints need lubrication	1. Lube with specified lubricant.
	2. Steering gear adjusted too tightly	2. Adjust over-center and thrust bearing preload to specifications.
	3. Steering gear-to-column misalignment	3. Align columns.
	4. Front wheel alignment incorrect (caster)	4. Check alignment and correct as necessary.

CASE STUDY

A customer complained about excessive steering effort and poor steering wheel returnability after a turn on a 2009 General Motors Sierra truck with power steering. The technician road tested the car and found the customer's description of the problems to be accurate except for one point. The steering continually required excessive steering effort, and the steering wheel did not return properly after a turn. However, the customer did not mention, or possibly did not notice, that a squawking and creaking noise was sometimes heard during a turn.

The technician checked the power steering fluid level and condition, and found this fluid to be in good condition and at the proper level. Next, the technician checked the power steering belt condition and the power steering pump pressure. The belt tension and

condition were satisfactory, and the power steering pump pressure was normal. A check of the power steering pump mounting bolts and brackets indicated they were in good condition. The technician disconnected the center link from the pitman arm and rotated the steering wheel with the engine running. Under this condition, the steering wheel turned very easily. Therefore, the technician concluded the excessive steering effort and poor returnability problems were not in the steering column or steering gear. Next, the technician disconnected the idler arm from the center link. When the technician attempted to move the idler arm back and forth, the idler arm had a severe binding problem. After an idler arm replacement, a road test revealed the excessive steering effort and poor returnability problems had disappeared.

TERMS TO KNOW

Accidental air bag deployment
Air bag deployment module
Backup power supply
Clock spring electrical connector
Collapsible steering column
Molybdenum disulphide lithium-based grease
Sheared injected plastic
Steering wheel free play
Tapered-head bolts

ASE-STYLE REVIEW QUESTIONS

1. While discussing steering column service on an air-bag-equipped vehicle:
Technician A says service personnel should disconnect the negative battery cable and wait one minute prior to servicing an air bag system component.
Technician B says a 12-V test lamp may be used to diagnose an air bag system.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

2. While discussing steering column service on an air-bag-equipped vehicle:
Technician A says an air bag deployment module should be placed face downward on the work-bench.
Technician B says the backup power supply provides power to deploy the air bag if the battery is disconnected during a frontal collision.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

3. While discussing steering wheel and clock spring electrical connector removal and replacement on an air-bag-equipped vehicle:
Technician A says the steering may bind if the clock spring is improperly installed.
Technician B says when the clock spring electrical connector is installed, the front wheels should be straight ahead, and the clock spring should be turned fully clockwise.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

4. While discussing steering wheel removal:
Technician A says a steering wheel should be marked in relation to the steering shaft.
Technician B says the steering wheel should be grasped firmly with both hands and pulled from the shaft.
 Who is correct?
 A. A only C. Both A and B
 B. B only D. Neither A nor B
5. While discussing collapsible steering column damage:
Technician A says if the vehicle has been in a frontal collision, the injected plastic in the column jacket, gearshift tube, and steering shaft may be sheared.
Technician B says after a collision, some steering columns may be shifted on the bracket.
 Who is correct?
 A. A only C. Both A and B
 B. B only D. Neither A nor B
6. All of these statements about steering column service are true EXCEPT:
 A. Many ignition switches must be in the ACC position before removing the switch cylinder.
 B. An improperly installed dust seal may cause excessive steering wheel free play.
 C. High steering effort may be caused by an improperly aligned steering column.
 D. A worn steering shaft universal joint may cause excessive steering wheel free play.
7. A rattling noise in the steering column and linkage may be caused by:
 A. A bent center link.
 B. A binding idler arm.
 C. A worn steering shaft U-joint.
 D. Loose tie-rod sleeve clamps.
8. When diagnosing and servicing tie-rod ends:
 A. Rubber-encapsulated tie-rod ends should be tightened with the wheels turned fully to the right or left.
 B. The machined part of the tie-rod stud should be visible above the surface of the steering arm.
 C. The nut on the tie-rod stud may be loosened to install the cotter pin.
 D. If the turning torque on a rubber-encapsulated tie-rod end is less than specified, the tie-rod end must be replaced.
9. When diagnosing and servicing steering linkages:
 A. A worn tie-rod end causes excessive front wheel toe change.
 B. Bent steering linkages may be straightened in a hydraulic press.
 C. The slot in a tie-rod sleeve clamp must be positioned above the slot in the tie-rod sleeve.
 D. Front wheel shimmy may be caused by a binding idler arm.
10. An idler arm has 5/8 in. (15.8 mm) vertical movement. To correct this problem it is necessary to:
 A. Install thicker shims between the idler arm and the bracket.
 B. Install an oversize bushing in the idler arm.
 C. Replace the idler arm assembly.
 D. Replace the Belleville washer and spacer under the bushing.

ASE CHALLENGE QUESTIONS

1. A preliminary steering inspection reveals that the steering wheel has nearly 1/2 inch of movement in either direction before the pitman arm begins to move. All of the following could cause this problem EXCEPT:
 A. Coupling joints.
 B. U joints.
 C. Tight or seized shaft bearing.
 D. Worn or out-of-adjustment steering gear.
2. A customer complains that sometimes the ignition switch won't unlock and the key won't turn. A preliminary inspection reveals that turning the steering wheel does not help but repositioning the key, after several attempts, unlocks the ignition.
Technician A says the problem could be the column assembly is misaligned.
Technician B says the problem could be the ignition key is worn.
 Who is correct?
 A. A only C. Both A and B
 B. B only D. Neither A nor B

3. If the clock spring electrical connector is not properly centered before it is installed:
- A. The steering may pull to one side.
 - B. The clock spring electrical connector may be broken.
 - C. The air bag may deploy without the vehicle being in an accident.
 - D. The steering may have a binding condition.

4. A customer says the steering on his vehicle is very hard to turn in both directions. A preliminary inspection reveals no problems with the manual rack and pinion steering gear.

Technician A says the problem could be a misaligned steering column.

Technician B says the problem could be tight or frozen tie-rod ends.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

5. A customer says his steering has a shimmy problem above 50 mph (80 km/h). Preliminary inspection indicates excessive wear on the right front tire.

Technician A says the problem could be a worn tie-rod end.

Technician B says the problem could be a worn idler arm ball joint.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

Name _____ Date _____

REMOVE AND REPLACE AIR BAG INFLATOR MODULE AND STEERING WHEEL

Upon completion of this job sheet, you should be able to remove and replace an air bag inflator module and steering wheel.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-1, B-2. Disable and enable supplemental restraint system (SRS). Remove and replace steering wheel, center/time supplemental restraint system (SRS) coil block spring.

Tools and Materials

Steering wheel puller
Torque wrench

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Turn the ignition switch to the Lock position and place the front wheels facing straight ahead.
2. Remove the negative battery terminal and wait the time period specified by the vehicle manufacturer before servicing air bag components.

☐


Specified waiting period _____

After the negative battery cable is disconnected, explain why a waiting period is necessary before working on the air bag system.

3. Loosen the air bag retaining screws under the steering wheel.
4. Loosen the other two air bag retaining screws under the steering wheel.

☐
☐

Loosen all the screws until the groove along the screw circumference catches on the screw case.

 **WARNING:** When an air bag deployment module is temporarily stored on the workbench, always place this module face upward. If the air bag deployment module accidentally deployed when facing downward, the module would become a projectile and personal injury may result.

Task Completed

☐

5. Pull the air bag deployment module from the steering wheel, and disconnect the air bag module electrical connector. Do not pull on the air bag wires in the steering column. Place the air bag deployment module face upward on the workbench.

☐

6. Disconnect the air bag wiring retainer in the steering wheel.

☐

7. Use the proper size socket and a ratchet to remove the steering wheel retaining nut.

☐

8. Observe the matching alignment marks on the steering wheel and the steering shaft. If these alignment marks are not present, place alignment marks on the steering wheel and steering shaft with a center punch and a hammer.

Alignment marks on steering wheel and steering shaft:

☐ Satisfactory ☐ Unsatisfactory



WARNING: Do not pull on the steering wheel in an attempt to remove it from the steering shaft. The steering wheel may suddenly come off, resulting in personal injury, or the steering wheel may be damaged by the pulling force.

☐

9. Install a steering wheel puller with the puller bolts threaded into the bolt holes in the steering wheel. Tighten the puller nut to remove the steering wheel. Visually check the steering wheel condition. If the steering wheel is bent or cracked, replace the wheel.

Steering wheel condition: ☐ Satisfactory ☐ Unsatisfactory

☐

10. Disconnect the four retaining screws, and remove the clock spring electrical connector.

☐

11. Be sure the front wheels are facing straight ahead. Turn the clock spring electrical connector counterclockwise by hand until it becomes harder to turn as it becomes fully wound in that direction.

12. Turn the clock spring electrical connector clockwise three turns, and align the red mark on the center part of the spring face with the notch in the cable circumference. This action centers the clock spring electrical connector.

Is the clock spring centered? ☐ Yes ☐ No

Instructor check _____

Explain why the clock spring electrical connector must be centered before it is installed.

☐

13. Install the clock spring electrical connector, and tighten the four retaining screws to the specified torque.

14. Align the marks on the steering wheel and the steering shaft, and install the steering wheel on the shaft.

Are the marks on the steering wheel and steering shaft aligned? ☐ Yes ☐ No

Instructor check _____



CAUTION:

Do not hammer on the top of the steering shaft to remove the steering wheel. This action may damage the shaft.

15. Install the steering wheel retaining nut, and tighten this nut to the specified torque.

Specified steering wheel retaining nut torque _____

Actual steering wheel retaining nut torque _____

16. Install the air bag wiring retainer in the steering wheel. ☐

17. Hold the air bag deployment module near the top of the steering wheel, and connect the air bag module connector. ☐

18. Install the air bag deployment module in the top of the steering wheel, and tighten the retaining screws. ☐

19. Reconnect the negative battery cable. ☐

20. Reset the clock and radio. ☐

21. Turn on the ignition switch and start the vehicle. Check the operation of the air bag system warning light. ☐

Explain the air bag system warning light operation that indicates normal air bag system operation.

Instructor's Response _____



CAUTION:

Failure to center a clock spring prior to installation may cause a broken conductive tape in the clock spring.

Name _____ Date _____

REMOVE AND REPLACE STEERING COLUMN

Upon completion of this job sheet, you should be able to remove and replace a steering column.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-3: Diagnose steering column noises, looseness, and binding concerns (including tilt mechanisms), determine necessary action.

Tools and Materials

Seat cover

Torque wrench

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. Disconnect the negative battery cable. If the vehicle is equipped with an air bag, wait for the time period specified by the vehicle manufacturer.

Specified waiting period prior to servicing air bag components _____

Explain why it is necessary to disconnect the battery before removing the steering column.

2. Install a seat cover on the front seat.

☐

3. Place the front wheels in the straight-ahead position and remove the ignition key from the switch to lock the steering column.

Are the front wheels straight? ☐ Yes ☐ No

Is the ignition key removed?

Instructor check _____

☐

4. Remove the cover under the steering column and remove the lower finish panel if necessary.

☐

5. Disconnect all wiring connectors from the steering column.

☐

6. If the vehicle has a column-mounted gearshift lever, disconnect the gearshift linkage at the lower end of the steering column.

☐

Task Completed

☐☐☐☐☐☐☐☐☐

7. Remove the retaining bolt or bolts in the lower universal joint or flexible coupling.
8. Remove the steering-column-to-instrument-panel mounting bolts.
9. Carefully remove the steering column from the vehicle. Be careful not to damage the upholstery or paint.
10. Install the steering column under the instrument panel and insert the steering shaft into the lower universal joint.
11. Install the steering column to instrument panel mounting bolts. Be sure the steering column is properly positioned, and tighten these bolts to the specified torque.
Specified torque, steering column mounting bolts _____
Actual torque, steering column mounting bolts _____
12. Install the retaining bolt or bolts in the lower universal joint or flexible coupling, and tighten the bolt(s) to the specified torque.
Specified torque, lower U-joint retaining bolt(s) _____
Actual torque, lower U-joint retaining bolt(s) _____
13. Connect the gearshift linkage if the vehicle has a column-mounted gearshift.
14. Connect all the wiring harness connectors to the steering column connectors.
15. Install the steering column cover and the lower finish panel.
16. Reconnect the negative battery cable.
17. Road test the vehicle, and check for proper steering column operation.

Steering column operation: ☐ Satisfactory ☐ Unsatisfactory

Instructor's Response _____

Name _____ Date _____

DIAGNOSE, REMOVE, AND REPLACE IDLER ARM

Upon completion of this job sheet, you should be able to diagnose, remove, and replace an idler arm.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-17: Inspect and replace pitman arm, relay (centerlink/intermediate) rod, idler arm and mountings, steering linkage damper.

Tools and Materials

Pull scale
Dial indicator
Torque wrench
Grease gun

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Attach the magnetic base of a dial indicator to the frame near the idler arm.
2. Position the dial indicator stem against the upper side on the outer end of the idler arm. Preload the dial indicator stem, and zero the dial.
3. Use a pull scale to apply 25 lbs. (11.34 kg) of force downward and then upward on the idler arm. Observe the total vertical idler arm movement on the dial indicator. If this vertical movement exceeds the vehicle manufacturer's specifications, replace the idler arm.

☐
☐

Specified vertical idler arm movement _____

Actual vertical idler arm movement _____

Recommended idler arm service _____

Explain the effect of idler arm wear on steering quality.

4. Remove the idler arm to center link cotter pin and nut.
5. Remove the center link from the idler arm.

☐
☐

Task Completed☐

6. Remove the idler arm bracket mounting bolts and remove the idler arm.
7. If the idler arm has a steel bushing, thread the bracket into the idler arm bushing until the specified clearance is obtained between the center of the lower bracket bolt hole and the upper idler arm surface.

Specified distance from center of lower bracket hole to upper idler arm surface

Actual distance from center of lower bracket hole to upper idler arm surface

8. Install the idler arm bracket to frame bolts and tighten the bolts to the specified torque. Be sure that lock washers are installed on the bolts.

Specified idler arm retaining bolt torque _____

Actual idler arm retaining bolt torque _____

9. Install the center link into the idler arm and tighten the mounting nut to the specified torque. Install the cotter pin in the nut.

Specified center link to idler arm retaining nut torque _____

Actual center link to idler arm retaining nut torque _____

☐

10. If the idler arm has a grease fitting, lubricate as required.

Instructor's Response _____

Name _____ Date _____

REMOVE AND REPLACE OUTER TIE-ROD END, PARALLELOGRAM STEERING LINKAGE

Upon completion of this job sheet, you should be able to remove and replace outer tie-rod ends in a parallelogram steering linkage.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-18: Inspect, replace, and adjust tie rod ends (sockets) tie rod sleeves, and clamps.

Tools and Materials

Tie-rod puller

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

1. Raise the vehicle on a lift with the tires supported on the lift. If the vehicle has rubber-encapsulated tie-rod ends, be sure the front wheels are straight ahead.
2. Loosen the nut on the tie-rod sleeve bolt that retains the sleeve to the tie-rod ends.
3. Measure from the top center of the tie-rod end ball stud to the outer end of the tie-rod sleeve, and record the measurement.
Distance from the center of the tie-rod end ball stud to the outer end of the tie-rod sleeve _____
4. Remove the cotter pin from the tie-rod end retaining nut.
5. Loosen the tie-rod end retaining nut.
6. Use a tie-rod end puller to loosen the tie-rod end taper in the steering arm.
7. Remove the tie-rod end retaining nut and remove the tie-rod end from the steering arm.
8. Count the number of turns required to thread the tie-rod end out of the tie-rod sleeve.
Number of turns required to remove the tie-rod end from the tie-rod sleeve _____

Describe the effect of worn, loose outer tie-rod ends on steering quality.

9. Install the new tie-rod end in the tie-rod sleeve using the same number of turns recorded in step 8.

10. Push the tie-rod end ball stud fully into the steering arm opening. Only the threads on the tie-rod end ball stud should be visible above the steering arm surface.

Is the taper on the tie-rod end ball stud visible above the steering arm surface?

☐ Yes ☐ No

If the answer to this question is yes, state the necessary repairs required to correct this problem.

Instructor check _____

11. With the tie-rod end ball stud pushed fully upward into the steering arm, measure the distance from the center of the ball stud to the outer end of the tie-rod sleeve.

Distance from the center of the tie-rod end ball stud to the outer end of the tie-rod sleeve

12. If this distance is not the same as recorded in step 3, remove the tie-rod end ball stud from the steering arm, and rotate the tie-rod end until this distance is the same as recorded in step 3.

13. Install the tie-rod end ball stud retaining nut, and tighten this nut to the specified torque.

Specified ball stud nut torque _____

Actual ball stud nut torque _____



WARNING: Never loosen a tie-rod end ball stud nut to align the openings in the ball stud and nut to allow cotter pin installation. This action may cause the nut to loosen during operation of the vehicle, and this will result in excessive steering free play. Complete loss of steering control will occur if the nut comes off the tie-rod end ball stud, and this may cause a collision.

14. Install a new cotter pin through the tie-rod end ball stud and nut openings, and bend the cotter pin legs separately around this nut.

15. Tighten the nut on the outer tie-rod sleeve clamp bolt to the specified torque. Be sure the slot in the tie-rod sleeve is positioned away from the opening in the clamp.

16. Measure the front wheel toe with a toe bar.

Specified front wheel toe _____

Actual front wheel toe _____

Explain the type of front tire wear that is caused by improper front wheel toe.

Instructor's Response _____

Chapter 10

POWER STEERING PUMP DIAGNOSIS AND SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Check power steering belt condition and adjust belt tension.
- Diagnose power steering belt problems.
- Check power steering fluid level and add fluid as required.
- Drain and flush power steering system.
- Bleed air from power steering system.
- Perform power steering pump pressure test.
- Check power steering pump fluid leaks.
- Remove and replace power steering pumps, and inspect pump mounts.
- Remove and replace power steering pump pulleys.
- Remove and replace power steering pump integral reservoirs.
- Remove, replace, and check flow control valve and pressure relief valve.
- Remove, replace, and check power steering pump rotating components.
- Remove and replace power steering pump seals and O-rings.
- Check, remove, and replace power steering lines.
- Inspect, test, diagnose, and service hybrid electric vehicles (HEVs) and electrohydraulic power steering (EHPS) systems.

Power steering pump diagnosis and service is very important to maintain vehicle safety and driver convenience. If a badly worn power steering pump belt is undetected, the belt may suddenly break while the driver is completing a turn. Under this condition, steering effort is greatly increased, and this may result in a collision. Therefore, the power steering belt should be inspected at regular intervals. A loose power steering belt may cause hard steering intermittently, and this condition requires increased driver steering effort, which reduces driver comfort and convenience. Therefore, one of the first checks when diagnosing a power steering system is to inspect the belt condition and test the belt tension.

POWER STEERING PUMP BELT SERVICE

Checking Belt Condition and Tension

Power steering belt condition and tension are extremely important for satisfactory power steering pump operation. A loose belt causes low pump pressure and hard steering. The steering wheel may jerk and surge during a turn if the power steering pump belt is loose. A loose, dry, or worn belt may cause squealing and chirping noises, especially during engine acceleration and cornering.



BASIC TOOLS

Basic technician's tool set
Service manual
Pry bar
Floor jack
Safety stands
Oil drain pan
Crocus cloth



SPECIAL TOOLS

Belt tension gauge




FIGURE 10-1 Defective belt conditions.

Classroom Manual

Chapter 10,
page 234



CAUTION:

Do not pry on the pump reservoir with a pry bar. This action may damage the reservoir.



SERVICE TIP:

During rainy or wet conditions, a loose power steering belt, which causes low power steering pump pressure and increased steering effort, may be more noticeable because the belt becomes wet and slips more easily.

The power steering pump belt should be checked for tension, cracks, oil-soaking, worn or glazed edges, tears, and splits (Figure 10-1). If any of these conditions are present, belt replacement is necessary.

Since the friction surfaces are on the sides of a **V-type belt**, wear occurs in this area. If the belt edges are worn, the belt may be rubbing on the bottom of the pulley. This condition requires belt replacement. Belt tension may be checked by measuring the belt deflection. Press on the belt with the engine stopped to measure the belt deflection, which should be 1/2 inch per foot of free span. The belt tension may be checked with a **belt tension gauge** placed over the belt (Figure 10-2). The tension on the gauge should equal the vehicle manufacturer's specifications.

If the belt requires tightening, follow this procedure:

1. Loosen the power steering pump bracket or tension adjusting bolt.
2. Loosen the power steering pump mounting bolts.
3. Check the bracket and pump mounting bolts for wear. If these bolts or bolt openings in the bracket or pump housing are worn, replacement is necessary.
4. Pry against the pump ear and hub with a pry bar to tighten the belt. Some pump brackets have a 1/2-inch square opening in which a breaker bar may be installed to move the pump and tighten the belt.
5. Hold the pump in the position described in step 4, and tighten the bracket or tension adjusting bolt.
6. Recheck the belt tension with the tension gauge. If the belt does not have the specified tension, repeat steps 1 through 5.
7. Tighten the tension adjusting bolt and the mounting bolts to the manufacturer's specified torque.




FIGURE 10-2 Methods of checking belt tension.




FIGURE 10-3 Proper and improper installation of ribbed V-belt on a pulley.




FIGURE 10-4 Belt tension scale.

Some power steering pumps have a **ribbed V-belt** (or **serpentine belt**). Many ribbed V-belts have an automatic tensioning pulley; therefore, a tension adjustment is not required. The ribbed V-belt should be checked to make sure it is installed properly on each pulley in the belt drive system (Figure 10-3). The tension on a ribbed V-belt may be checked with a belt tension gauge in the same way as the tension on a V-belt.

Many ribbed V-belts have a spring-loaded tensioner pulley that automatically maintains belt tension. As the belt wears or stretches, the spring moves the tensioner pulley to maintain the belt tension. Some of these tensioners have a belt length scale that indicates the new belt range and used belt range (Figure 10-4). If the indicator on the tensioner is out of the used belt length range, belt replacement is required. Many belt tensioners have a 1/2-inch drive opening in which a ratchet or flex handle may be installed to move the tensioner pulley off the belt during belt replacement (Figure 10-5).

Belt pulleys must be properly aligned to minimize belt wear. The edges of the pulleys must be in line when a straightedge is placed on the pulleys (Figure 10-6). Repeated belt failure may be caused by a misaligned power steering pump pulley or by extremely high pump pressure caused by a sticking pressure relief valve or a continual or intermittent restriction in the high pressure hose.




FIGURE 10-5 One-half inch drive opening in the tensioner pulley.




FIGURE 10-6 Checking pulley alignment.

**Classroom
Manual**
Chapter 10,
page 235

CUSTOMER CARE: When servicing vehicles, always promote preventive maintenance to the customer. For example, if you are performing some underhood service, such as replacing a battery and starting motor, always make a quick inspection of the belt or belts and cooling system hoses. If you see a ribbed V-belt with chunks out of it, recommend a belt replacement to the customer. The customer will usually appreciate this service and authorize the belt replacement. If you ignore the belt with chunks out of it, and the belt breaks the next day while the customer is driving on the freeway, the customer is inconvenienced and has to pay a tow bill. Although you did a satisfactory battery and starting motor replacement, the customer will not be happy if this problem occurs the day after you worked on the vehicle. The next time this unhappy customer requires automotive service, he or she may take the vehicle to another repair shop.

POWER STEERING PUMP FLUID SERVICE

Fluid Level Inspection

Most car manufacturers recommend power steering fluid or automatic transmission fluid in power steering systems. Always use the type of power steering fluid recommended in the vehicle manufacturer's service manual. If the power steering fluid level is low, **steering effort** is increased and may be erratic. A low fluid level may cause a growling noise in the power steering pump. Some car manufacturers now recommend checking the power steering pump fluid level with the fluid at an ambient temperature of 176°F (80°C).

Steering effort is the amount of effort required by the driver to turn the steering wheel.

Follow these steps to check the power steering fluid level:

1. With the engine idling at 1,000 rpm or less, turn the steering wheel slowly and completely in each direction several times to boost the fluid temperature (Figure 10-7).
2. If the vehicle has a remote power steering fluid reservoir, check for foaming in the reservoir, which indicates low fluid level or air in the system.
3. Observe the fluid level in the remote reservoir. This level should be at the hot full mark. Shut off the engine, and remove dirt from the neck of the reservoir with a shop towel. If the power steering pump has an integral reservoir, the level should be at the hot level on the dipstick. When an external reservoir is used, the dipstick is located in the external reservoir (Figure 10-8).




FIGURE 10-7 Boosting fluid temperature.



FIGURE 10-8 Power steering pump dipstick.

4. Pour the required amount of the car manufacturer's recommended power steering fluid into the reservoir to bring the fluid level to the hot full mark on the reservoir or dipstick with the engine idling.



CAUTION:

Always use the vehicle manufacturer's recommended power steering fluid. Using the wrong power steering fluid may cause improper power steering operation.

A **remote reservoir** is mounted externally from the power steering pump.

Power Steering System Draining and Flushing

If the power steering fluid is contaminated with moisture, dirt, or metal particles, the system must be drained and new fluid installed.

Follow these steps to drain and flush the power steering system:

1. Lift the front of the vehicle with a floor jack and install safety stands under the suspension. Lower the vehicle onto the safety stands, and remove the floor jack.
2. Remove the return hose from the **remote reservoir** that is connected to the steering gear. Place a plug on the reservoir outlet and position the return hose in an empty drain pan (Figure 10-9).
3. With the engine idling, turn the steering wheel fully in each direction and stop the engine (Figure 10-10).
4. Fill the reservoir to the hot full mark with the manufacturer's recommended fluid.
5. Start the engine, and run the engine at 1,000 rpm while observing the return hose in the drain pan. When fluid begins to discharge from the return hose, shut the engine off.
6. Repeat steps 4 and 5 until there is no air in the fluid discharging from the return hose.
7. Remove the plug from the reservoir and reconnect the return hose. Bleed the power steering system.

Bleeding Air from the Power Steering System

When air is present in the power steering fluid, a growling noise may be heard in the pump and steering effort may be increased or erratic.

When a power steering system has been drained and refilled, follow this procedure to remove air from the system:

1. Fill the power steering pump reservoir as outlined previously.
2. With the engine running at 1,000 rpm, turn the steering wheel fully in each direction three or four times (Figure 10-11). Each time the steering wheel is turned fully




FIGURE 10-9 Return hose installed in drain pan for power steering draining and flushing.




FIGURE 10-10 Draining fluid from the power steering system.




FIGURE 10-11 Turning the steering wheel slowly to bleed air from the power steering system.




FIGURE 10-12 Power steering fluid level after bleeding.

to the right or left, hold it there for 2 to 3 seconds before turning it in the other direction.

3. Check for foaming of the fluid in the reservoir. When foaming is present, repeat steps 1 and 2.
4. Check the fluid level with the engine running and be sure it is at the hot full mark. Shut off the engine, and make sure the fluid level does not increase more than 0.020 in. (5 mm) (Figure 10-12).

Power Steering Bleeding Procedure with Vacuum Hand Pump

Some vehicle manufacturers recommend using a vacuum hand pump to bleed air from the power steering system. Follow this procedure to bleed the power steering system with a vacuum hand pump:

1. Remove the power steering pump reservoir cap.
2. Install a special fitting to the reservoir cap opening that allows a vacuum hose to be connected to the fitting.
3. Connect the vacuum hand pump hose to the fitting installed on the power steering pump reservoir.
4. Operate the vacuum hand pump until the vacuum gauge on the pump indicates 20 in. Hg. (68 kPa).
5. Wait for 5 minutes or vehicle manufacturer's specified time interval.
6. Release the vacuum in the hand pump and reservoir. Remove the hand pump hose and special fitting from the power steering pump.
7. Check the fluid level in the power steering pump reservoir, and correct as necessary.
8. Install the pump reservoir cap and dipstick and check the operation of the power steering system.

POWER STEERING PUMP DIAGNOSIS

Power Steering Pump Pressure Test

Since there are some variations in power steering pump pressure test procedures and pressure specifications, the vehicle manufacturer's test procedures and specifications must be used. If the power steering pump pressure is low, steering effort is increased. Erratic power steering pump pressure causes variations in steering effort, and the steering wheel may jerk as it is turned. Since a power steering pump will never develop the specified pressure if the



SPECIAL TOOLS

Power steering
pressure test gauge




FIGURE 10-13 Pressure gauge connection to power steering pump.




FIGURE 10-14 Bleeding air from the power steering pump system and checking fluid temperature.

belt is slipping, the belt tension must be checked and adjusted, if necessary, prior to a pump pressure test.

The following is a typical power steering pressure test procedure:

1. With the engine stopped, disconnect the pressure line from the power steering pump and connect the gauge side of the **pressure gauge** to the pump outlet fitting. Connect the valve side of the gauge to the pressure line (Figure 10-13).
2. Start the engine, and turn the steering wheel fully in each direction two or three times to bleed air from the system (Figure 10-14). Be sure the fluid level is correct and the fluid temperature is at least 176°F (80°C). A thermometer may be inserted in the pump reservoir fluid to measure the fluid temperature.

A **pressure gauge** is designed to measure the high pressure in the power steering system.

Classroom Manual

Chapter 10,
page 241

! WARNING: During the power steering pump pressure test with the engine idling, close the pressure gauge valve for no more than 10 seconds because excessive pump pressure may cause power steering hoses to rupture, resulting in personal injury.

! WARNING: Do not allow the fluid to become too hot during the power steering pump pressure test. Excessively high fluid temperature reduces pump pressure. Wear protective gloves, and always shut the engine off before disconnecting gauge fittings, because the hot fluid may cause burns.

3. With the engine idling, close the pressure gauge valve for no more than 10 seconds, and observe the pressure gauge reading (Figure 10-15). Turn the pressure gauge valve to the fully open position. If the pressure gauge reading does not equal the vehicle manufacturer's specifications, repair or replace the power steering pump.
4. Inspect the power steering pump pressure with the engine running at 1,000 rpm and 3,000 rpm, and record the pressure difference between the two readings (Figure 10-16). If the pressure difference between the pressure readings at 1,000 rpm and 3,000 rpm does not equal the vehicle manufacturer's specifications, repair or replace the **flow control valve** in the power steering pump.

The **flow control valve** controls power steering fluid flow from the pump to the steering gear.




FIGURE 10-15 Power steering pump pressure test with pressure gauge valve closed.




FIGURE 10-16 Power steering pump pressure test at 1,000 and 3,000 rpm.

5. With the engine running, turn the steering wheel fully in one direction and observe the steering pump pressure while holding the steering wheel in this position (Figure 10-17). If the pump pressure is less than the vehicle manufacturer's specifications, the steering gear housing has an internal leak and should be repaired or replaced.
6. Be sure the front tire pressure is correct and center the steering wheel with the engine idling. Connect a spring scale to the steering wheel and measure the steering effort in both directions (Figure 10-18). If the power steering pump pressure is satisfactory and the steering effort is more than the vehicle manufacturer's specifications, the power steering gear should be repaired. Photo Sequence 17 shows a typical procedure for pressure testing a power steering pump.



SPECIAL TOOLS

Spring scale

Power Steering Pump Oil Leak Diagnosis

The possible sources of power steering pump oil leaks are the driveshaft seal, reservoir O-ring seal, high-pressure outlet fitting, and the dipstick cap. If leaks occur at any of the seal locations, seal replacement is necessary. When a leak is present at the high-pressure outlet fitting, tighten this fitting to the specified torque (Figure 10-19). If the leak still occurs, replace the O-ring seal on the fitting and retighten the fitting.




FIGURE 10-17 Power steering pump pressure test with the front wheels turned fully in one direction.



FIGURE 10-18 Steering effort measurement.




FIGURE 10-19 Power steering pump oil leak diagnosis.

PHOTO SEQUENCE 17


TYPICAL PROCEDURE FOR PRESSURE TESTING A POWER STEERING PUMP



P17-1 Connect the pressure gauge to the power steering pump.



P17-2 Connect a tachometer to the ignition system.



P17-3 Look up the vehicle manufacturer's specified power steering pump pressure in the service manual.



P17-4 Start the engine, and turn the steering wheel from lock to lock three times to bleed air from the system and heat the power steering fluid.



P17-5 Check the power steering fluid level, and add fluid as required.



P17-6 Place a thermometer in the power steering fluid reservoir. Be sure the fluid temperature is at least 176°F (80°C).



P17-7 With the engine idling, close the pressure gauge valve for no more than 10 seconds. Observe and record the pressure gauge reading.



P17-8 Check and record the power steering pump pressure at 1,000 rpm.



P17-9 Check and record the power steering pump pressure at 3,000 rpm.



P17-10 Check and record the power steering pump pressure with the steering wheel turned fully in one direction and the engine idling.

POWER STEERING PUMP SERVICE

Power Steering Pump Replacement



WARNING: If the vehicle has been driven recently, the pump, hoses, and fluid could be extremely hot. Use caution when handling components to avoid burns.

If a growling noise is present in the power steering pump after the fluid level is checked and air has been bled from the system, the pump bearings or other components are defective and pump replacement or repair is required. When the power steering pump pressure is lower than specified, pump replacement or repair is necessary.

To replace the power steering pump, proceed as follows:

1. Disconnect the power steering return hose from the remote reservoir or pump. Allow the fluid to drain from this hose into a drain pan. Discard the used fluid.
2. Loosen the bracket or belt tension adjusting bolt and the pump mounting bolt.
3. Loosen the belt tension until the belt can be removed. On some cars, it is necessary to lift the vehicle on a hoist and gain access to the power steering pump from underneath the vehicle.
4. Remove the hoses from the pump and cap the pump fittings and hoses.
5. Remove the belt tension adjusting bolt and the mounting bolt, and remove the pump.
6. Check the pump mounting bolts and bolt holes for wear. Worn bolts must be replaced. If the bolt mounting holes in the pump are worn, pump replacement is necessary.
7. Reverse steps 1 through 5 to install the power steering pump. Tighten the belt as described previously, and tighten the pump mounting and bracket bolts to the manufacturer's specifications. If O-rings are used on the pressure hose, replace the O-rings. Be sure the hoses are not contacting the exhaust manifold, catalytic converter, or exhaust pipe during or after pump replacement.
8. Fill the pump reservoir with the manufacturer's recommended power steering fluid and bleed air from the power steering system as described earlier.



SPECIAL TOOLS

Puller for power steering pump pulley, press-on pulley



SPECIAL TOOLS

Power steering pump pulley installing tool, press-on pulley

Power Steering Pump Pulley Replacement

If the pulley wobbles while it is rotating, the pulley is probably bent, and pulley replacement is necessary. Worn pulley grooves also require pulley replacement. Always check the pulley




FIGURE 10-20 Press-on power steering pump pulley removal.




FIGURE 10-21 Press-on power steering pump pulley installation.




FIGURE 10-22 Removing power steering pump pulley and nut.

A **woodruff key** is a half-moon shaped key that fits snugly in a shaft opening, with the top edge of the key extending out of the shaft. The top edge of the key fits snugly in a groove cut inside the pulley hub. When the pulley is installed on the shaft, the pulley groove slides over the key to prevent pulley rotation on the shaft.

An **integral reservoir** is mounted on the power steering pump.

Crocus cloth is a very fine polishing-type emery paper.

for cracks. If this condition is present, pulley replacement is essential. A pulley that is loose on the pump shaft must be replaced. Never hammer on the pump drive shaft during pulley removal or replacement. This action will damage internal pump components. If the pulley is pressed onto the pump shaft, a special puller is required to remove the pulley (Figure 10-20), and a pulley installation tool is used to install the pulley (Figure 10-21).

If the power steering pump pulley is retained with a nut, mount the pump in a vise. Always tighten the vise on one of the pump mounting bolt surfaces. Do not tighten the vise with excessive force. Use a special holding tool to keep the pulley from turning, and loosen the pulley nut with a box end wrench (Figure 10-22). Remove the nut, pulley, and **woodruff key**. Inspect the pulley, shaft, and woodruff key for wear. Be sure the key slots in the shaft and pulley are not worn. Replace all worn components.

Remove and Replace the Power Steering Pump Reservoir

Power steering pump service procedures vary depending on the type of pump. Always follow the vehicle manufacturer's recommended service procedures in the service manual. The following service procedures are for a power steering pump with an **integral reservoir**.

When the power steering pump has an integral reservoir, follow these steps for reservoir removal and replacement:

1. Remove the filler cap and drain the oil from the reservoir.
2. Remove the two clips that retain the reservoir to the housing.
3. Rock the reservoir by hand or tap it gently with a soft hammer to remove it from the housing.
4. Clean all the parts and discard the O-ring. Inspect the O-ring surfaces for damage.
5. Lubricate the new O-ring with the manufacturer's recommended power steering fluid and install it (Figure 10-23).
6. Install the reservoir and retaining clips.

Remove and Replace Flow Control Valve and End Cover

When the flow control valve and end plate are serviced, follow these steps:

1. Remove the retaining ring with a slotted screwdriver and a punch (Figure 10-24).
2. Remove the flow control valve, end cover, spring, and magnet. Inspect the flow control valve for burrs. Remove minor burrs with **crocus cloth** and clean the flow control




FIGURE 10-23 Integral power steering pump reservoir seal and O-ring.




FIGURE 10-24 Retaining ring removal.

valve in solvent. Damaged or worn flow control valves must be replaced. Inspect the end cover sealing surface for damage. Inspect the pump driveshaft for corrosion and damage. Remove corrosion with crocus cloth (Figure 10-25). Clean the magnet with a shop towel.

3. Clean all parts and lubricate the end cover with power steering fluid.
4. Install the end cover, retaining ring, and related components.




FIGURE 10-25 End cover and related component service.

Remove and Replace Pressure Relief Valve

The **pressure relief valve** limits the maximum power steering pump pressure.

Follow this procedure to service the pressure relief valve:

1. Wrap a shop towel around the land end of the flow control valve and clamp this end in a soft-jawed vise. Be very careful not to mark valve lands.
2. Remove the hex-head ball seat (Figure 10-26). Clean the components in solvent. A worn or damaged pressure relief ball, spring, guide, or seat must be replaced.

INSPECTING AND SERVICING POWER STEERING LINES AND HOSES

Power steering lines should be inspected for leaks, dents, sharp bends, cracks, and contact with other components. Lines and hoses must not rub against other components. This action could wear a hole in the line or hose. Many high-pressure power steering lines are made from high-pressure steel-braided hose with molded steel fittings on each end (Figure 10-27).




FIGURE 10-26 Pressure relief valve removal.

FIGURE 10-27 Power steering hoses and lines.

POWER STEERING HOSE REPLACEMENT



WARNING: If the engine has been running, the power steering hoses, components, and fluid may be extremely hot. Wear protective gloves and use caution to avoid burns.

When power steering hose replacement is required, follow these steps:

- 1. With the engine stopped, remove the return hose at the power steering gear, and allow the fluid to drain from this hose into a drain pan. On some cars, the vehicle must be lifted on a hoist to replace the power steering hoses.
- 2. Loosen and remove all hose fittings from the pump and steering gear.
- 3. Remove all hose-to-chassis clips.
- 4. Remove the hoses from the chassis and cap the pump and steering gear fittings.
- 5. If O-rings are used on the hose ends, install new O-rings.
- 6. Reverse steps 1 through 4 to install the power steering hoses. Tighten all fittings to the manufacturer's specified torque. Be sure all hose-to-chassis clips are in place. Do not position hoses where they rub on other components.
- 7. Fill the pump reservoir to the full mark with the manufacturer's recommended fluid. Bleed air from the power steering system, as mentioned previously in this chapter. Check the fluid level in the reservoir and add fluid as required.

Refer to Table 10-1 for steering column and steering linkage diagnosis

TABLE 10-1 STEERING COLUMN AND STEERING LINKAGE DIAGNOSIS

Problem	Symptoms	Possible Causes
Underhood noise	Squealing noise during engine acceleration or during steering wheel rotation	Loose power steering pump belt
	Squealing and chirping noise with the engine idling	Dry power steering pump belt friction surfaces
	Growling noise with engine idling	Low power steering fluid level Air in the power steering fluid
Improper steering wheel turning effort	Erratic steering wheel turning effort while cornering	Loose power steering pump belt Low power steering fluid level Air in the power steering fluid
	Excessive steering wheel turning effort	Loose power steering pump drive belt Low power steering fluid level Low power steering pump pressure
Power steering pump fluid leaks	Fluid leaks at the drive shaft behind the pulley	Worn drive shaft seal
	Fluid leaks between the reservoir and the housing	Leaking reservoir O-ring
	Fluid leaks at the back of the reservoir	Leaking O-ring seals or pump-to-line fittings
Rapid power steering belt wear	Power steering belt wears out prematurely	Misalignment of power steering pump pulley, and other pulleys driven by the same belt
		Excessive power steering belt tension

HYBRID ELECTRIC VEHICLE (HEV) AND ELECTROHYDRAULIC POWER STEERING (EHPS) DIAGNOSING AND SERVICING PROCEDURES

HEV Service Precautions

Most HEVs have high-voltage electrical systems that pose a severe electrical shock hazard for anyone servicing these vehicles. When servicing HEV electrical systems, always follow these precautions:

1. Wear high-voltage electrical lineman's gloves rated at 1,000 V. Inspect these gloves periodically to be sure they do not contain pin holes or other damage. Immediately replace all damaged gloves.
2. When working on an HEV, always be sure the HEV system is deactivated by removing the electronic or conventional key from the instrument panel. This action prevents the engine from starting.
3. Turn the high-voltage circuit switch off to isolate the battery pack from the electrical system (Figure 10-28). Some HEV manufacturers recommend removing the 20-A yellow HEV fuse in the underhood fuse block (Figure 10-29).
4. Disconnect the negative cable on the 12-V battery (Figure 10-30).
5. After the disabling procedure on some HEVs, power is maintained in the SRS system for 90 seconds and in the high-voltage system for 5 minutes. After disabling the electrical system, always wait for the time period specified by the vehicle manufacturer.

Classroom Manual

Chapter 10,
page 241




FIGURE 10-28 Battery disconnect key in the ESB.




FIGURE 10-29 Removing HEV fuse from fuse block.




FIGURE 10-30 Disconnecting the 12-V battery.

6. Be sure the high- and low-voltage systems have been disabled before using welding equipment on the vehicle. If the HEV system is not disabled, the welding equipment may send high-voltage spikes through the system resulting in component damage.
7. If the battery pack has experienced collision or other damage and battery pack leakage is suspected, wear protective gloves and safety goggles when servicing the battery pack. Nickel–metal hydride batteries contain potassium hydroxide a highly alkaline solution that damages human tissue. Battery pack leakage may be sprayed with vinegar to neutralize the solution.
8. Inspect high-voltage (orange) cables for frayed insulation and damage which could result in electrical shocks, sparks, and fires. Frayed, damaged orange cables must be replaced.
9. If HEVs are towed with the drive wheels on the road surface, the generator may begin producing voltage and current even if the high-voltage electrical system is disabled. This may result in sparks and a fire.
10. The battery packs in many HEVs contain nickel–metal hydride type batteries. These batteries self-discharge quickly compared with a conventional lead acid battery. A nickel–metal hydride battery may lose 30 percent of its charge per month. Do not leave an HEV sitting for 2 or 3 months without starting the engine. If an HEV is not being driven, the engine should be started and allowed to run for 30 minutes every 2 or 3 weeks to maintain the battery pack state of charge. Some test equipment manufacturers are designing battery chargers for HEV battery packs, but this test equipment is not available at the present time. The engine must be operated to allow the generator to recharge the battery pack. Some HEVs have an auxiliary starter to start the engine if the battery pack is discharged.
11. When working on an HEV with a smart key, always be sure the smart key is removed from the instrument panel, and the disable button under the steering column is pushed to the Off position. This action prevents the HEV system from being activated by pressing the smart key when it is located in close proximity to the vehicle.
12. Use caution when hoisting or lifting HEVs to avoid damage to the high-voltage cable compartments and cables.
13. On HEVs the refrigerant oil specified by the vehicle manufacturer such as SE 10-Y, ND-OIL, 11 must be used in the AC system. Many HEVs have an electric-drive AC compressor that remains operational during the engine stop mode to maintain AC system operation. In many of these compressors, 300 V from the inverter is supplied to the compressor drive motor. This higher voltage requires lower amperes of current through the compressor clutch coil. The refrigerant oil in these compressors must have special insulating qualities or the high-voltage insulation inside the compressor may be damaged.

Starting/Stopping Procedures and Warning Indicators

Technicians must be familiar with the proper starting and stopping procedures and warning indicators on HEVs. The engine starting/stopping procedures and warning indicators may vary on hybrid vehicles depending on the vehicle and model year. Always refer to the vehicle manufacturers' information. The following procedures and indicators are typical. Some hybrid vehicles have an electronic key that fits into a key slot in the dash. A power button and an indicator light are located above the electronic key slot in the dash (Figure 10-31). The power button is pressed to cycle through the ignition modes rather than rotating the electronic key in the slot. The electronic key also contains the remote keyless entry buttons and a hidden metal key (Figure 10-32).

The doors are unlocked and locked by pressing the appropriate buttons on the electronic key. Another option for opening the doors is to remove the hidden metal key from the electronic key, and insert the metal key into the key cylinder in the drivers' door. Rotating the metal key once unlocks the drivers' door, and rotating this key a second time unlocks the other doors. There are no lock cylinders in the other doors.




FIGURE 10-31 Electronic key and power button.




FIGURE 10-32 Electronic key with remote keyless entry button and hidden metal key.

To activate the HEV system and other electronic systems, insert the electronic key into the slot in the dash. With the brake pedal released, pressing the power button once turns on the accessory mode, and pushing the power button again turns on the ignition mode. Pressing the power button a third time turns the ignition off. When the ignition mode is off, the power button indicator light is also off. In the accessory mode the power button indicator light is green, and in the ignition mode this light is amber. When a defect occurs in the electrical system, the amber power button light starts blinking.

With the brake pedal depressed, pressing the power button once activates the HEV and other electronic systems. Starting the vehicle takes priority over all other modes. When the HEV system is activated, the power button indicator light goes off and the Ready light in the instrument panel is illuminated (Figure 10-33). When starting off under light load conditions,




FIGURE 10-33 Ignition modes and starting sequence.

the engine does not start because the vehicle is only driven by the propulsion motor. Never work on an HEV with the electronic key installed in the dash and the HEV system activated. Under this condition, the engine may start and cause personal injury and/or vehicle component damage if the battery pack voltage reaches a specific discharged state. To shut off the vehicle, bring the vehicle to a complete stop and press the power button once and remove the electronic key. When the Ready light is illuminated, the electronic key cannot be removed from the key slot.

The vehicle may have an optional smart entry system with a smart electronic key. This key contains a transceiver that communicates bidirectionally and allows the vehicle to recognize the smart key in close proximity to the vehicle. The smart entry and smart key can unlock and lock the doors without pushing the buttons on the smart key. This system can also start the hybrid system without inserting the smart key into the dash slot. If the smart key is in close proximity to the vehicle, the doors may be unlocked by touching the sensor on the backside of either exterior front door handle (Figure 10-34). Press the black lock button on either exterior front door handle to lock the doors. If the smart key is in close proximity to the vehicle, the normal ignition modes and start mode are operational. The smart key also contains a hidden metal key. Vehicles equipped with a smart key and smart entry system have a disabling button located in the dash under the steering column. If the disable button is pressed, the smart key must be inserted into the key slot to activate the ignition modes and start the vehicle (Figure 10-35).

The speedometer, gear shift indicator, Ready light, fuel gauge, and warning lights are located in a digital display in the center of the dash near the base of the windshield. An LCD monitor located at the top, center of the dash displays fuel consumption, A/C controls, and energy monitor (Figure 10-36). The electronic gearshift selector is a momentary select, shift-by-wire system that engages the transaxle in Reverse, Neutral, Drive, or engine Brake modes. There are no mechanical connections between the dash indicators and the transaxle. The dash indicator also informs the driver regarding the gear selected (Figure 10-37). After selecting the desired gear position, the transaxle remains in that position as indicated by the dash display, but the shift selector returns to a default mode. When the vehicle is stopped, Park may be selected by pressing the P switch in the dash display. If the power button is pressed to shut off the vehicle, Park is automatically engaged. Voltage is supplied to the gearshift selector and the electromechanical parking pawl by the 12-V battery. If the 12-V battery is discharged, or disconnected, the vehicle cannot be started or shifted out of park.

When the Ready light is illuminated, the vehicle is operational even though the engine is not running. The driver simply selects Drive (D) or Reverse (R) on the gearshift selector, releases




FIGURE 10-34 Smart key and smart entry system.




FIGURE 10-35 Disable button on smart key systems.




FIGURE 10-36 Digital dash displays.




FIGURE 10-37 Gearshift indicator.

the brake pedal, and steps on the accelerator pedal to begin driving the vehicle. The vehicle computer decides when to start and stop the engine depending on many factors such as vehicle load and speed, and battery pack state of charge. A hybrid vehicle does not have the usual noise associated with starting motor operation, because the battery simply passes current through the generator windings to rotate and start the engine. The vehicle computer stops the engine during deceleration below a specific speed, and during idle operation, to improve fuel economy.

Scan Tool Diagnosis of HEV and EHPS Systems

To begin the HEV system diagnosis, visually inspect all HEV system components, wiring harnesses, and connectors. Any damaged components, wiring harnesses, or connectors should be replaced. The orange high-voltage cables may be checked for high-voltage leakage by using a digital volt-ohm meter (DVOM). With the DVOM on the highest DC voltage scale, connect the negative DVOM lead to ground on the vehicle chassis, and move the red lead along the high-voltage cable surfaces. High-voltage leakage causes a reading on the voltmeter. A scan tool may be used to diagnose the HEV system. HEV system diagnosis varies depending on the vehicle make and model year. Always use the vehicle manufacturer's specific diagnostic information for the vehicle being diagnosed and serviced. The following is a typical HEV diagnosis. The scan tool and the module installed in the scan tool must be compatible with the HEV system and the vehicle network(s). A special CANdi module must be used with the scan tool on some HEV systems. If the visual inspection does not indicate any HEV system problems, the scan tool may be used to perform a diagnostic system check. Follow these steps to complete the diagnostic system check:

1. Connect the scan tool to the DLC under the dash. If the scan tool does not power up, check the 12-V supply terminal and the ground terminal in the DLC.
2. Turn the ignition switch on with the engine off. Using the scan tool, attempt to establish communication with the energy storage control module (ESCM), hybrid control module




FIGURE 10-38 The LAN bus interconnects the SGCM, PCM, EHPS modules, ESB, and DLC.

(HCM), and the starter/generator control module (SGCM). If the scan tool does not communicate with any of these modules, there is a problem in the LAN network and further network diagnosis is required (Figure 10-38). Refer to Chapter 8 in the Shop Manual for network diagnosis. Always follow the vehicle manufacturer's specific diagnostic procedure for the vehicle being diagnosed.

3. Use the scan tool to establish communication with the PCM. If the scan tool does not communicate with the PCM, there is a problem in the Class 2 network and further diagnosis of this network is necessary.
4. Select PCM DTC display on the scan tool. DTCs with a U prefix indicate network problems, and specific DTC diagnosis is required.
5. Check the scan tool display for PCM DTCs. When DTCs are present, the cause of the DTCs must be diagnosed and repaired.

Diagnostic example for a U0131 network DTC

Current vehicles have hundreds of DTCs, and thus it is impossible to include an interpretation and diagnostic procedure for all DTCs in this publication. A U0131 DTC is set when the communication is lost between the EHPS module and the PCM. Under this condition, the EHPS operates in a default mode. The possible causes of this DTC are as follows:

1. An open circuit in the EHPS module connector.
2. An open circuit in the LAN network.
3. An open circuit in the voltage supply or ground circuits to the EHPS module.
4. An internal module malfunction. Many modules have specific DTCs for internal module defects.

To locate the root cause of the U0131 DTC, the technician must perform tests with a DVOM or lab scope on the suspected components.

Diagnostic Example for a P0562 DTC

A P0562 DTC is set when the PCM detects an improper voltage below 11 V for 5 seconds. When this DTC is set in the PCM memory, the PCM takes these actions:

1. The PCM stores faulty circuit conditions that were present when the DTC set.
2. The PCM disables many outputs.
3. The transmission defaults to a predetermined gear.
4. Torque converter clutch lockup is inhibited.
5. The instrument panel cluster (IPC) displays a warning message.
6. The malfunction indicator light (MIL) will not illuminate.

When this DTC is present in the PCM memory, the technician must use an amp-volt tester to test the charging circuit and use a DVOM to test all the electrical circuits between the charging circuit, battery, and PCM to locate the root cause of the problem. DTCs may be erased with the scan tool.

A scan tool data display may be useful when diagnosing HEV and EHPS systems especially when there is a system problem with no DTCs. Before using the data display, the diagnostic system check should be performed and all DTCs corrected. Available scan tool data from a HEV with EHPS is illustrated in Figure 10-39. Photo Sequence 18 illustrates the safety precautions that must be observed when working on hybrid vehicles.

Scan Tool Parameter	Data List	Units Displayed	Typical Data Value
Park brake set with the ignition switch ON/Ignition Switch in RUN/Automatic Transmission in PARK/Air Conditioning is OFF			
Brake Pedal Travel	Data	mm	–50 to 200 mm
BPP Sensor Rate	Data	ms	0 to +10%/25ms
BPP Sensor Input Volts	Data	Volts	0 to 5 Volts
BPP Sensor Output Volts	Data	Volts	0 to 5 Volts
EHPS 42 V Bus Voltage	Data	Volts	0 to 76 Volts
EHPS Ignition 0	Data	OFF/ON	ON
EHPS Ignition 1	Data	OFF/ON	ON
EHPS Demand	Data	%	–100 to +100%
EHPS Demand Speed	Data	RPM	0 to +7500 RPM
EHPS ECU Temperature	Data	°C	–180 to +180°C (–238 to +302°F)
EHPS Manifold Temperature	Data	°C	–180 to +180°C (–238 to +302°F)
EHPS Motor Current	Data	A	0 to +200A
EHPS Motor RPM	Data	RPM	0 to +7500 RPM
Steering Wheel Rate	Data	°/s	0 to 2048°/s
Steering Wheel Sensor Phase A Volts	Data	Low/High	Low
Steering Wheel Sensor Phase B Volts	Data	Low/High	High
Vehicle Speed	Data	km/h	0

FIGURE 10-39 EHPS data

PHOTO SEQUENCE 18

OBSERVING SAFETY PRECAUTIONS WHEN SERVICING HYBRID ELECTRIC VEHICLES (HEVs)



P18-1 Always wear high-voltage lineman's gloves when servicing HEV electrical systems.



P18-2 Periodically inspect the high-voltage gloves for pin holes or damage.



P18-3 Shut off the high-voltage circuit switch to isolate the battery pack from the electrical system.



P18-4 Disconnect the negative cable on the 12-V battery.



P18-5 After the high- and low-voltage systems are disabled, wait for the time specified by the vehicle manufacturer to allow these systems to completely power down.



P18-6 Inspect the high-voltage (orange) cables for frayed insulation and damage.



P18-7 If the HEV is not driven for a few weeks, the engine should be started and run for 30 minutes every 2 weeks to maintain the state of charge in the high-voltage battery pack.



P18-8 Always remove the electronic or conventional key from the instrument panel to prevent the engine from starting when working on an HEV electrical system.

CASE STUDY

TERMS TO KNOW

Belt tension gauge
Crocus cloth
Flow control valve
Integral reservoir
Pressure gauge
Pressure relief valve
Remote reservoir
Ribbed V-belt
Steering effort
Serpentine belt
V-type belt
Woodruff key

The owner of a Dodge Magnum with a 5.7 L turbo-charged engine requested a price on a power steering gear replacement. The service writer questioned the owner regarding the reason for the steering gear replacement, and discovered that the problem was intermittent hard steering. Further discussion with the owner also revealed that the car had been taken to another automotive service center, and the owner was informed that her car required a steering gear replacement. The owner was now looking for a second opinion.

The technician road tested the vehicle and found no indication of hard steering. The owner was asked about the exact driving conditions when the hard steering was experienced, and the answer to this question provided the solution to the problem. The owner indicated that the hard steering was usually experienced while cornering

and always on a rainy day. Once this information was revealed, the technician suspected a problem with the power steering belt, because a wet belt slips more easily. A check of the power steering belt indicated the belt was oil soaked from engine oil leaks and was also slightly loose. The power steering belt was replaced and adjusted, and the owner was informed that the engine oil leaks should be corrected or the belt would become oil soaked again.

A short while later, after a rain, the owner brought the car to the shop to have the engine oil leaks repaired. The owner reported that the belt corrected the hard steering problem. In this situation, a brief discussion about the customer's complaint led to accurate diagnosis of the problem, and because of this accurate diagnosis, the shop gained a steady customer.

ASE-STYLE REVIEW QUESTIONS

- While discussing power steering belt adjustment:
Technician A says the tension on a power steering pump V-belt should be checked with a tension gauge.
Technician B says that some ribbed V-belts have an automatic tensioning pulley that eliminates the need for tension adjustments.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
- While discussing power steering belt adjustment:
Technician A says that a power steering pump V-belt should be tightened with a pry bar installed against the pump reservoir.
Technician B says a loose power steering pump V-belt may cause the steering wheel to jerk while turning.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
- In a hybrid electric vehicle (HEV) electrical system with a electrohydraulic power steering system (EHPS), a diagnostic trouble code (DTC) with U prefix represents a fault in the:
A. EHPS module.
B. Powertrain control module (PCM).
C. Inverter.
D. Vehicle network.
- While discussing the steering pump pressure test:
Technician A says the pressure gauge and valve should be connected in the power steering pump return hose to check pump pressure.
Technician B says the pressure gauge valve should be closed for 30 seconds during the power steering pump pressure test.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
- While discussing power steering system draining, flushing, refilling, and bleeding:
Technician A says the return hose from the remote reservoir should be disconnected at the remote reservoir to drain the fluid.
Technician B says the return hose should be loosened at the remote reservoir with the engine running to bleed air from the power steering system.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

6. A vehicle experiences excessive, erratic steering effort. The most likely cause of this problem is:
 - A. Underinflated and worn front tires.
 - B. Power steering pump V-belt pump bottomed in the pulley.
 - C. Worn power steering pump mountings.
 - D. Continual low power steering pump pressure.
7. A power steering system has the specified pressure with the pressure gauge valve closed or with the pressure gauge valve open and the engine running at 1,000 and 3,000 rpm. The power steering pump pressure is lower than specified with the front wheels turned fully in either direction. The cause of this problem could be:
 - A. A defective steering gear.
 - B. A stuck flow control valve.
 - C. A stuck pressure relief valve.
 - D. Worn pump vanes and cam ring.
8. All of these statements about power steering pump pulley replacement are true EXCEPT:
 - A. If the pulley is retained with a nut, a woodruff key prevents pulley rotation on the shaft.
 - B. If the pulley is pressed onto the shaft, a special puller must be used to remove the pulley.
 - C. If the pulley is pressed onto the shaft, a soft hammer may be used to drive the pulley onto the shaft when reinstalling the pulley.
 - D. If the pulley is misaligned with the engine running, the power steering pump mountings may be worn.
9. A power steering pump has the specified pressure with the pressure gauge valve closed. However, with this valve open, the pump does not have the specified pressure difference between the pressure readings at 1,000 and 3,000 rpm. The cause of this problem could be:
 - A. A sticking pressure relief valve.
 - B. A sticking flow control valve.
 - C. A slipping pump belt.
 - D. A misaligned pump pulley.
10. All of these statements about HEV service precautions are true EXCEPT:
 - A. Open the high-voltage switch to isolate the high-voltage battery pack.
 - B. High-voltage gloves must be worn when servicing HEV electrical systems.
 - C. If the vehicle is not being driven, the high-voltage battery pack must be vented manually.
 - D. Remove the electronic or conventional key from the instrument panel.

ASE CHALLENGE QUESTIONS

1. A vehicle has intermittent excessive steering effort.
Technician A says inspect the fluid because it probably has air in it.
Technician B says inspect the belt because it is probably slipping.
 Who is correct?
 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
2. While discussing power steering pump leaks:
Technician A says leaks at the driveshaft seal will leave a wet and oily pump pulley backside.
Technician B says leaks at the driveshaft seal may leave oil on the hood pad above the pump.
 Who is correct?
 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
3. A vehicle has continual excessive steering effort, but there is no noise and the fluid level in the reservoir is correct.
Technician A says the cause of the problem could be a stuck flow control valve.
Technician B says the cause of the problem could be air in the power steering fluid.
 Who is correct?
 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B

4. There is air in the power steering fluid. To correct this problem, you should:
- A. With the engine running, crack the pressure line at the pump to release trapped air.
 - B. With the engine running, turn the steering wheel full left and right.
 - C. With the engine running, drain all fluid from the system and refill.
 - D. With the engine stopped, raise wheels and remove the return hose from the gear. Turn the steering wheel full left and right. Refill the reservoir and replace the return hose.

5. All of the following are true EXCEPT:
- A. A loose belt may cause the steering wheel to jerk.
 - B. If V-belt edges are worn, the belt may be stretched or the wrong width.
 - C. An oil-soaked V-belt may slip only in wet weather.
 - D. When air is in the fluid, the fluid will never reach operating temperature.

Name _____ Date _____

DRAINING AND FLUSHING POWER STEERING SYSTEM

Upon completion of this job sheet, you should be able to drain and flush a power steering system.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-11: *Flush, fill, and bleed power steering systems.*

Tools and Materials

Drain pan
Specified type of power steering fluid
Floor jack
Safety stands

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Describe the steering problems and noises that occur when there is air in the power steering system.

2. Lift the front of the vehicle with a floor jack and install safety stands under the suspension. Lower the vehicle onto the safety stands, and remove the floor jack. ☐

3. Remove the return hose from the remote reservoir that is connected to the steering gear. Place a plug on the reservoir outlet and position the return hose in an empty drain pan. ☐

4. With the engine idling, turn the steering wheel fully in each direction and stop the engine. ☐

5. Fill the reservoir to the hot full mark with the manufacturer's recommended fluid.

Specified type of power steering fluid _____

Power steering reservoir filled to the specified level with the proper power steering fluid? ☐ Yes ☐ No

Instructor check _____

Task Completed☐

6. Start the engine, and run the engine at 1,000 rpm while observing the return hose in the drain pan. When fluid begins to discharge from the return hose, shut the engine off.
7. Repeat steps 4, 5, and 6 until there is no air in the fluid discharging from the return hose.

Have steps 4, 5, and 6 been repeated? ☐ Yes ☐ No

Instructor check _____

8. Remove the plug from the reservoir and reconnect the return hose.

Is the return hose connected and tightened? ☐ Yes ☐ No

Instructor check _____

☐

9. Fill the power steering pump reservoir to the specified level.

10. With the engine running at 1,000 rpm, turn the steering wheel fully in each direction three or four times. Each time the steering wheel is turned fully to the right or left, hold it there for 2 to 3 seconds before turning it in the other direction.

Number of times the steering wheel was turned fully in each direction _____

11. Check for foaming of the fluid in the reservoir. When foaming is present, repeat steps 8 and 9.

Is foaming present in the power steering pump reservoir? ☐ Yes ☐ No

Have steps 8 and 9 been repeated? ☐ Yes ☐ No

Instructor check _____

☐

12. Check the fluid level and be sure it is at the hot full mark.

☐

13. Raise vehicle with a floor jack, remove safety stands, and lower vehicle.

14. Explain how you know that all the air has been bled from the power steering system.

Instructor's Response _____

Name _____ Date _____

TESTING POWER STEERING PUMP PRESSURE

Upon completion of this job sheet, you should be able to test power steering pump pressure.

Tools and Materials

Specified type of power steering fluid

Power steering pressure test gauge

Thermometer

Describe the vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. With the engine stopped, disconnect the pressure line from the power steering pump.
2. Connect the gauge side of the pressure gauge to the pump outlet fitting. Connect the valve side of the gauge to the pressure line.

Is the power steering pressure gauge properly connected? ☐ Yes ☐ No

Are all power steering gauge fittings tightened to the specified torque? ☐ Yes ☐ No


3. Start the engine and turn the steering wheel fully in each direction two or three times to bleed air from the system.


4. Install a thermometer in the pump reservoir fluid to measure the fluid temperature. Be sure the fluid level is correct and the fluid temperature is at least 176°F (80°C).

Is the power steering fluid at the specified level? ☐ Yes ☐ No

Is the power steering fluid at the proper temperature? ☐ Yes ☐ No

Instructor check _____

 **WARNING:** During the power steering pump pressure test with the engine idling, close the pressure gauge valve for no more than 10 seconds because excessive pump pressure may cause power steering hoses to rupture, resulting in personal injury.

 **WARNING:** Do not allow the fluid to become too hot during the power steering pump pressure test. Excessively high fluid temperature reduces pump pressure. Wear protective gloves, and always shut the engine off before disconnecting gauge fittings, because the hot fluid may cause burns.

5. With the engine idling, close the pressure gauge valve for no more than 10 seconds, and observe the pressure gauge reading. Turn the pressure gauge valve to the fully open position. If the pressure gauge reading does not equal the vehicle manufacturer's specifications, repair or replace the power steering pump.

Specified power steering pump pressure with pressure gauge valve closed _____

Actual power steering pump pressure with the pressure gauge valve closed _____

Recommended power steering pump service.

6. Check the power steering pump pressure with the engine running at 1,000 rpm and 3,000 rpm. Record the pressure difference between the two readings.

Specified power steering pump pressure at 1,000 rpm _____

Specified power steering pump pressure at 3,000 rpm _____

Actual power steering pump pressure at 1,000 rpm _____

Actual power steering pump pressure at 3,000 rpm _____

Recommended power steering pump service. _____

7. With the engine running, turn the steering wheel fully in one direction. Observe the steering pump pressure while holding the steering wheel in this position.

Specified power steering pump pressure with the steering wheel turned fully in one direction _____

Actual power steering pump pressure with the steering wheel turned fully in one direction _____

Recommended power steering service.

8. Be sure the front tire pressure is correct, and center the steering wheel with the engine idling. Connect a spring scale to the steering wheel, and measure the steering effort in both directions.

Specified force required to turn the steering wheel to the right _____

Specified force required to turn the steering wheel to the left _____

Actual force required to turn the steering wheel to the right _____

Actual force required to turn the steering wheel to the left _____

List all the required power steering service and explain the reasons why this service is necessary.

Instructor's Response _____

Name _____ Date _____

MEASURE AND ADJUST POWER STEERING BELT TENSION AND ALIGNMENT

Upon completion of this job sheet, you should be able to measure and adjust power steering belt tension and alignment.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-13: Remove, inspect, replace and adjust power steering pump belt.

Tools and Materials

Belt tension gauge
Pry bar

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed _____

1. Describe the power steering problems and noises that occur when the power steering pump belt is loose.

2. Inspect the power steering belt for fraying, oil soaking, wear on friction surfaces, cracks, glazing, and splits.

☐

Belt condition: ☐ Satisfactory ☐ Unsatisfactory

3. With the engine stopped, press on the belt at the longest belt span to measure the belt deflection which should be 1/2 inch per foot of free span.

☐

Length of belt span where belt deflection is measured _____

Amount of belt deflection _____

Belt tension: ☐ Satisfactory ☐ Unsatisfactory

4. Install a belt tension gauge over the belt in the center of the longest span to measure the belt tension.

Specified belt tension _____

Actual belt tension _____

Task Completed

- ☐
- ☐
- ☐
- ☐

5. Loosen the power steering pump bracket or tension adjusting bolt.
6. Loosen the power steering pump mounting bolts.
7. Remove the power steering belt.
8. Check the bracket and pump mounting bolts for wear.

Power steering pump mounting bolt holes and bolt condition:

☐ Satisfactory ☐ Unsatisfactory

Power steering pump bracket and bracket bolt condition:

☐ Satisfactory ☐ Unsatisfactory

List the required power steering pump and bracket service and explain the reasons for your diagnosis.

- ☐
- ☐
- ☐

9. Install the new power steering pump belt over all the pulleys.
10. Pry against the pump ear and hub with a pry bar to tighten the belt. Some pump brackets have a 1/2-inch square opening in which a breaker bar may be installed to move the pump and tighten the belt.
11. Hold the pump in the position described in step 9 and tighten the bracket or tension adjusting bolt.
12. Recheck the belt tension with the tension gauge.

Specified power steering belt tension _____

Actual power steering pump belt tension _____

13. Tighten the tension adjusting bolt and the mounting bolts to the manufacturer's specified torque.

Specified power steering pump mounting bolt torque _____

Actual power steering pump mounting bolt torque _____

Specified power steering pump bracket or tension adjusting bolt torque _____

Actual power steering pump bracket or tension adjusting bolt torque _____

14. Check alignment of the power steering pump pulley in relation to the other pulleys surrounded by the power steering belt.

Power steering pump pulley alignment: ☐ Satisfactory ☐ Unsatisfactory

Explain the service required to align the power steering pump pulley with other related pulleys and give the reasons for your diagnosis.

Instructor's Response _____

Chapter 11

RECIRCULATING BALL STEERING GEAR DIAGNOSIS AND SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Diagnose power recirculating ball steering gear problems.
- Remove and replace power recirculating ball steering gears.
- Adjust worm shaft thrust bearing preload in power recirculating ball steering gears.
- Adjust sector lash in power recirculating ball steering gears.
- Diagnose and repair oil leaks in power recirculating ball steering gears.
- Disassemble, repair, and reassemble power recirculating ball steering gears.

Steering gear and linkage inspection and service is extremely important to maintain vehicle safety! For example, if a vehicle has excessive steering wheel free play, this problem should be diagnosed and corrected as soon as possible. If the excessive steering wheel free play is caused by a loose sector shaft lash or worm bearing preload adjustments, follow the proper adjustment procedure to correct the problem. However, if this problem is caused by worn tie-rod ends or loose steering gear mounting bolts, these conditions create a safety hazard. If a worn tie-rod end becomes disconnected, or the steering gear becomes disconnected from the frame, the result is a complete loss of steering control. This condition may cause a collision resulting in vehicle damage and/or personal injury.

POWER RECIRCULATING BALL STEERING GEAR DIAGNOSIS

If the steering gear is noisy, check these items:

1. Loose pitman shaft lash adjustment—may cause a rattling noise when the steering wheel is turned.
2. Cut or worn dampener O-ring on the valve spool—when this defect is present, a squawking noise is heard during a turn.
3. Loose steering gear mounting bolts.
4. Loose or worn flexible coupling or steering shaft U-joints.

A hissing noise from the power steering gear is normal if the steering wheel is at the end of its travel, or when the steering wheel is rotated with the vehicle standing still. If the steering wheel jerks or surges when the steering wheel is turned with the engine running, check the power steering pump belt condition and tension. When excessive kickback is felt on the steering wheel, check the poppet valve in the steering gear.



BASIC TOOLS

Basic technician's tool set

Service manual

Classroom Manual

Chapter 11,
page 257

When the steering is loose, check these defects:

1. Air in the power steering system. To remove the air, fill the power steering pump reservoir and rotate the steering wheel fully in each direction several times.
2. Loose pitman lash adjustment.
3. Loose worm shaft thrust bearing preload adjustment.
4. Worn flexible coupling or universal joint.
5. Loose steering gear mounting bolts.
6. Worn steering gears.

A complaint of hard steering while parking could be caused by one of these defects:

1. Loose or worn power steering pump belt.
2. Low oil level in the power steering pump.
3. Excessively tight steering gear adjustments.
4. Defective power steering pump with low-pressure output.
5. Restricted power steering hoses.
6. Defects in the steering gear such as:
 - (a) Pressure loss in the cylinder because of scored cylinder, worn piston ring, or damaged backup O-ring.
 - (b) Excessively loose spool in the valve body.
 - (c) Defective or improperly installed gear check poppet valve.



CAUTION:

Hard steel bolts can be used for steering gear mounting. Ribs on the bolt head indicate the bolt hardness. Harder bolts have five, six, or seven ribs on the bolt heads. Never substitute softer steel bolts in place of the harder original bolts, because these softer bolts may break, allowing the steering gear box to detach from the frame and resulting in a loss of steering control.



CAUTION:

When the steering linkage is disconnected from the gear, do not turn the steering wheel hard against the stops. This action may damage internal steering gear components.

POWER RECIRCULATING BALL STEERING GEAR REPLACEMENT

When the power steering gear is replaced, proceed as follows:

1. Disconnect the hoses from the steering gear and cap the lines and fittings to prevent dirt from entering the system.
2. Remove the pitman arm nut and washer and mark the pitman arm in relation to the shaft with a center punch. Use a puller to remove the pitman arm.
3. Disconnect the steering shaft from the worn shaft.
4. Remove the steering gear mounting bolts and remove the steering gear from the chassis (Figure 11-1).
5. Reverse steps 1 through 4 to install the steering gear. All bolts must be tightened to the specified torque. Be sure the pitman arm is installed in the original position.




FIGURE 11-1 Removing steering gear from the chassis.



WARNING: The steering gear is often mounted near the exhaust system components. Wear protective gloves when working on a steering gear located near the exhaust system.

POWER RECIRCULATING BALL STEERING GEAR ADJUSTMENTS

Worm Shaft Thrust Bearing Preload Adjustment

A loose worm shaft thrust **bearing preload** adjustment or sector lash adjustment causes excessive **steering wheel free play** and steering wander. The power recirculating ball steering gear adjustment procedures may vary depending on the vehicle make and model year. Always follow the vehicle manufacturer's recommended procedure in the service manual.

When the worm shaft thrust bearing preload adjustment is performed, use this procedure:

1. Remove the worm shaft thrust bearing adjuster plug locknut with a hammer and brass punch (Figure 11-2).
2. Turn this adjuster plug inward, or clockwise, until it bottoms, and tighten the plug to 20 ft-lb. (27 Nm).
3. Place an index mark on the steering gear housing next to one of the holes in the adjuster plug (Figure 11-3).
4. Measure 0.50 in. (13 mm) counterclockwise from the index mark, and place a second index mark at this position (Figure 11-4).
5. Rotate the adjuster plug counterclockwise until the hole in the adjuster plug is aligned with the second index mark placed on the housing (Figure 11-5).
6. Install and tighten the adjuster plug locknut to the specified torque.

Photo Sequence 19 shows a typical procedure for performing a worm shaft bearing preload adjustment.

Pitman Sector Shaft Lash Adjustment

When the **sector shaft lash** adjustment is too loose, steering wheel free play is excessive, which causes **vehicle wander** when the vehicle is driven straight ahead. A loose sector shaft lash adjustment decreases driver **road feel**. If the sector lash adjustment is too tight, steering effort is increased, especially with the front wheels in the straight-ahead position.




FIGURE 11-2 Removing worm shaft thrust bearing adjuster plug locknut.




FIGURE 11-3 Placing index mark on steering gear housing opposite one of the adjuster plug holes.

Classroom Manual

Chapter 11,
page 258

Bearing preload is a condition when end play is removed from the bearing and slight tension is applied to the bearing.

Steering wheel free play is the amount of steering wheel movement before the front wheels begin to turn.



SPECIAL TOOLS

Worm shaft adjuster plug rotating tool

Sector shaft lash refers to the movement between the sector teeth and ball nut teeth.

Vehicle wander is the tendency of a vehicle to steer right or left as it is driven straight ahead.

TYPICAL PROCEDURE FOR PERFORMING A WORM SHAFT BEARING PRELOAD ADJUSTMENT



P19-1 Retain the steering gear in a vise.



P19-2 Remove the worm shaft bearing locknut with a hammer and brass punch.



P19-3 Use the proper tool to turn the worm shaft adjuster plug clockwise until it bottoms, and tighten this plug to 20 ft-lb. (27 Nm).



P19-4 Place an index mark on the steering gear housing next to one of the adjuster plug holes.



P19-5 Measure 0.50 in. (13 mm) counterclockwise from the mark placed on the housing in step P11-4, and place a second mark on the housing.



P19-6 Rotate the worm shaft adjuster plug counterclockwise until the adjuster plug hole is aligned with the second mark placed on the housing.



P19-7 Install and tighten the worm shaft adjuster plug locknut.




FIGURE 11-4 Measuring 0.50 in. (13 mm) counterclockwise from the index mark on the steering gear housing.




FIGURE 11-5 Aligning adjuster plug hole with the second index mark placed on steering gear housing.

When the pitman sector shaft lash adjustment is performed, proceed as follows:

1. Rotate the stub shaft from stop to stop and count the number of turns.
2. Starting at either stop, turn the stub shaft back one-half of the total number of turns. In this position, the flat on the stub shaft should be facing upward (Figure 11-6), and the master spline on the pitman shaft should be aligned with the pitman shaft backlash adjuster screw (Figure 11-7).
3. Loosen the locknut and turn the pitman shaft backlash adjuster screw fully counterclockwise, and then turn it clockwise one turn.
4. Use an inch-pound torque wrench to turn the stub shaft through a 45° arc on each side of the position in step 2. Read the over-center torque as the stub shaft turns through the center position (Figure 11-8).
5. Continue to adjust the pitman shaft adjuster screw until the torque is 6 to 10 in-lb. (0.6 to 1.2 Nm) more than the torque in step 4.
6. Hold the pitman shaft adjuster screw in this position, and tighten the locknut to the specified torque as illustrated in Photo Sequence 20.

Road feel is experienced by a driver when the steering wheel is turned and the driver has a positive feeling that the front wheels are turning in the intended direction.



SERVICE TIP:

When tightening the pitman backlash adjuster screw locknut, it is very important to hold the pitman arm lash adjuster screw with a screwdriver to prevent this screw from turning. If the pitman lash adjuster screw turns when the locknut is tightened, the adjustment is changed.




FIGURE 11-6 Stub shaft flat facing upward and parallel with the side cover.






FIGURE 11-7 Pitman shaft master spline aligned with the pitman backlash adjuster screw.

PITMAN SECTOR SHAFT LASH ADJUSTMENT




P20-1. Clamp the steering gear securely in a vise.



P20-2. Rotate the stub shaft from stop to stop and count the number of turns.



P20-3. Position the stub shaft at either stop and rotate the shaft back one-half the number of total turns.



P20-4. Be sure the master spline on the stub shaft is aligned with the pitman shaft backlash adjuster screw.



P20-5. Loosen the locknut and rotate the backlash adjuster screw fully counterclockwise, and then turn this screw clockwise one turn.



P20-6. Use an inch-pound torque wrench and the proper size socket to rotate the stub shaft through a 45° on each side of the stub shaft center position.



P20-7. Read the over-center torque reading on the torque wrench as the stub shaft is rotated through the center position.



P20-8. While rotating the stub shaft through the center position, turn the sector backlash adjuster screw until the torque wrench reading is 6-10 in-lb. (0.6-1.2 Nm) more than the torque reading in step 7.



P20-9. Hold the sector backlash adjuster screw in this position and tighten the locknut to the specified torque.




FIGURE 11-8 Measuring wormshaft turning torque to adjust pitman backlash adjuster screw.

POWER RECIRCULATING BALL STEERING GEAR OIL LEAK DIAGNOSIS

Five locations where oil leaks may occur in a power steering gear are the following:

1. Side cover O-ring seal (Figure 11-9)
2. Adjuster plug seal
3. Pressure line fitting
4. Pitman shaft oil seals
5. End cover seal

If an oil leak is present at any of these areas, complete or partial steering gear disassembly and seal or O-ring replacement is necessary.

POWER RECIRCULATING BALL STEERING GEAR SEAL REPLACEMENT

Side Cover O-Ring Replacement

Prior to any disassembly procedure, clean the steering gear with solvent or in a parts washer. The steering gear service procedures vary depending on the make of gear. Always follow the vehicle manufacturer's recommended procedure in the service manual.

Following is a typical side cover O-ring replacement procedure:

1. Loosen the pitman backlash adjuster screw locknut and remove the side cover bolts. Rotate the pitman backlash adjuster screw clockwise to remove the cover from the screw (Figure 11-10).




FIGURE 11-9 Power recirculating ball steering gear oil leak locations.




FIGURE 11-10 Removing steering gear side cover.




FIGURE 11-11 Removing steering gear end plug, retaining ring, and seal.

2. Discard the O-ring and inspect the side cover matching surfaces for metal burrs and scratches.
3. Lubricate a new O-ring with the vehicle manufacturer's recommended power steering fluid and install the O-ring.
4. Rotate the pitman backlash adjuster screw counterclockwise into the side cover until the side cover is properly positioned on the gear housing. Turn this adjuster screw fully counterclockwise and then one turn clockwise. Install and tighten the side cover bolts to the specified torque. Adjust the pitman sector shaft lash as explained earlier.

End Plug Seal Replacement

Follow these steps for end plug seal replacement:

1. Insert a punch into the access hole in the steering gear housing to unseat the retaining ring, and remove the ring (Figure 11-11).
2. Remove the end plug and seal.
3. Clean the end plug and seal contact area in the housing with a shop towel.
4. Lubricate a new seal with the vehicle manufacturer's recommended power steering fluid, and install the seal.
5. Install the end plug and retaining ring.



CAUTION:

The bearing identification number must face the driving tool to prevent bearing damage during installation.

Worm Shaft Bearing Adjuster Plug Seal and Bearing Replacement

Follow these steps for worm shaft bearing adjuster plug seal and bearing service:

1. Remove the adjuster plug locknut, and use a special tool to remove the adjuster plug.
2. Use a screwdriver to pry at the raised area of the bearing retainer to remove this retainer from the adjuster plug (Figure 11-12).
3. Place the adjuster plug face down on a suitable support, and use the proper driver to remove the needle bearing, dust seal, and lip seal.
4. Place the adjuster plug face up on a suitable support, and use the proper driver to install the needle bearing dust seal and lip seal.

CUSTOMER CARE: As an automotive technician, you should be familiar with the maintenance schedules recommended by various vehicle manufacturers. Of course, it is impossible to memorize all the maintenance schedules on different makes of vehicles, but maintenance schedule books are available. This maintenance schedule information is available in the owner's manual, but the vehicle owner may not take time to read this manual. If you advise the customer that his or her vehicle requires some service, such as a cooling system flush, according to the vehicle manufacturer's maintenance schedule, the customer will often have the service performed. The customer will usually appreciate your interest in his or her vehicle, and the shop will benefit from the increased service work.

Classroom Manual

Chapter 11,
page 259




FIGURE 11-12 Removing and replacing worm shaft adjuster plug, bearing, and seal.

5. Install the bearing retainer in the adjuster plug, and lubricate the bearing and seal with the vehicle manufacturer's recommended power steering fluid.
6. Install the adjuster plug and locknut, and adjust the worm shaft bearing preload as discussed previously.

TABLE 11-1 STEERING GEAR DIAGNOSIS

Problem	Symptoms	Possible Causes
Excessive steering wheel free play	Steering wander when driving straight ahead	Loose worm shaft preload adjustment Loose sector lash adjustment Loose steering gear mounting bolts Worn steering linkage components Worn flexible coupling or universal joint in steering shaft.
Excessive steering effort	Excessive steering wheel turning effort when turning a corner or parking	Lack of steering gear lubricant Tight worm shaft bearing preload adjustment Tight sector lash adjustment
Underhood noise	Rattling noise when driving over road irregularities Squawking noise while turning a corner	Worn flexible coupling or universal joint in steering shaft Loose steering gear mounting bolts Cut or worn dampener O-ring on spool valve
Erratic steering effort	Erratic steering effort when turning a corner	Low power steering fluid level Air in power steering system Worn, damaged worm shaft, ball nut, or sector teeth

CASE STUDY

The owner of a 2005 Chevrolet Silverado truck complained about increased and somewhat erratic steering effort. The service writer asked the customer about the conditions when this problem occurred, and the customer said that the condition was always present. During a road test, the technician discovered that the customer's description of the problem was accurate.

The technician checked the power steering fluid level and made a careful check of the belt tension and condition without finding any problems. Next, the technician

checked the power steering pump pressure and found it to be normal. A check of the power steering hoses did not reveal any hose restrictions.

The technician removed and disassembled the steering gear and found a severely scored cylinder bore in the gear housing. The ball nut piston ring was also worn and scored. A replacement steering gear was installed, and the system filled with the manufacturer's recommended power steering fluid. A road test indicated the new gear worked satisfactorily.

TERMS TO KNOW

Bearing preload

Sector shaft lash

Road feel

Steering wheel free play

Vehicle wander

ASE-STYLE REVIEW QUESTIONS

1. While discussing power recirculating ball steering gear diagnosis:

Technician A says excessive steering wheel free play may be caused by a worm shaft bearing preload adjustment that is tighter than normal.

Technician B says excessive steering wheel free play may be caused by loose steering gear mounting bolts.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

2. While discussing power recirculating ball steering gear service:

Technician A says steering wander may be caused by a loose sector lash adjustment.

Technician B says a loose sector lash adjustment may cause reduced feel of the road.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

3. While discussing power recirculating steering gear diagnosis:

Technician A says the sector lash adjustment is performed with the worm shaft halfway between the centered position and the full-right position.

Technician B says the worm shaft bearing preload adjustment is performed before the sector lash adjustment.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

4. A power recirculating ball steering gear has a rattling noise while driving the vehicle. The most likely cause of this problem is:

- A. Low power steering fluid level.
B. Worn flexible coupling in the steering shaft.
C. Loose worm bearing preload adjustment.
D. Leaking pitman shaft seal.

5. A power recirculating ball steering gear has a fluid leakage problem, and fluid appears on the top of the gear.

Technician A says the side cover O-ring seal may be leaking.

Technician B says the high pressure line fitting on the gear may be leaking.

Who is correct?

- A. A only
B. B only
C. Both A and B
D. Neither A nor B

6. A power recirculating ball steering gear has excessive kickback on the steering wheel. The most likely cause of this problem is:

- A. A loose sector lash adjustment.
B. A loose worm shaft bearing preload adjustment.
C. A defective poppet valve in the steering gear.
D. A worn pitman shaft bearing.

7. All of these statements about power recirculating ball steering gear defects are true EXCEPT:
- A. A worn steering shaft U-joint may cause a growling noise when turning the front wheels.
 - B. Excessive steering effort may be caused by a defective power steering pump.
 - C. Excessive steering effort may be caused by a scored steering gear cylinder.
 - D. Steering wheel jerking when turning may be caused by a slipping power steering belt.
8. When adjusting on a power recirculating ball steering gear:
- A. The worm shaft bearing adjuster plug should be bottomed and then backed off until the specified worm shaft turning torque is obtained.
 - B. The sector lash adjustment screw should be tightened one turn before the worm shaft bearing preload is adjusted.
 - C. The pitman shaft backlash adjuster screw is turned fully counterclockwise and then one turn clockwise prior to the backlash adjustment.
 - D. The pitman shaft is positioned one-half turn from the fully right or left position prior to the pitman shaft backlash adjustment.
9. A power recirculating ball steering gear experiences excessive steering effort while parking. The most likely cause of this problem is:
- A. A restricted high-pressure steering hose.
 - B. A misaligned power steering belt.
 - C. A leaking pitman shaft seal.
 - D. Excessive torque on the worm shaft adjuster plug locknut.
10. A power recirculating ball steering gear experiences hard steering for a short time after the vehicle sits overnight. The most likely cause of this problem is:
- A. Excessively tight worm bearing preload adjustment.
 - B. A scored cylinder and worn piston ring in the steering gear.
 - C. A restricted power steering return hose.
 - D. A binding U-joint in the steering shaft.

ASE CHALLENGE QUESTIONS

1. A car with a power recirculating ball steering gear has excessive steering kickback, and a preliminary inspection shows no abnormal wear in the linkage. Which of the following could be the cause of the problem?
- A. Worn gear piston or bore.
 - B. Slipping pump belt.
 - C. Worn pump poppet valve.
 - D. Sticking valve spool.
2. The complaint is loss of power assist, but there is no mention of any associated noise. All of the following could cause this problem EXCEPT:
- A. Low fluid.
 - B. Improperly inflated tires.
 - C. Broken pump belt.
 - D. Steering column misalignment.
3. While discussing steering problems:
- Technician A* says a “jerky” steering wheel and a “clunking” noise could indicate worn steering column U joints.
- Technician B* says lack of assist and a “growling” noise in a fluid-filled steering pump could indicate a hose or pump internal restriction.
- Who is correct?
- A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B

4. A vehicle with a power recirculating ball steering system requires much higher than normal steering effort, especially in the parking lot.

Technician A says the cause of the problem is a worn pitman shaft seal.

Technician B says the cause of the problem is a worn worm shaft thrust bearing.

Who is correct?

- | | |
|-----------|--------------------|
| A. A only | C. Both A and B |
| B. B only | D. Neither A nor B |

5. The complaint is excessive steering wheel free play. All of the following could cause this problem EXCEPT:

- A. Loose worm shaft bearing preload.
- B. Worn steering gears.
- C. Steering gear column misalignment.
- D. Worn flex coupling or U joint.

Name _____ Date _____

POWER RECIRCULATING BALL STEERING GEAR OIL LEAK DIAGNOSIS

Upon completion of this job sheet, you should be able to diagnose oil leaks in a power recirculating ball steering gear.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-4: Diagnose power steering gear (non-rack and pinion) binding, uneven turning effort, looseness, hard steering, and noise concerns, determine necessary action.

Tools and Materials

Modern vehicle with a power recirculating ball steering gear.

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

1. Place fender, seat, and floor mat covers on the vehicle.
2. Clean the outside of the steering gear.
3. Be sure the power steering pump reservoir is filled to the proper level with the specified fluid.
4. Start the engine and observe the power steering gear while an assistant turns the steering wheel fully in each direction several times. Turn off the ignition switch.
5. If the power steering gear is leaking fluid on the lower side, raise the front of the vehicle with a floor jack and support the front suspension on safety stands positioned at the specified vehicle lift points. Repeats steps 2–4.
6. List the fluid leak locations on the power steering gear.

7. State the necessary repairs to correct the power steering gear leaks.

Instructor's Response _____

Task Completed



Name _____ Date _____

ADJUST POWER RECIRCULATING BALL STEERING GEAR WORM SHAFT THRUST BEARING PRELOAD, STEERING GEAR REMOVED

Upon completion of this job sheet, you should be able to adjust worm shaft thrust bearing preload on power recirculating ball steering gears.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-7: Adjust non-rack and pinion worm bearing preload and sector lash.

Tools and Materials

Torque wrench, in-lb.

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Make of steering gear _____

Procedure

1. Remove the worm shaft thrust bearing adjuster plug locknut with a hammer and brass punch.
2. Turn this adjuster plug inward, or clockwise, until it bottoms and tighten the plug to 20 ft-lb. (27 Nm).

Actual worm shaft adjuster plug locknut torque _____

3. Place an index mark on the steering gear housing next to one of the holes in the adjuster plug.

Is an index mark placed on steering gear housing beside one of the adjuster plug holes?

☐ Yes ☐ No

Instructor check _____

4. Measure 0.50 in. (13 mm) counterclockwise from the index mark, and place a second index mark at this position.

Is a second index mark placed 0.50 in. (13 mm) counterclockwise from the first index mark?

☐ Yes ☐ No

Instructor check _____

Task Completed



Task Completed

5. Rotate the adjuster plug counterclockwise until the hole in the adjuster plug is aligned with the second index mark placed on the housing.

Is the hole in adjuster plug properly aligned with second index mark?

☐ Yes ☐ No

Instructor check _____

6. Install and tighten the adjuster plug locknut to the specified torque.

Specified adjuster plug locknut torque _____

Actual adjuster plug locknut torque _____

Instructor's Response _____

Name _____ Date _____

ADJUST POWER RECIRCULATING BALL STEERING GEAR SECTOR LASH, STEERING GEAR REMOVED

Upon completion of this job sheet, you should be able to adjust sector lash on power recirculating ball steering gears.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-7: Adjust non-rack and pinion worm bearing preload and sector lash.

Tools and Materials

Torque wrench, in-lb.

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Make of steering gear _____

Procedure

Task Completed

1. Rotate the worm shaft from stop to stop and count the number of turns.

Total number of worm shaft turns from stop to stop _____

2. Starting at either stop, turn the worm shaft back two-thirds of the total number of turns.

Number of worm shaft turns from fully right or fully left to position the worm shaft properly prior to sector lash adjustment _____

Explain the reason for placing the worm shaft in this position prior to the sector lash adjustment.

3. In this position, the flat on the worm shaft should be facing upward, and the master spline on the pitman shaft should be aligned with the pitman shaft backlash adjuster screw.

Is the worm shaft flat properly positioned? ☐ Yes ☐ No

Is the master spline on the pitman shaft properly positioned? ☐ Yes ☐ No

If the answer is no to either of the above questions, state the necessary corrective action.

Task Completed

4. Turn the pitman shaft backlash adjuster screw fully counterclockwise, and then turn it clockwise one turn.

Is the pitman shaft backlash adjuster screw properly positioned? ☐ Yes ☐ No

Instructor check _____

5. Use an inch-pound torque wrench to turn the worm shaft through a 45° arc on each side of the position in step 2. Read the over-center torque as the worm shaft turns through the center position.

Stub shaft turning torque _____

6. Continue to adjust the pitman shaft adjuster screw until the torque is 6 to 10 in-lb. (0.6 to 1.2 Nm) more than the torque in step 5.

Final worm shaft turning torque after adjustment _____

7. Hold the pitman shaft adjuster screw in this position and tighten the locknut to the specified torque.

Specified pitman shaft adjuster screw locknut torque _____

Actual pitman shaft adjuster screw locknut torque _____

Instructor's Response _____

Chapter 12

RACK AND PINION STEERING GEAR DIAGNOSIS AND SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Perform a manual or power rack and pinion steering gear inspection.
- Remove and replace manual or power rack and pinion steering gears.
- Disassemble, inspect, repair, and reassemble manual rack and pinion steering gears.
- Adjust manual rack and pinion steering gears.
- Diagnose manual rack and pinion steering systems.
- Diagnose oil leaks in power rack and pinion steering gears.
- Disassemble, inspect, and repair power rack and pinion steering gears.
- Adjust power rack and pinion steering gears.
- Diagnose Magnasteer.
- Diagnose electronic power steering systems.

Proper rack and pinion steering gear operation is essential to maintain vehicle safety and reduce driver fatigue. Such steering gear conditions as looseness and excessive steering effort may contribute to a loss of steering control, resulting in a vehicle collision. Worn steering gear mountings may cause improper wheel alignment and **bump steer**. Improper wheel alignment increases tire tread wear, and bump steer may increase driver fatigue. Excessive steering gear looseness or high steering effort also contribute to driver fatigue. Therefore, in the interest of vehicle safety and driver alertness, rack and pinion steering gear diagnosis and service are extremely important.

MANUAL OR POWER RACK AND PINION STEERING GEAR ON-CAR INSPECTION

The wear points are reduced to four in a rack and pinion steering gear. These wear points are the inner and outer tie-rod ends on both sides of the rack and pinion assembly (Figure 12-1).

The first step in manual or power rack and pinion steering gear diagnosis is a very thorough inspection of the complete steering system. During this inspection, all steering system components such as the inner and outer tie-rod ends, **bellows boots**, mounting bushings, couplings or universal joints, ball joints, tires, and **steering wheel free play** must be checked.

Follow these steps for manual or power rack and pinion steering gear inspection:

1. With the front wheels straight ahead and the engine stopped, rock the steering wheel gently back and forth with light finger pressure (Figure 12-2). Measure the maximum steering wheel free play. The maximum specified steering wheel free play on some vehicles is 1.18 in. (30 mm). Always refer to the vehicle manufacturer's specifications in the service manual. Excessive steering wheel free play indicates worn steering components.



BASIC TOOLS

Basic technician's tool set

Service manual

Floor jack

Safety stands

Machinist's rule

Bump steer occurs when one of the front wheels strikes a road irregularity while driving straight ahead, and the steering suddenly veers to the right or left.




FIGURE 12-1 Wear points at the inner and outer tie-rod ends in a rack and pinion steering gear.

Bellows boots are clamped over each end of the steering gear housing to keep dirt out of the rack.

Steering wheel free play is the distance that the steering wheel moves before the front wheels begin to turn when the steering wheel is rocked back and forth with light finger pressure.



FIGURE 12-2 Checking steering wheel free play.

2. With the vehicle sitting on the shop floor and the front wheels straight ahead, have an assistant turn the steering wheel about 1/4 turn in both directions. Watch for looseness in the flexible coupling or universal joints in the steering shaft. If looseness is observed, replace the coupling or universal joint.
3. While an assistant turns the steering wheel about 1/2 turn in both directions, watch for movement of the steering gear housing in the mounting bushings. If there is any movement of the housing in these bushings, replace the bushings. The steering gear mounting bushings may be deteriorated by oil soaking, heat, or age.
4. Grasp the pinion shaft extending from the steering gear and attempt to move it vertically. If there is steering shaft vertical movement, a pinion bearing preload adjustment may be required. When the steering gear does not have a pinion bearing preload adjustment, replace the necessary steering gear components.
5. Road test the vehicle and check for excessive steering effort. A bent steering rack, tight rack bearing adjustment, or damaged front drive axle joints in a front-wheel-drive car may cause excessive steering effort.
6. Visually inspect the bellows boots for cracks, splits, leaks, and proper clamp installation. Replace any boot that indicates any of these conditions. If the boot clamps are loose or improperly installed, tighten or replace the clamps as necessary. Since the bellows boots protect the inner tie-rod ends and the rack from contamination, boot condition is extremely important. Boots should be inspected each time under-car service such as oil and filter change or chassis lubrication is performed.
7. Loosen the inner bellows boot clamps and move each boot toward the outer tie-rod end until the inner tie-rod end is visible. Push outward and inward on each front tire, and watch for movement in the inner tie-rod end. If any movement or looseness is present, replace the inner tie-rod end. An alternate method of checking the inner tie-rod ends is to squeeze the bellows boots and grasp the inner tie-rod end socket. Movement in the inner tie-rod end is then felt as the front wheel is moved inward and outward. Hard plastic bellows boots may be found on some applications. With this type of bellows boot, remove the ignition key from the switch to lock the steering column and push inward and outward on the front tire while observing any lateral movement in the tie-rod. When lateral movement is observed, replace the inner tie-rod end.



WARNING: Bent steering components must be replaced. Never straighten steering components, because this action may weaken the metal and result in sudden component failure, serious personal injury, and vehicle damage.

8. Grasp each outer tie-rod end and check for vertical movement. While an assistant turns the steering wheel 1/4 turn in each direction, watch for looseness in the outer tie-rod ends. If any looseness or vertical movement is present, replace the tie-rod end. Check the outer tie-rod end seals for cracks and proper installation of the nuts and cotter pins. Cracked seals must be replaced. Inspect the tie-rods for a bent condition. Bent tie-rods or other steering components must be replaced. Do not attempt to straighten these components.

MANUAL OR POWER RACK AND PINION STEERING GEAR REMOVAL AND REPLACEMENT

The replacement procedure is similar for manual or power rack and pinion steering gears. This removal and replacement procedure varies depending on the vehicle. On some vehicles, the front crossmember or engine support cradle must be lowered to remove the rack and pinion steering gear. Always follow the vehicle manufacturer's recommended procedure in the service manual.

The following is a typical rack and pinion steering gear removal and replacement procedure:

1. Place the front wheels in the straight-ahead position and remove the ignition key from the ignition switch to lock the steering wheel. Place the driver's seat belt through the steering wheel to prevent wheel rotation if the ignition switch is turned on (Figure 12-3). This action maintains the clock spring electrical connector or spiral cable in the centered position on air-bag-equipped vehicles.
2. Lift the front end with a floor jack, and place safety stands under the vehicle chassis. Lower the vehicle onto the safety stands. Remove the left and right fender apron seals (Figure 12-4).



FIGURE 12-3 Driver's seat belt wrapped around the steering wheel to prevent wheel rotation.




FIGURE 12-4 Left and right fender apron seals.

3. Place punch marks on the lower universal joint and the steering gear pinion shaft so they may be reassembled in the same position (Figure 12-5). Loosen the upper universal joint bolt, remove the lower universal joint bolt, and disconnect this joint.
4. Remove the cotter pins from the outer tie-rod ends. Loosen, but do not remove, the tie-rod end nuts. Use a tie-rod end puller to loosen the outer tie-rod ends in the steering arms (Figure 12-6). Remove the tie-rod end nuts and remove the tie-rod ends from the arms.
5. Use the proper wrenches to disconnect the high-pressure hose and the return hose from the steering gear (Figure 12-7). This step is not required on a manual steering gear. The removal procedure for a power rack and pinion steering gear is shown in Photo Sequence 21.
6. Remove the four stabilizer bar mounting bolts (Figure 12-8).
7. Remove the steering gear mounting bolts (Figure 12-9).
8. Remove the steering gear assembly from the right side of the car (Figure 12-10).
9. Position the right and left tie-rods the specified distance from the steering gear housing (Figure 12-11). Install the steering gear through the right fender apron.
10. Install the pinion shaft in the universal joint with the punch marks aligned. Tighten the upper and lower universal joint bolts to the specified torque.
11. Install the steering gear mounting bolts and tighten these bolts to the specified torque.



SPECIAL TOOLS

Tie-rod end puller




FIGURE 12-5 Punch marks on universal joint and pinion shaft.




FIGURE 12-6 Removing outer tie-rod ends.




FIGURE 12-7 Removing high-pressure and return hoses from steering gear.



FIGURE 12-8 Removing stabilizer bar mounting bolts.




FIGURE 12-9 Removing steering gear mounting bolts.




FIGURE 12-10 Removing steering gear from the car.




FIGURE 12-11 Right and left tie-rod position in relation to the steering gear housing prior to installation.



CAUTION:

Do not loosen the tie-rod end nuts to align cotter pin holes. This action causes improper torquing of these nuts.


12. Install the stabilizer bar mounting bolts and torque these bolts to specifications.
13. Install and tighten the high-pressure and return hoses to the specified torque. (This step is not required on a manual rack and pinion steering gear.)
14. Install the outer tie-rod ends in the steering knuckles, and tighten the nuts to the specified torque. Install the cotter pins in the nuts.
15. Check the front wheel toe and adjust as necessary. Tighten the outer tie-rod end jam nuts to the specified torque, and tighten the outer bellows boot clamps.
16. Install the left and right fender apron seals, and lower the vehicle with a floor jack.
17. Fill the power steering pump reservoir with the vehicle manufacturer's recommended power steering fluid and bleed the air from the power steering system. (Refer to Chapter 10 for these tasks. This step is not required on a manual rack and pinion steering gear.)
18. Road test the vehicle and check for proper steering gear operation and steering control.

PHOTO SEQUENCE 21


TYPICAL PROCEDURE FOR REMOVING AND REPLACING A POWER RACK AND PINION STEERING GEAR




P21-1 Position the vehicle on a tire-contact lift, and place the front wheels in the straight-ahead position.



P21-2 Remove the key from the ignition switch to lock the steering column, and place the driver's seat belt through the steering wheel opening to prevent wheel rotation if the ignition switch is turned on.




P21-3 Raise the vehicle a short distance off the floor, and remove the left and right fender apron seals.



P21-4 Place punch or chalk marks on the lower universal joint and steering gear pinion shaft so they may be reassembled in the same position.



P21-5 Loosen the upper universal joint bolt, remove the lower universal joint bolt, and disconnect the lower universal joint.



P21-6 Remove the cotter pins from the outer tie-rod ends, and loosen but do not remove the tie-rod end nuts. Use a tie-rod end puller to loosen the outer tie-rod ends in the steering arms. Remove the tie-rod end nuts, and remove the tie-rod ends from the steering arms.



P21-7 Use the proper size wrenches to remove the high-pressure hose and return hose from the steering gear.



P21-8 Remove the four stabilizer bar mounting bolts.




P21-9 Remove the steering gear mounting bolts.

PHOTO SEQUENCE 21 (CONTINUED)



P21-10 Remove the steering gear through one of the fender apron openings.




P21-11 Measure the distance from the outer end of the steering gear housing to the outer edge of the outer tie-rod end on both sides of the steering gear, and record these measurements.



P21-12 Rotate the pinion shaft to obtain the measurements obtained in step 11, and install the steering gear through one of the fender apron openings.



P21-13 Install the pinion shaft into the universal joint with the punch marks aligned. Tighten the upper and lower universal joint bolts to the specified torque.




P21-14 Install the steering gear mounting bolts and tighten these bolts to the specified torque.



P21-15 Install the stabilizer mounting bolts and tighten these bolts to the specified torque.



P21-16 Install and tighten the high-pressure and return line fittings to the specified torque.



P21-17 Install the outer tie-rod ends in the steering arms, and tighten the retaining nuts to the specified torque. Install the cotter pins in the nuts.



P21-18 Lower the vehicle to a convenient working height, and install the fender apron seals.



P21-19 Fill the power steering pump reservoir to the proper level with the specified power steering fluid. Start the engine for a short time, then shut the engine off, and add power steering fluid as required. Run the engine for several minutes, turn the steering wheel fully in both directions, and then add power steering fluid as necessary.

MANUAL RACK AND PINION STEERING GEAR DIAGNOSIS AND SERVICE

Manual Rack and Pinion Steering Gear Tie-Rod Service

Follow these steps for manual rack and pinion steering gear disassembly:

1. Clamp the center of the steering gear housing in a **soft-jaw vise**. Do not apply excessive force to the vise.
2. Insert a short piece of wire through each outer tie-rod end cotter pin hole and connect a pull scale to this wire. Pull upward on the scale to check the tie-rod articulation effort (Figure 12-12). If this effort is not within specifications, replace the inner tie-rod end.
3. Mark the outer tie-rod and jam nut position with masking tape wrapped around the tie-rod threads next to the jam nut, or place a dab of paint on the jam nut and tie-rod threads (Figure 12-13). Loosen the jam nuts and remove the outer tie-rod ends.

A **soft-jaw vise** has brass jaws to prevent marking components.




FIGURE 12-12 Measuring inner tie-rod end articulation effort.




FIGURE 12-13 Marking outer tie-rod end and jam nut position.




FIGURE 12-14 Straightening lock plate where it is bent over the inner tie-rod end.




FIGURE 12-15 Removing inner tie-rod end from the rack.

4. Remove the inner and outer bellows boot clamps and pull the bellows boots from the tie-rods.
5. Hold the rack in a soft-jaw vise and straighten the lock plate where it is bent over the inner tie-rod end (Figure 12-14). Hold the rack with a wrench, and use the proper size wrench to remove the inner tie-rod end from the rack (Figure 12-15). A jam nut is used in place of the lock ring on some inner tie-rod ends, and a roll pin retains some inner tie-rod ends to the rack. Various inner tie-rod socket removal procedures are required depending on the socket design.
6. Rotate the inner tie-rod ends onto the rack until they bottom. Install the inner tie-rod pins, or stake these ends as required. Always use a wooden block to support the opposite side of the rack and inner tie-rod end while staking. If jam nuts are located on the inner tie-rod ends, be sure they are tightened to the specified torque.
7. Place a large bellows boot clamp over each end of the gear housing. Install the bellows boots, and be sure the boots are seated in the housing and the tie-rod undercuts. Install and tighten the large inner boot clamps.
8. Install the outer bellows boot clamps on the tie-rods, but do not install these clamps on the boots until the steering gear is installed and the toe is adjusted.
9. Install the jam nuts and the outer tie-rod ends. Align the marks placed on these components during the disassembly procedure. Leave the jam nuts loose until the steering gear is installed and the toe is adjusted.
10. Install the steering gear in the vehicle and check the front wheel toe. Tighten the outer bellows boot clamps and the outer tie-rod end jam nuts.

Diagnosis of Manual Steering and Suspension Systems

It is sometimes difficult to separate the diagnosis of manual steering gears, steering columns, and suspension systems because some noises and symptoms may be caused by problems in any of these components or systems. Diagnostic information on three common steering problems is provided in Table 12-1. Refer to the vehicle manufacturer's service manual for complete diagnosis.

POWER RACK AND PINION STEERING GEAR DIAGNOSIS AND SERVICE Fluid, Filter, and Fluid Leak Diagnosis

Power steering fluid should be inspected for discoloration and contamination with metal particles, dirt, or water. A suction gun may be used to remove some fluid from the power steering reservoir for inspection. If the fluid is contaminated or discolored, the power steering system

TABLE 12-1 DIAGNOSIS OF MANUAL STEERING GEARS, SUSPENSION SYSTEMS, AND STEERING COLUMNS

Condition	Possible Cause	Correction
Loose steering	<ol style="list-style-type: none"> 1. Steering linkage connections loose 2. Steering linkage ball stud rubber deteriorated 3. Pitman arm-to-steering-gear attaching nut loose 4. Flex coupling-to-steering-gear attaching bolt loose 5. Intermediate shaft-to-steering-column-shaft attaching bolt loose 6. Flex coupling damaged or worn 7. Front and/or rear suspension components loose, damaged, or worn 8. Steering gear adjustment set too low 	<ol style="list-style-type: none"> 1. Tighten as required. 2. Replace as required. 3. Tighten to specifications. 4. Tighten the bolt to specifications. 5. Tighten the bolt to specifications. 6. Replace as required. 7. Tighten or replace as required. 8. Check the steering gear adjustment and readjust as required.
Noise: Knock, clunk, rapping, squeaking noise when turning	<ol style="list-style-type: none"> 1. Steering wheel-to-steering-column shroud interference 2. Lack of lubrication where speed control brush contacts steering wheel pad 3. Steering column mounting bolts loose 4. Intermediate shaft-to-steering-column-shaft attaching bolt loose 5. Flex coupling-to-steering-gear attaching bolt loose 6. Steering gear mounting bolts loose 7. Tires rubbing or grounding out against body or chassis 8. Front suspension components loose, worn, or damaged 9. Steering linkage ball stud rubber deteriorated 10. Normal lash between sector gear teeth and ball nut gear teeth when the steering gear is in the off-center position permits gear tooth chuckle noise while turning on rough road surfaces 	<ol style="list-style-type: none"> 1. Adjust or replace as required. 2. Lubricate as required. 3. Tighten the bolt to specifications. 4. Tighten the bolt to specifications. 5. Tighten the bolt to specifications. 6. Tighten the bolt to specifications. 7. Adjust/replace as required. 8. Tighten or replace as required. 9. Replace as required. 10. This is a normal condition and cannot be eliminated.
Vehicle pulls/drifts to one side <i>Note:</i> This condition cannot be caused by the manual steering gear.	<ol style="list-style-type: none"> 1. Vehicle overloaded or unevenly loaded 2. Improper tire pressure 3. Mismatched tires and wheels 4. Unevenly worn tires 5. Loose, worn, or damaged steering linkage 6. Steering linkage stud not centered within the socket 7. Bent spindle or spindle arm 8. Broken and/or sagging front and/or rear suspension springs 9. Loose, bent, or damaged suspension components 10. Bent rear axle housing 11. Excessive camber/caster split (excessive side-to-side variance in the caster/camber settings) 12. Improper toe setting 13. Front wheel bearings out of adjustment 14. Investigate tire variance (conicity for radial tires and unequal circumference for bias-ply and belted bias-ply tires) 	<ol style="list-style-type: none"> 1. Correct as required. 2. Adjust air pressure as required. 3. Install correct tire and wheel combination. 4. Replace as required (check for cause). 5. Tighten or replace as required. 6. Repair or replace as required. 7. Repair or replace as required. 8. Replace as required. 9. Tighten or replace as required. 10. Replace as required. 11. Adjust camber/caster split as required. 12. Adjust as required. 13. Adjust as required. 14. Repair or replace as required.





FIGURE 12-16 Power steering reservoir and filter.

must be flushed and then filled to the specified level with the vehicle manufacturer's specified fluid. After refilling the power steering system, an air bleeding procedure is usually necessary. Some power steering systems have a filter that is usually located in the remote power steering reservoir (Figure 12-16). On some systems, the filter and reservoir must be replaced as an assembly. Filter/reservoir replacement is necessary if the power steering system has been opened for repairs or if the fluid is contaminated with water, metal, or dirt particles. The filter/reservoir and fluid should also be changed at the vehicle manufacturer's specified service intervals. A restricted power steering filter may cause erratic steering operation.



WARNING: If the engine has been running for a length of time, power steering gears, pumps, lines, and fluid may be very hot. Wear eye protection and protective gloves when servicing these components.

If power steering fluid leaks from the cylinder end of the power steering gear, the outer rack seal is leaking (Figure 12-17).




If a leak is detected at the housing cylinder end, the origin of the leak is the outer rack seal.

FIGURE 12-17 Oil leak diagnosis at outer rack seal.

The inner rack seal is defective if oil leaks from the pinion end of the housing when the rack reaches the left internal stop (Figure 12-18). An oil leak at one rack seal may result in oil leaks from both boots because the oil may travel through the breather tube between the boots.


If an oil leak occurs at the pinion end of the housing and this leak is not influenced when the steering wheel is turned, the pinion seal is defective (Figure 12-19).

If an oil leak occurs in the pinion coupling area, the input shaft seal is leaking (Figure 12-20). This seal and the pinion seal will require replacement because the pinion seal must be replaced if the pinion is removed.



If the leak at the pinion end of the housing spurts when the rack reaches the left internal stop, the inner rack seal is at fault.

FIGURE 12-18 Inner rack seal leak diagnosis.



If you detect a leak at the pinion end of the housing and it is not influenced by the direction of the turn, the origin of the leak is the pinion seal.

FIGURE 12-19 Pinion seal leak diagnosis.



If you discover a leak at the pinion coupling area, you'll have to replace both the input shaft seal and the lower pinion seal.

FIGURE 12-20 Oil leak diagnosis on pinion coupling area.




FIGURE 12-21 Rack seals and pinion seal.



SERVICE TIP:

To provide equal turning effort in both directions, the rack must be centered with the front wheels straight ahead.

Steering effort imbalance

is the difference in steering effort when making right and left turns.

When the rack is removed, the inner and outer rack seals and the pinion seal must be replaced (Figure 12-21). If oil leaks occur at fittings, these fittings must be torqued to the manufacturer's specifications. If the leak is still present, the line and fitting should be replaced. Leaks in the lines or hoses require line or hose replacement.

Turning Imbalance Diagnosis

The same amount of effort should be required to turn the steering wheel in either direction. A pressure gauge connected to the high-pressure hose should indicate the same pressure when the steering wheel is turned in each direction. **Steering effort imbalance** or lower power assist in each direction may be caused by defective rack seals (Figure 12-22). Steering




FIGURE 12-22 Effect of defective rack seals on steering effort imbalance and low power assist.

Kinked hose or faulty inlet seal. Low-power assist in both directions.

Valve passages or lines clogged with dirt. Low-power assist in one or both directions.

Low-power assist because return oil will block movement of rack piston.

Valve body pressure rings leaking. Low-power assist in one or both directions.




FIGURE 12-23 Effect of worn rotary valve rings and seals or restricted lines or hoses on steering effort.

In a power rack and pinion steering gear, a condition that causes excessive steering effort when the vehicle is first started may be called “morning sickness.”



SPECIAL TOOLS

Steering gear holding tool

Claw washers are used in some steering gears to lock the tie-rods to the rack.

effort imbalance or low power assist in both directions may also be caused by defective rotary valve rings and seals or restricted hoses and lines (Figure 12-23).

Power Rack and Pinion Steering Gear Tie-Rod and Rack Bearing Service

1. Install a holding tool on the steering gear housing, and clamp this tool in a vise (Figure 12-24).
2. Mark the outer tie-rod ends, jam nuts, and tie-rods (Figure 12-25). Loosen the jam nuts and remove the tie-rod ends and jam nuts.
3. Loosen the inner and outer clamps on both bellows boots, and remove these boots (Figure 12-26).
4. Clamp the inner tie-rod socket lightly in a soft-jaw vise and use a hammer and chisel to unstake the **claw washers** on the inner tie-rod sockets (Figure 12-27).




FIGURE 12-24 Steering gear holding tool.




FIGURE 12-25 Marking outer tie-rod ends, jam nuts, and tie-rods prior to outer tie-rod end removal.



SERVICE TIP:

A common problem with power rack and pinion steering gears is excessive steering effort when the car is first started after sitting overnight. The steering effort becomes normal, however, after the steering wheel is turned several times. This problem usually indicates severe scoring where the pinion sealing rings contact the pinion housing. Steering gear replacement is required to correct this problem.



FIGURE 12-26 Removing bellows boot clamps.




FIGURE 12-27 Removing claw washers from inner tie-rod sockets.



SERVICE TIP:

In some power rack and pinion steering gears, the inner tie-rod ends are staked after they are installed on the rack (refer to Photo Sequence 22 later in this chapter). In other power rack and pinion steering gears, a pin retains the inner tie-rod ends to the rack, and this pin must be removed before the inner tie-rod ends are removed. When the inner tie-rod ends are replaced, a new retaining pin must be installed.

5. Hold the rack with an adjustable wrench and use the proper tool to loosen the inner tie-rod ends (Figure 12-28). Remove the inner tie-rod ends and the claw washers.
6. Use the proper tool to loosen the adjuster plug locknut (Figure 12-29).
7. Remove the adjuster plug with the proper tool (Figure 12-30).
8. Remove the spring, rack guide, and the seat from the adjuster plug opening (Figure 12-31).




FIGURE 12-28 Loosening inner tie-rod ends.




FIGURE 12-29 Loosening adjuster plug locknut.




FIGURE 12-30 Removing adjuster plug.




FIGURE 12-31 Removing spring, rack guide, and seat.

9. Clean and inspect the spring, rack guide, and seat. Replace only worn components. Lubricate the rack guide and seat with the specified power steering fluid.
10. Coat the rack guide seat and rack guide with power steering fluid. Install the rack guide seat, rack guide, and spring (Figure 12-32). Apply Loctite 242 sealant or its equivalent to the first two or three threads on the rack spring cap. Install the rack spring cap and tighten it to the specified torque (Figure 12-33).
11. Use the proper tool to rotate the rack spring cap 12° counterclockwise. Turn the pinion shaft fully in each direction, and repeat this action. Loosen the rack spring cap until there is no tension on the rack guide spring. Place the proper turning tool and a foot-pound torque wrench on top of the pinion shaft. Tighten the rack spring cap while rotating the pinion shaft back and forth (Figure 12-34). Continue tightening the rack spring cap until the specified turning torque is indicated on the torque wrench.




FIGURE 12-32 Installing rack guide seat, rack guide, and spring.




FIGURE 12-33 Installing rack spring cap.




FIGURE 12-34 Adjusting pinion shaft turning torque.




FIGURE 12-35 Tightening locknut on rack spring cap.

12. Apply Loctite 242 sealant or its equivalent to the first two or three threads on the locknut. Install the locknut on the rack spring cap. Use the proper tool to hold the rack spring cap, and tighten the locknut to the specified torque (Figure 12-35).
13. Install a new claw washer on the inner tie-rod end, and then install the inner tie-rod end on the rack. Hold the rack with an adjustable wrench, and use a torque wrench with the correct tool to tighten the inner tie-rod end to the specified torque (Figure 12-36). Clamp the inner tie-rod end in a soft-jaw vise and stake the claw washer with a brass bar and a hammer (Figure 12-37). Repeat this procedure on both inner tie-rod ends.




FIGURE 12-36 Tightening inner tie-rod end on the rack.




FIGURE 12-37 Staking claw washer on inner tie-rod end.




FIGURE 12-38 Rack vent holes must be open.




FIGURE 12-39 Minimum clearance between boot clamp ends.




FIGURE 12-40 Aligning marks on the outer tie-rod ends, jam nuts, and tie-rods.

- 14.** Check the vent hole in each end of the rack and be sure they are not clogged with grease or other material (Figure 12-38). These vent holes allow air flow from one boot to the other during a turn.
- 15.** Install the bellows boots, clamps, and clips. When the inner boot clamps are tightened, there must be a minimum of 2 mm (0.08 in.) between the ends of the clamps (Figure 12-39).
- 16.** Install the outer tie-rod ends and jam nuts. Align the marks placed on the tie-rod ends, jam nuts, and tie-rods during disassembly (Figure 12-40). Leave the jam nuts loose until the steering gear is installed and the front wheel toe is adjusted.
- 17.** Follow the steering gear installation procedure described earlier in this chapter to install the steering gear in the vehicle. Tighten all fasteners to the specified torque. (See Chapter 10 for power steering pump filling and bleeding procedure.) Check the front wheel toe and tighten the outer tie-rod end jam nuts to the specified torque. Tighten the outer bellows boot clamps. Road test the vehicle and check for proper steering operation and control.

Photo Sequence 22 shows a typical procedure for removing and replacing an inner tie-rod end on a power rack and pinion steering gear.

PHOTO SEQUENCE 22

TYPICAL PROCEDURE FOR REMOVING AND REPLACING INNER TIE-ROD END, POWER RACK, AND PINION STEERING GEAR



P22-1 Place an index mark on the outer tie-rod end, jam nut, and tie-rod.



P22-2 Loosen the jam nut and remove the outer tie-rod end and jam nut.



P22-3 Remove the inner and outer boot clamps.



P22-4 Remove the bellows boot from the tie-rod.



P22-5 Hold the rack with the proper size wrench and loosen the inner tie-rod end with the proper wrench.



P22-6 Remove the inner tie-rod from the rack.



P22-7 Be sure the shock damper ring is in place on the rack.



P22-8 Install the inner tie-rod on the rack, and tighten the tie-rod to the specified torque while holding the rack with the proper size wrench.



P22-9 Support the inner tie-rod on a vise, and stake both sides of the inner tie-rod joint with a hammer and punch.

PHOTO SEQUENCE 22 (CONTINUED)



P22-10 Use a feeler gauge to measure the clearance between the rack and the inner tie-rod joint housing stake.



P22-11 Install the bellows boot and new clamps.



P22-12 Install the jam nut and outer tie-rod end with the index marks aligned.

DIAGNOSIS OF POWER STEERING, STEERING COLUMN, AND SUSPENSION SYSTEMS

Some power steering problems may be caused by defects in the steering gear, pump, or column. For example, heavy steering effort may be caused by a defective power steering pump, damaged rack piston and ring, or misalignment of the steering column. Diagnostic information on common power steering problems is provided in Table 12-2. Refer to the vehicle manufacturer's service manual for more complete diagnosis.



SERVICE TIP:

A scored cylinder surface in the steering gear housing may cause temporary excessive steering effort after the car sits overnight.

TABLE 12-2 POWER STEERING SYSTEM, STEERING COLUMN, AND SUSPENSION SYSTEM DIAGNOSIS

Condition	Possible Cause	Correction
Wander: The vehicle wanders side to side on the roadway when it is driven straight ahead, while the steering wheel is held in a firm position. Evaluation should be conducted on a level road (little road crown).	<ol style="list-style-type: none"> 1. Loose/worn tie-rod ends or ball socket 2. Inner ball housing loose or worn 3. Gear assembly loose crossmember 4. Excessive yoke clearance 5. Loose suspension struts or ball joints 6. Column intermediate shaft connecting bolts loose 7. Column intermediate shaft joints loose or worn 8. Improper wheel alignment 9. Tire size and pressure 10. Vehicle unevenly loaded or overloaded 11. Steering gear mounting insulators and/or attachment bolts loose or damaged 12. Steering gear adjustments 13. Front end misaligned 14. Worn front end parts or wheel bearings 15. Unbalanced or badly worn steering gear control valve 	<ol style="list-style-type: none"> 1. Replace tie-rod end or tie-rod assembly. 2. Replace tie-rod assemblies. 3. Tighten the two mounting nuts to specification. 4. Adjust yoke clearance. 5. Tighten or replace as required. 6. Tighten bolts to specification at gear and column. 7. Replace intermediate shaft assembly. 8. Set alignment to specification. 9. Check tire sizes and adjust tire pressure. 10. Adjust load. 11. Replace insulators and/or attachment nuts and bolts. Tighten to specification. 12. Refer to steering gear section of <i>Shop Manual</i>. 13. Check and align to specifications. 14. Inspect and replace affected parts. 15. Inspect and replace affected parts.

(Continued)

TABLE 12-2 (continued)

Condition	Possible Cause	Correction
Pulls to one side: The vehicle tends to pull to one side when driven on a level surface.	<ol style="list-style-type: none"> 1. Improper tire pressure 2. Improper tire size or different type 3. Vehicle unevenly or excessively loaded 4. Improper wheel alignment 5. Damaged front suspension components 6. Damaged rear suspension components 7. Steering gear valve effort out of balance 	<ol style="list-style-type: none"> 1. Adjust tire pressure. 2. Replace as required. 3. Adjust load. 4. Adjust as required. 5. Refer to front suspension section of Shop Manual. 6. Refer to rear suspension section of Shop Manual. 7. Place transmission in Neutral while driving and turn engine off (coasting). <ul style="list-style-type: none"> — If vehicle does not pull, replace the steering gear valve assembly. Refer to steering gear section of Shop Manual. — If vehicle does drift: <ul style="list-style-type: none"> • Cross-switch front tire/wheel assemblies. • If vehicle pulls to opposite side, cross-switch tire/wheel assemblies that were on the rear to the same on the front. • If vehicle pull direction is not changed, check front suspension components and wheel alignment.
	8. Front and rear brakes operation	8. Adjust if necessary.
	9. Bent rear axle housing, or damaged or sagging springs in the front and/or rear suspension	9. Replace if necessary.
	10. Loose/worn shock absorber or suspension attaching fasteners in rear suspension	10. Tighten all attaching fasteners to specification.



CAUTION:

Always be sure the ignition switch is off when connecting or disconnecting the scan tool. Computer system and/or scan tool damage may occur if the ignition switch is on when connecting or disconnecting the scan tool from the data link connector (DLC).

DIAGNOSIS OF MAGNASTEER SYSTEMS

The most common customer complaints on Magnasteer systems are continually heavy or light steering effort. When diagnosing a Magnasteer system, the first step is to visually inspect the system. Be sure the power steering fluid level is correct, and check the power steering belt tension. Inspect the wiring harness connected to the actuator solenoid in the steering gear.

If the visual inspection does not locate any defects, connect a scan tool to the DLC near the steering column under the dash (Figure 12-41). Turn the ignition switch on and select the Electronic Brake and Traction Control Module (EBTCM) on the scan tool menu. If there is an electrical defect in the actuator solenoid, connecting wires, or EBTCM, Diagnostic Trouble Code (DTC) C1241 will be displayed on the scan tool. To locate the exact cause of this DTC, perform voltmeter tests on the actuator solenoid and connecting wires. A detailed diagnostic chart is included in the vehicle manufacturer's service manual.




FIGURE 12-41 Data link connector (DLC) on-board diagnostic II (OBD-II) system.

If the customer complains about continually heavy or light steering and there are no defects in the Magnasteer system, reprogramming of the system may be required.

To reprogram the system, follow these steps:

1. Connect the scan tool to the DLC.
2. Select Magnasteer and Recalibration on the scan tool.
3. Respond to the VIN query on the scan tool. If the displayed VIN is incorrect, enter the correct VIN.
4. When Factory Standard Calibration Will Be Used For This VIN appears on the scan tool, press Enter on the scan tool to install factory calibration.
5. When calibration is complete, disconnect the scan tool.



SERVICE TIP:

Some generic scan tools do not have the capability to reprogram computers.

DIAGNOSIS OF RACK-DRIVE ELECTRONIC POWER STEERING

When the ignition switch is turned on, in a vehicle with **rack-drive electronic power steering** electronic power steering (EPS) light in the instrument panel should be illuminated (Figure 12-42). This EPS light action proves the bulb and related circuit are functioning normally. When the engine starts, the EPS light is turned off by the EPS control unit if there are no electrical defects in the EPS system. The EPS light should remain off while the engine is running.

If an electrical defect occurs in the EPS system, the EPS control unit turns on the EPS light to alert the driver that a defect exists in the EPS system. Under this condition, the EPS control unit shuts down the EPS system, and electric assist is no longer available. Manual steering with increased steering effort is provided in this mode. When the EPS control unit senses an electrical defect in the EPS system, a diagnostic trouble code (DTC) is stored in the control unit memory. The EPS control unit memory is erased if battery voltage is disconnected from the control unit. The 7.5 ampere clock fuse may be disconnected for 10 seconds to disconnect battery voltage from the EPS control unit and erase the DTCs from the control unit memory.

If the EPS light is on with the engine running, shut the ignition switch off and disconnect the clock fuse for 10 seconds; then road test the car to determine if the EPS light comes back on. If the EPS light comes on again with the engine running, proceed with the diagnosis. Locate the two-wire EPS service check connector under the glove box. With the ignition switch off, connect a special jumper wire to the service check connector (Figure 12-43). This connects the two wires together in the service check connector. When the ignition switch is turned on, the EPS light begins to flash DTCs. Each DTC is indicated by a long light flash or flashes followed by a short flash or flashes. For example, DTC 11 is one long flash followed by a short flash, and DTC 12 is one long flash followed by two short flashes (Figure 12-44).



SERVICE TIP:

If the special jumper wire is left in the EPS service connector and the engine is started, the malfunction indicator light (MIL) for the engine computer system is illuminated.




FIGURE 12-42 Electronic power steering (EPS) warning light.




FIGURE 12-43 EPS system service check connector and special jumper wire.




FIGURE 12-44 DTC 11 is one long flash followed by a short flash, and DTC 12 is one long flash followed by two short flashes.



SERVICE TIP:

If DTC 33 is set in the EPS control unit memory, the EPS system remains functional, but the EPS light is illuminated.

If more than one DTC is stored in the EPS control unit memory, these DTCs are flashed in numerical order. The DTC sequence continues until the ignition switch is turned off. Be sure to remove the special jumper wire after the ignition switch is turned off.

All the possible DTCs in the EPS system are provided in Figure 12-45. A DTC indicates a defect in a certain area. For example, DTC 11 indicates high or low voltage from the torque sensor. The defect may be in the sensor itself, or the problem could be in the connecting wires from the sensor to the control unit. Tests usually have to be performed with a voltmeter or ohmmeter to locate the exact cause of the defect. Detailed diagnostic charts are provided in the car manufacturer's service manual.

Classroom Manual

Chapter 12,
page 279

CUSTOMER CARE: Diagnosing automotive problems is an extremely important part of a technician's job on today's high-tech vehicles. Always take time to diagnose a customer's vehicle accurately. Fast, inaccurate diagnosis of automotive problems leads to unnecessary, expensive repairs and unhappy customers, who may take their business to another shop. Accurate diagnosis may take more time, but in the long term it will improve customer relations and bring customers back to the shop.

Diagnostic trouble code (DTC)	EPS indicator light	Description/symptom	Diagnostic period			After detecting for system	Reset	
			Individual diagnosis	Individual diagnosis	Regular diagnosis		Individual diagnosis	Individual diagnosis
—	○	EPS indicator light does not come on when ignition is switched ON						17 – 27
—	○	EPS indicator light does not go off after engine is started				System OFF		17 – 29
3	○	A problem with the current sensor offset	○			^		17 – 36
4	○	A problem with the current sensor offset	○	○		^	○	
5	○	A problem with the current sensor fixed		○		^	○	
6	○	A problem with the current sensor fixed		○		^	○	
11	○	A problem the high voltage with or low voltage of the torque sensor (TRQ1 and TRQ2)		○		^	○	17 – 31
12	○	A problem with the voltage for torque sensor (TRQ3)		○		^	○	
13	○	A problem with the average of voltage on TRQ1 and TRQ2		○		^	○	
14	○	A problem with the 2.5-V reference voltage		○		^	○	
21	○	A problem with the circuit for the input motor voltage in the EPS control unit	○	○	○	^	○	17 – 36
22	○	A problem with the lower current			○	^	○	
23	○	A problem with the circuit for check function in the EPS control unit	○	○		^	○	
24	○	The fail-safe relay or power relay is stuck ON	○			^	○	
25	○	The lower FET is stuck ON	○			^	○	
26	○	The upper FET is stuck ON	○			^	○	
31	○	A problem with the voltage for IG1	○	○		^	○	—
33	○	A problem with the average of VSS1 and VSS2			○	^	○	17 – 38
34	○	A problem with the CPU in the EPS control unit	○	○	○	^	○	Replace EPS control unit

- Initial diagnosis: Performed right after the engine starts until the EPS indicator light goes off.
- Regular diagnosis: Continuously performed (under some conditions) after the EPS indicator goes off and engine is running.
- Individual part/system diagnosis: Diagnoses a specific part/system under its operating conditions.
- CPU: Central Processing Unit.

FIGURE 12-45 DTC list for EPS system.

DIAGNOSIS OF COLUMN-DRIVE ELECTRONIC POWER STEERING

When diagnosing a **column-drive EPS**, the first step is to verify the customer complaint. Road test the vehicle if necessary to be sure the complaint is identified. The next step is to perform a visual inspection of the EPS using the following steps:

1. Inspect all EPS electrical connections for corrosion or looseness including ground connections.
2. Inspect EPS wiring for damaged insulation.
3. Be sure the vehicle is equipped with the vehicle manufacturer's specified tire and wheel sizes.
4. Inspect the steering column and EPS components for collision damage.
5. Be sure the battery is fully charged and that the battery connections are clean and tight.
6. Check all the EPS fuses.
7. Inspect the vehicle for aftermarket accessories such as stereo equipment that could affect the EPS operation if they are improperly installed.
8. Search for service bulletins related to the EPS complaint.



SERVICE TIP:

When connecting certain scan tools to controller area network (CAN) or local area network (LAN) data link systems, a CAndi module must be connected in series between the scan tool and the DLC. Always refer to the vehicle manufacturer's recommended procedure.

On-Board Diagnostic II (OBD II) systems are a type of computer system mandated on cars and light trucks since 1996. OBD II systems have a number of mandated standardized features including several monitoring systems in the PCM.

Repair any problems discovered during the visual inspection. If the visual inspection did not locate any problems, perform a diagnostic system check using the following procedure:

1. Be sure the ignition switch is off, and connect a scan tool to the DLC under the left side of the dash.
2. Turn on the ignition switch, and select Vehicle DTC Information on the scan tool. If the scan tool displays No Comm. From Any Computer, repair the data link communication problem by referring to the appropriate diagnostic procedure in the vehicle manufacturer's service manual.
3. Be sure the engine cranks and starts properly.
4. Turn on the ignition switch with the engine stopped, and select List All DTCs on the scan tool.
5. Record all DTCs displayed on the scan tool. Check for DTCs from other computer systems that may affect the EPS system. For example, a DTC representing the VSS is displayed as a PCM DTC, but this sensor signal is transmitted on the data links to the PSCM and affects EPS operation.

Repair the causes of the DTCs displayed on the scan tool. Some typical EPS DTCs are:

1. C0460 steering position sensor
2. C0475 electric steering motor circuit
3. C0545 steering wheel torque input sensor
4. C0870 PSCM voltage range performance

In these **On-Board Diagnostic II (OBD II)** DTCs the first letter C indicates the DTC is related to a chassis problem. If the second digit in the DTC is a 0, the DTC is a universal Society of Automotive Engineers (SAE) code. When the second digit in the DTC is a 1, a vehicle manufacturer's code is indicated. The third digit in the DTC indicates the sub-system to which the DTC belongs, and the last two digits indicate the specific area where the fault exists. A complete list of DTCs is provided in the vehicle manufacturer's service manual. Some scan tools provide an explanation of each DTC indicating the area where the problem is located. A DTC indicates only the area in which a problem exists. Voltmeter and ohmmeter tests may be required to test the circuit and locate the exact cause of the problem. The vehicle manufacturer's service manual also provides a detailed diagnostic procedure for each DTC. Always follow these diagnostic procedures when diagnosing the cause of a DTC.

Scan Tool Data Display

The scan tool also displays the following EPS data which are very helpful when diagnosing EPS defects:

1. Battery voltage – The scan tool displays 6.5 V to 16.5 V as sensed at the power steering control module.
2. Calculated system temperature – The ambient temperature up to 275° F (135° C) as sensed by an internal temperature sensor in the PSCM.
3. Motor command – The amount of EPS assist motor current commanded by the PSCM.
4. Steering shaft torque – The amount of torque being applied to the steering column shaft. A positive value indicates a right turn, and a negative number indicates a left turn.
5. Steering position sensor voltage 1 – The amount of steering position sensor voltage from the sensor signal 1 circuit. The voltage range is 0 V to 5 V as the steering wheel is turned.
6. Steering position sensor voltage 2 – The amount of steering position sensor voltage from the sensor signal 2 circuit. The voltage range is 0 V to 5 V as the steering wheel is turned.
7. Steering tuning – The scan tool displays 1 or 2 depending on the vehicle. Steering tuning 1 is for 4-cylinder engines, and steering tuning 2 is for 6-cylinder engines. Steering tuning 3 is for the extended sedan.

8. Steering wheel position – The scan tool displays from 562° to –562° indicating the number of degrees the steering wheel has been turned for the center position. A positive number indicates a right turn, and a negative number indicates a left turn.
9. Torque sensor signal 1 – The scan tool displays 0.25 V to 4.75 V indicating the voltage from the steering shaft torque sensor 1 circuit.
10. Torque sensor signal 2 – The scan tool displays 0.25 V to 4.75 V indicating the voltage from the steering shaft torque sensor 2 circuit.
11. Vehicle speed – The actual vehicle speed from 0 to 158 mph (255 km/h).

Steering Position Sensor Calibration

If the PSCM or steering column is replaced, use the scan tool to calibrate the center position of the steering wheel position sensor as follows:

1. Be sure the ignition switch is off, and connect the scan tool to the DLC.
2. Turn on the ignition switch, but do not start the engine.
3. Turn the steering wheel from lock-to-lock and count the number of turns. From the fully left or fully right position, turn the steering wheel back toward the center position one-half the total number of turns.
4. Select Special Functions on the scan tool.
5. Select Steering Position Sensor Calibration on the scan tool and press the enter key. The scan tool screen indicates Calibration in Progress during the calibration procedure.
6. When the calibration process is completed, and the scan tool displays Calibration Completed, press the exit key.
7. Use the scan tool to clear any DTCs.
8. Turn off the ignition switch and disconnect the scan tool.

Torque Sensor Calibration

If the PSCM or steering column is replaced, a scan tool must be used to perform a center position calibration for the steering shaft torque sensor as described in the following steps:

1. Be sure the ignition switch is off, and connect the scan tool to the DLC.
2. Turn on the ignition switch, but do not start the engine.
3. Turn the steering wheel from lock-to-lock and count the number of turns. From the fully left or fully right position, turn the steering wheel back toward the center position one-half the total number of turns.
4. After the steering wheel is centered, remove your hands or any other objects from the steering wheel. Be sure the suspension is relaxed, and that no uneven force is applied to the steering system.
5. Select Special Functions on the scan tool.
6. Select Torque Sensor Calibration on the scan tool and press the enter key. The scan tool screen indicates Calibration in Progress during the calibration procedure.
7. When the calibration process is completed, and the scan tool displays Calibration Completed, press the exit key.
8. Use the scan tool to clear any DTCs.
9. Turn off the ignition switch and disconnect the scan tool.

If the PSCM and motor assembly is removed from the steering column, inspect the steering column assist mechanism input shaft for the rotor isolator bumper (Figure 12-46). If present, the isolator bumper should be removed from the input shaft, and this bumper must be installed in the rotor isolator in the PSCM and motor assembly. Remove any debris from the steering column assist mechanism housing, but do not remove the remaining grease on the steering column assist mechanism input shaft.



SERVICE TIP:

After the ignition switch is turned off, wait 25 seconds before performing any procedures that require disconnecting the vehicle battery. If this precaution is not observed, the PSCM memory may be erased. This precaution also applies to torque sensor calibration and steering tuning selection.



SERVICE TIP:

The combination steering wheel position sensor and steering shaft torque sensor are not serviced separately; the steering column and these two sensors are replaced as an assembly. The PSCM and motor can be replaced as an assembly separate from the steering column.




FIGURE 12-46 Removing and replacing the PSCM and motor assembly.

Steering Tuning Selection

If the PSCM is replaced, these steps must be followed to perform a steering tuning procedure:

1. Be sure the ignition switch is off, and connect the scan tool to the DLC.
2. Turn on the ignition switch, but do not start the engine.
3. Select Special Functions on the scan tool.
4. Select Steering Tuning Selection on the scan tool and press the enter key. The scan tool screen indicates Selection in Progress during the selection procedure.
5. When the selection process is completed, and the scan tool displays Selection Completed, press the exit key.
6. Use the scan tool to clear any DTCs.
7. Turn off the ignition switch and disconnect the scan tool.

ACTIVE STEERING SYSTEM PRELIMINARY DIAGNOSIS

The active steering system has a warning light and a service light in the instrument panel (Figure 12-47). When the active steering system is operating normally, the active steering warning light and service light go out after the engine starts. If an electronic defect occurs in the active steering system, the warning and service lights are illuminated. The service light indicates that a service message is available in the central information display screen in the instrument panel. When “service” is selected in the central information display screen, the following messages may be displayed:

1. Active steering! Exercise care when steering.
Active steering fault.
Steering behavior altered. Steering wheel might be at an angle. Possible to continue journey with caution. Exercise care when steering. Have the problem checked by the nearest BMW service.
2. Active steering inactive.
Active steering.
Active steering inactive.
Steering behavior altered. Steering wheel might be at an angle. Possible to continue journey with caution. Exercise care when steering.




FIGURE 12-47 Active Steering System light.

3. Servotronic failure!
Servotronic failure.
Possible to continue journey with caution.
Important: Power steering assistance is no longer automatically adapted to the vehicle's speed.
Have problem checked by the nearest BMW service.

Preliminary Inspection

If the active steering warning lights are illuminated indicating a defect in the system, the first step in the diagnostic procedure is to perform a visual inspection of all system components, wiring, and fiber-optic cables. During the preliminary inspection, check these items:

1. Check the power steering fluid level and condition.
2. Inspect all wiring harness and electrical connectors in the system for damage, corrosion, and frayed insulation.
3. Inspect all fiber-optic cables for sharp bends, heat damage, punctures, cuts, or looseness.
4. Check all the hydraulic lines and fittings for damage or leaks.
5. Inspect all system mounting bolts for looseness.

Fiber-Optic Cable Service

Many vehicles with active steering have fiber-optic cable networks. **Media oriented systems transport (MOST) networks** have green fiber-optic cables, and **intelligent safety and integration systems (ISIS) networks** have yellow fiber-optic cables. Some manufacturers provide orange fiber-optic cables for repair purposes. Fiber-optic cables should always be inspected for sharp bends, heat damage, punctures or cracks, and loose connectors. Repair or replace fiber-optic cables as necessary. To remove a fiber-optic cable from a connector, follow this procedure:

1. To remove the connector, use a small screwdriver in the connector openings (Figure 12-48), and expand the cover catches. Remove the cover.
2. To remove the fiber optic cable from the connector lift the lock (Figure 12-49) and carefully feed the fiber optic cable out of the connector.
3. To install the fiber-optic cable in the connector, push the cable all the way into the connector and be sure the lock secures the cable.



FIGURE 12-48 Removing cover on a fiber-optic connector.



FIGURE 12-49 Removing a fiber-optic cable from a connector.



FIGURE 12-50 Removing a fiber-optic connector from its mounting surface.

4. If it is necessary to remove the fiber optic cable from its mounting position press to release the lock in the bore (Figure 12-50) and remove the cable connector.

Active Steering Diagnosis System

A diagnosis system is supplied by the vehicle manufacturer (Figure 12-51). The diagnosis system is connected to the vehicle DLC, and this system is used for all coding, programming, and diagnosis of the active steering system and other systems. ECU and module replacement nearly always requires coding/programming of the replacement ECU or module. After the diagnosis system is connected to the DLC, to access the active steering system, select “Service functions,” “Suspension,” and “Active steering” on the diagnosis system menus. Always follow the vehicle manufacturer’s recommended service, diagnosis, or programming procedure when using the diagnosis system.

If an electronic defect occurs in the active steering system, the diagnosis system displays DTCs. As in other electronic systems, the DTCs represent defects in a certain area, and voltmeter or ohmmeter tests may have to be performed to locate the root cause of the




FIGURE 12-51 Diagnosis system.

problem. The technician must select the appropriate ECU to access the DTCs. For example, the **servotronic valve** and the **electronically controlled orifice (ECO) valve** are controlled by the **safety and gateway module (SGM)** on some models. Therefore, DTCs representing electronic faults in these valves are stored in the SGM, and the technician must access the SGM in the diagnosis system to obtain these DTCs. On other models, the servotronic valve and ECO valve are controlled by the **active steering ECU**, and DTCs representing defects in these components are stored in this ECU.

Certain service procedures and specific adjustments must be performed using the diagnosis system. For example, a steering angle sensor adjustment must be performed after any of the following procedures:

1. Adjustment procedures on the front steering or suspension.
2. Disconnecting the battery.
3. Any replacement of steering components.
4. Replacement of steering column sensors or switches.
5. Replacement of **dynamic stability control (DSC) ECU**, **active roll stabilization (ARS) ECU**, or active steering ECU.

When the active steering system is accessed in the diagnosis system, the steering angle sensor adjustment procedure is entered by selecting “Initial operation/adjustment for active front steering.” Follow the vehicle manufacturer’s recommended procedure in the diagnosis system to complete the steering angle sensor adjustment. Service and adjustment procedures may vary depending on the model and year of vehicle.

The need for a wheel alignment is indicated by any of the following conditions:

1. Inclination of the steering wheel from the straight ahead position with no faults stored in the active steering ECU memory.
2. Fault(s) stored in the active steering ECU memory and diagnosis system troubleshooting provides “Check wheel alignment” message.
3. Replacement of suspension and/or steering components that requires wheel alignment.

CASE STUDY

A customer complains about excessive steering effort on a 2008 Cadillac CTS. The technician road tested the car and found no evidence of hard steering. Further questioning of the customer revealed that the problem only occurred when the engine was first started in the morning after the car had been parked all night. The service writer informed the customer that the car would have to be parked overnight in the shop and then diagnosed the following morning. The customer complied with this request.

Prior to starting the engine the next morning, the technician connected a power steering pressure test gauge in series with the high-pressure hose. When the engine was started, the technician discovered the steering effort was very high, and the steering felt much like manual steering while the steering wheel was turned. However, the power steering pump pressure on the pressure gauge was higher than specified. Once the steering wheel was turned in one direction, the steering

effort quickly decreased to normal. Since the power steering pump pressure was higher than specified, the technician concluded the pump and drive belt must be in satisfactory condition. The technician also reasoned that other causes of excessive steering effort, such as binding in the steering column or flexible coupling, would be constant. Therefore, the technician decided that the problem must be in the steering gear.

After receiving the customer’s approval to remove and inspect the steering gear, the gear was removed and disassembled. The technician found the rack cylinder was severely ridged and scored in the center area, and the Teflon ring on the rack piston was badly worn. The customer was advised that the steering gear required replacement. A replacement steering gear was installed, and the system was flushed and refilled with power steering fluid. When the engine was started, the steering effort and the power steering pump pressure were normal.

TERMS TO KNOW

Active roll stabilization (ARS) ECU
Active steering ECU
Bellows boots
Bump steer
Claw washers
Column-drive EPS
Dynamic stability control (DSC) ECU
Electronically controlled orifice (ECO) valve
On-board diagnostic II (OBD II)
Rack-drive electronic power steering
Safety and gateway module (SGM)
Servotronic valve
Soft-jaw vise
Steering effort imbalance
Steering wheel free play

ASE-STYLE REVIEW QUESTIONS

1. While discussing steering wheel free play:
Technician A says excessive steering wheel free play may be caused by a worn outer tie-rod end.
Technician B says excessive steering wheel free play may be caused by loose steering gear mounting bushings.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
2. While discussing steering effort:
Technician A says a tight rack bearing adjustment may cause excessive steering effort.
Technician B says a loose inner tie-rod end may cause excessive steering effort.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. While discussing steering gear removal and replacement on air-bag-equipped vehicles:
Technician A says the steering column should be locked in the centered position to prevent air bag deployment.
Technician B says the rack should be centered in the housing prior to steering gear installation.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
4. While discussing power rack and pinion steering gear adjustment:
Technician A says the self-locking nut on the pinion shaft should be rotated to adjust the pinion shaft bearing preload.
Technician B says the rack spring cap should be rotated to obtain the specified turning torque on the pinion shaft.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
5. When servicing an active steering system, a steering angle sensor adjustment is required after all of these service procedures EXCEPT:
A. Replacement of the active steering ECU.
B. Replacement of a fiber-optic cable in the MOST network.
C. Replacement of the steering gear.
D. Adjustment of front wheel camber and caster.
6. All of these statements about diagnosing and servicing power rack and pinion steering gears are true EXCEPT:
A. The inner rack seal may be defective if oil leaks from the pinion end of the housing when the rack reaches the left inner stop.
B. A leaking rack piston seal causes increased steering effort in one direction.
C. Leaking Teflon rings on the rotary valve may increase steering effort in both directions.
D. If the pinion shaft is removed, the pinion seal and the input shaft seal must be replaced.
7. When diagnosing and servicing power rack and pinion steering gears:
A. The rack should not be held when the outer tie-rod ends are loosened on the rack.
B. In some steering gears, claw washers lock the tie-rods in position on the rack.
C. A straightedge must be used to check the rack for a bent condition.
D. Bent tie-rods may be straightened in a hydraulic press and then reinstalled.
8. When diagnosing and servicing power rack and pinion steering gears:
A. Teflon rings on the rack piston may be expanded by heating them with a propane torch.
B. A bent rack may cause excessive steering wheel free play.
C. A compressing tool may be used to compress the Teflon rings on the rotary valve prior to installation.
D. A scored cylinder surface in the steering housing may cause excessive steering wheel kickback.

9. When diagnosing electronic power steering (EPS) systems:
- A. The EPS system enters the diagnostic mode when the ignition switch is cycled three times in a 5-second interval.
 - B. If the EPS warning light is on with the engine shut off and the ignition switch on, there is a defect in the EPS system.
 - C. The EPS warning light flashes diagnostic trouble codes (DTCs) in numerical order.
 - D. The EPS control unit memory has the capability to store only one DTC.
10. When diagnosing electronic power steering (EPS) systems:
- A. The DTCs may be erased from the EPS control unit by disconnecting the stop light fuse for 10 seconds.
 - B. A DTC indicates the exact cause of an electrical defect in the EPS system.
 - C. If a DTC is stored in the EPS control unit memory, the EPS system is usually inoperative and manual steering is available.
 - D. In the EPS diagnostic mode if the EPS warning light provides two long flashes followed by two short flashes, code 2 is indicated.

ASE CHALLENGE QUESTIONS

1. While discussing power rack and pinion steering gears:
- Technician A* says inner rack seal leaks can cause power rack and pinion steering to turn easier in one direction than another.
- Technician B* says a hissing noise is normal when the steering is turned to the limit on either side.
- Who is correct?
- A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
2. Wandering or poor straight-ahead tracking may be caused by all of the following EXCEPT:
- A. Worn or loose rack mounting bushings.
 - B. Rack piston seal leaks.
 - C. Steering gear off-center.
 - D. Loose or worn tie-rod ends.
3. A customer says his front-wheel-drive car with power rack and pinion steering is hard to steer for several minutes the first time the car is driven during the day.
- Technician A* says the cause of the problem could be a plugged spool valve spring.
- Technician B* says the cause of the problem could be a scored steering gear cylinder.
- Who is correct?
- A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
4. A front-wheel-drive car requires very heavy steering effort in the parking lot but seems not too bad on the highway. Tire pressure is fine. After checking the fluid and finding the level is OK, you should:
- A. Check the engine idle speed.
 - B. Look for steering system leaks.
 - C. Check the tie-rod ends.
 - D. Inspect the rack for damage.
5. *Technician A* says an oil leak at one rack seal may result in oil leaking from both boots.
- Technician B* says the inner rack seal is defective if oil leaks from the pinion end of the housing when the rack reaches the left internal stop.
- Who is correct?
- A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B

Name _____ Date _____

INSPECT MANUAL OR POWER RACK AND PINION STEERING GEAR AND TIE-RODS

Upon completion of this job sheet, you should be able to inspect manual or power rack and pinion steering gears and tie-rods.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-18: Inspect, replace, and adjust tie-rod ends (sockets), tie-rod sleeves, and clamps.

Tools and Materials

Tape measure

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Make of steering gear _____

Procedure

Task Completed _____

1. With the front wheels straight ahead and the engine stopped, rock the steering wheel gently back and forth with light finger pressure, and measure the maximum steering wheel free play with a tape measure.

Specified steering wheel free play _____

Actual steering wheel free play _____

State the necessary repairs to correct steering wheel free play.

2. With the vehicle sitting on the shop floor and the front wheels straight ahead, have an assistant turn the steering wheel about 1/4 turn in both directions. Watch for looseness in the steering shaft and the flexible coupling or universal joints.

Looseness in U-joints or flexible coupling: ☐ Satisfactory ☐ Unsatisfactory

Looseness in steering shaft: ☐ Satisfactory ☐ Unsatisfactory

State the necessary repairs and explain the reasons for your diagnosis.

3. While an assistant turns the steering wheel about 1/2 turn in both directions, watch for movement of the steering gear housing in the mounting bushings.

Looseness in steering gear mounting bushings: ☐ Satisfactory ☐ Unsatisfactory

State the necessary repairs and explain the reasons for your diagnosis.

4. Grasp the pinion shaft extending from the steering gear and attempt to move it vertically. If there is steering shaft vertical movement, a pinion bearing preload adjustment may be required. When the steering gear does not have a pinion bearing preload adjustment, replace the necessary steering gear components.

Excessive pinion shaft vertical endplay: ☐ Satisfactory ☐ Unsatisfactory

State the necessary repairs and explain the reasons for your diagnosis.

5. Road test the vehicle and check for excessive steering effort. A bent steering rack, tight rack bearing adjustment, or damaged front drive axle joints in front-wheel-drive cars may cause excessive steering effort.

Steering effort: ☐ Satisfactory ☐ Excessive

State the necessary repairs and explain the reasons for your diagnosis.

6. Visually inspect the bellows boots for cracks, splits, leaks, and proper clamp installation. Replace any boot that indicates any of these conditions.

Condition of tie-rod bellows boots and clamps:

Left side boot: ☐ Satisfactory ☐ Unsatisfactory

Right side boot: ☐ Satisfactory ☐ Unsatisfactory

State the necessary repairs and explain the reasons for your diagnosis.


7. Loosen the inner bellows boot clamps and move each boot toward the outer tie-rod end until the inner tie-rod end is visible. Push outward and inward on each front tire, and watch for movement in the inner tie-rod end. An alternate method of checking the inner tie-rod ends is to squeeze the bellows boots and grasp the inner tie-rod end socket. Movement in the inner tie-rod end is then felt as the front wheel is moved inward and outward. Hard plastic bellows boots may be found on some applications. With this type of bellows boot, remove the ignition key from the switch to lock the steering column, and push inward and outward on the front tire while observing any lateral movement in the tie-rod.

Condition of inner tie-rod ends:

Left side inner tie-rod end: ☐ Satisfactory ☐ Unsatisfactory

Right side inner tie-rod end: ☐ Satisfactory ☐ Unsatisfactory

State the necessary repairs and explain the reasons for your diagnosis.

 **WARNING:** Bent steering components must be replaced. Never straighten steering components because this action may weaken the metal and result in sudden component failure, serious personal injury, and vehicle damage.

8. Grasp each outer tie-rod end and check for vertical movement. While an assistant turns the steering wheel 1/4 turn in each direction, watch for looseness in the outer tie-rod ends. Check the outer tie-rod end seals for cracks and proper installation of the nuts and cotter pins. Cracked seals must be replaced. Inspect the tie-rods for a bent condition.

tie-rod and outer tie-rod end condition:

Left side tie-rod and outer tie-rod end condition: ☐ Satisfactory ☐ Unsatisfactory

Right side tie-rod and outer tie-rod end condition: ☐ Satisfactory ☐ Unsatisfactory

List the necessary repairs and explain the reasons for your diagnosis.

Instructor's Response _____

Name _____ Date _____

REMOVE AND REPLACE MANUAL OR POWER RACK AND PINION STEERING GEAR

Upon completion of this job sheet, you should be able to remove and replace manual or power rack and pinion steering gears.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task List B-8: Remove and replace rack and pinion steering gear; inspect mounting bushings and brackets.

Tools and Materials

Floor jack
Safety stands
Outer tie-rod end puller
Tape measure
Torque wrench
Power steering fluid

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Place the front wheels in the straight-ahead position and remove the ignition key from the ignition switch to lock the steering wheel. Place the driver's seat belt through the steering wheel to prevent wheel rotation if the ignition switch is turned on. This action maintains the clock spring electrical connector or spiral cable in the centered position on air-bag-equipped vehicles.

Are the front wheels straight ahead and steering wheel locked? ☐ Yes ☐ No

Instructor check _____

2. Lift the front end with a floor jack and place safety stands under the vehicle chassis. Lower the vehicle onto the safety stands. Remove the left and right fender apron seals.

Is the chassis properly supported on safety stands? ☐ Yes ☐ No

Are the fender apron seals removed? ☐ Yes ☐ No

Instructor check _____

3. Place punch marks on the lower universal joint and the steering gear pinion shaft so they may be reassembled in the same position.

Are the pinion shaft and U-joint punchmarked? ☐ Yes ☐ No

Instructor check _____

Task Completed

4. Loosen the upper universal joint bolt, remove the lower universal joint bolt, and disconnect this joint.

Is the U-joint disconnected from pinion shaft? ☐ Yes ☐ No

Instructor check _____

5. Remove the cotter pins from the outer tie-rod ends. Loosen, but do not remove, the tie-rod end nuts.

Are the outer tie-rod end nuts loosened? ☐ Yes ☐ No

Instructor check _____

6. Use a tie-rod end puller to loosen the outer tie-rod ends in the steering arms. Remove the tie-rod end nuts and remove the tie-rod ends from the arms.

Are the outer tie-rod ends removed from the steering arms? ☐ Yes ☐ No

Instructor check _____

7. Use the proper wrenches to disconnect the high-pressure hose and the return hose from the steering gear. (This step is not required on a manual steering gear.)

Are the high-pressure and return hoses disconnected from the steering gear?
☐ Yes ☐ No

Instructor check _____

8. Remove the four stabilizer bar mounting bolts.

Are the stabilizer mounting bolts removed? ☐ Yes ☐ No

Instructor check _____

9. Remove the steering gear mounting bolts.

Are the steering gear mounting bolts removed? ☐ Yes ☐ No

Instructor check _____

- ☐ 10. Remove the steering gear assembly from the right side of the car.

11. Position the right and left tie-rods the specified distance from the steering gear housing. Measure this distance with a tape measure.

Are the right and left tie-rods positioned at equal distances from the steering gear housing? ☐ Yes ☐ No

Instructor check _____

- ☐ 12. Install the steering gear through the right fender apron.

13. Install the pinion shaft in the universal joint with the punch marks aligned. Tighten the upper and lower universal joint bolts to the specified torque.

Are the punch marks on the pinion shaft and U-joint properly aligned?
☐ Yes ☐ No

Instructor check _____

Specified U-joint bolt torque _____

Actual U-joint bolt torque _____

Instructor check _____

Task Completed

14. Install the steering gear mounting bolts and tighten these bolts to the specified torque.

Specified steering gear mounting bolt torque _____

Actual steering gear mounting bolt torque _____

15. Install the stabilizer bar mounting bolts and torque these bolts to specifications.

Specified stabilizer mounting bolt torque _____

Actual stabilizer mounting bolt torque _____

16. Install and tighten the high-pressure and return hoses to the specified torque.

(This step is not required on a manual rack and pinion steering gear.)

Specified high-pressure and return hose fitting torque _____

Actual high-pressure and return hose fitting torque _____

17. Install the outer tie-rod ends in the steering knuckles, and tighten the nuts to the specified torque. Install the cotter pins in the nuts.

Specified outer tie-rod end nut torque _____

Actual outer tie-rod end nut torque _____

Are the cotter pins properly installed? ☐ Yes ☐ No

18. Tighten the outer tie-rod end jam nuts to the specified torque; then tighten the outer bellows boot clamps.

Specified outer tie-rod end jam nut torque _____

Actual outer tie-rod end jam nut torque _____

Are the bellows boot clamps properly installed and tightened? ☐ Yes ☐ No

Instructor check _____

19. Install the left and right fender apron seals; then lower the vehicle with a floor jack.

☐

20. Fill the power steering pump reservoir with the vehicle manufacturer's recommended power steering fluid, and bleed air from the power steering system. (This step is not required on a manual rack and pinion steering gear.)

Is the power steering pump reservoir filled to the specified level with the proper power steering fluid? ☐ Yes ☐ No

Is the air bled from the power steering system? ☐ Yes ☐ No

21. Perform a front wheel toe measurement, and adjust the toe as required.

Toe satisfactory ☐ Yes ☐ No

Toe adjustment performed ☐ Yes ☐ No

Instructor check _____



CAUTION:

Do not loosen the tie-rod end nuts to align the cotter pin holes. This action causes improper torquing of these nuts.

22. Road test the vehicle and check for proper steering gear operation and steering control.

Steering operation: ☐ Satisfactory ☐ Unsatisfactory

If the steering operation is unsatisfactory, state the necessary repairs and explain the reason for your diagnosis.

Instructor's Response _____

Name _____ Date _____

DIAGNOSE POWER RACK AND PINION STEERING GEAR OIL LEAKAGE PROBLEMS

Upon completion of this job sheet, you should be able to diagnose power rack and pinion steering gear oil leakage problems.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-5: Diagnose power steering gear (rack and pinion) binding uneven turning effort, looseness, hard steering, and noise concerns; determine necessary action.

Tools and Materials


Power steering fluid

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed _____

 **WARNING:** If the engine has been running for a length of time, power steering gears, pumps, lines, and fluid may be very hot. Wear eye protection and protective gloves when servicing these components.

1. Be sure the power steering reservoir is filled to the specified level with the proper power steering fluid. ☐
2. Be sure the power steering fluid is at normal operating temperature. If necessary, rotate the steering wheel several times from lock-to-lock to bring the fluid to normal operating temperature.

Is the power steering reservoir filled to the specified level? ☐ Yes ☐ No

Is the power steering fluid at normal temperature? ☐ Yes ☐ No

Instructor check _____

3. Inspect the cylinder end of the steering gear for oil leaks.

Oil leaks at cylinder end of the power steering gear:

☐ Satisfactory ☐ Unsatisfactory

Task Completed



SERVICE TIP:

An oil leak at one rack seal may result in oil leaks from both boots because the oil may travel through the breather tube between the boots.

If there are oil leaks in this area, state the necessary repairs and explain the reasons for your diagnosis.

4. Inspect the steering gear for oil leaks at the pinion end of the housing with the engine running and the steering wheel turned so the rack is against the left internal stop.

Oil leaks at the pinion end of the steering gear with the rack against the left inner stop:

☐ Satisfactory ☐ Unsatisfactory

If there are oil leaks in this area, state the necessary repairs and explain the reasons for your diagnosis.

5. Inspect the pinion end of the power steering gear housing for oil leaks with the steering wheel turned in either direction.

Oil leak at the pinion end of the housing with the steering wheel turned in either direction: ☐ Satisfactory ☐ Unsatisfactory

If there are oil leaks in the area, state the necessary repairs and explain the reasons for your diagnosis.

6. Inspect the pinion coupling area for oil leaks.

Oil leaks in the pinion coupling area: ☐ Satisfactory ☐ Unsatisfactory

If there are oil leaks in the area, state the necessary repairs and explain the reasons for your diagnosis.

7. Inspect all the lines and fittings on the steering gear for oil leaks as an assistant turns the wheels with the engine running.

Oil leaks at steering gear fittings: ☐ Satisfactory ☐ Unsatisfactory

Oil leaks in steering gear hoses and lines: ☐ Satisfactory ☐ Unsatisfactory

If there are oil leaks in the power steering fittings, lines, or hoses, state the necessary repairs and explain the reasons for your diagnosis.

8. With the engine running, turn the steering wheel fully in each direction and check the steering effort.

Steering effort in both directions: ☐ Normal ☐ Excessive

If the steering effort is not equal in both directions, state the direction in which steering effort is highest: ☐ Right ☐ Left

If the steering effort is excessive or unequal, state the necessary repairs and explain the reason for your diagnosis. _____

Instructor's Response _____

Chapter 13

ELECTRONIC FOUR-WHEEL STEERING DIAGNOSIS AND SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Perform a preliminary inspection on a four-wheel steering (4WS) system.
- Perform a trouble code diagnosis on a 4WS system with the ignition switch on.
- Perform a trouble code diagnosis on a 4WS system with the engine running.
- Remove and replace the rear steering actuator.
- Remove and replace the tie-rod ends on the rear steering actuator.
- Remove and replace tie-rods and boots on the rear steering actuator.
- Remove and replace the rear main steering angle sensor.
- Remove and replace the rear sub steering angle sensor.
- Diagnose four-wheel active steering systems (4WAS).



BASIC TOOLS

Basic technician's tool set

Service manual

Jumper wire

Floor jack

Safety stands

Wax marker

Silicone grease

Chassis lubricant

Cotter pins

Length of stiff wire

Diagnosis, service, and adjustments on 4WS systems must be performed precisely as explained in the vehicle manufacturer's service manual. On some systems inaccurate sensor adjustments may cause improper rear wheel steering operation, and this may result in reduced steering control. Always follow the diagnostic, service, and adjustment procedures carefully and accurately!

PRELIMINARY INSPECTION

Prior to any four-wheel steering diagnosis, the following concerns should be considered:

1. Have any suspension modifications been made that would affect steering?
2. Are the tire sizes the same as specified by the vehicle manufacturer?
3. Are the tires inflated to the pressure specified by the vehicle manufacturer?
4. Is the power steering belt adjusted to the vehicle manufacturer's specified tension?
5. Is the power steering pump reservoir filled to the proper level with the type of fluid specified by the vehicle manufacturer?
6. Is the engine idling at the speed specified by the vehicle manufacturer? Is the idle speed steady?
7. Is the steering wheel original equipment?
8. Is the battery fully charged?
9. Are all electrical connections clean and tight?
10. Is there any damaged electrical wiring in the system?
11. Are the rear wheel steering fuses in satisfactory condition?
12. Are there any damaged or worn rear steering gear or rear axle components?
13. Is the Service 4 Wheel Steer indicator illuminated in the instrument panel cluster?

Photo Sequence 23 illustrates a preliminary four-wheel steering inspection.

PRELIMINARY INSPECTION, FOUR-WHEEL STEERING DIAGNOSIS



P23-1 Inspect the front and rear suspension and steering for modifications and damage that could affect steering.



P23-2 Check the tire sizes to be sure they are the size specified by the vehicle manufacturer.




P23-3 Inflate the tires to the specified pressure.




P23-4 Check the power steering belt tension.



P23-5 Check the fluid level in the power steering pump reservoir.



P23-6 Be sure the engine idle speed is correct.



P23-7 Be sure the steering wheel is original equipment.



P23-8 Be sure the battery is fully charged.



P23-9 Inspect all electrical connections and harness in the four-wheel steering system to be sure they are in satisfactory condition.

PHOTO SEQUENCE 23 (CONTINUED)

PRELIMINARY INSPECTION, FOUR-WHEEL STEERING DIAGNOSIS



P23-10 Check the rear wheel steering system fuses.



P23-11 Check the four-wheel steering warning light in the instrument panel for proper operation.

A fail-safe mode may be called a backup mode.

The Society of Automotive Engineers (SAE) J1930 terminology is an attempt to standardize electronics terminology in the automotive industry.

In the SAE J1930 terminology, the term malfunction indicator light (MIL) replaces other terms for computer system indicator lights.

QUADRASTEER DIAGNOSIS

Fast, accurate QuadraSteer diagnosis is very important when correcting steering complaints. If the preliminary inspection does not indicate any problems, the next step in QuadraSteer diagnosis is to perform a diagnostic system check using these steps:

1. With the ignition switch off, connect a scan tool to the DLC under the dash.
2. Turn on the ignition switch, and select Rear Wheel Steering Control Module on the scan tool. If the scan tool does not communicate with this module, check the scan tool electrical connection and the data links. Be sure the scan tool communicates with all the other modules on the vehicle.
3. Access the Class 2 Power Mode on the scan tool, and rotate the ignition switch through all positions while observing the scan tool. The engine may start with the ignition switch in the Start position. The ignition switch position displayed on the scan tool should match the actual ignition switch position.
4. Select the Display DTCs function on the scan tool and then select Rear Wheel Steering Control Module to display the DTCs related to the 4WS system. Select all the other modules on the vehicle, and display any DTCs stored in these modules. Record all DTCs.
5. Are there any DTCs beginning with a U? These DTCs relate to data link problems and must be repaired before proceeding with 4WS diagnosis.
6. Does the scan tool display DTC B1000? This DTC indicates an internal defect in the body control module (BCM), and causes the BCM to refuse all additional inputs. The QuadraSteer system depends on some inputs from the BCM. Therefore, 4WS operation is affected by this BCM problem.

Rear Wheel Steering Data Display

Select Rear Wheel Steering and Data Display on the scan tool. Observe the data displayed on the scan tool and illustrated in Figures 13-1 and 13-2. Compare the displayed data to the vehicle manufacturer's specified data. Repair the cause of any incorrect data.

Compare the incorrect data to the DTCs recorded previously. If any DTCs and incorrect data are from the same component, repair this component or the related circuit.

Rear Wheel Steering DTC Interpretation

The possible 4WS system DTCs and causes are the following:

1. B3593 – The mode select switch 5 V reference circuit is open, shorted to ground, or shorted to voltage.
2. C0000 – The vehicle speed sensor, related circuit, or Class 2 data links are defective.

**Classroom
Manual**

Chapter 13,
page 305

Operating conditions: Ignition ON/Engine ON

Scan tool parameter	Data List	Units displayed	Typical data value
2 wheel steer mode lamp	Output	On/Off	Varies
4 wheel steer mode lamp	Output	On/Off	Varies
4WS-Tow mode lamp	Output	On/Off	Varies
8-digit GM part number	ID information	Numerical	Varies
Actual rear wheel steering angle	Data display	Degrees	0° to 12°
Base model part number	ID information	Numerical	Varies
Battery voltage	Data display	Voltage	9.0-16.0 volts
Calibration part number	ID information	Numerical	Varies
Calibration S/W suffix	ID information	Numerical	Varies
Digital SWPS phase A	Data display	High/Low	Varies
Digital SWPS phase B	Data display	High/Low	Varies
Hall sensor reference	Data display	Voltage	12 volts
Ignition 3	Data display	Voltage	9.0-16.0 volts

FIGURE 13-1 Rear wheel steering data.

Operating conditions: Ignition ON/Engine ON

Scan tool parameter	Data List	Units displayed	Typical data value
Ign. cycles since last fault	Data display	Counts	Counts
Marker pulse	Data display	High/Low	1
Motor current	Data display	Amps	20-50A typical 0 to 85A max.
Motor relay commanded state	Data display	On/Off	Varies
Motor relay feedback state	Data display	On/Off	Varies
Rear steer mode actual	Data display	2WS,4WS,4WS tow	Varies
Rear steer mode requested	Data display	2WS,4WS,4WS tow	Varies
Rear steer position 1	Data display	Voltage	.25 to 4.75 volts
Rear steer position 2	Data display	Voltage	.25 to 4.75 volts
Rear steer select switch	Data display	On/Off	Off
Rear wheel centering 1	Data display	Voltage	2.5 volts
Rear wheel centering 2	Data display	Voltage	2.5 volts
Requested rear steer angle	Data display	Degrees	0° to 12°
Sensor supply voltage	Data display	Voltage	4.97 volts
Steering wheel angle	Data display	Degrees	-609° to +609°
Steering wheel angle (TBC)	Data display	Degrees	.25 to 4.75 volts
Steering wheel sensor signal	BCM data	Voltage	Varies
Vehicle speed	Data display	km/h (mph)	

FIGURE 13-2 Rear wheel steering data (continued).

3. C0253 – The steering wheel position sensor phase A and phase B voltage signals may be out of the valid alignment range, or the steering wheel position marker pulse points may not be occurring at the proper time in relation to steering wheel rotation (Figure 13-3). The steering wheel position sensor analog voltage may be out of the valid alignment range (Figure 13-4), the rear wheel position sensor analog voltage may be out of the valid alignment range, or a valid Learn Wheel Alignment Procedure may not have been performed.
4. C0455 – The steering wheel position sensor phase A, phase B, or marker pulse signals are defective or the related circuits are open, or shorted to ground or voltage. This DTC may also be caused by a fault that sets a BCM DTC C0472 or C0473.
5. C0472 or C0473 – The BCM detects the analog steering wheel position sensor circuit is open or shorted to ground or voltage.
6. C0522 – The rear wheel position sensor position 1 or position 2 signals are defective, the 5 V reference circuit to this sensor is open or shorted, or the sensor ground circuit is open.
7. C0527 – The Hall Effect switches in the rear steering gear actuator motor are defective, the voltage supply to these switches is open, or the ground circuit is open.
8. C0532 – The rear wheel position sensor and the actual rear wheel position varies by more than 1.4°.
9. C0533 – The shorting relay in the rear steering actuator motor is stuck open or closed.
10. C0538 – The rear steering motor electrical circuit is open, or shorted to ground or voltage.
11. C0543 – The difference between the commanded rear wheel steering position and the actual rear wheel steering position exceeds 3°.
12. C0550 – When the ignition switch is turned on, the rear wheel steering control module detects an internal malfunction.



SERVICE TIP:

If any of the sensors or the control module is replaced in a QuadraSteer system, a Learn Rear Wheel Alignment Procedure must be performed with a scan tool.




FIGURE 13-3 Steering wheel position sensor phase A, phase B, and marker pulse signals.




FIGURE 13-4 Steering wheel position sensor analog voltage.



SERVICE TIP:

If step 6 is not completed properly, a false steering wheel position sensor DTC may be set in the rear wheel steering control module memory.

The vehicle manufacturer's service manual contains detailed diagnostic procedures for each rear wheel steering DTC. These procedures must be followed when diagnosing the cause of any DTC. Table 13-1 provides a general QuadraSteer diagnostic procedure.

Rear Wheel Steering Learn Rear Wheel Alignment Procedure

Follow these steps to complete a Learn Rear Wheel Alignment procedure:

1. Turn on the ignition switch and start the engine.
2. Connect the scan tool to the DLC under the dash.
3. Center the steering wheel.
4. Lift the rear of the vehicle so the rear tires are a few inches off the shop floor. Be sure the chassis is securely supported on safety stands, and the rear wheels are centered.
5. Select the Learn Alignment menu on the scan tool.

TABLE 13-1 QUADRASTEER DIAGNOSIS

Problem	Symptoms	Possible Causes
Inoperative rear wheel steer system	Rear wheels do not steer when front wheels are turned	Open fuse(s) related to 4WS system Defect in data links Defective BCM Defective input sensor(s) Defective rear wheel steering gear
Repeated blowing of fuse(s) related to 4WS system	Inoperative rear wheel steering system	Grounded or shorted circuit in related fuse circuit
Improper 4WS operation	Steering wheel position sensor phase A, phase B, marker pulse, and steering wheel position analog voltage signals are out of alignment with steering wheel rotation; DTC C0253 displayed	Defective steering wheel position sensor Learn Rear Wheel Alignment procedure not performed after component replacement

Classroom Manual

Chapter 13,
page 307

6. Follow the directions on the scan tool. When directed, the front wheels must be turned 90° to the left and 90° to the right, and then returned to the center position.
7. Press the Continue button on the scan tool until the alignment procedure is completed.
8. Use the scan tool to erase the rear wheel steering DTCs.
9. Shut off the ignition, disconnect the scan tool, and lower the rear wheels onto the shop floor.

ELECTRONICALLY CONTROLLED FOUR-WHEEL STEERING DIAGNOSIS

If the four-wheel steering (4WS) control unit senses a failure in the system, the control unit switches to a **fail-safe mode**. In this mode, the control unit stores a trouble code or codes and illuminates the 4WS indicator light to inform the driver that a problem exists in the system. When this mode is entered, the 4WS control unit shuts off voltage to the rear steering unit and the rear wheels remain in the straight-ahead position.

Damper Control

When the 4WS control unit enters the fail-safe mode, a quick return of the rear wheels to the straight-ahead position would adversely affect steering under certain steering wheel and rear wheel positions. To prevent this action, the 4WS control unit energizes the damper relay when it enters the fail-safe mode. The rear steering actuator motor is spun by the steering shaft movement as this shaft is moved to the centered position by centering spring force. This action causes the motor armature to act as a voltage generator. The voltage generated by the armature is fed back through the damper relay to the motor armature. Under this condition, the motor rotation is slowed and the return spring slowly moves the rear steering shaft to the straight-ahead position. Without the action of the damper relay, the return spring would move the rear steering shaft quickly to the straight-ahead position.

Trouble Code Diagnosis

Road Test

CUSTOMER CARE: While discussing customers' automotive problems, always remain polite and never make statements that make customers feel uninformed about their vehicles.

The 4WS control unit stores a fault code and illuminates the 4WS indicator light if a defect occurs in the system, even if the defect is temporary. Always ask the customer about the conditions that caused the 4WS indicator light to come on, and duplicate this condition during a road test. If the 4WS light is not illuminated during the road test, the system is satisfactory electronically and does not require further electronic diagnosis. The troubleshooting procedures in the vehicle manufacturer's service manual assume that the problem is present at the time of diagnosis.

Trouble Code Display with Ignition Switch On

Always follow the exact 4WS service and diagnostic procedures in the vehicle manufacturer's service manual. These procedures vary depending on the make and year of the vehicle.

The following are typical procedures for a Honda Prelude. These procedures should be avoided until after the diagnosis is complete because any of these procedures will erase trouble codes:

1. Disconnect the battery terminals.
2. Disconnect the 4WS control unit connector.
3. Remove the number 43 clock-radio 10-A fuse from the underhood fuse/relay box.

Classroom Manual

Chapter 13,
page 302



CAUTION:

When diagnosing a computer system, never connect or ground any terminals unless instructed to do so in the vehicle manufacturer's service manual. This action may damage electronic components.



CAUTION:

When diagnosing a computer system, never disconnect or connect any computer system component with the ignition switch on unless instructed to do so in the vehicle manufacturer's service manual. This action may damage the computer or system components.



CAUTION:

When performing electronic diagnosis on a vehicle equipped with an air bag, most vehicle manufacturers recommend turning the ignition switch off, disconnecting the negative battery cable, and waiting one minute before proceeding with electronic component diagnosis or service.



CAUTION:

When performing electronic diagnosis on a vehicle equipped with an air bag, follow all the service precautions recommended in the vehicle manufacturer's service manual. If these precautions are not followed, electronic components may be damaged.

When the two terminals on the **service check connector** are connected together, the 4WS computer supplies flash codes on the 4WS indicator light.




FIGURE 13-5 Dual-terminal service check connector positioned behind the center console.

Follow these steps to obtain the trouble codes:

1. Remove the dual-terminal **service check connector** located behind the center console, and connect the two terminals in this connector with a jumper wire (Figure 13-5).
2. Turn on the ignition switch, but do not start the engine.
3. Observe the 4WS indicator light to read the trouble codes. Three longer flashes followed by a brief pause and one quicker flash indicates code 31. The codes are given in numerical order.
4. Record the fault codes.

Trouble Code Display with Engine Running

The 4WS control unit actually contains two processing units that are referred to as the main and sub processing units. Each processing unit can store a maximum of 10 trouble codes. If the trouble code diagnosis is performed with the engine running, the code display indicates whether the codes are stored in the main or sub processor.

When the service connector terminals are connected with a jumper wire and the engine is started, the 4WS indicator light follows this sequence if there are trouble codes in the main and sub processors:

1. Blinks quickly once when the ignition switch is turned on
2. Pauses for 3 seconds
3. Displays codes stored in the main processor
4. Pauses for 1.6 seconds
5. Blinks quickly for 3 seconds to indicate a separation between the main and sub processor codes
6. Pauses for 1.6 seconds
7. Displays codes stored in the sub processor
8. Pauses for 3 seconds, and then repeats the cycle (Figure 13-6)



CAUTION:

Do not start the engine with the rear steering center lock pin in place. This action may damage the lock pin and rear steering actuator.



SERVICE TIP:

Do not attempt to disassemble the rear steering actuator other than tie-rods, tie-rod ends, and sensors. This actuator is serviced as an assembly. Because individual parts for the actuator are not available, disassembly is a waste of time.



CAUTION:

Use the tie-rod end removal tool carefully to avoid damage to the tie-rod boot.



SPECIAL TOOLS

Tie-rod end removal tool

The **rear steering center lock pin** locks the rear steering in the centered position for test and service purposes.




FIGURE 13-8 Removing a tie-rod end with a special tool.

3. Install a 12-millimeter (mm) nut on each tie-rod end until the nuts are flush with the tie-rod stud.
4. Install the special tool on the tie-rod end, and with the tool arms parallel, tighten the screw on the tool to loosen the tie-rod end (Figure 13-8). Repeat the procedure on both tie-rod ends.
5. Remove the nuts from the tie-rods and remove the tie-rods from the steering arms.
6. Remove the rear steering actuator cover (Figure 13-9).
7. Remove the cap bolt and washer and install the **rear steering center lock pin** (Figure 13-10).
8. Remove the ground cable connector and all wiring harness connectors on the rear steering actuator (Figure 13-11).
9. Remove the four mounting bolts and bracket, and remove the rear steering actuator (Figure 13-12).




FIGURE 13-9 Removing the rear steering actuator cover.




FIGURE 13-10 Removing the cap bolt and washer, and installing the rear steering center lock pin.




FIGURE 13-11 Removing the ground cable connector and all wiring harness connectors on the rear steering actuator.




FIGURE 13-12 Removing the four mounting bolts, bracket, and rear steering actuator.



SPECIAL TOOLS

Rack holding tool



SERVICE TIP:

Hold the special holding tool firmly while loosening the tie-rod to avoid applying rotational force to the shaft screw in the actuator.

Tie-Rod and Tie-Rod End Removal

Follow these steps for tie-rod and tie-rod end removal:

1. Mark the relative position of the tie-rod end, locknut, and tie-rod with a wax marker.
2. Hold the tie-rod end with a wrench and loosen the locknut (Figure 13-13).
3. Remove the tie-rod end.
4. Remove the boot bands and clamps from the inner tie-rod ends (Figure 13-14).
5. Place the flat side of the rack holding tool toward the actuator housing and drive the special rack holding tool between the actuator housing and the stop washer with a soft hammer (Figure 13-15).
6. Straighten the tabs on the tie-rod lock washer.
7. Hold the shaft screw with the holding tool and loosen the tie-rod with a wrench (Figure 13-16).
8. Thread the tie-rod off the shaft screw and repeat this procedure on each tie-rod end.




FIGURE 13-13 Loosening the tie-rod end locknut.




FIGURE 13-14 Removing boot bands and clamps from the inner tie-rod end.




FIGURE 13-15 Installing the special rack holding tool between the actuator housing and the stop washer.




FIGURE 13-16 Removing the tie-rod from the shaft screw.



CAUTION:

Do not put grease on the boot installation shoulder and tapered section of the ball pin in the tie-rod end. Grease may cause these components to become loose.

Tie-Rod End Boot Removal and Replacement

Tie-rod end boots must be replaced if they are cracked, split, deteriorated, or loose.

Follow these steps to remove and replace the tie-rod end boots:

1. Use a large screwdriver to pry the old boot from the tie-rod end.
2. Pack the interior of the new boot with the vehicle manufacturer's recommended grease and place a light coating of grease on the boot lip.
3. Wipe the grease off the sliding surfaces of the ball pin with a shop towel; then pack the lower area around the ball pin and body with grease (Figure 13-17).
4. Use the special driving tool to install the new boot on the tie-rod end (Figure 13-18).
5. Wipe any grease from the tapered section of the ball pin with a shop towel. Apply sealant around the lower edge of the boot and tie-rod body.




FIGURE 13-17 Packing the boot and tie-rod end with grease.




FIGURE 13-18 Driving the boot onto the tie-rod end with a special driving tool.



CAUTION:

Do not allow dust, dirt, or foreign material to enter the tie-rod end ball joint or boot because this contamination causes rapid component wear.



SPECIAL TOOLS

Tie-rod end removal tool

Installation of Tie-Rods and Tie-Rod Ends

Inner tie-rod boots must be replaced if they are cracked, split, deteriorated, or damaged.

Follow these steps for tie-rod and tie-rod end installation:

1. Install the tie-rod ends so the marks on the tie-rod ends, nuts, and tie-rods are aligned, and tighten the tie-rod nuts to the specified torque.
2. Screw each inner tie-rod onto the shaft screw while holding the lock washer so its tabs are in the inner tie-rod end. The stop washer must be installed on the shaft screw with the chamfered side facing outward (Figure 13-19).
3. Drive the special holding tool between the actuator housing and the stop washer with a soft hammer (Figure 13-20).
4. Hold the shaft screw with the holding tool and tighten the inner tie-rod end to the specified torque.



CAUTION:

Never apply axial impact or rotational force to the shaft screw in the rear steering actuator. Either of these actions may cause internal actuator damage.




FIGURE 13-19 Installing the inner tie-rod end on the shaft screw.




FIGURE 13-20 Installing the special tool to hold the shaft screw while tightening the inner tie-rod end.




FIGURE 13-21 Lubricating of the inner tie-rod joint housing.



CAUTION:

While staking the boot clamps, be careful not to damage the inner tie-rod boots.

5. Bend the lock washer tabs against the flat on the inner tie-rod end.
6. Remove the special holding tool and apply silicone grease to the sliding surface of the tie-rod (Figure 13-21). Place a light coating of silicone grease inside the tie-rod boot.
7. Apply the vehicle manufacturer's recommended grease to the circumference of the inner tie-rod joint housing.
8. Install the boots on the actuator housing; then install the boot bands with the locking tabs properly positioned in relation to the actuator housing (Figure 13-22).
9. Tighten the boot bands and bend both sets of locking tabs over the band (Figure 13-23). Tap lightly on the doubled-over portion of the band to reduce its height and stake the locking tabs firmly.




FIGURE 13-22 Proper boot band position in relation to the actuator housing.




FIGURE 13-23 Tightening and staking the inner tie-rod boot clamps.




FIGURE 13-24 Removing the rear sub steering angle sensor.




FIGURE 13-25 Removing the rear main steering angle sensor.

The **rear sub steering angle sensor** sends a voltage signal to the 4WS computer in relation to the amount of rack movement in the rear steering actuator.

The **rear main steering angle sensor** sends a voltage signal to the 4WS computer in relation to ball screw rotation in the rear steering actuator.



SERVICE TIP:

Cover the rear main steering sensor and rear sub steering sensor openings in the actuator housing with masking tape or its equivalent to keep dirt and foreign material out of the actuator housing.

Remove and Replace Rear Steering Actuator Sensors

Follow these steps to remove and replace the rear sub steering angle sensor and the rear main steering angle sensor:

1. Loosen the rear sub steering angle sensor locknut and rotate the sensor to thread it out of the housing (Figure 13-24). Discard the sensor O-ring.
2. Remove the two mounting bolts in the rear main steering angle sensor, and then remove the sensor from the actuator housing (Figure 13-25). Note the position of the dowel pins, and discard the O-ring.
3. Install the locknut and a new O-ring on the rear sub steering angle sensor.
4. Place a light coating of grease on the O-ring and install the sensor in the actuator housing.
5. Rotate the sensor until it touches the tapered shaft and back it out one-half turn. Tighten the locknut finger tight. Final adjustment of the rear sub steering angle sensor is completed with the actuator installed in the vehicle.
6. Place a light coating of grease on the rear main steering angle sensor O-ring and install this O-ring on the sensor.
7. Install the rear main steering angle sensor and O-ring in the actuator housing with the dowel pins properly positioned, and tighten the mounting bolts to the specified torque.

Installing Rear Steering Actuator

Follow these steps for rear steering actuator installation:

1. Install the rear steering actuator and the four mounting bolts and bracket. The arrow on the bracket must face upward (Figure 13-26).
2. Tighten the rear steering actuator mounting bolts to the specified torque.
3. Reconnect the tie-rod ends to the steering arms and tighten the castelated nut to the specified torque. If necessary, tighten the nut slightly to align the nut slots with the tie-rod pin hole.




FIGURE 13-26 Installing the rear steering actuator, four mounting bolts, and bracket.




FIGURE 13-28 Installing wiring connectors on the rear steering actuator.




FIGURE 13-27 Proper installation of cotter pin in the tie-rod end.



CAUTION:

Tighten the castle nut on the tie-rod ends to the specified torque, and then tighten these nuts enough to align the slots in the nut with the hole in the tie-rod pin. Do not loosen the nut to align the nut slots with the tie-rod pin hole. If this nut is loosened to align the slot with the hole, the tie-rod end may become loose in service.

4. Install the cotter pin in the nut and tie-rod end pin openings, and bend one leg of the cotter pin downward over the nut. Bend the other cotter pin leg upward over the top of the tie-rod end pin (Figure 13-27).
5. Check all the wiring connectors for contamination and clean as necessary. Install all the wiring connectors on the rear steering actuator and tighten all the terminal nuts to the specified torque (Figure 13-28).
6. Install the terminal cover on the rear main steering sensor terminals. Remove the rear steering lock pin and install the cap bolt and washer. Leave the steering actuator cover removed until after the final rear steering actuator adjustments.

Photo Sequence 24 shows a typical procedure for diagnosing an electronically controlled four-wheel steering system.

DIAGNOSIS OF FOUR-WHEEL ACTIVE STEERING (4WAS) SYSTEM

Service Precautions Related to the Supplemental Restraint System (SRS)

The SRS contains air bags in different locations and seat belt pre-tensioners. Improper service procedures may result in unintended air bag deployment and personal injury. To avoid personal injury and/or rendering the SRS inoperative, all precautions recommended by the vehicle manufacturer must be observed. These precautions include the following:

1. Never use any electrical test equipment on any circuit unless this equipment is recommended in the vehicle manufacturer's service manual.
2. Use only service procedures recommended by the vehicle manufacturer.

TYPICAL PROCEDURE FOR DIAGNOSING AN ELECTRONICALLY CONTROLLED FOUR-WHEEL STEERING SYSTEM




P24-1 Road test the vehicle to check 4WS operation and indicator light.



P24-2 Lower the vehicle and locate the service check connector behind the center console.



P24-3 Look up the diagnostic procedure and trouble codes in the car manufacturer's service manual.



P24-4 Connect a jumper wire between the terminals in the service check connector.



P24-5 Turn on the ignition switch.



P24-6 Observe the 4WS indicator light flashes to obtain the fault codes.



P24-7 Turn off the ignition switch.



P24-8 Remove the jumper wire from the service check connector.

3. If heavy vibration occurs near a SRS system sensor while the ignition switch is on or the engine is running, air bag deployment may occur. When using air or electric power tools and hammers, always turn the ignition switch Off, disconnect the negative battery cable followed by the positive battery cable, and wait 3 minutes before proceeding with the service work.
4. To avoid accidental air bag deployment when working on the electrical system, turn the ignition switch Off, disconnect both battery cables, and wait 3 minutes.

Service Precautions Related to Electronic Control Unit (ECU) Replacement

Before removing and replacing any ECU, turn the push-button ignition switch to the Lock position, and then disconnect negative battery cable followed by the positive battery cable. After the replacement control unit is installed, be sure all electrical connectors are properly connected and all related wiring harness is in satisfactory condition. Then reconnect the positive cable followed by the negative cable. Use the vehicle manufacturer's recommended scan tool to perform a self-diagnosis on the replacement control unit.

Safety Precautions Related to the Steering Lock Unit

A number of vehicles are equipped with a push-button ignition switch and a steering lock that engages if the battery is disconnected or discharged. If steering wheel rotation is required with the steering lock engaged, follow these steps:

1. Connect both battery cables.
2. If the battery is discharged, use jumper cables connected from a booster battery to the battery terminals with the correct polarity to provide battery voltage to the electrical system.
3. Turn the push-button ignition switch to the ACC position. This action releases the steering lock.
4. Disconnect the negative battery cable followed by the positive battery cable. The steering lock will remain released with both battery cables disconnected, and steering wheel rotation is possible.
5. When the service work is completed, reconnect the positive battery cable followed by the negative cable. With the brake pedal released, turn the push-button ignition switch from the ACC position to the On position, and then to the Lock position. The steering lock will be engaged when the ignition switch is moved to the Lock position. Use the vehicle manufacturer's recommended scan tool to perform a self-diagnosis of all control units in the system being serviced.

Preliminary Diagnosis and Visual Inspection

When diagnosing the 4WAS system, the first step is to identify the complaint. Questioning the customer regarding the vehicle operation often helps to identify the complaint. A vehicle road test may be necessary to experience and determine the exact complaint. After the complaint is identified, the next step is to visually inspect the system to identify any defects. When diagnosing the 4WAS system, be sure the power steering fluid level and the belt tension are correct. Inspect all the wiring harness and wiring connectors for damage and corrosion. Be sure all system components such as the front and rear actuators are mounted securely. Check the 4WAS warning light. This light should go out after the engine starts. If the warning light remains On with the engine running, the 4WAS system has an electronic defect. If no defects are found during the visual inspection, further diagnosis is required.

Scan Tool Diagnosis

The ignition switch should be in the Off position when connecting and disconnecting the scan tool. A scan tool may be connected to the DLC to perform these tests:

- 1. Self-diagnostic tests – retrieves DTCs indicating electronic defects in certain electronic areas.
- 2. Data monitor tests – reads data from the system components to determine component operation and condition.
- 3. CAN diagnostic monitor – indicates if CAN transmit/receive communication is satisfactory.
- 4. Active tests – activates specific system components to determine component operation.
- 5. ECU part number – identifies the front ECU part number.

Diagnostic Example DTC C1631

The electronic systems on current vehicles contain many DTCs and provide a large number of data items. The lists of DTCs and data items for various electronic systems are provided in the vehicle manufacturer’s service manual. We will provide some diagnostic examples to illustrate how the DTCs and data items may be used to diagnose the 4WAS system.

If DTC C1631 is displayed on the scan tool, the DTC list for the front control unit indicates this DTC represents an error in the front ECU or in the voltage supply to the front ECU. To locate the root cause of this defect, follow these steps:

- 1. Turn the ignition switch Off and disconnect terminal M41 and M42 on the front ECU as illustrated in Figures 13-29 and 13-30. A partial wiring diagram is shown in Figure 13-31.
- 2. With the ignition switch Off, connect a voltmeter from terminal 11 to ground in terminal M41. The voltmeter should indicate 12 V. When the voltmeter is connected from terminal 15 in connector M42 to ground, the meter should read 0 V.
- 3. Turn the ignition switch On and the voltage measured from both terminals 11 and 15 to ground should be 12 V.
- 4. If the voltage reading is low at terminal 11 to ground, check the 40-A fuse and related circuit, and repair as necessary. When the voltage reading is low at terminal 15, check the 10-A fuse and related circuit, and repair as required.
- 5. Turn off the ignition switch and connect an ohmmeter from terminal 12 in terminal M41 to ground. The meter should read very low resistance if the ground wire is satisfactory. A high meter reading indicates excessive resistance in this wire or wire terminals and connectors. If a high reading is obtained, repair or replace the ground wire from terminal 12 to ground.
- 6. Connect the ohmmeter leads from terminals 18 to ground and 34 to ground in connector M42. The ohmmeter should indicate a very low reading at each of these connections. If either connection indicates a high ohmmeter reading, repair or replace the ground wires from terminals 18 and 34 to ground.
- 7. If the meter readings in steps 1 through 7 are satisfactory, replace the front ECU.

Diagnostic Example DTC C1902

If DTC C1902 is obtained on the scan tool, a rear motor current error is indicated. To pinpoint the root cause of this DTC, follow this procedure:



FIGURE 13-29 Wiring connection M41 front ECU




FIGURE 13-30 Wiring connection M42 front ECU



- | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|--|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | | | | |
| 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

A diagram of a two-chambered heart. It consists of a single ventricle divided into two equal halves by a vertical septum. The left half is labeled '1' and the right half is labeled '2'. Above the ventricle is a single atrium, represented by a rectangular box. The entire heart is enclosed in a rounded outer boundary.

450

tool data monitor. The following readings should be obtained on the scan tool during these selections:

MOTOR VOLTAGE 12 V

MOTOR CURRENT 0–20 A

MTR CRNT OPE – with the steering in the straight ahead position, the rear actuator in the neutral condition –2 to 2A, and rear motor running –20 to 20A.

6. If the readings in step 5 are not within specifications, replace the rear actuator.
7. If all the readings in steps 1 through 5 are satisfactory and DTC 1902 continues to appear, replace the rear ECU.

4WAS Adjustments

If the front ECU or front actuator is replaced or a wheel alignment is performed, a front actuator neutral position adjustment is necessary. Proceed as follows to perform the front actuator neutral position adjustment:

1. With the ignition switch Off, connect the scan tool to the DLC.
2. Be sure the front wheels are in the straight ahead position. Start the engine and select DATA MONITOR and ACTR ROTA ANG on the scan tool.
3. Turn the steering wheel until the ACTR ROTA ANG reading on the scan tool indicates –3.5 to 3.5 degrees.
4. Turn the ignition switch Off.

CASE STUDY

A customer complained about the 4WS indicator light coming on intermittently on a Honda Prelude with an electronic 4WS system. The technician asked the customer about any other steering problems, and the customer reported the car steered normally. The technician road-tested the car, but the 4WS light did not come on, which indicated there were no electronic problems in the system. The customer was concerned about a possible safety hazard while driving this vehicle with the 4WS indicator light illuminated. In reply to this concern, the technician explained to the customer about the fail-safe function in the 4WS system and the rear wheels being centered in this mode.

The technician asked the customer about any recent service work completed on the vehicle. In response to this question, the customer replied that the car had been in a rear end collision recently, and when the body work was completed, the 4WS indicator light problem started occurring. The technician informed the customer that a 4WS system diagnosis and inspection should be performed.

Since the 4WS indicator light was not illuminated, the technician concluded that a trouble code diagnosis would probably not provide any diagnostic answers. However, the technician checked the system for codes in case there was a code caused by abnormal

or harsh driving, which would not cause the indicator light to be illuminated.

When the technician raised the vehicle on a hoist, it was clearly visible that many of the rear suspension and body parts had been replaced recently. Even the rear steering actuator cover had been replaced. The technician removed the rear steering actuator cover to inspect the wiring on the actuator. All the wiring connectors were inspected, including the terminals on the rear main steering angle sensor. When the technician inspected the rear sub steering angle sensor wiring harness, he found this harness had been punctured by a sharp object near the sensor. The technician probed the sensor wires at the sensor and connected a pair of ohmmeter leads from each wire at the sensor to the corresponding colored wire in the sensor connector. Each wire showed a normal zero-ohm resistance. The technician repeated these ohmmeter connections and wiggled the wires at the damaged location. On one of the wires, the ohmmeter reading went to infinite while wiggling the wires, indicating an intermittent open circuit.

The technician replaced the rear sub steering angle sensor and performed the electronic neutral check and the rear sub steering angle sensor adjustment. During a road test, the 4WS indicator light did not come on.

TERMS TO KNOW

Fail-safe mode
Rear main steering angle sensor
Rear steering center lock pin
Rear sub steering angle sensor
Service check connector

ASE-STYLE REVIEW QUESTIONS

1. While discussing the fail-safe function:
Technician A says the 4WS indicator light is illuminated during the fail-safe function.
Technician B says the rear wheels steer normally when the 4WS control unit enters the fail-safe mode.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
2. While discussing the fail-safe function and damper control:
Technician A says the rear wheels move instantly to the centered position when the 4WS control unit enters the fail-safe mode.
Technician B says the return spring moves the rear wheels away from the centered position.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. While discussing trouble code diagnosis:
Technician A says the 4WS system service check connector is located under the driver's seat.
Technician B says when one of the service check connector terminals is grounded, the 4WS system enters the diagnostic mode.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
4. While discussing trouble code diagnosis:
Technician A says many 4WS system trouble codes are cancelled when the ignition switch is turned off.
Technician B says codes representing problems caused by abnormal or harsh driving conditions do not illuminate the 4WS indicator light.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
5. While discussing rear steering actuator service:
Technician A says the rear steering actuator is a replacement unit except for tie-rods and sensors.
Technician B says the arrows on the rear steering actuator brackets must face downward.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
6. All of these statements about rear steering actuators and actuator service are true EXCEPT:
A. Axial impact on the shaft screw may damage the actuator.
B. Rotational force on the shaft screw may damage the actuator.
C. The engine may be started with the rear steering lock pin in place.
D. The shaft screw must be held with a special tool while loosening the tie-rods.
7. When diagnosing a Quadrateer system a DTC B1000 is displayed on the scan tool. The most likely reason for this DTC is:
A. A defective steering wheel position sensor.
B. A defective rear wheel steering motor.
C. An internal defect in the BCM.
D. An open circuit in the wiring to the rear steering motor.
8. When performing a Learn Rear Wheel Alignment procedure:
Technician A says the steering wheel must be centered.
Technician B says during this procedure the front wheels must be lifted off the shop floor.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
9. A DTC representing a data link defect begins with a:
A. B. C. P.
B. C. D. U.
10. When diagnosing a 4WAS with a scan tool:
Technician A says the CAN diagnostic monitor indicates if transmit/receive communication is satisfactory.
Technician B says that during the active tests the scan tool activates specific system components.
Who is correct?

ASE CHALLENGE QUESTIONS

1. While discussing electronic 4WS:

Technician A says jumping the two terminals of the service check connector with the engine off will display DTCs.

Technician B says jumping the service check connector then starting the engine displays the processor in which the codes are stored.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

2. The Honda Prelude 4WS system uses a main and a sub processing unit, each storing 10 trouble codes. If the 4WS light on the dash blinks quickly and repeatedly for three seconds, it means:

- A. A DTC is stored in the main processor.
B. A DTC is stored in the sub processor.
C. The system is moving from the main to the sub processor memory.
D. A DTC sequence will be repeated.

3. Honda Prelude temporary “abnormal or harsh driving” 4WS DTCs range from to .

- A. 07/14 C. 17/24
B. 70/74 D. 44/47

4. The Honda Prelude 4WS light has gone on and remains on.

Technician A says that before performing any diagnostic tests, the 10A fuse for the clock radio should be removed.

Technician B says to retrieve the DTC, the 4WS control unit connector must be disconnected.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

5. While discussing electronic 4WS:

Technician A says that after repairing a defect of the main steering angle sensor in the Honda Prelude 4WS system, fuse #43 must be removed to cancel the code.

Technician B says the battery terminal must be removed to cancel DTCs in parts of the Honda Prelude 4WS system other than the main steering angle sensor.

Who is correct?

- A. A only C. Both A and B
B. B only D. Neither A nor B

Name _____ Date _____

RETRIEVE DIAGNOSTIC TROUBLE CODES (DTCs), FOUR-WHEEL STEERING (4WS) SYSTEM

Upon completion of this job sheet, you should be able to retrieve diagnostic trouble codes (DTCs) on four-wheel steering (4WS) systems.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task B-19: Test and diagnose components of electronically controlled steering systems using a scan tool: determine necessary action.

Tools and Materials

Jumper wire

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. Be sure the ignition switch is off and remove the dual-terminal service check connector located behind the center console. Connect the two terminals in this connector with a jumper wire.

Is the jumper wire properly connected? ☐ Yes ☐ No

Instructor check _____

2. Turn the ignition switch on, but do not start the engine. ☐

3. Observe the 4WS indicator light to read the diagnostic trouble codes (DTCs). Three longer flashes followed by a brief pause and one quicker flash indicates code 31. The codes are given in numerical order. ☐

4. List the DTCs provided with ignition switch on and the engine not running and include the DTC interpretation.

1. _____

2. _____

3. _____

5. Turn the ignition switch off and start the engine while observing the 4WS indicator light in the instrument panel. ☐

6. Does the 4WS indicator light blink once quickly when the ignition switch is turned on?

4WS light operation: ☐ Satisfactory ☐ Unsatisfactory

If the 4WS light operation is unsatisfactory, describe the light operation.

Task Completed

7. After the quick flash in step 6, did the 4WS indicator light pause for 3 seconds?

4WS light operation: ☐ Satisfactory ☐ Unsatisfactory

If the 4WS light operation is unsatisfactory, describe the light operation.

8. List the main processor DTCs displayed after the pause in step 7 and include the DTC interpretation.

1. _____

2. _____

3. _____

9. Did the 4WS indicator light pause for 1.6 seconds after the DTCs displayed in step 8?

☐ Yes ☐ No

4WS light operation: ☐ Satisfactory ☐ Unsatisfactory

If the 4WS light operation is unsatisfactory, describe the light operation.

10. Did the 4WS indicator light blink quickly for three seconds to indicate a separation between the main and sub processor codes? ☐ Yes ☐ No

4WS light operation: ☐ Satisfactory ☐ Unsatisfactory

If the 4WS light operation is unsatisfactory, describe the light operation.

11. Did the 4WS indicator light pause for 1.6 seconds? ☐ Yes ☐ No

4WS light operation: ☐ Satisfactory ☐ Unsatisfactory

If the 4WS light operation is unsatisfactory, describe the light operation.

12. List the sub processor DTCs displayed after the pause in step 11, and include the DTC interpretation.

1. _____

2. _____

3. _____

13. Did the 4WS indicator light pause for 3 seconds and then repeat the cycle? ☐ Yes ☐ No

4WS light operation: ☐ Satisfactory ☐ Unsatisfactory

If the 4WS light operation is unsatisfactory, describe the light operation.

14. On the basis of all the DTCs displayed, state the required diagnostic procedure to locate the exact cause of the defect(s) and explain the reasons for your diagnosis.

Instructor's Response _____

Name _____ Date _____

PERFORM A LEARN REAR WHEEL ALIGNMENT PROCEDURE ON A QUADRASTEER SYSTEM

Upon completion of this job sheet, you should be able to perform a Learn Rear Wheel Alignment procedure on a Quadrateer system.

NATEF Correlation

This job sheet is correlated with NATEF Automotive Suspension and Steering Task B-19: Test and diagnose components of electronically controlled steering systems using a scan tool; determine necessary action.

Tools and Materials

Vehicle with a Quadrateer system
Compatible scan tool

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed _____

1. Turn on the ignition switch and start the engine.
Engine running, ☐ Yes ☐ No
2. Connect the scan tool to the DLC under the dash.
Scan tool properly connected to the DLC, ☐ Yes ☐ No
3. Center the steering wheel.
Steering wheel properly centered, ☐ Yes ☐ No
4. Lift the rear of the vehicle so the rear tires are a few inches off the shop floor. Be sure the chassis is securely supported on safety stands, and the rear wheels are centered.
Rear wheels raised off the shop floor, ☐ Yes ☐ No
Chassis properly supported on safety stands, ☐ Yes ☐ No
Steering wheel centered, ☐ Yes ☐ No
5. Select the Learn Alignment menu on the scan tool.
Learn Alignment displayed on the scan tool, ☐ Yes ☐ No
6. Follow the directions on the scan tool. When directed, the front wheels must be turned 90° to the left and 90° to the right, and then returned to the center position.
Steering wheel rotated 90° in each direction, ☐ Yes ☐ No
Steering wheel centered, ☐ Yes ☐ No
7. Press the Continue button on the scan tool until the Learn Alignment procedure is completed.
Learn Alignment procedure properly completed, ☐ Yes ☐ No
8. Use the scan tool to erase the rear wheel steering DTCs.
DTCs erased, ☐ Yes ☐ No

Task Completed

9. Shut off the ignition, disconnect the scan tool, and lower the rear wheels onto the shop floor.
- Ignition shut off and scan tool disconnected, ☐ Yes ☐ No
- Vehicle lowered onto shop floor, ☐ Yes ☐ No

Instructor's Response _____

Name _____ Date _____

QUADRASTEER DIAGNOSTIC SYSTEM CHECK

Upon completion of this job sheet, you should be able to perform a Diagnostic System Check on a QuadraSteer System.

NATEF Correlation

This job sheet is correlated with NATEF Automotive Suspension and Steering Task D-4: Diagnose, inspect, adjust, repair or replace components of electronically controlled steering systems (including sensors, switches, and actuators), initialize system as required.

Tools and Materials

Vehicle with a QuadraSteer system

Compatible scan tool

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed

1. With the ignition switch off, connect a scan tool to the DLC under the dash.
Scan tool properly connected to the DLC, ☐ Yes ☐ No
2. Turn on the ignition switch, and select Rear Wheel Steering Control Module on the scan tool. If the scan tool does not communicate with this module, check the scan tool electrical connection and the data links. Be sure the scan tool communicates with all the other modules on the vehicle.
Proper scan tool communication with rear wheel steering control module and other modules on the vehicle, ☐ Yes ☐ No
3. Access the Class 2 Power Mode on the scan tool, and rotate the ignition switch through all positions while observing the scan tool. The engine may start with the ignition switch in the Start position. The ignition switch position displayed on the scan tool should match the actual ignition switch position.
Actual ignition switch positions match displayed ignition switch positions on the scan tool, ☐ Yes ☐ No
4. Select the Display DTCs function on the scan tool and then select Rear Wheel Steering Control Module to display the DTCs related to the 4WS system. Select all the other modules on the vehicle, and display any DTCs stored in these modules. Record all DTCs.
Rear wheel steering control module DTCs _____

DTCs from other modules _____

Task Completed

5. Are there any DTCs beginning with a U? These DTCs relate to data link problems and must be repaired before proceeding with 4WS diagnosis.
DTCs beginning with a U _____
6. Does the scan tool display DTC B1000? This DTC indicates an internal defect in the body control module (BCM) and causes the BCM to refuse all additional inputs.
DTC B1000 displayed, ☐ Yes ☐ No

Instructor's Response _____

Chapter 14

FRAME DIAGNOSIS AND SERVICE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Take the necessary precautions to avoid frame damage.
- Diagnose the causes of frame damage.
- Follow safety precautions when measuring and welding frames.
- Visually inspect frames.
- Measure frames with a plumb bob and diagnose frame damage.
- Measure frames with a tram gauge and diagnose frame damage.
- Perform unitized body measurements with a tram gauge.
- Perform unitized body measurements with a dedicated bench system.

Improper frame or unitized body alignment may cause wheel alignment defects, rapid tire tread wear, and reduced directional stability. After collision damage, a unitized body vehicle may be repaired so it has satisfactory cosmetic appearance, but body and wheel alignment defects are still present. These defects may contribute to reduced directional stability, especially during such extreme conditions as hard cornering or severe braking. Therefore, diagnosing and correcting frame and unitized body alignment is very important to restoring vehicle safety! Body shops have mechanical or electronic body and chassis alignment equipment that can help correct improper body alignment.

INDICATIONS OF FRAME DAMAGE

The most common cause of frame damage on cars and light-duty trucks is collision damage. In some cases, the collision damage may be repaired to make the cosmetic appearance of the vehicle satisfactory, but the frame damage may not always be correctable.

When driving the vehicle, some indications of frame damage are:

1. Excessive tire wear when the front suspension alignment angles are correct.
2. Steering pull when the front suspension alignment angles are correct.
3. Steering wheel not centered when driving straight ahead, but the steering wheel was centered in the shop.

FRAME DIAGNOSIS

Preventing Frame Damage

Since frame problems affect wheel alignment, technicians must be able to diagnose frame defects so they are not confused with wheel alignment problems.



BASIC TOOLS

Basic technician's tool set

Service manual

Tape measure

Chalk

Floor jack

Safety stands

**Classroom
Manual**

Chapter 14,
page 325

Section modulus is a measure of the frame's strength based on its height, width, thickness, and the shape of the side rails. Section modulus does not account for the type of material in the frame.

Frame flange is the horizontal part of the frame on the top and bottom of the web.

Frame web refers to the vertical side of the frame.

Yield strength is a measure of the strength of the material from which the frame is manufactured. Yield strength is the maximum load that may be placed on a material and still have the material retain its original shape. Yield strength is measured in pounds per square inch (psi) or kilopascals (kPa).

Follow these precautions to minimize frame damage:

1. Do not overload the vehicle.
2. Place the load evenly in a vehicle.
3. Do not operate the vehicle on extremely rough terrain.
4. Do not mount equipment such as a snow plow on a vehicle unless the frame is strong enough to carry the additional load and force.

Diagnosis of Frame Problems

Side Sway. The causes of frame side sway are:

1. Collision damage.
2. Fire damage.
3. Use of equipment on the vehicle for which the frame was not designed.

Sag. The causes of frame sag are:

1. Vehicle loads that exceed the load-carrying capacity of the frame.
2. Uneven load distribution.
3. Sudden changes in **section modulus**.
4. Holes drilled in the **frame flange**.
5. Too many holes drilled in the **frame web**.
6. Holes drilled too close together in the frame web.
7. Welds on the frame flange.
8. Cutting holes in the frame with a cutting torch.
9. Cutting notches in the frame rails.
10. A fire involving the vehicle.
11. Collision damage.
12. The use of equipment for which the frame was not designed.

Buckle. The causes of frame buckle are:

1. Collision damage.
2. Using equipment such as a snow plow when the frame was not designed for this type of service.
3. A fire involving the vehicle.

Diamond-Shaped. Diamond-shaped frame damage may be caused by:

1. Collision damage.
2. Towing another vehicle with a chain attached to one corner of the frame.
3. Being towed by another vehicle with a chain attached to one corner of the vehicle frame.

Twist. Frame twist may be caused by:

1. An accident or collision, especially one involving a rollover.
2. Operating the vehicle on extremely rough terrain.

CHECKING FRAME ALIGNMENT

Safety Concerns

While servicing vehicle frames, always wear the proper safety clothing and safety items for the job being performed. This includes proper work clothing, safety goggles, ear protection, respirator, proper gloves, welding shield, and safety shoes (Figure 14-1).

If arc welding is necessary on a vehicle frame, follow these precautions:

1. Remove the negative battery cable before welding (Figure 14-2).
2. Remove the fuel tank before welding (Figure 14-3).
3. Protect the interior and exterior of the vehicle as necessary (Figure 14-4).




FIGURE 14-1 Safety items for frame service.



FIGURE 14-2 Remove the negative battery cable before arc welding on a vehicle.




FIGURE 14-3 Remove the fuel tank before arc welding on a vehicle.



FIGURE 14-4 Protect the interior and exterior of the vehicle while arc welding.

Visual Inspection

Prior to frame measurement, the frame and suspension should be visually inspected. Check for wrinkles on the upper flange of the frame, which indicate a sag problem. Visually inspect the lower flange for wrinkles, which are definite evidence of buckle. Since suspension or axle problems may appear as frame problems, the suspension components should be inspected for wear and damage. For example, an offset rear axle may appear as a diamond-shaped frame. Check all suspension mounting bushings and inspect leaf-spring shackles and center bolts.

The frame should be inspected for cracks, bends, and severe corrosion. Minor frame bends are not visible, but severe bends may be visible. Straight cracks may occur at the edge of the frame flange, and **sunburst cracks** may radiate from a hole in the frame web or cross member (Figure 14-5).

Sunburst cracks radiate outward from a hole in a frame web or cross member.



CAUTION:

Always follow the vehicle manufacturer's recommendations in the service manual regarding welding or reinforcing the frame, or mounting additional equipment on the frame. If these recommendations are not followed, the frame may be weakened and damaged.




FIGURE 14-5 Straight cracks may occur in the frame flange; sunburst cracks may radiate from a hole in the frame web or cross member.

Frame Welding

Follow these steps for a typical frame welding procedure:

1. Remove any components that would interfere with the weld or be damaged by heat.
2. Find the extreme end of the crack and drill a 0.25 in. (6-mm) hole at this point.
3. V-grind the entire length of the crack from the starting point to the drilled hole.
4. The bottom of the crack should be opened 0.062 in. (2 mm) to allow proper weld penetration. A hacksaw blade may be used to open the crack.
5. Arc weld with the proper electrode and welding procedure.

Frame Measurement, Plumb Bob Method

Photo Sequence 25 shows a typical procedure for performing frame measurement using the plumb bob method.

Locating the Frame Centerline. Some vehicle manufacturers recommend measuring the frame with the **plumb bob** method.

Follow these steps to complete a plumb bob measurement for frame damage:

1. Place the vehicle on a level area of the shop floor and use a floor jack to raise the front and rear suspension off the floor. Support the chassis on safety stands at the manufacturer's recommended locations.
2. Suspend a plumb bob at locations 1, 2, 11, and 12 on the inside of the frame web, and allow the plumb bob to almost touch the floor surface (Figure 14-6). Points 1 and 2 are at the centerline of the slotted hole in each front bumper bracket, and points 11 and 12 are on the inside of the rear frame web. Mark these plumb bob locations on the floor with chalk.
3. Use a plumb bob to transfer points 3 through 10 from the frame to chalk marks on the floor.
4. Raise the vehicle with the floor jack, remove the safety stands, and lower the vehicle onto the floor. Move the vehicle away from the chalk-marked area.
5. Measure the distance between points 1 and 2 with a tape measure, and chalk mark the exact halfway point in this distance. This mark is the frame centerline at the front.
6. Measure the distance between points 11 and 12, and chalk mark the exact center of this measurement. This chalk mark is the frame centerline at the rear.
7. Draw a straight chalk line from the centerline at the front of the frame to the centerline at the rear of the frame. This chalk line is the complete centerline of the frame.



SERVICE TIP:

If the frame is cracked, frame alignment is often necessary.

A **plumb bob** is a weight with a sharp, tapered point that is suspended and centered on a string. Plumbers use this tool for locating pipe openings directly above each other in the tops and bottoms of partitions.



SPECIAL TOOLS

Plumb bob

PHOTO SEQUENCE 25

TYPICAL PROCEDURE FOR PERFORMING FRAME MEASUREMENT, PLUMB BOB METHOD




P25-1 Park the vehicle on a level area of the shop floor.



P25-2 Raise the front suspension with a floor jack and lower the chassis onto safety stands positioned at the manufacturer's recommended lifting points.



P25-3 Raise the rear suspension with a floor jack and lower the chassis onto safety stands positioned at the manufacturer's recommended lifting points.




P25-4 Suspend a plumb bob at the manufacturer's recommended frame measurement locations and place a chalk mark on the floor directly under the plumb bob.



P25-5 Use a floor jack to lift the vehicle, remove the safety stands, and lower the vehicle.



P25-6 Drive the vehicle away from the chalk-marked area.



P25-7 Use a tape measure to measure the vehicle's frame measurements between the chalk marks on the floor.



P25-8 Compare the frame measurements obtained with the vehicle manufacturer's specifications in the service manual.



SERVICE TIP:

The points on the left and right frame webs must be at the same location on each web for accurate measurements.



SERVICE TIP:

When using a tape measure, avoid twists and bends in the tape to provide accurate readings.




FIGURE 14-6 Suspend a plumb bob at the locations shown on the frame and mark these locations on the floor with chalk.

Horizontal Frame Measurements

The procedure used for horizontal frame measurements follows:

1. Measure the distance from the frame centerline to points 3 through 10. Each pair of these points should be equal within 0.125 in. (3 mm). For example, the distance from point 5 to the centerline should be equal to the distance from point 6 to the centerline.
2. Measure diagonally from point 1 to 6 and point 2 to 5. These distances should be equal or within the manufacturer's specified tolerance. Place a straight chalk mark from points 1 to 6 and points 2 to 5. These diagonal lines should cross each other at the frame centerline.
3. Repeat step 2 at all the other diagonal frame measurements, such as points 3 to 10, 4 to 9, 5 to 12, and 6 to 11. All these diagonal measurements should be equal or within the vehicle manufacturer's specified tolerance. Each pair of diagonal lines must cross each other at the vehicle centerline (Figure 14-7).

When such frame problems as side sway, buckle, or a diamond-shaped condition are present, some of the horizontal frame measurements are not within specifications, and some of the diagonal chalk lines do not cross at the frame centerline, depending on the location of the damaged area.

Frame Measurement, Tram Gauge Method

A **tram gauge** is a long, straight bar with two adjustable pointers. The distance between the pointers is adjustable, and the height of the pointers is also adjustable (Figure 14-8).

The horizontal frame measurements may be completed with a tram gauge, rather than using the plumb bob method. When measuring a frame, horizontal measurements are




FIGURE 14-7 Each pair of diagonal measurement lines on the frame must cross each other at the frame centerline.

A **tram gauge** is a long, straight bar with two adjustable pointers that is used for frame measurements. A tram gauge may be called a tracking or track gauge.




FIGURE 14-8 Tram gauge for frame measurements.




FIGURE 14-9 Horizontal and vertical frame measurements.

completed straight across the frame and diagonally forward and rearward on the frame, as discussed previously.

Vertical measurements from specific locations on the frame to an imaginary standard line are also necessary to detect such conditions as frame sag and twist (Figure 14-9). This imaginary horizontal line used for vertical frame measurements is called the **datum line**.

When vertical frame measurements are completed with the tram gauge, the gauge pointers must be set at the manufacturer's specified distance for each frame location (Figure 14-11). With the tram gauge pointers set at the specified height and the gauge properly installed across the frame in the recommended frame openings, the tram gauge should be level if the vertical frame measurements are within specifications. If the frame is twisted, the tram gauge is not level when adjusted to specifications and installed in the twisted area.

To measure frame sag, three tram gauges may be installed at various locations for vertical frame measurement. When viewed from the front or the rear, the tram gauges must be level with each other. If the tram gauge near the center of the frame is lower than the tram gauges at the front and rear of the frame, the frame is sagged.

Frame Straightening

Frame straightening is usually done with special hydraulically operated bending equipment. This equipment must be operated according to the equipment manufacturer's recommended procedures. Since frame straightening is usually done by experienced body technicians, we will not discuss this service in detail. All safety precautions must be observed while operating

An imaginary horizontal line parallel to the frame is used for vertical frame measurements. This line is called the **datum line**.



SERVICE TIP:

When the tram gauge is installed on the frame, be sure the pointers are seated properly in the frame openings (Figure 14-10).




FIGURE 14-10 Correct and incorrect tram gauge pointer seating in the frame openings.




FIGURE 14-11 Tram gauge setting and locations for vertical frame measurements, rear subframe.



SPECIAL TOOLS

Tram gauge

Classroom Manual

Chapter 14,
page 326




FIGURE 14-12 Do not stand in front of pulling equipment while it is in operation.

frame-straightening equipment. Never stand in front of pulling equipment when it is in operation (Figure 14-12).

MEASURING UNITIZED BODY ALIGNMENT

Tram Gauge

On unitized bodies, a tram gauge may be used to perform such measurements as the upper strut towers (Figure 14-13) and the front cross member (Figure 14-14).

If the underhood body measurements such as the strut tower measurements are not within specifications, the strut towers may not be in the original position. Collision damage may cause the strut towers to move out of the original position. If the strut towers are out of position, the front alignment angles are incorrect. Photo Sequence 26 illustrates the underhood body measurements.

Because the lower control arms are attached to the cross member or cradle and also to the lower end of the steering knuckle, if the crossmember is moved from the original intended position, front wheel alignment is adversely affected (Figure 14-15). Improper cross member position may be caused by loose, worn cross member mounts or a bent cross member. Improper front wheel alignment may result in excessive front tire tread wear, steering pull, steering wander, and reduced directional stability. When removing a front cross member, always mark the cradle in relation to the chassis so it can be re-installed in the original position.




FIGURE 14-13 Performing an upper strut tower measurement with a tram gauge on a unitized body vehicle.




FIGURE 14-14 Tram gauge measurements on the front cross member of a unitized body vehicle.




FIGURE 14-15 Lower control arm-to-cradle attachment.

The engine and transaxle mounts are also connected to the front cross member. Therefore, a bent cross member or improperly positioned cross member mounts may cause improper engine and transaxle position, which results in vibration problems. Therefore, when diagnosing and correcting engine, drive axle, or transaxle vibration problems, always be sure the front cross member, engine mounts, transaxle mounts, and cross member mounts are in satisfactory condition. The tram gauge may be used to perform vertical measurements on the front and rear subframes on a unitized body vehicle.

Bench

A **dedicated bench system** is necessary to check many unitized body measurements after medium or heavy collision damage. The dedicated bench system has three main parts: the bench, transverse beams, and the dedicated fixtures. When used together, this equipment will perform many undercar unitized body measurements, including length, width, and height at the same time. The bench contains strong steel beams mounted on heavy casters (Figure 14-16). The top of the bench acts as a datum line.

Transverse Beams

The transverse beams are mounted perpendicular to the bench. There are a variety of holes in the bench for proper transverse beam attachment (Figure 14-17). Various holes in the transverse beams provide the correct dedicated fixture positions.




FIGURE 14-16 Bench from a dedicated bench system.




FIGURE 14-17 Transverse beams placed on the bench.

Classroom Manual
Chapter 14,
page 324



SPECIAL TOOLS
Dedicated bench
system




FIGURE 14-18 Dedicated fixtures are specific to the body style being measured.




FIGURE 14-19 Dedicated fixtures are bolted to the transverse beams in specific locations depending on the body style.

Dedicated Fixtures

The dedicated fixtures are specific to the body style being measured (Figure 14-18). These fixtures are bolted to the transverse beams, and the holes in the upper end of the fixtures must be aligned with specific body openings (Figure 14-19).

The unitized body must be straightened until the holes in the dedicated fixtures and the body openings are aligned. If the holes in the unitized body are behind and above the dedicated fixture openings, the unitized body must be pulled forward and downward in that area (Figure 14-20).

Universal benches are now available with computer measuring systems. Measuring a unitized body with a bench system and straightening these bodies with special body pulling equipment is usually done in an autobody shop rather than an automotive repair shop.




FIGURE 14-20 When holes in the body are behind and above the openings in the dedicated fixture, the unitized body must be pulled forward and downward in that area.

Electronic body and chassis alignment equipment using laser beam technology is used in many body shops during collision repair.

Unitized Body Straightening

WARNING: Always follow all the recommended precautions and procedures in the vehicle manufacturer's service manual and in the equipment manufacturer's operator's manual when straightening a unitized body. Failure to follow these precautions and procedures may result in severe personal injury and property damage.

Since unitized body straightening is usually performed by experienced body technicians, our discussion is brief on this subject. During the straightening process on a unitized body, the body is securely bolted to the dedicated bench at all the possible locations except those where misalignment is present. The dedicated bench is securely chained to special holding fixtures in the shop floor. Hydraulically operated pulling equipment is then attached securely to the unitized body to pull the body in the intended direction. **Single-pull** equipment pulls only one location at a time (Figure 14-21), and **multipull** equipment pulls in several locations at the same time (Figure 14-22). The unitized body is pulled until the holes in the body are aligned with the holes in the dedicated fixtures.

CUSTOMER CARE: Always treat customers and their vehicles with respect! Remember that all customers deserve to be treated with respect regardless of their appearance, the mood they are in, or the type of vehicle they drive. When customers notice that you always respect them and their vehicle, they will have a better impression of your business, and they are likely to return to your shop for all their service requirements.




FIGURE 14-21 Single-pull unitized body straightening system.




FIGURE 14-22 Multipull unitized body straightening system.

Single-pull body straightening equipment will pull only one location at a time.


Multipull body straightening equipment will pull in several locations at the same time.

Classroom Manual

Chapter 14,
page 000

PHOTO SEQUENCE 26


PERFORMING UNDERHOOD MEASUREMENTS




P26-1 Perform horizontal underhood measurements.



P26-2 Record the horizontal underhood measurements.




P26-3 Compare horizontal underhood measurements to specifications and identify measurements that are not equal to the specifications (Figure 14-23).



P26-4 Perform point-to-point underhood measurements.



P26-5 Record the point-to-point underhood measurements.




P26-6 Compare point-to-point underhood measurements to specifications and identify measurements that are not equal to the specifications (Figure 14-24).



P26-7 Perform diagonal underhood measurements.



P26-8 Record the diagonal underhood measurements.



P26-9 Compare diagonal underhood measurements to specifications and identify measurements that are not equal to the specifications (Figure 14-25).

TABLE 14-1 DIAGNOSING FRAME AND BODY DAMAGE

Problem	Symptoms	Possible Causes
Excessive front tire tread wear	Front tire tread wear with correct front suspension alignment angles	Frame, front cradle damage
Steering pull when driving straight ahead	Steering pull with correct front and rear alignment angles	Frame, front cradle damage
Steering wheel not centered when driving straight ahead	Steering wheel centered in the shop, but it is not centered when driving straight ahead	Frame, front cradle damage
Improper strut tower position	Incorrect front suspension alignment angles, steering pull, tire tread wear	Collision damage
Frame buckle	Wrinkles in frame flanges	Collision damage, vehicle abuse
Improper cradle measurements or position	Incorrect front suspension alignment angles, steering pull, tire tread wear	Collision damage, worn or improperly positioned cradle mounts




FIGURE 14-23 Performing horizontal underhood measurements.




FIGURE 14-24 Performing point to point underhood measurements.




FIGURE 14-25 Performing diagonal underhood measurements.

CASE STUDY

A customer complained about a vibration problem on an Chrysler Concorde with front-wheel drive. Further questioning of the customer revealed that the vibration occurred when accelerating and decelerating at 40 to 60 mph (64 to 96 km/h). During a road test, the technician found the customer's description of the problem was accurate. The car did have a vibration problem at the speed indicated by the customer. While road-testing the car, the technician thought about the causes of this problem and decided the most likely cause of the vibration would be inner front drive axle joints. The technician informed the customer that a drive axle joint inspection was necessary.

The technician raised the vehicle on a hoist and checked the front drive axle joints. He was surprised to discover the inner and outer joints were all in good condition with no cracked boots or looseness. An inspection of the engine cradle indicated the crosspiece at the rear

of the cradle was severely damaged near the left side of the cradle. It appeared this crosspiece may have struck an object such as a rock during off-road driving. A check of the cradle mounts indicated the cradle openings were jammed into the rubber mounts on the left side of the cradle. The rubber mounts were bulged at the rear of the cradle openings, indicating the left side of the cradle was driven rearward.

The technician informed the customer that cradle removal, measurement, and possible replacement was necessary. After the customer approved this service operation, the technician removed the cradle and measured it with a tram gauge. The diagonal measurements on the cradle were not within the manufacturer's specifications. Since the cradle was severely distorted, a replacement cradle was installed, and all damaged cradle mounting bushings were replaced. A road test indicated the vibration problem was corrected.

TERMS TO KNOW

Datum line
Dedicated bench system
Frame flange
Frame web
Multipull
Plumb bob
Section modulus
Single-pull
Sunburst cracks
Tram gauge

ASE-STYLE REVIEW QUESTIONS

1. While discussing frame sag:
Technician A says frame sag may be caused by holes drilled in the frame flange.
Technician B says frame sag may be caused by holes drilled too close together in the frame web.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
2. While discussing frame side sway:
Technician A says frame side sway may be caused by uneven load distribution.
Technician B says frame side sway may result from too many holes drilled in the frame web.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. While discussing a diamond-shaped frame condition:
Technician A says this condition may be caused when the vehicle is involved in a fire.
Technician B says this condition may be caused by towing another vehicle with the chain attached to one corner of the frame.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
4. When discussing the plumb bob method of frame measurement:
Technician A says the distance from the frame centerline to the same point on each side of the frame should be equal.
Technician B says diagonal frame measurement lines on each side of the vehicle should cross each other at the frame centerline.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
5. When discussing vertical frame measurements:
Technician A says the datum line is an imaginary horizontal line parallel to the vehicle frame that is used for vertical frame measurements.
Technician B says if three tram gauges are properly adjusted and installed at specified locations on the frame, these gauges should be level with each other.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
6. All of these statements about frame problems are true EXCEPT:
A. Frame sag may be caused by overloading the vehicle.
B. Frame sag may be caused by the use of equipment for which the frame was not designed.
C. Frame buckle may be caused by using a snow plow on the front of the vehicle.
D. A diamond-shaped frame may be caused by operating the vehicle on extremely rough terrain.
7. While diagnosing and inspecting vehicle frames:
A. Wrinkles on the lower frame flange indicate frame buckle.
B. Fire damage may cause frame twist.
C. Unequal vehicle load distribution may cause frame side sway.
D. Frame twist may be caused by cutting notches in the frame flanges.
8. When welding a vehicle frame crack:
A. A 0.25 in. hole should be drilled in the center of the crack.
B. The crack should be V-ground at both ends of the crack.
C. Disconnect the negative battery cable before welding the crack.
D. Use a cutting torch to open the crack for proper weld penetration.
9. While performing unitized body measurements:
A. A dedicated bench system performs measurements on upper strut towers.
B. Fixtures on a dedicated bench system are specific for the vehicle body being straightened.
C. The fixtures are bolted to the bench in a dedicated bench system.
D. The transverse beams on a dedicated bench system are specific for the body being straightened.
10. While inspecting and measuring a front cradle on a front-wheel-drive car:
A. Front wheel alignment angles may be changed by a bent front cradle.
B. Engine mounting position is not affected by a bent front cradle.
C. A bent front cradle has no effect on front drive axle vibration.
D. A bent front cradle may cause premature front wheel bearing failure.

ASE CHALLENGE QUESTIONS

1. When making horizontal frame measurements to determine if the frame or unibody is straight, all of the measurements should be made with reference to which one of the following?
A. Vertical C. Horizontal
B. Centerline D. Body bushings
2. A bent front cross member affects all of the following alignments EXCEPT:
A. Centerline. C. Axle.
B. Suspension. D. Engine.
3. While discussing frame damage:
Technician A says a possible indication of frame damage is an uncentered steering wheel when driving straight ahead.
Technician B says suspension alignment may be impossible if the frame is bent. Who is correct ?
A. A only C. Both A and B
B. B only D. Neither A nor B
4. Which of the following makes this statement true? Measurement points of a frame or unibody using a tram gauge are:
A. Seam notches.
B. Calculated by computer.
C. Based on a vertical datum plane.
D. Manufacturer's-specified frame openings.
5. Referring to Figure 14-14:
Technician A says the measurement between "e" and "b" should be no more than ± 1.0 in. different from the measurement between "E" and "B."
Technician B says frame damage problems, such as buckling, can be determined if the measurements between points "e" and "E" are more than ± 0.25 in. different than between "b" and "B."
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

Name _____ Date _____

FRAME MEASUREMENT, PLUMB BOB METHOD

Upon completion of this job sheet, you should be able to perform frame measurements with a plumb bob.

Tools and Materials

Floor jack Plumb bob
Safety stands Chalk

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

1. Place the vehicle on a level area of the shop floor and use a floor jack to raise the front and rear suspension off the floor. Support the chassis on safety stands at the manufacturer's recommended locations.

Is the vehicle chassis supported securely on safety stands? ☐ Yes ☐ No

Instructor check _____

2. Locate the frame measurement locations in the vehicle manufacturer's service manual. ☐

3. Suspend a plumb bob at each frame measurement location and place a chalk mark on the floor directly below the tip of the plumb bob.

Are all frame measurement locations chalk marked on the shop floor? ☐ Yes ☐ No

Instructor check _____

4. Raise the vehicle with the floor jack, remove the safety stands, and lower the vehicle onto the floor. Move the vehicle away from the chalk-marked area. ☐

5. Measure the distance between the two chalk marks directly across from each other at the front of frame, and chalk mark the exact halfway point in this distance. This mark is the frame centerline at the front.

Distance between the two chalk marks directly across from each other at the front of the frame _____

Midpoint in the distance between the two chalk marks directly across from each other at the front of the frame _____

6. Measure the distance between the two chalk marks directly across from each other at the rear of the frame, and chalk mark the exact halfway point of this distance. This mark is the frame centerline at the rear.

Task Completed



SERVICE TIP:

The measurement points on the left and right frame webs must be at the same location on each web to obtain accurate measurements.



SERVICE TIP:

When using a tape measure, avoid twists and bends in the tape to provide accurate readings.

Distance between the two chalk marks directly across from each other at the rear of the frame _____

Midpoint of the distance between the two chalk marks directly across from each other at the rear of the frame _____

7. Draw a straight chalk line from the centerline at the front of the frame to the centerline at the rear of the frame. This chalk line is the complete centerline of the frame.

Is the vehicle centerline chalk marked on shop floor? ☐ Yes ☐ No

Instructor check _____

8. Use a tape measure to measure the distance from the frame centerline to all frame measurement points directly opposite each other. Each pair of these points should be equal within 0.125 in. (3 mm).

Frame measurements between specified measurement locations that are directly opposite each other and the vehicle centerline, starting at the front of the frame:

A. left side _____ right side _____ difference _____

B. left side _____ right side _____ difference _____

C. left side _____ right side _____ difference _____

D. left side _____ right side _____ difference _____

Necessary frame repairs:

9. Use a tape measure to complete all diagonal frame measurements at the vehicle manufacturer's recommended locations. These distances should be equal or within the manufacturer's specified tolerances.

Distances between diagonal frame measurement points:

Diagonal frame measurements at the front of the frame:

diagonal A _____ diagonal B _____

difference between diagonal A and B _____

Diagonal frame measurements at the center of the frame:

diagonal C _____ diagonal D _____

difference between diagonal C and D _____

Diagonal frame measurements at the rear of the frame:

diagonal E _____ diagonal F _____

difference between diagonal E and F _____

Necessary frame service:

10. Use a long, straight steel bar to place a straight chalk mark between all frame diagonal measurement locations. These diagonal lines should cross each other at the frame centerline.

If all diagonal lines do not cross the frame centerline at the same location, state the required frame repairs.

Instructor's Response _____

Name _____ Date _____

INSPECT AND MEASURE FRONT CRADLE

Upon completion of this job sheet, you should be able to inspect and measure front cradles.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task: check front and/or rear cradle (sub frame alignment; determine necessary action.

Tools and Materials

Tram gauge

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed
☐

1. Raise the vehicle on a lift using the vehicle manufacturer's specified lifting points.
2. Inspect front cradle mounts for looseness, damage, oil soaking, wear, and deterioration.
Cradle mount condition: right front _____ right rear _____
left front _____ left rear _____
3. Inspect front cradle for visible bends and damage.
Front cradle condition indicated in visible inspection:

4. Inspect front cradle alignment.
Is the front cradle aligning hole(s) properly aligned with the matching hole in the chassis? ☐ Yes ☐ No
Recommended cradle service:

5. Use a tram gauge to complete all measurements across the width of the cradle starting at the front of the cradle.
Width measurement A _____
Specified width measurement A _____
Width measurement B _____
Specified width measurement B _____

Width measurement C _____

Specified width measurement C _____

Width measurement D _____

Specified width measurement D _____

Width measurement E _____

Specified width measurement E _____

Necessary cradle service:

6. Use a tram gauge to complete all front-to-rear measurements on the cradle, starting on the left side of the cradle.

Front-to-rear measurement A _____

Specified front-to-rear measurement A _____

Front-to-rear measurement B _____

Specified front-to-rear measurement B _____

Front-to-rear measurement C _____

Specified front-to-rear measurement C _____

Front-to-rear measurement D _____

Specified front-to-rear measurement D _____

Necessary cradle service:

7. Use a tram gauge to complete all diagonal cradle measurements, starting at the left side of the cradle.

Diagonal measurement A _____

Specified diagonal measurement A _____

Diagonal measurement B _____

Specified diagonal measurement B _____

Diagonal measurement C _____

Specified diagonal measurement C _____

Diagonal measurement D _____

Specified diagonal measurement D _____

Necessary cradle service:

Instructor's Response _____

Name _____ Date _____

INSPECT AND WELD VEHICLE FRAME

Upon completion of this job sheet, you should be able to inspect and weld a vehicle frame.

Tools and Materials

- Hand pump Welding hammer
- Arc welder Welding rods

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
 VIN _____ Engine type and size _____

Procedure

1. Raise the vehicle on a lift using the vehicle manufacturer's specified lifting points.
2. Read the instructions for disconnecting the negative battery cable in the vehicle manufacturer's service manual. These instructions may include connecting a 12-V power source to the cigarette lighter socket to maintain power to computer memories, radio-stereo, and other electronic equipment.

List the vehicle manufacturer's instructions for disconnecting the negative battery cable.

Have these instructions been completed on the vehicle being serviced? ☐ Yes ☐ No
 Instructor check _____

3. If the vehicle is air-bag-equipped, determine the specified waiting period after the negative battery cable is disconnected before performing service work.
 Waiting period _____

4. Disconnect the negative battery cable.
 Is the negative battery cable disconnected? ☐ Yes ☐ No
 Has the specified waiting period been completed before servicing the vehicle?
☐ Yes ☐ No
 Instructor check _____

5. Use a hand pump to pump all the fuel from the fuel tank. Place the fuel in the proper fuel safety containers and store this fuel away from the work area and other ignition sources.
 Has all the fuel been pumped from the tank? ☐ Yes ☐ No
 Is this fuel placed in proper fuel safety containers and stored away from the work area? ☐ Yes ☐ No
 Instructor check _____



CAUTION:

Always wear eye protection while working in the shop, and use the specified eye protection while arc welding to prevent eye injury.

Task Completed
☐

6. Remove the fuel tank from the vehicle and store the fuel tank away from the work area and other ignition sources.

Is the fuel tank removed? ☐ Yes ☐ No

Fuel tank stored away from the work area? ☐ Yes ☐ No

Instructor check _____

7. Protect the interior and exterior of the vehicle from heat or sparks generated by the welding process.

Are the vehicle's interior and exterior protected? ☐ Yes ☐ No

Instructor check _____

8. Inspect the entire frame for cracks, bends, severe corrosion, and wrinkles in the flanges.

Defective frame conditions:

9. Remove any components that would interfere with the weld or be damaged by heat.

Have all components been removed that would interfere with the weld or be damaged by the heat? ☐ Yes ☐ No

Instructor check _____

10. Find the extreme end of the crack and drill a 0.25 in. (6-mm) hole at this point.

Is a 0.25 in. hole drilled at the end of the crack? ☐ Yes ☐ No

Instructor check _____

11. V-grind the entire length of the crack from the starting point to the drilled hole.

Is the entire length of the crack V-ground? ☐ Yes ☐ No

Instructor check _____

12. The bottom of the crack should be opened 0.062 in. (2 mm) to allow proper weld penetration. A hacksaw blade may be used to open the crack.

Is the bottom of the crack open 0.062 in. (2 mm)? ☐ Yes ☐ No

Instructor check _____

13. Arc weld the crack with the electrodes specified by the frame and/or vehicle manufacturer. Complete several passes with the arc weld to fill the crack.

Is the crack filled with arc weld material? ☐ Yes ☐ No

Instructor check _____

14. Use a pointed welding hammer to remove slag from the exterior of the weld.

Is the slag removed from the weld? ☐ Yes ☐ No

Instructor check _____

Instructor's Response _____

Chapter 15

FOUR WHEEL ALIGNMENT PROCEDURE

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Perform a prealignment inspection.
- Diagnose wheel alignment and tire wear problems.
- Position a vehicle on the alignment rack and connect the wheel units on a computer wheel aligner to the wheel rims.
- Select the specifications in the computer wheel aligner for the vehicle being aligned.
- Perform a preliminary wheel alignment inspection with the preliminary inspection screen.
- Perform a ride height inspection and measurement with the ride height screen.
- Perform an automatic or manual wheel runout compensation procedure.
- Measure front wheel camber and caster.
- Measure front and rear wheel setback.
- Measure steering axis inclination (SAI).
- Measure front wheel toe and turning radius.
- Measure toe change during front wheel jounce and rebound to check steering linkage height.
- Diagnose bent front struts.
- Recognize the symptoms of improper rear wheel alignment.
- Measure rear wheel camber and toe.

WHEEL ALIGNMENT PRELIMINARY DIAGNOSIS AND INSPECTION

Customer Complaints Related to Suspension or Brakes

Drivers may experience a variety of symptoms related to incorrect wheel alignment or defective brakes (Figure 15-1). Not all the symptoms are related to wheel alignment, but the customer may request an alignment to correct these problems. The technician must diagnose and correct the cause of the specific complaint. Wheel alignment angles that affect tire wear are toe and camber. The most likely symptoms of incorrect toe or camber settings are pull to one side while driving, wander, feathered tire wear, or tire wear on one side.

Road Test

In many cases, a **road test** is necessary to verify customer complaints. During a road test, the vehicle should be driven under the conditions when the customer complaint occurred. While road-testing the vehicle, the technician should listen for any unusual noises related to suspension and steering.



BASIC TOOLS

Basic technician's
tool set

Service manual




FIGURE 15-1 Customer complaints related to wheel alignment or brakes.

Classroom Manual

Chapter 15,
page 334

Memory steer occurs when the steering does not want to steer straight ahead after a turn because the steering does not return to the straight-ahead position.

The technician should check for these steering problems during a road test:

1. Excessive vertical chassis oscillations
2. Chassis waddle
3. Steering wander, pull, or drift
4. High steering effort and binding
5. Tire squeal while cornering
6. Bump steer
7. Torque steer
8. Excessive steering wheel free play
9. Suspension bottoming on rough road surfaces
10. Wheel hop during hard acceleration
11. Nose dive while braking or rear suspension squat when accelerating
12. Excessive body sway when cornering
13. Memory steer
14. Steering wheel return

Chassis waddle may be caused by excessive tire or wheel runout. Excessive vertical chassis oscillations are the result of defective shock absorbers or struts. (Refer to Chapter 4 for tire and wheel runout diagnosis and Chapter 5 for shock absorber and strut diagnosis.)

Most steering systems are designed so the steering wheel returns to within 30° to 60° of center after a 180° turn (Figure 15-2). If the steering wheel returnability is not satisfactory and **memory steer** is evident, the steering shaft dash seal or the steering shaft universal




FIGURE 15-2 Steering wheel returnability.

joints may be binding. When memory steer occurs on a front-wheel-drive car, the upper strut mounts may be binding. High steering effort, or binding, can also be caused by a loose power steering belt, low power steering fluid level, worn front tires, or a defective steering gear.

A front-wheel-drive vehicle with unequal drive axles produces some **torque steer** on hard acceleration. Some front-wheel-drive vehicles, especially those with higher horsepower, have equal front drive axles to reduce torque steer. On a front-wheel-drive vehicle, torque steer is aggravated by different tire tread designs on the front tires or uneven wear on the front tires. Torque steer may also be aggravated by worn and sagged transaxle and engine mounts that cause improper drive axle angles.

Bump steer occurs if the tie-rods are not the same height, meaning one of the tie-rods is not parallel to the lower control arm. This condition may be caused by a bent or worn idler arm or pitman arm on a parallelogram steering linkage. On a rack and pinion steering system, worn steering gear mounting bushings may cause this unparallel condition between one of the tie-rods and the lower control arm.

Steering pull may be caused by improper caster or camber adjustments.

During a road test, any of the following symptoms may indicate improper rear wheel alignment:

1. The front wheel **toe-in** is set correctly with the steering wheel centered on the alignment rack, but the steering wheel is not centered when the vehicle is driven straight ahead.
2. When there are no worn suspension parts or defective tires and all front suspension angles are within specifications, but the vehicle wanders or drifts to one side.
3. The vehicle is not overloaded, all front suspension angles are within specifications, and there are no worn suspension parts, but tire wear recurs.

Prealignment Inspection

The technician should identify the exact suspension or steering complaint before a wheel alignment or other suspension work is performed. The technician must diagnose the cause or causes of the complaint and correct this problem during the wheel alignment (Figure 15-3). Since collision damage may affect wheel alignment angles, an inspection for collision damage on the vehicle should be completed prior to a wheel alignment (Figure 15-4).

Worn suspension and steering components must be replaced before a wheel alignment is performed. A wheel alignment should be performed after suspension components such as struts have been replaced.

The following components and measurements should be checked in a prealignment inspection:

1. Curb weight
2. Tires
3. Suspension height
4. Steering wheel free play
5. Shock absorbers or struts
6. Wheel bearing adjustment
7. Ball joint condition
8. Control arms and bushings
9. Steering linkages and tie-rod ends
10. Stabilizers and bushings
11. Full fuel tank

Components to be checked in a **prealignment inspection** and wheel alignment measurements are summarized in Figure 15-5.

These checks should be completed with the car on the floor:

Torque steer is the tendency of the steering to pull to one side during hard acceleration.

Bump steer is the tendency of the steering to veer suddenly in one direction when one or both front wheels strikes a bump.



SERVICE TIP:

If steering pull or drift is evident during the road test, drive the vehicle on the same road in the opposite direction to determine if a crosswind is causing the steering pull.

Toe-in occurs when the distance between the front edges of the front or rear tires is less than the distance between the rear edges of the tires.

Worn suspension and steering components must be replaced before a wheel alignment is performed.

After suspension components such as struts have been replaced, a wheel alignment should be performed.

Condition	Probable Cause
<p>Tire wear:</p> <p>Outer shoulder Inner shoulder Sawtooth pattern: Sharp edge towards center Sharp edge away from center</p> <p>Both shoulders Tread roll under Cupping, dishing Diagonal wipe</p>	<p>Too much positive camber Too much negative camber</p> <p>Too little toe-in Too much toe-in Underinflation, high-speed cornering, overloading High speed in curves Wheel imbalance, radial runout Incorrect rear toe FWD Vehicle</p>
<p>Shimmy:</p> <p>With or without vehicle instability</p> <p>Without instability</p>	<p>Too much positive caster, unequal caster between wheels Tire imbalance, tire runout, driveline vibration</p>
<p>Vibration:</p> <p>(Caster/camber not a probable cause. The condition is listed because it is sometimes misdiagnosed as shimmy.)</p>	<p>Driveline misalignment, driveline imbalance, vehicle shake (accompanied by a characteristic moan), tire runout, unequal weight distribution between wheels</p>
Steering wander/pull	<p>Incorrect camber Unequal caster Overload, which elevates front end</p>
Brake pull	<p>Too much negative caster Unequal tire pressure, brake line damage that impedes hydraulic action on one side</p>
Hard steering	<p>Incorrect caster Damaged steering linkage, worn steering linkage, damaged spindles, rear-end overload, bent steering arm causing incorrect turning angle</p>

FIGURE 15-3 Diagnosis of wheel alignment problems.

1. Inspect for excessive mud adhered to the chassis. Remove heavy items from the trunk and passenger compartment that are not considered in the vehicle curb weight. If heavy items such as tool display cases or merchandise are normally carried in the vehicle, these items should be left in the car during a wheel alignment.

Look at the complete vehicle

If you suspect collision damage to the inner body panels, measure the reference points or body and frame alignment as described in the service manual.




FIGURE 15-4 Collision damage inspection.

2. Inflate tires to the recommended pressure and note any abnormal tread wear or damage on each tire. Be sure all tires are the same size.
3. Check the front tires and wheels for radial runout. (Refer to Chapter 4 for this measurement.)
4. Check the suspension **ride height**. If this measurement is not within specifications, check for broken or sagged springs. On a torsion bar suspension system, check the torsion bar adjustment.
5. Inspect front and rear suspension bumpers. Worn bumpers may indicate weak springs or worn-out shock absorbers or struts.
6. When the wheels are in the straight-ahead position, rotate the steering wheel back and forth to check for play in the steering column, steering gear, or linkages.
7. Inspect the shock absorbers or struts for loose mounting bushings and bolts. Examine each shock absorber or strut for leakage.
8. Inspect the condition of each shock absorber or strut with a bounce test at each corner of the vehicle. (This test is explained in Chapter 5.)

The following checks should be performed with the vehicle raised and the suspension supported:

1. Inspect the front wheel bearings for lateral movement. (This inspection is described in Chapter 3.) On front-wheel-drive vehicles, perform this inspection on all four wheel bearings. Wheel bearings must be properly adjusted prior to a wheel alignment. Clean, repack, or adjust the wheel bearings as necessary.
2. Measure the ball joint radial and axial movement. If excessive movement exists in either direction, ball joint replacement is required. (Ball joint diagnosis and replacement is explained in Chapter 6.) Be sure the suspension is supported correctly during ball joint diagnosis.
3. Inspect the control arms for damage and inspect the control arm bushings for wear.
4. Inspect all the steering linkages and tie-rod ends for looseness.
5. Inspect for worn stabilizer mounting links and bushings.
6. Inspect for loose steering gear mounting bolts and worn mounting brackets and bushings.

Tire Wear Diagnosis

Various types of tire tread wear patterns indicate specific alignment or balance defects (Figure 15-6).

A **prealignment inspection** of all steering and suspension components must be completed before a wheel alignment procedure.



SERVICE TIP:

Decreasing the rear ride height 1 in. (25.4 mm) moves the front wheel caster 1° more positive.

Ride height is the distance from a specified location on the front or rear suspension to the road surface.

Improper camber settings cause wear on one side of the front tire treads.

PREALIGNMENT INSPECTION CHECKLIST

Owner _____ Phone _____ Date _____

Address _____ VIN _____

Make _____ Model _____ Year _____ Lic. number _____ Mileage _____

1. Road test results		Yes	No	Right	Left	7. Ball joints				OK		
Above 30 MPH						Load bearings						
Below 30 MPH						Specs		Readings				
Bump steer						Right _____ Left _____		Right _____ Left _____				
When braking						Follower						
Steering wheel movement						Upper strut bearing mount						
Stopping from 2 to 3 MPH(Front)						Rear						
Vehicle steers hard						8. Power steering				OK		
Strg wheel returnability normal						Belt tension						
Strg wheel position						Fluid level						
Vibration		Yes	No	Frnt	Rear	Leaks/hose fittings						
						Spool valve centered						
2. Tire pressure		Specs Frnt _____ Rear _____				9. Tires/wheels				OK		
Record pressure found						Wheel runout						
RF _____ LF _____ RR _____ LR _____						Condition						
3. Chassis height		Specs Frnt _____ Rear _____				Equal tread depth						
Record height found						Wheel bearing						
RF _____ LF _____ RR _____ LR _____						10. Brakes operating properly						
Springs sagged		Yes		No		11. Alignment						
Torsion bars adjusted						Spec		Initial reading		Adjusted reading		
							R	L	R	L	R	L
						Camber						
						Caster						
						Toe						
4. Rubber bushings		OK				Bump steer		Toe change right wheel		Toe change left wheel		
Upper control arm								Amount		Direction		
Lower control arm								Amount		Direction		
Sway bar / stabilizer link								Amount		Direction		
Strut rod								Amount		Direction		
Rear bushing								Amount		Direction		
5. Shock absorbers/struts		Frnt		Rear		Chassis down 3"						
						Chassis up 3"						
6. Steering linkage		Frnt OK		Rear OK		Spec		Initial reading		Adjusted reading		
Tie-rod ends							R	L	R	L	R	L
Idler arm						Toe-out on turns						
Center link						SAI						
Sector shaft						Rear camber						
Pitman arm						Rear total toe						
Gearbox/rack adjustment						Rear indiv. toe						
Gearbox/rack mounting						Wheel balance						
						Radial tire pull						

FIGURE 15-5 Prealignment inspection and wheel alignment checklist.














Conditions	Rapid wear at shoulders	Rapid wear at center	Cracked treads	Wear on one edge	Feathered edge	Diagonal wipe rear tire FWD vehicles	Scalloped wear
Effect							
Causes	Underinflation or lack of rotation	Overinflation or lack of rotation	Underinflation or excessive speed	Excessive camber	Incorrect toe	Incorrect wheel toe	Lack of rotation of tires or worn or out-of-alignment suspension
							
Corrections	Adjust pressure to specifications when tires are cool. Rotate tires.			Adjust camber to specs	Adjust toe to specs	Perform rear wheel alignment	Rotate tires and inspect suspension

FIGURE 15-6 Tire tread wear patterns and causes.

FOUR WHEEL ALIGNMENT WITH COMPUTER ALIGNMENT SYSTEMS

Preliminary Procedure

 **WARNING:** When using a computer wheel aligner, always follow the equipment manufacturer's recommended procedures to provide accurate readings and to avoid equipment and vehicle damage or personal injury.

The vehicle should be on an **alignment ramp** with a **turntable** under each front tire and conventional **slip plates** under the rear tires (Figure 15-7). Slip plates under the rear tires allow unrestricted movement of the rear wheels during rear wheel camber and toe adjustments (Figure 15-8). If suspension adjustments are made with the tires contacting the alignment ramp or the shop floor, the tires cannot move when the adjustment is completed. This action causes inaccurate suspension adjustments. The center of the front wheel spindles should be in line with the zero mark on the turning plates. The locking pins must be left in these plates and the parking brake applied.

Mount the **rim clamps** on each wheel. It may be necessary to remove the chrome discs or hub caps before these clamps can be installed. The adjustment knob on the rim clamp should be pointing toward the top of the wheel, and the bubble on the wheel unit should be centered (Figure 15-9). A set knob on the wheel unit allows the service technician to lock the wheel unit in this position. Some computer wheel aligners have a display on the monitor that indicates if any of the wheel sensors are not level (Figure 15-10). These sensors may be leveled by pressing a control knob on each wheel sensor. Some **digital signal processor (DSP)** wheel sensors contain a microprocessor and a **high-frequency transmitter** that acquire measurements and process data and then send these data to a **receiver** mounted on top of

An **alignment ramp** is a special steel ramp on which the vehicle is positioned for a wheel alignment.



SPECIAL TOOLS

Computer wheel aligner

A **turntable** is placed under each front wheel during a wheel alignment. The turntables allow the wheels to turn, and they also allow the wheels to move during alignment adjustments.




FIGURE 15-7 Alignment ramp with turntables.




FIGURE 15-8 Rear wheel slip plates. (Courtesy of Snap-On Tools Corp.)

Slip plates under the rear wheels allow the wheels to move during alignment adjustments.

Classroom Manual

Chapter 15,
page 337

Rim clamps mount each wheel sensor to the rim.

A **digital signal processor (DSP)** in each wheel sensor provides digital signals indicating wheel alignment angles.

A **high-frequency transmitter** in each wheel sensor processes data from the DSP and transmits this data to the computer wheel aligner.

the wheel alignment monitor. This type of wheel sensor does not require any cables connected between the sensors and the computer wheel aligner. The data from this type of wheel sensor signal are virtually uninterrupted, even by solid objects. When these wheel sensors are stored on the computer wheel aligner, a “docking station” feature charges the batteries in the wheel sensors.

Some wheel sensors contain infrared emitter/detectors or light-emitting diodes (LEDs) between the front and rear wheel sensors to perform alignment measurements. Older wheel sensors have strings between the front and rear wheel sensors. Each wheel sensor contains a microprocessor with a preheat circuit that stabilizes the readings in relation to temperature. Some wheel sensors have touch keypads on the wheel units to allow the entry of commands from each unit. The front wheel units have arms that project toward the front of the vehicle to transmit signals between these units. When a blocked beam prompt appears on any screen,



FIGURE 15-9 Rim clamp and wheel sensor.




FIGURE 15-10 Wheel sensor level indicator on the monitor screen.

the beam between two wheel units is blocked. This could be caused by a person standing in the beam, an open car door, or a suspension jack. The blocked beam prompt must be eliminated before any tests are completed.

The manufacturers of various types of computer alignment systems publish detailed operator's manuals for their specific equipment. Our objective here is to discuss some of the general screens that a technician uses while measuring wheel alignment angles with a typical computer aligner.

Main Menu

One of the first items displayed on the computer aligner screen is the **main menu** screen. From this screen, the technician makes a selection by touching the desired selection on the monitor screen with a mouse (Figure 15-11) or by pressing the number on the keypad that matches the number beside the desired procedure. A cursor may also be used to select the type of alignment.

A **receiver** mounted on or in the computer wheel aligner receives data from the high-frequency transmitters in the wheel sensors.




FIGURE 15-11 Making screen selections with a mouse.




FIGURE 15-12 Entering vehicle specifications.

Specifications Menu

Some computer wheel aligners have specifications contained on CDs. The appropriate CD must be placed in the aligner. Several methods may be used to enter the vehicle specifications. The technician may scroll through the **specifications menu** and then press Enter when the appropriate vehicle is highlighted on the screen (Figure 15-12). The technician may also select the proper vehicle specifications by pointing with the light pen or by typing in the vehicle identification number (VIN) or the first letter in the vehicle make.

On other computer wheel aligners, the specifications are contained on a floppy disk and the technician selects the appropriate make, model, and year of vehicle with the cursor on the screen.

On early computer alignment systems, the vehicle specifications were contained on bar graphs. The technician moved a wand across the appropriate bar graph to enter the specifications for the vehicle being aligned.

Preliminary Inspection Screen

The **preliminary inspection screen** allows the technician to enter the condition of all front and rear suspension components that must be checked during a prealignment inspection. On some computer alignment systems, the technician may enter checked, marginal, and repair or replace for each component (Figure 15-13). These entered conditions may be printed out at any time or with the complete wheel alignment results.




FIGURE 15-13 Preliminary inspection screen.

Ride Height Screen

Some computer wheel aligners have optical encoders in the wheel sensors that measure ride height when this selection is displayed on the screen and the ride height attachment on each wheel sensor is lifted until it touches the lower edge of the fender (Figure 15-14). The ride height measurement is displayed on the screen. If the screen display is green, the ride height is within specifications. A red ride height display indicates this measurement is not within specifications. Improper ride height may be caused by sagged or broken springs, bent components such as control arms, or worn components such as control arm bushings.

Some computer wheel aligners provide a **ride height screen** with a graphic display indicating the exact location where the ride height should be measured (Figure 15-15). The computer aligner compares the ride height measurements entered by the technician to the specifications.



CAUTION:

The ride height must be within specifications before proceeding with the wheel alignment. Improper curb riding height affects many of the other suspension angles.

Tire Condition Screen

When the **tire inspection screen** is displayed, the technician may enter various tire wear conditions for each tire (Figure 15-16). The cursor on the screen is moved to the tire being inspected. The tire conditions are printed out with the preliminary inspection results and




FIGURE 15-14 Ride height screen and ride height attachment in wheel sensor.




FIGURE 15-15 Ride height screen.




FIGURE 15-16 Tire inspection screen.

the alignment report. On other computer wheel aligners, tire condition is included in the preliminary inspection screens.

Wheel Runout Compensation

As mentioned previously, screen indicators on some computer wheel aligners inform the technician if any of the wheel sensors require leveling or compensating for wheel runout. Runout compensation is accomplished by pressing the appropriate button on each wheel sensor. Some wheel sensors provide continuous compensation. This feature provides accurate alignment angles even when a wheel is rotated after the compensation button on the wheel sensor has been pressed. When the wheel runout screen is displayed, the technician is directed to level and lock each wheel unit and then press the compensation button on each wheel sensor to provide automatic wheel runout compensation (Figure 15-17).

If the computer aligner does not have automatic wheel runout compensation, a manual wheel runout procedure must be followed. This type of computer aligner displays a wheel




FIGURE 15-17 Wheel runout compensation screen.

runout measurement screen. During this procedure, the wheel being checked for runout is lifted with the hydraulic jack on the alignment rack and the wheel is rotated until the rim clamp knob faces downward. Level and lock the wheel unit in this position; then push Yes on the wheel unit as instructed on the screen. Rotate the wheel until the rim clamp knob faces upward; then level and lock the wheel unit. After this procedure, press Yes on the wheel unit. This same basic procedure is followed at each wheel.

WHEEL ALIGNMENT SCREENS

Front and Rear Wheel Alignment Angle Screen

Prior to a display of the **front and rear wheel alignment angle screen** on some computer wheel aligners, the screen display directs the technician to position the front wheels straight ahead, lock the steering wheel, apply the **brake pedal depressor**, and level and lock the wheel units. See Photo Sequence 27. The brake pedal depressor is an adjustable rod installed between the front edge of the front seat and the brake pedal (Figure 15-18). If the vehicle has power brakes, the engine should be running when the depressor is used to apply the brakes. Some steering wheel holders are installed between the steering wheel and the top of the front seat (Figure 15-19). A ratchet and handle on the steering wheel holder allow extension of this holder.

After the wheel runout compensation procedure is completed at each wheel sensor, some computer wheel aligners automatically display **camber**, toe-in or **toe-out**, **total toe**,



FIGURE 15-18 Brake pedal depressor.



FIGURE 15-19 Steering wheel holder.



SERVICE TIP:

Many computer wheel aligners can print out any single screen. It may be helpful to print out the wheel alignment angle screen before and after the alignment angles are adjusted to the vehicle manufacturer's specifications. These printouts may be presented to the customer; many customers appreciate this service.

Camber is the tilt of a line through the tire and wheel centerline in relation to the true vertical centerline of the tire and wheel.

Toe-out is present when the distance between the front edges of the front or rear wheels is more than the distance between the rear edges of the front or rear wheels.

Total toe is the sum of the toe settings on the front wheels.

PHOTO SEQUENCE 27

TYPICAL PROCEDURE FOR PERFORMING FOUR-WHEEL ALIGNMENT WITH A COMPUTER WHEEL ALIGNER




P27-1 Position the vehicle on the alignment ramp.




P27-2 Be sure the front tires are positioned properly on the turntables.




P27-3 Position the rear wheels on slip plates.




P27-4 Attach the wheel units.



P27-5 Select the vehicle make and model year.




P27-6 Check items on the screen during preliminary inspection.



P27-7 Display the ride height screen.




P27-8 Check the tire condition for each tire on the tire condition screen.



P27-9 Display the wheel runout compensation screen.


PHOTO SEQUENCE 27 (CONTINUED)



P27-10 Display the front and rear wheel alignment angle screen.



P27-11 Display the turning angle screen and perform the turning angle check.



P27-12 Display the adjustment screens.




FIGURE 15-20 Wheel swing instructions on the screen.

setback, and **thrust line** measurements on the front and rear suspension. After this procedure, the screen directs the technician to swing the front wheels outward a specific amount (Figure 15-20). The steering wheel holder must be released and the lock pins removed from the front turntables before the wheel swing procedure. This front wheel swing may be referred to as a **caster/SAI swing**. The amount of front wheel swing varies depending on the make of the computer aligner. Older computer wheel aligners required the technician to read the degrees of wheel swing on the turntable degree scales. On some newer computer wheel aligners, the required amount of wheel swing is illustrated on the screen (Figure 15-21).

After the front wheel swing procedure, all the front and rear wheel alignment angles are displayed, including **caster**, **steering axis inclination (SAI)**, and **included angle** (Figure 15-22). Some computer wheel aligners highlight any wheel alignment angles that are not within specifications. If cross camber and cross caster are displayed on the screen, these readings indicate the maximum difference allowed between the right and left side readings. Alignment angles within specifications are highlighted in green; alignment angles that are not within specifications are highlighted in red.

Setback is the distance that one front or rear wheel is moved rearward in relation to the opposite front or rear wheel.

The **thrust line** is positioned at 90° in relation to the rear axle, and this line projects forward.

Caster is the tilt of a line through the centers of the lower ball joint and upper strut mount in relation to a vertical line through the center of the wheel and spindle as viewed from the side.

The **steering axis inclination (SAI)** line is an imaginary line through the centers of the upper and lower ball joints or through the center of the lower ball joint and the upper strut mount.



FIGURE 15-21 Wheel swing procedure illustrated on the screen.

Vehicle Measurements and Adjustments			
Chevrolet Truck & Rear Wheel Drive Van : K Series/Silverado (HX4) 1972-2001 Pickup : 1999-2000 : Silverado (GM1800) : 1500			
Front	Left	Right	
Camber	0.4°	-0.2°	
Cross Camber		0.6°	
Caster	4.0°	4.3°	
Cross Caster		-0.4°	
SAI	10.3°	11.3°	
Cross SAI		-1.0°	
Toe	-0.04°	0.10°	
Total Toe		0.06°	
Rear	Left	Right	
Camber	-0.1°	-0.5°	
Cross Camber		0.4°	
Toe	0.15°	-0.05°	
Total Toe		0.10°	
Thrust Angle		0.10°	
Save the "before" alignment measurements.			
Show Virtual View		Show Secondary Measurements	Save "Before" Measurements

FIGURE 15-22 Front and rear wheel alignment screen.

The SAI angle is the angle between the SAI line and the true vertical centerline of the tire and wheel.

The **included angle** is the sum of the SAI angle and the camber angle if the camber is positive. If the camber is negative, the camber setting must be subtracted from the SAI angle to obtain the included angle.

Turning Angle Screen


Some computer wheel aligners have a turning angle screen. When this screen is displayed, the technician removes the locking pins from the turntables. Each front wheel must be turned outward a specified amount, and the turning angle on the opposite front wheel must be entered with the keypad as directed on the screen (Figure 15-23). A toe-out on turns option is available on some DSP wheel sensors. This option has optical encoders in the wheel sensors that measure the turning angle electronically rather than reading the degree scales on the front turntables. Photo Sequence 28 shows a manual procedure for measuring turning angle.

WinAlign 10.0 Software with Advanced Vehicle Handling (AVH)

Advanced vehicle handling (AVH) is a standard feature of WinAlign 10.0 computer alignment software. AVH allows the technician to locate the cause of hidden suspension, chassis, and body problems prior to alignment adjustments. All chassis and suspension components should be inspected during the preliminary alignment inspection, and any worn or defective components must be replaced prior to using the AVH alignment software. AVH measurements include the following:

1. **Caster offset** – Caster offset is the distance from the caster line to the center of the front spindle (Figure 15-24). Caster offset may be called **caster trail**. Assuming the right and

Left front wheel
turned outward
20°



Right front wheel
turned inward
18°




FIGURE 15-23 Turning angle screen.





FIGURE 15-24 Caster offset measurement.




FIGURE 15-25 Rolling force lever measurement.

left caster angles are equal, if the right and left caster offset measurements are not equal, suspension components such as the strut or spindle may be worn or bent. Unequal caster offset may cause steering pull or drift.

2. Rolling force lever geometry – The rolling force lever distance is measured from the caster line viewed from the front or rear to a line parallel to the caster line and intersecting the outer end of the spindle (Figure 15-25). If the left and right rolling force lever measurements are unequal, steering pull or drift may occur. Assuming that all suspension and steering components are satisfactory, if the left and right rolling force lever measurements are not equal, one of the spindles is likely bent.
3. Body centerline angle and body centerline offset – Body centerline angle and offset isolates body and chassis centerline. Body centerline and/or body centerline offset problems may indicate collision damage that has not been properly corrected.
4. Body overhang – Body overhang indicates unequal left and right body overhang which usually indicates worn or damaged body mounts or collision damage.
5. Excessive body roll angle when vehicle is steered – This usually indicates defective or worn suspension components such as the stabilizer bar and related parts.
6. Track circle and curb-to-curb distance measurements – If these measurements are not correct, suspension components such as control arms may be defective or bent.
7. Bump steer – Measures suspension angles in relation to suspension movement.

AVH alignment software enables the technician to find the cause(s) of steering problems such as unusual pull complaints including steering pull while braking, excessive torque steer, and bump steer. Locating and correcting the root cause of these problems eliminates steering related comebacks.

ADJUSTMENT SCREENS

The technician may select adjustment screens that provide bar graph readings of camber, caster, and toe. An arrow on the bar graph shows the amount and direction the actual measurement is from the preferred specification. As the alignment angle is adjusted, the arrow moves. If an alignment angle moves from out of the specification range to within the specification

PHOTO SEQUENCE 28

TYPICAL PROCEDURE FOR FRONT WHEEL TURNING RADIUS MEASUREMENT



P28-1 Perform a prealignment inspection.



P28-2 Measure and adjust the other front and rear suspension angles.



P28-3 Be sure the front wheels are centered on the turntables and the brake pedal jack is installed to apply the brakes.



P28-4 Remove the turntable locking pins and be sure the turning radius gauges are in the zero position with the front wheels straight ahead.



P28-5 Turn the right front wheel inward toward the center of the vehicle until the turning radius gauge indicates 20°.



P28-6 With the front wheels positioned as described in step 5, read and record the reading on the left turning radius gauge. The reading on the left turning radius gauge should be 22°, or 2° more than the reading on the right turning radius gauge.



P28-7 Turn the left front wheel inward toward the center of the vehicle until the turning radius gauge indicates 20°.



P28-8 With the front wheels positioned as described in step 7, read and record the reading on the right turning radius gauge. The reading on the right turning radius gauge should be 22°, or 2° more than the reading on the left turning radius gauge.




FIGURE 15-26 Alignment angle adjustment screens.

Axle offset occurs when the rear axle is rotated so it is no longer at a 90° angle to the vehicle centerline.

Lateral axle sideset occurs when the rear axle moves inward or outward in relation to the vehicle centerline, but the axle and vehicle centerline remain at a 90° angle.

range, the bar graph color changes from red to green (Figure 15-26). When the arrow on the bar graph is in the zero position, the alignment angle is at the preferred specification. A zoom feature on some computer wheel aligners provides enlarged bar graphs so they may be seen at a distance while performing the actual suspension adjustments (Figure 15-27). Some computer aligners have a jack and hold feature that allows the suspension to be lifted on the alignment rack to perform an adjustment while maintaining accurate displays on the adjustment screen. Other computer wheel aligners have a remote display that may be connected to the aligner and taken under the car for close-up viewing while performing suspension adjustments (Figure 15-28). The remote display duplicates the bar graphs shown on the monitor screen.

Some computer wheel aligners provide **symmetry angle measurements** that help the technician determine if out-of-specification readings may have been caused by collision or frame damage. These symmetry angle measurements display **axle offset**, right or left **lateral axle sideset** and track-width difference, front and rear wheel setback, and wheelbase difference (Figure 15-29). Setback is an angle formed by a line drawn at a 90° angle to the centerline and a line connecting the centers of the front or rear wheels (Figure 15-30). Wheelbase difference is an angle created by a line through the rear wheel centers and a line through the front wheel centers (Figure 15-31). Right or left lateral offset is an angle between the thrust line and a line connecting the centers of the left front and left rear wheels or right front and right rear wheels (Figure 15-32). Track-width difference is an angle created by the line



FIGURE 15-27 Zoom feature on adjustment screens.




FIGURE 15-28 Remote display for computer wheel aligner.




FIGURE 15-29 Symmetry angle measurements.




FIGURE 15-30 Front or rear wheel setback.




FIGURE 15-31 Wheelbase difference.




FIGURE 15-32 Right or left lateral sideset.




FIGURE 15-33 Track-width difference.




FIGURE 15-34 Axle offset.

connecting the centers of the right rear and right front wheels and the line connecting the centers of the left rear and left front wheels (Figure 15-33). Axle offset is an angle formed by the line that is projected forward at 90° in relation to the center of the rear axle and the thrust line (Figure 15-34).

DIAGNOSTIC DRAWING AND TEXT SCREENS

The technician may select tools and kits for the vehicle being serviced from the tools and kits database. When this feature is selected, the monitor screen displays the necessary wheel alignment adjustment tools for the vehicle selected at the beginning of the alignment (Figure 15-35). The kits displayed on the monitor screen are special components such as adjustment shims that are available for alignment adjustments on the car being serviced.

The technician may select **digital adjustment photos** that indicate how to perform wheel alignment adjustments (Figure 15-36). These digital photos include photos for cradle inspection and correction of cradle-to-body alignment (Figure 15-37). Live-action videos can also be selected. These CD videos provide suspension component inspection procedures (Figure 15-38).

A **part-finder database** is available in some computer wheel aligners. This database allows the technician to access part numbers and prices from many under-car parts manufacturers.

On many front-wheel-drive cars, the rear wheel camber and toe are adjusted with shims. Some computer aligners have a **shim display screen** that indicates the thickness of shim required and the proper position of the shim. On some computer wheel aligners, the technician may use the light pen to change the orientation angle of the shim on the monitor screen while observing the resulting change in camber and toe (Figure 15-39). Some computer wheel




FIGURE 15-35 Wheel alignment tools and kits display.




FIGURE 15-36 Wheel alignment adjustment photos.




FIGURE 15-37 Cradle inspection and correction photos.



FIGURE 15-38 Live-action videos of suspension inspection and service.




FIGURE 15-39 Shim selection screen.




FIGURE 15-40 Automatic bushing calculation screen.





FIGURE 15-41 Control arm movement monitor indicates the required shim thickness to provide specified camber and caster.

aligners provide an automatic bushing calculator screen (Figure 15-40). This screen shows the required bushing and the proper bushing position to obtain the specified camber and caster on twin I-beam front suspension systems.

A **control arm movement monitor** is available on some computer wheel aligners. On short-and-long arm front suspensions, this feature indicates the required shim thickness to provide the specified camber and caster (Figure 15-41).

On some computer wheel aligners, the technician may select Print at any time, and print out the displayed screen, including diagnostic drawings. Another optional procedure is to print out the wheel alignment report before and after the adjustment of wheel alignment angles.

CHECKING TOE CHANGE AND STEERING LINKAGE HEIGHT

If the steering linkage on each side is not the same height, a condition called bump steer may occur. When bump steer occurs, the steering suddenly swerves to one side when one of the front wheels strikes a road irregularity. When this steering linkage condition is present, abnormal toe changes occur during wheel jounce and rebound.

Follow this procedure to check for abnormal toe changes during wheel jounce and rebound:

1. Be sure the toe is adjusted to specifications with the front wheels centered and the steering wheel locked.
2. Pull the chassis downward approximately 3 in. (7.6 cm) and observe the toe change. It is acceptable if the toe setting on each front wheel remains at the original reading or if each front wheel toes in or toes out an equal small amount (Figure 15-42).
3. During wheel jounce, if one front wheel toes inward or outward while the opposite wheel remains at the original setting, the steering linkage height is not equal and must be corrected (Figure 15-43).
4. During wheel jounce, if one front wheel toes in and the opposite front wheel toes out, the steering linkage height is unequal and must be corrected (Figure 15-44).
5. Push the chassis upward 3 in. (7.6 cm) and inspect the toe change (Figure 15-45). If the steering linkage height is equal, the toe setting on each front wheel remains the same or moves the same amount to a toe-in or toe-out position.
6. If the toe on one front wheel remains at the original setting while the opposite front wheel toe changes to a toe-in or toe-out setting, the steering linkage height is unequal. When one front wheel moves to a toe-in position, and the opposite front wheel moves to a toe-out setting, unequal steering linkages are indicated.




FIGURE 15-42 Normal toe change during wheel jounce.




FIGURE 15-43 If the toe change on one front wheel remains at the original setting while the toe on the opposite wheel toes in or out during wheel jounce, unequal steering linkage height is indicated.




FIGURE 15-44 If the toe on one front wheel toes in and the toe on the opposite front wheel toes out during wheel jounce, unequal steering linkage height is indicated.




FIGURE 15-45 Pull the chassis upward 3 in. (7.6 cm) to check for improper toe change indicating unequal steering linkage height.




FIGURE 15-46 On some imported vehicles, shims between the rack and pinion steering gear and the chassis adjust the steering linkage height.




FIGURE 15-47 Measuring rack and pinion steering gear height at various locations.

On some imported vehicles, the steering linkage height can be adjusted with shims between the rack and pinion steering gear and the chassis (Figure 15-46). The idler arm may be moved upward or downward on some domestic vehicles to adjust the steering linkage height. On other vehicles, if the steering linkage height is unequal, steering components are worn or bent. These components include tie-rods, tie-rod ends, idler arms, pitman arms, and rack and pinion steering gear mounting bushings.

Another method of inspecting for equal tie-rod height on rack and pinion steering gears is to measure the distance from the center of the inner retaining bolt on the lower control arm to the alignment ramp on each side of the front suspension (distances A and B in Figure 15-47). If this distance is not equal on each side of the front suspension, one of the front springs may be sagged or such components as control arm bushings may be worn. When distances A and B are not equal, this problem must be corrected before performing the steering gear measurements. If distances A and B are equal, measure from the outer ends of the rack and pinion steering gear to the alignment ramp (distances C and D). If these distances are not equal, the rack and pinion steering gear mountings may be worn or distorted.

BENT FRONT STRUT DIAGNOSIS

Diagnostic Procedure

Front struts that are bent forward or rearward may be diagnosed as follows:

1. With the vehicle on the aligning rack and the magnetic gauges in position for the camber measurement, swing one front wheel out 10° and read the camber.

2. Turn the same wheel inward 10° and read the camber. The difference between the two readings is usually less than 4 1/2°. If the strut is bent forward or rearward, the difference in the camber readings will be excessive. A 10° difference is not uncommon.
3. Repeat steps 1 and 2 on the other front wheel.

Front struts could also be bent inward or outward. To diagnose this condition, use the following procedure:

1. With the wheel aligner in operation, sit on the front fender to load the suspension downward, and then read the camber.
2. Unload the suspension and lift up on the vehicle while the camber is recorded. The two camber readings should be within 1/2°. If the strut is bent inward or outward, the difference in the two camber readings will be excessive. A 4° to 6° camber change is not uncommon.
3. Repeat steps 1 and 2 on the other front wheel.

CUSTOMER CARE: Always concentrate on quality workmanship and customer satisfaction. Most customers do not mind paying for vehicle repairs if the work is done properly and their vehicle problem is corrected. To determine customer satisfaction, make follow-up phone calls a few days after repairing their vehicle. This indicates that you are interested in their vehicle and that you consider quality work and satisfied customers a priority.

CASE STUDY

A customer complained about erratic steering on a front-wheel-drive Dodge Intrepid. A road test revealed the car steered reasonably well on a smooth road surface, but while driving on irregular road surfaces, the steering would suddenly swerve to the right or left.

The technician performed a preliminary wheel alignment inspection and found the right tie-rod end was loose; all the other suspension and steering components were in satisfactory condition. The technician replaced the loose tie-rod end, but a second road test indicated that the bump steer problem was still present. After advising the customer that a complete wheel alignment was necessary, the technician drove the vehicle on the wheel aligner and carefully checked all front and rear alignment angles. Each front and rear wheel alignment angle was within specifications. The technician realized that somehow he had not diagnosed this problem correctly.

While thinking about this problem, the technician remembered a general diagnostic procedure he learned while studying automotive technology. This procedure stated: Listen to the customer complaints, be sure the complaint is identified, think of the possible

causes, test to locate the exact problem, and be sure the complaint is eliminated. The technician realized he had not thought much about the causes of the problem, and so he began to recall the wheel alignment theory he learned in college. He remembered that the tie-rods must be parallel to the lower control arms, and if the tie-rod height is unequal, this parallel condition no longer exists. The technician also recalled that unequal tie-rod height causes improper toe changes during wheel jounce and rebound, which result in bump steer.

An inspection of the toe during front wheel jounce and rebound indicated the toe on the right front wheel remained the same during wheel jounce and rebound, but the toe on the left front wheel moved to a toe-out position. Since the tie-rods had been inspected during the preliminary alignment inspection, the technician turned his attention to the rack and pinion steering gear mounting. He found the bushing on the right end of the steering gear was worn and loose. This bushing was replaced and all the steering gear mounting bolts were tightened to the specified torque. An inspection of the toe change during wheel jounce and rebound revealed a normal toe change.

TERMS TO KNOW

Advanced vehicle handling (AVH)
Alignment ramp
Axle offset
Brake pedal depressor
Bump steer
Camber
Caster
Caster offset
Caster trail
Control arm movement monitor
Digital adjustment photos
Digital signal processor (DSP)
Front and rear wheel alignment angle screen
High-frequency transmitter
Included angle
Lateral axle sideset
Main menu
Memory steer
Part-finder database
Prealignment inspection
Preliminary inspection screen
Receiver
Ride height
Ride height screen
Rim clamps
Road test
Setback
Shim display screen
Slip plates
Specifications menu
Steering axis inclination (SAI)
Symmetry angle measurements
Thrust line
Tire inspection screen

TERMS TO KNOW

(continued)

Toe-in

Toe-out

Torque steer

Total toe

Turntable

From this experience the technician learned the following two things:

1. His understanding of wheel alignment theory was very important in diagnosing steering problems.

2. Always be thorough! During a prealignment inspection, check all suspension and steering components, including rack and pinion steering gear mountings.

ASE-STYLE REVIEW QUESTIONS

1. While discussing a front suspension height that is 1 in. (2.54 cm) less than specified:

Technician A says the suspension height must be correct before a wheel alignment is performed.

Technician B says the lower front suspension height may be caused by worn lower control arm bushings.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

2. While performing a prealignment inspection:

Technician A says improper front wheel bearing adjustment may affect wheel alignment angles.

Technician B says worn ball joints have no effect on wheel alignment angles.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

3. While discussing a front suspension system in which the right front wheel has 2° positive camber and the left front wheel has 1/2° positive camber:

Technician A says when the vehicle is driven straight ahead, the steering will pull to the left.

Technician B says there will be excessive wear on the inside edge of the left front tire tread.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

4. When discussing unsatisfactory steering wheel returnability:

Technician A says the rack and pinion steering gear mounts may be worn.

Technician B says this problem may be caused by interference between the dash seal and the steering shaft.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

5. While discussing turning radius measurement:

Technician A says a bent steering arm will cause the turning radius to be out-of-specification.

Technician B says if the turning radius is not within specification, tire tread wear is excessive while cornering.

Who is correct?

- A. A only
- B. B only
- C. Both A and B
- D. Neither A nor B

6. While measuring and adjusting front wheel toe:

A. If the positive caster is increased on the right front wheel, this wheel moves toward a toe-in position.

B. Improper front wheel toe setting causes steering wander and drift.

C. The front wheel toe should be checked with the front wheels straight ahead.

D. Improper front wheel toe setting causes wear on the inside edge of the tire tread.

7. All of these statements about front wheel toe change during wheel jounce and rebound are true EXCEPT:

A. If one front wheel toes in and the opposite front wheel toes out during front wheel jounce and rebound, the tie-rod height is unequal.

B. If both front wheels toe in or toe out a small, equal amount during front wheel jounce and rebound, the tie-rods are parallel to the lower control arms.

C. The improper toe change during front wheel jounce and rebound may cause bump steer.

D. Improper toe change during front wheel jounce and rebound may be caused by a worn upper strut mount.

8. While using a computer wheel aligner:
 - A. The technician may select defective suspension components from a list on the screen.
 - B. It is not necessary to check or compensate for wheel runout.
 - C. If the camber bar graph is red, the camber setting is within specifications.
 - D. A wheel sensor containing a high-frequency transmitter requires a cable connected to the aligner computer.
9. While using computer wheel aligners:
 - A. On many computer wheel aligners, the technician may only print out the four-wheel alignment results.
 - B. Some wheel sensors have the capability to measure ride height and display this reading on the screen.
 - C. A front wheel swing is necessary before reading the front wheel camber.
 - D. If the computer aligner contains a control arm movement monitor, the technician has to estimate the necessary shim thickness.
10. While using computer wheel aligners:
 - A. Symmetry angle measurements display thrust angle, rear wheel toe, and rear wheel camber.
 - B. Setback is the angle formed by a line at 90° to the vehicle centerline at the axle attachment point and a line through the left and right wheel centers.
 - C. Wheelbase difference is an angle created by a line through the rear wheel centers and the thrust line.
 - D. Right or left lateral offset is an angle between a line through the left front and left rear tires and a line between the right front and right rear tires.

ASE CHALLENGE QUESTIONS

1. While discussing turning radius:

Technician A says incorrect turning radius may often be noted by tire squeal while cornering.

Technician B says to adjust turning radius toe-out on turns, turn the inner wheel to stop.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
2. The customer says that sometimes her car suddenly swerves to one side on a bump. All of the following could cause this problem EXCEPT:
 - A. Loose steering gear.
 - B. Worn tie-rods.
 - C. Sagging front springs.
 - D. Steering gear lash adjustment.
3. While discussing steering diagnosis:

Technician A says uneven half-shaft axle lengths may cause a vehicle to pull to one side when accelerating.

Technician B says abnormal toe changes can cause a vehicle to pull to one side on road irregularities.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B
4. After you have completed a front end alignment, a customer returns to your shop and complains of continued vehicle drift. To correct this problem, you should:
 - A. Inspect the manual steering gear for possible mis-centering of the sector gear.
 - B. Inspect rear wheel alignment.
 - C. Ask the customer to fill the fuel tank.
 - D. Inspect the steering column flex coupling.
5. While performing a prealignment inspection:

Technician A says a prealignment inspection should include checking the vehicle interior for heavy items.

Technician B says tools and other items normally carried in the vehicle should be included during an alignment.

Who is correct?

 - A. A only
 - B. B only
 - C. Both A and B
 - D. Neither A nor B

Name _____ Date _____

ROAD-TEST VEHICLE AND DIAGNOSE STEERING OPERATION

Upon completion of this job sheet, you should be able to road-test a vehicle and diagnose steering operation.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task E-1: Diagnose vehicle wander, drift, pull, hard steering, bump steer, memory steer, torque steer, and steering return concerns; determine necessary action.

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed

1. Road-test vehicle under such driving conditions as slow-speed driving, cornering, and normal cruising speed while driving on a straight, level road surface. Check for the following abnormal steering conditions:
2. Vertical chassis oscillations: ☐ Satisfactory ☐ Unsatisfactory
3. Chassis lateral waddle: ☐ Satisfactory ☐ Unsatisfactory
4. Steering pull to right: ☐ Satisfactory ☐ Unsatisfactory
5. Steering pull to left: ☐ Satisfactory ☐ Unsatisfactory
6. Steering effort: ☐ Satisfactory ☐ Unsatisfactory
7. Tire squeal while cornering: ☐ Satisfactory ☐ Unsatisfactory
8. Bump steer: ☐ Satisfactory ☐ Unsatisfactory
9. Torque steer: ☐ Satisfactory ☐ Unsatisfactory
10. Memory steer: ☐ Satisfactory ☐ Unsatisfactory
11. Steering wheel return: ☐ Satisfactory ☐ Unsatisfactory
12. Steering wheel free play: ☐ Satisfactory ☐ Unsatisfactory
13. Return the vehicle to the shop and inspect suspension and steering to determine the cause of abnormal conditions. List the necessary repairs and/or adjustments to correct all abnormal conditions that occurred during the road test.

Instructor's Response

Name _____ Date _____

MEASURE FRONT AND REAR WHEEL ALIGNMENT ANGLES WITH A COMPUTER WHEEL ALIGNER

Upon completion of this job sheet, you should be able to measure front and rear wheel alignment with a computer wheel aligner.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Tasks:

- E-2. Perform prealignment inspection and measure vehicle ride height; perform necessary action.
- E-3. Prepare vehicle for wheel alignment on the alignment machine; perform four-wheel alignment by checking and adjusting front and rear wheel caster, camber, and toe as required; center steering wheel.
- E-4. Check toe-out on turns (turning radius); determine necessary action.
- E-5. Check steering axis inclination (SAI) and included angle; determine necessary action.
- E-6. Check rear wheel thrust angle; determine necessary action.
- E-7. Check front wheel setback; determine necessary action.
- E-8. Check front and/or rear cradle (subframe) alignment; determine necessary action.

Tools and Materials

Computer wheel aligner

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
VIN _____ Engine type and size _____

Procedure

Task Completed _____



WARNING: When you drive a vehicle onto an alignment ramp, be sure no one is standing in front of the vehicle to avoid causing personal injury.

1. Lock the front turntables and drive the vehicle onto the alignment ramp. Apply the parking brake.

Are the front tires properly positioned on the front turntables? ☐ Yes ☐ No

Are the rear tires properly positioned on the slip plates? ☐ Yes ☐ No

Instructor check _____

2. Install the rim clamps and wheel sensors. Perform wheel sensor leveling and wheel runout compensation procedures.

Are the wheel sensors level? ☐ Yes ☐ No

Is the wheel runout compensation procedure completed? ☐ Yes ☐ No

Instructor check _____

3. Select the specifications for the vehicle being aligned.

Are the specifications selected? ☐ Yes ☐ No

Instructor check _____

4. Perform a prealignment inspection using the checklist in the computer wheel aligner. List any components that must be repaired or replaced, and explain the reasons for your diagnosis.

5. Measure the ride height.

Left front ride height _____ Specified ride height _____

Right front ride height _____ Specified ride height _____

Left rear ride height _____ Specified ride height _____

Right rear ride height _____ Specified ride height _____

State the necessary repairs to correct ride height and explain the reasons for your diagnosis.

6. Measure the front and rear suspension alignment angles following the prompts on the computer wheel aligner screen.

Left front camber _____ Right front camber _____

Cross camber _____ Specified front wheel camber _____

Specified cross camber _____

Left front caster _____ Right front caster _____

Cross caster _____ Specified front wheel caster _____

Specified cross caster _____

Left front SAI _____ Right front SAI _____

Specified SAI _____ Included angle _____

Thrust angle _____

Specified thrust angle _____

Left front toe _____

Right front toe _____

Total toe _____

Specified front wheel toe _____

Left rear camber _____

Right rear camber _____

Specified camber _____

Left rear toe _____

Right rear toe _____

Total toe _____

Specified rear wheel toe _____

State the necessary adjustments and repairs to correct front and rear suspension alignment angles and explain the reasons for your diagnosis.

7. Measure the turning radius.

Left turn: Turning radius right front wheel _____

Turning radius left front wheel _____

Specified turning radius _____

Right turn: Turning radius left front wheel _____

Turning radius right front wheel _____

Specified turning radius _____

State the necessary repairs to correct the turning radius, and explain the reasons for your diagnosis.

Instructor's Response _____

Name _____ Date _____

CHECK PROPER STEERING LINKAGE HEIGHT BY MEASURING TOE CHANGE

Upon completion of this job sheet, you should be able to check steering linkage height by measuring toe change.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task A-2: Identify and interpret suspension and steering system concerns; determine necessary action.

Tools and Materials

Computer wheel aligner

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed _____

1. Be sure the toe is adjusted to specifications with the front wheels centered and the steering wheel locked.

Toe, left front _____

Toe, right front _____

Total toe, front wheels _____

2. Pull the chassis downward approximately 3 in. (7.6 cm) and record the toe change.

Toe change left front from _____ to _____

Toe change right front from _____ to _____

3. During the wheel jounce in step 2, did the toe remain at the original setting on the left front? Amount of toe change from the original setting on the left front wheel _____

During the wheel jounce in step 2, did the toe remain at the original setting on the right front? Amount of toe change from the original setting on the right front wheel _____

4. During the wheel jounce in step 2, did the right and the left front wheels move an equal amount toward a toe-in position? Amount of toe change toward a toe-in position on both front wheels _____

5. During the wheel jounce in step 2, did one front wheel move toward a toe-in or toe-out position while the opposite front wheel remained at the original position? Amount that one front wheel moved toward a toe-in or toe-out position while the opposite front wheel remained at the original position _____

6. During the wheel jounce in step 2, did one front wheel move toward a toe-in and the opposite front wheel move toward a toe-out position?

Amount that one front wheel moved toward a toe-in position _____

Amount the opposite front wheel moved toward a toe-out position _____

7. Push the chassis upward 3 in. (7.6 cm) and inspect the toe change.

Left front toe change: from _____ to _____

Right front toe change: from _____ to _____

8. During the wheel rebound in step 7, did one front wheel remain at the original setting and the opposite front wheel move toward a toe-in or toe-out position?

Amount that one front wheel moved toward a toe-in or toe-out position while the opposite front wheel remained at the original setting _____

9. During the wheel rebound in step 7, did one front wheel move toward a toe-in position while the opposite front wheel moved toward a toe-out position?

Amount that one front wheel moved toward a toe-in position, and the amount the opposite front wheel moved toward a toe-out position _____

10. List all the abnormal conditions that indicate unequal steering arm height.

11. Inspect the front steering linkages and steering gear mountings, and list the necessary repairs to correct the improper toe change during wheel jounce and rebound. Explain the reasons for your diagnosis.

Instructor's Response _____

Chapter 16

FOUR WHEEL ALIGNMENT ADJUSTMENTS

UPON COMPLETION AND REVIEW OF THIS CHAPTER, YOU SHOULD BE ABLE TO:

- Adjust front wheel camber on various front suspension systems.
- Adjust front wheel caster on various front suspension systems.
- Correct setback conditions.
- Check and correct front engine cradle position.
- Correct SAI angles that are not within specifications.
- Adjust front wheel toe.
- Center steering wheel.
- Recognize the symptoms of improper rear wheel alignment.
- Diagnose the causes of improper rear wheel alignment.
- Perform rear wheel camber adjustments.
- Perform rear wheel toe adjustments.
- Use a track gauge to measure rear wheel tracking.
- Diagnose rear wheel tracking problems from the track gauge measurements.

Proper front and rear wheel alignment is extremely important because it affects directional stability, tire tread wear, and vehicle safety! Technicians must know how to check front and rear wheel alignment angles and diagnose the causes of steering and alignment problems. It is also essential for technicians to know how to adjust front and rear suspension angles while maintaining vehicle safety. On certain vehicles, some wheel alignment angles are considered non-adjustable by the vehicle manufacturer, but aftermarket suppliers often provide parts kits to provide adjustments on these suspension systems. This chapter provides various adjustment procedures of front and rear suspension alignment angles as summarized in Photo Sequence 29 on page 550.

WHEEL ALIGNMENT PROCEDURE

The proper procedure for front and rear wheel alignment is important since adjusting one wheel alignment angle may change another angle. For example, adjusting front wheel caster changes front wheel toe. The wheel alignment adjustment procedure is especially critical on four-wheel independent suspension systems. A front wheel adjustment procedure is provided in Figure 16-1, and a typical rear wheel adjustment procedure is given in Figure 16-2. Always follow the wheel alignment procedure in the vehicle manufacturer's service manual. On rear wheel drive vehicles the rear wheel alignment is performed first.



BASIC TOOLS

Basic technician's
tool set

Service manual

Chalk



SERVICE TIP:

Since rear wheel alignment plays a significant role in aiming or steering the vehicle, the rear wheel alignment should be corrected before adjusting front suspension angles. The rear wheel camber, toe, and thrust line must be within specifications before adjusting the front suspension angles.

Classroom Manual

Chapter 15,
page 345

A **camber adjustment** is usually a shim-type or eccentric cam-type mechanism that is used to correct the camber angle on front or rear wheels.




FIGURE 16-1 Front wheel alignment adjustment procedure.




FIGURE 16-2 Rear wheel alignment adjustment procedure.

CAMBER ADJUSTMENT
Shims

Various methods are provided by car manufacturers for camber adjustment. Some car manufacturers provide a shim-type **camber adjustment** between the upper control arm mounting and the inside of the frame (Figure 16-3). In this type of camber adjustment, increasing the shim thickness moves the camber setting to a more negative position, whereas decreasing shim thickness changes the camber toward a more positive position. Shims of equal thickness should be added or removed on both upper control arm mounting bolts to change the camber setting without affecting the caster setting.




FIGURE 16-3 Shim-type camber adjustment between upper control arm mounting and the inside of the frame.




FIGURE 16-4 Shim-type camber adjustment between upper control arm mounting and the outside of the frame.

Other vehicle manufacturers provide a shim-type camber adjustment between the upper control arm mounting and the outside of the frame (Figure 16-4). On this shim-type camber adjustment, increasing the shim thickness increases positive camber.

Older vehicles have shim-type camber adjustments, but newer vehicles have eccentric cams for this adjustment.

Eccentric Cams

Some vehicles have **eccentric cams** on the inner ends of the upper control arm to provide camber adjustment (Figure 16-5), whereas other suspension systems have eccentric cams on the inner ends of the lower control arms (Figure 16-6). If the original cam adjustment on the inner ends of the upper control arms does not provide enough camber adjustment, aftermarket upper control arm shaft kits are available that provide an extra 1 1/2° of camber adjustment (Figure 16-7). The suspension adjustments shown in Figures 16-3 through 16-7 are used on rear-wheel-drive cars with short-and-long arm front suspension systems.

Eccentric cams are out-of-round pieces of metal mounted on a retaining bolt with the shoulder of the cam positioned against a component. When the cam is rotated, the component contacting the cam shoulder is moved.




FIGURE 16-5 Cam adjustment on the inside ends of the upper control arm.




FIGURE 16-6 Cam adjustment on the inner ends of the lower control arms.




FIGURE 16-7 Upper control arm shaft kit provides an extra 1 1/2° camber adjustment.

Some MacPherson strut front suspension systems on front-wheel-drive cars have a cam on one of the steering-knuckle-to-strut bolts to adjust camber (Figure 16-8). Aftermarket camber adjustment kits that provide 2-1/2° of camber adjustment are available for many MacPherson strut suspension systems (Figures 16-9 and 16-10). Similar camber adjustment kits are available for many cars with MacPherson strut front suspension systems. On some double-wishbone front suspension systems, a graduated cam on the inner end of the lower control arm provides a camber adjustment (Figure 16-11).

On late model Ford F-150 light-duty truck 4 x 2 front suspension systems, an alignment plate is installed on the upper control arm attaching nuts when the vehicle is manufactured (Figure 16-12). If a camber or caster adjustment is required, remove the control arm attaching nuts one at a time and install eccentric cams behind the adjusting nuts (Figure 16-13). Turn the eccentric cams equally on the front and rear upper control arm attaching nuts to adjust the camber. To increase the positive caster, move the front of the upper control arm outboard and move the rear of the upper control arm inboard (Figure 16-14). If it is necessary to decrease the positive caster, move the front of the upper control arm inboard and move the rear of the upper control arm outboard (Figure 16-15). These front suspension systems




FIGURE 16-8 Eccentric steering knuckle-to-strut camber adjusting bolt, MacPherson strut front suspension.



FIGURE 16-9 Camber adjustment kits provide 2 1/2° camber adjustment on some General Motors cars.



FIGURE 16-10 Camber adjustment kits provide 2 1/2° camber adjustment on some vehicles.




FIGURE 16-11 Camber adjustment double-wishbone front suspension.




FIGURE 16-12 Alignment plate on upper control arm attaching nut.




FIGURE 16-13 Eccentric cam installed behind upper control arm attaching nut.




FIGURE 16-14 To increase the positive caster, move the front of the upper control arm (A) outboard and move the rear of the upper control arm (B) inboard.

also have eccentric cams on the lower control arm attaching bolts (Figure 16-16). However, these eccentric cams are only for factory use, and they must not be adjusted in service. When removing the lower control arms, always mark the eccentric cams on the attaching bolts and reinstall these cams in their original position.

In some front suspension systems such as on the PT Cruiser, eccentric cams are not installed to provide a camber adjustment. In these suspension systems, the manufacturer supplies slightly undersize strut bracket-to-knuckle attaching bolts which allow a 2° camber adjustment on each side of the front suspension. If a camber adjustment is required, remove




FIGURE 16-15 To decrease the positive caster move the front of the upper control arm (A) inboard and move the rear of the upper control arm (B) outboard.




FIGURE 16-16 Factory-set eccentric cam on lower control arm attaching bolts.

the strut bracket-to-knuckle attaching bolts one at a time and install the undersize bolts. Install the nuts snugly on these bolts, but do not torque the nuts. Install each bolt from the rear of the knuckle. With the car on a wheel alignment rack, pull or push the top of the tire to obtain the specified camber. After the camber is set to specifications, tighten the strut bracket-to-knuckle attaching bolts to the specified torque.

Slotted Strut Mounts and Frames

On some MacPherson strut front suspension systems, the upper strut mounts may be loosened and moved inward or outward to adjust camber (Figure 16-17). Other MacPherson strut front suspension systems do not provide a camber adjustment. For these cars, aftermarket manufacturers sell slotted upper strut bearing plates that provide camber adjustment capabilities (Figure 16-18). If the front wheel camber adjustment is not correct, check for worn components such as ball joints or upper strut mounts. Also check the engine cradle mounts. Since the inner ends of the lower control arms are attached to the engine cradle on many front-wheel-drive cars, a cradle that is out of position may cause improper camber readings.

For example, if the vehicle has been impacted on the left-front corner in a collision, the cradle may be shifted to the right. This action moves the bottom of the left-front wheel inward and the bottom of the right-front wheel outward. Therefore, the left-front wheel has excessive positive camber and the right-front wheel has too much negative camber. If the vehicle has been impacted on the left-front corner, the cradle may be squashed to some extent with the left side being moved toward the right side without moving the right side of the cradle out of position. In this case the left front wheel has excessive positive camber, and the side-to-side cradle measurements are less than specified.

A camber plate is locked in place with a pop rivet on some upper strut mounts. The pop rivet may be removed to release the camber plate (Figure 16-19). After the upper strut mount bolts are loosened, the mount may be moved inward or outward to adjust the camber. When the camber is adjusted to the vehicle manufacturer's specification, the strut mount bolts should be tightened to the correct torque and a new pop rivet installed.

On some short-and-long arm front suspension systems, the bolt holes in the frame are elongated for the inner shaft on the upper control arm. When these bolts are loosened, the upper control arm may be moved inward or outward to adjust camber (Figure 16-20).

When a camber adjustment is required on some MacPherson strut front suspensions, the vehicle manufacturer recommends removing the strut-to-steering knuckle retaining bolts and removing the strut from the knuckle. A round file is then used to elongate the lower bolt opening in the strut (Figure 16-21). Reinstall the strut and retaining bolts, but leave the nuts slightly loose on the bolts. With the vehicle in the proper position on the wheel aligner rack, grasp the tire and move the top of the tire inward or outward to obtain the desired camber adjustment, and then tighten the nuts on the strut-to-knuckle bolts to the specified torque.




FIGURE 16-17 The upper strut mounting bolts can be loosened and the mount moved inward or outward to adjust camber on some MacPherson strut front suspension systems.




FIGURE 16-18 Slotted upper strut bearing plates provide camber adjustment on some MacPherson strut front suspension systems.




FIGURE 16-19 Upper strut mount with camber plate and rivet, modified MacPherson strut front suspension.




FIGURE 16-20 Elongated bolt holes for upper control arm shaft bolts provide camber adjustment on some short-and-long arm front suspension systems.




FIGURE 16-21 Elongated lower strut-to-knuckle bolt hole for camber adjustment.

Special Adjustment Bolts

On other vehicles such as the 2005 Dodge Magnum, the vehicle manufacturer recommends loosening the cradle mounts and shifting the cradle to provide minor camber and/or caster adjustments (Figure 16-22). If the desired camber adjustment cannot be obtained by shifting the cradle, the vehicle manufacturer provides an adjustment bolt package for camber and caster adjustment. These bolts are designed to replace the inboard bolts in the lower control arm and tension strut. To adjust camber use both bolts, and to adjust caster only use a replacement bolt in the tension strut.

The wheel alignment adjustment bolts have offset grooves cut into the length of the bolts (Figure 16-23). The grooves in the adjustment bolts force the bolt to be installed in one or two ways depending on whether more positive or negative camber is required. The bolt grooves work with “bat wing” holes in the lower control arm and tension strut bushings. The original




FIGURE 16-22 Loosening cradle mounting bolts and shifting the cradle to perform minor camber adjustments.




FIGURE 16-23 Camber/caster adjustment bolt with offset grooves.




FIGURE 16-24 Adjustment bolt positions in tension strut or lower control arm bushing to provide camber adjustment.



SERVICE TIP:

The bolt in the lower control arm bushing must be installed from the rear and the tension strut bushing bolt must be installed from the front to avoid contact with other suspension components.



CAUTION:

After an adjustment bolt is installed, do not attempt to rotate the bolt. This action will damage the “bat wing” in the control arm or tension strut bushing.

non-grooved bolt is installed between the “bat wings” in the center of the tension strut or lower control arm bushing opening (Figure 16-24, view C). After the original bolt is removed from the tension strut or control arm, move the control arm or tension strut inward or outward as desired. To provide more positive camber, install the adjustment bolt grooves in the “bat wings” (Figure 16-24, view A). The adjustment bolts provide an average of 3° camber adjustment in either direction. Always install a washer under the head of the bolt. Installing the adjustment bolts in the “bat wings” (Figure 16-24, view b) provides more negative camber. After an adjustment bolt is installed, hold the head of the bolt with the proper size tool, and tighten the nut to the specified torque.

To adjust the front wheel caster, follow the same procedure, but install the adjustment bolt only in the tension strut.

Special Tools for Camber Adjustment

Some vehicle manufacturers provide a special tool for adjusting front wheel camber and caster. This tool has threaded projections on each end extending at a right angle from a turnbuckle in the center of the tool. When the turnbuckle is rotated, the tool is lengthened or shortened. The tool is installed into openings in the lower control arm and the chassis (Figure 16-25).






FIGURE 16-25 Tool installed in lower control arm and chassis openings to adjust camber/caster.



Pre-1980



1980-type
short axle

FIGURE 16-26 Adjusting camber to a more positive setting, twin I-beam front suspension.



1980-type
short axle

FIGURE 16-27 Adjusting camber to a more negative setting, twin I-beam front suspension.

After the bolt is loosened in the inner end of the control arm, the tool can be lengthened or shortened to adjust the camber and/or caster.

Camber Adjustment on Twin I-Beam Front Suspension System

On twin I-beam front suspension systems, a special clamp-type bending tool with a hydraulic jack is used to bend the I beams and change the camber setting. On a twin I-beam front suspension, the clamp and hydraulic jack must be positioned properly to adjust the camber to a more positive setting (Figure 16-26) or a more negative setting (Figure 16-27).

CASTER ADJUSTMENT PROCEDURE

Strut Rod Length Adjustment

On some suspension systems, the nuts on the forward end of the strut rod may be adjusted to lengthen or shorten the strut rod, which changes the caster setting (Figure 16-28). Shorten the strut rod to increase the positive caster.

Eccentric Cams

The same eccentric cams on the inner ends of the upper or lower control arms may be used to adjust camber or caster (Figure 16-29). If an eccentric bushing in the outer end of the upper control arm is rotated to adjust camber, this same eccentric also adjusts caster. On some double-wishbone front suspension systems, the pivot adjuster mounting bolt nuts must be loosened under the compliance pivot, and the graduated cam may then be rotated to adjust caster (Figure 16-30).




CAUTION:

Some vehicle manufacturers do not recommend bending I beams and other suspension components.



SERVICE TIP:

The vehicle manufacturer does not recommend bending the I beams to adjust front wheel camber. However, this procedure is suggested by some equipment manufacturers.



Unscrew A then tighten B to increase caster

FIGURE 16-28 Strut rod nuts can be adjusted to lengthen or shorten the strut rod to adjust caster.




FIGURE 16-29 Eccentric cams on the inner ends of the upper or lower control arms can be used to adjust camber and caster.




FIGURE 16-30 Graduated cam for caster adjustment, double-wishbone front suspension.

Classroom Manual

Chapter 15,
page 349

A strut rod may be called a radius rod.

Slotted Strut Mounts and Frames

If a **caster adjustment** is required and the suspension does not have an adjustment for this purpose, check for worn components such as upper strut mounts and ball joints. Also check the engine cradle mounts. Since the inner ends of the lower control arms are attached to the engine cradle on many front-wheel-drive cars, a cradle that is out-of-position may cause improper caster readings.

The slots in the frame at the upper control arm shaft mounting bolts provide camber and caster adjustment. If the upper strut mount is adjustable on a MacPherson strut suspension, the mount retaining bolts may be loosened and the mount moved forward or rearward to adjust caster.

When a caster adjustment is necessary, some vehicle manufacturers recommend removing the upper strut mount bolts and elongating the bolt hole openings in the strut tower with a round file to provide a caster adjustment (Figure 16-31).



WARNING: After any alignment angle adjustment, always be sure the adjustment bolts are tightened to the vehicle manufacturer's specified torque. Loose




FIGURE 16-31 Elongating upper strut mount bolt openings to provide caster adjustment.

suspension adjustment bolts will result in improper alignment angles, steering pull, and tire wear. Loose suspension adjustment bolts may also cause reduced directional stability, which could result in a vehicle accident and possible personal injury.

Caster Adjustment on Twin I-Beam Front Suspension Systems

! WARNING: Improper use of bending equipment may result in personal injury. Always follow the equipment and vehicle manufacturer's recommended procedures.

The same bending tool and hydraulic jack may be used to adjust camber and caster on twin I-beam front suspension systems. This equipment is installed on the radius rods connected from the I beams to the chassis to adjust caster. If the hydraulic jack is placed near the rear end of the radius rod and the clamp arm is positioned over the center area of this rod, the rod is bent downward in the center when the jack is operated (Figure 16-32). This bending action tilts the I beam and caster line rearward to increase positive caster.

Aftermarket parts manufacturers supply a special radius arm bushing to provide a caster adjustment on some twin I-beam front suspension systems (Figure 16-33).



SPECIAL TOOLS

Twin I-beam radius rod bending tool




FIGURE 16-32 Hydraulic jack and bending tool positioned on the radius rod to increase positive caster on a twin I-beam front suspension.




FIGURE 16-33 Radius arm bushing for caster adjustment on some twin I-beam suspension systems.

SETBACK MEASUREMENT AND CORRECTION PROCEDURE

Setback is the distance that one wheel is moved rearward in relation to the opposite wheel.

Computer wheel aligners have **setback** measuring capabilities on the front wheels. These aligners automatically display setback angles with the other front suspension alignment angles. If a front-wheel-drive vehicle has experienced collision damage on the left front, the left side of the cradle or subframe may be driven rearward (Figure 16-34). This type of collision damage also moves the bottom of the left front strut rearward to a setback condition and shifts the caster to a negative position.




FIGURE 16-34 Collision damage on the left front moves the cradle and strut rearward to a setback condition and shifts the caster to a negative position.



WARNING: Prior to any service operation where the body is going to be moved in relation to the cradle or subframe, the intermediate shaft on the rack and pinion gear must be disconnected. If this shaft is not disconnected, it may be damaged, resulting in loss of steering control, serious vehicle damage, and personal injury.



CAUTION:

If the engine cradle has to be removed or loosened, the engine support fixture must hold the engine in the normal position to prevent damage to the fan shroud, power steering hoses, and other components.

Classroom Manual

Chapter 15,
page 337

With this type of collision damage, it may be possible to adjust the caster back to the specified setting, but that does not correct the setback problem. If the caster is adjusted and the setback problem is ignored, the steering may pull to one side while driving straight ahead, especially if the setback condition is severe. The cradle must be straightened and the unitized body must be pulled back to the original measurements to correct this problem. A severely bent, distorted cradle should be replaced.

Collision damage may push a front cradle sideways. This condition may increase the positive camber on one side of the car and move the camber toward a negative position on the opposite side. When this condition is encountered, always inspect and correct the cradle position. If the camber is adjusted in this situation, the steering will not provide proper directional control.

Prior to cradle removal, an engine support fixture must be installed to support the engine and transaxle (Figure 16-35). The engine support fixture must hold the engine in the original position to prevent damage to the power steering hoses or other components.

Before the body is moved in relation to the cradle or subframe, the intermediate shaft on the rack and pinion steering gear must be disconnected to prevent damage to this shaft. Remove all the engine and transaxle mount bolts in the cradle, plus the cradle retaining bolts and insulators to remove the cradle. Perform the front underbody measurements with a tram gauge (Figure 16-36), and pull the unitized body back to these specifications. This pulling operation is usually done in an automotive body shop rather than an automotive repair shop.

The cradle must be restored to the specified measurements (Figure 16-37). Inspect all cradle insulators and replace any that are damaged, oil soaked, or worn. When the cradle




FIGURE 16-35 Engine support fixture installed to support engine and transaxle prior to cradle removal.




FIGURE 16-36 Front and rear underbody measurements.




FIGURE 16-37 Front cradle measurements.

is replaced, all the insulators must be installed properly, and all the cradle bolts should be aligned with the bolt holes in the body. Alignment hole A in the cradle must be perfectly aligned with the matching alignment hole in the body (Figure 16-38). Observing this alignment hole is a quick way to check cradle position.




FIGURE 16-38 Cradle insulators and alignment holes in cradle and body.

STEERING AXIS INCLINATION (SAI) CORRECTION PROCEDURE

Steering axis inclination (SAI) is not considered adjustable. If the SAI is not within specifications, the upper strut tower may be out of position, the lower control arm may be bent, or the center cross member, or cradle, could be shifted. In most cases, these defects are caused by collision damage. When the SAI angle is correct, but the camber and included angle are less than specified, the strut or spindle may be bent. The difference in the included angles on the front wheels must not exceed 1°.

When the SAI is not within specifications, steering pull may occur while braking or accelerating and steering may be erratic on road irregularities.

The **steering axis inclination (SAI)** line is an imaginary line through the centers of the upper and lower ball joints, or through the center of the lower ball joint and the upper strut mount. The SAI angle is the angle between the SAI line and the true vertical centerline of the tire and wheel.

TOE ADJUSTMENT

WARNING: Do not heat tie-rod sleeves to loosen them. This action may weaken the sleeves, resulting in sudden sleeve failure, loss of steering control, personal injury, and vehicle damage.

WARNING: Do not use a pipe wrench to loosen tie-rod sleeves. This tool may crush and weaken the sleeve, causing sleeve failure, loss of steering control, personal injury, and vehicle damage. A tie-rod rotating tool must be used for this job.

When a front wheel toe adjustment is required, apply penetrating oil to the tie-rod adjusting sleeves and sleeve clamp bolts. Loosen the tie-rod adjusting sleeve clamp bolts enough to allow the clamps to partially rotate. One end of each tie-rod sleeve contains a right-hand thread; the opposite end contains a left-hand thread. These threads match the threads on

Classroom Manual

Chapter 16,
page 362



SPECIAL TOOLS

Tie-rod sleeve rotating tool

Total toe is the sum of the toe settings on the front wheels.

Classroom Manual
Chapter 16,
page 362

the tie-rod and outer tie-rod end. When the tie-rod sleeve is rotated, the complete tie-rod, sleeve, and tie-rod end assembly is lengthened or shortened. Use a tie-rod sleeve rotating tool to turn the sleeves until the toe-in on each front wheel is equal to one-half the **total toe** specification (Figure 16-39).

After the **toe-in** adjustment is completed, the adjusting sleeve clamps must be turned so the openings in the clamps are positioned away from the slots in the adjusting sleeves (Figure 16-40). Replace clamp bolts that are rusted, corroded, or damaged, and tighten these bolts to the specified torque.

On some rack and pinion steering gears, the tie-rod locknut is loosened and the tie-rod is rotated to adjust toe on each front wheel (Figure 16-41). Prior to rotating the tie-rod, the small outer bellows boot clamp should be removed to prevent it from twisting during tie-rod rotation. After the toe-in adjustment, the tie-rod locknut must be torqued to specifications, and the small bellows boot clamp must be reinstalled.

On other rack and pinion steering gears, the tie-rod and outer tie-rod end have internal threads, and a threaded adjuster is installed in these threads. One end of the adjuster has a




FIGURE 16-39 Rotating tie-rod sleeves to adjust front wheel toe.




FIGURE 16-40 Proper tie-rod adjusting sleeve and clamp position.




FIGURE 16-41 Rotating tie-rod to adjust the toe on a rack and pinion steering gear.




FIGURE 16-42 Rack and pinion steering gear with externally threaded toe adjuster and internal threads on the tie-rod and outer tie-rod end.

right-hand thread, and the opposite end has a left-hand thread. Matching threads are located in the outer tie-rod end and tie-rod. Clamps on the outer tie-rod end and tie-rod secure these components to the adjuster. A hex-shaped nut is designed into the center of the adjuster (Figure 16-42). After the clamps are loosened, an open-end wrench is placed on this hex nut to rotate the adjuster and change the toe setting.

When the toe-in adjustment is completed, the toe must be set within the manufacturer's specifications with the steering wheel in the centered position. If the steering wheel is not centered, a centering adjustment is required.

MANUAL STEERING WHEEL CENTERING PROCEDURE

Road test the vehicle and determine if the steering wheel spoke is centered when the vehicle is driven straight ahead.

If steering wheel centering is necessary, follow this procedure:

1. Lift the front end of the vehicle with a hydraulic jack and position safety stands under the lower control arms. Lower the vehicle onto the safety stands and place the front wheels in the straight-ahead position.
2. Use a piece of chalk to mark each tie-rod sleeve in relation to the tie-rod, and loosen the sleeve clamps (Figure 16-43).
3. Position the steering wheel spoke in the position it was in while driving straight ahead during the road test. Turn the steering wheel to the centered position and note the direction of the front wheels.
4. If the steering wheel spoke is low on the left side while driving the vehicle straight ahead, use a tie-rod sleeve rotating tool to shorten the left tie-rod and lengthen the right tie-rod (Figure 16-44). One-quarter turn on a tie-rod sleeve moves the steering wheel position approximately one inch. Turn the tie-rod sleeves the proper amount to bring the steering wheel to the centered position. For example, if the steering wheel spoke is two inches off-center, turn each tie-rod sleeve one-half turn.
5. If the steering wheel spoke is low on the right side while driving the vehicle straight ahead, lengthen the left tie-rod and shorten the right tie-rod.
6. Mark each tie-rod sleeve in its new position in relation to the tie-rod. Be sure the sleeve clamp openings are positioned properly, as indicated earlier in this chapter. Tighten the clamp bolts to the specified torque.
7. Lift the front chassis with a floor jack and remove the safety stands. Lower the vehicle onto the shop floor, and check the steering wheel position during a road test.



SERVICE TIP:

The most accurate check of a properly centered steering wheel is while driving the vehicle straight ahead during a road test.



SERVICE TIP:

Some computer wheel aligners have a steering wheel centering display that provides an easier method of steering wheel centering compared to the manual method.




FIGURE 16-43 Marking toe-rod sleeves in relation to the tie-rods and outer tie-rod ends.





FIGURE 16-44 Rotating tie-rod sleeves to center steering wheel.

When all the front suspension alignment angles are adjusted within the manufacturer's specifications, road-test the vehicle. When the vehicle is driven on a relatively smooth, straight road, there should be directional stability with no drift to the right or left, and the steering wheel must be centered.

CAUSES OF IMPROPER REAR WHEEL ALIGNMENT

The following suspension or chassis defects will cause incorrect rear wheel alignment:

- 1. Collision damage that results in a bent frame or distorted unitized body
- 2. A leaf-spring eye that is unwrapped or spread open
- 3. Leaf-spring shackles that are broken, bent, or worn
- 4. Broken leaf springs or leaf-spring center bolts
- 5. Worn rear upper or lower control arm bushings
- 6. Worn trailing arm bushings or dislocated trailing arm brackets
- 7. Bent components such as radius rods, control arms, struts, and rear axles

REAR SUSPENSION ADJUSTMENTS

Rear Wheel Camber Adjustment

Improper **rear wheel camber** causes excessive wear on the edges of the rear tire treads. Cornering stability may be affected by improper rear wheel camber, especially while cornering at high speeds. Improper rear wheel camber on a front-wheel-drive vehicle may change the understeer or oversteer characteristics of the vehicle. Since a tilted wheel rolls in the direction of the tilt, rear wheel camber may cause steering pull. For example, excessive positive camber on the right rear wheel causes the rear suspension to drift to the right and steering to pull to the left.

Rear suspension adjustments vary depending on the type of suspension system. Some manufacturers of wheel alignment equipment and tools provide detailed diagrams for front and rear wheel alignment adjustments on all makes of domestic and imported vehicles. Our objective is to show a few of the common methods of adjusting rear wheel alignment angles on various types of rear suspension systems.

On some semi-independent rear suspension systems, camber and toe are adjusted by inserting different sizes of shims between the rear spindle and the spindle mounting surface. These shims are retained by the spindle mounting bolts. The shim thickness is changed between the top or bottom of the spindle to adjust camber (Figure 16-45).

Many rear camber shims are now circular and are available in a wide variety of configurations to fit various rear wheels. Some computer wheel aligners indicate the thickness of shim required and the proper shim position. These same shims also adjust rear wheel toe (Figure 16-46).




FIGURE 16-45 Shim adjustment for rear wheel camber, semi-independent rear suspension system.



FIGURE 16-46 Circular shim for rear wheel camber and toe adjustment.



CAUTION:

Always follow the vehicle manufacturer's recommended rear suspension adjustment procedure in the service manual to avoid improper alignment angles and reduced steering control.

Rear wheel camber

is the tilt of a line through the center of a rear tire and wheel in relation to the true vertical centerline of the tire and wheel.



SPECIAL TOOLS

Rear suspension camber tool




FIGURE 16-47 Elongating the lower strut bolt hole provides camber adjustment.

On some transverse leaf rear suspension systems such as those on a later model Oldsmobile Cutlass Supreme, the spindle must be removed from the strut, and the lower strut bolt hole elongated to allow a camber adjustment (Figure 16-47). Once this bolt hole is elongated, assemble the knuckle and strut and leave the retaining bolts loose. The top of the tire and the spindle may be moved outward or inward to adjust camber. After the camber is adjusted to specifications, the strut-to-knuckle nuts must be tightened to the specified torque.

On some independent rear suspension systems with a lower control arm and ball joint, the strut-to-knuckle bolts are loosened and a special camber tool must be installed on the lower strut-to-knuckle bolt and the rear side of the strut (Figure 16-48). Rotate the adjusting bolt in the back of the tool to adjust the camber; then tighten the strut-to-knuckle nuts to the specified torque.

On other rear suspension systems, a camber adjustment wedge may be installed between the top of the knuckle and the strut to adjust camber (Figure 16-49). The nuts on the




FIGURE 16-48 Camber adjustment with special tool inserted on rear lower strut-to-knuckle bolt.




FIGURE 16-49 Camber adjusting wedge installed between the top of the rear knuckle and strut.




FIGURE 16-50 Rear wheel camber adjusting kit.




FIGURE 16-51 Graduated cam for rear camber adjustment, double wishbone suspension.

strut-to-knuckle bolts must be loosened prior to wedge installation, and these nuts must be tightened to the specified torque after the camber is adjusted to specifications. Aftermarket adjustment cam kits are available to adjust the rear wheel camber on many cars (Figure 16-50). On some double-wishbone rear suspension systems, graduated cams on the inner ends of the lower control arms provide camber adjustment (Figure 16-51). Improper rear wheel camber may be caused by sagged rear springs on some cars or station wagons (Figure 16-52). If the improper rear wheel camber is caused by sagged rear springs, the springs should be replaced and the camber adjusted to specifications.

Rear Wheel Toe Adjustment

Improper **rear wheel toe** moves the thrust line away from the geometric centerline, which causes steering pull and feathered tire tread wear. If the left rear wheel has excessive **toe-out**, the **thrust line** is moved to the left of the geometric centerline. Excessive toe-in on the left rear wheel moves the thrust line to the right of the geometric centerline. When toe-in or toe-out is excessive on the right rear wheel, it has the opposite effect on the thrust line compared to the left rear wheel. When the thrust line is moved to the left of the geometric centerline, the steering pulls to the right, whereas a thrust line positioned to the right of the **geometric centerline** results in steering pull to the left. Photo sequence 29 shows rear wheel alignment adjustment procedures.

Improper rear wheel toe adjustment on a non-driving rear axle causes diagonal wipe tire tread wear (Figure 16-53). The toe may be adjusted on many rear suspension systems used on front-wheel-drive cars by changing the tapered shim thickness between the front and rear

Rear wheel toe is the distance between the front edges of the rear tires in relation to the distance between the rear edges of the rear tires.

The **thrust line** is a line at 90° to the rear axle and projecting forward.

Geometric centerline is the true centerline between the front and rear axles.




FIGURE 16-52 Improper rear wheel camber may be caused by sagged rear springs on independent rear suspension systems.




FIGURE 16-53 Diagonal wipe tire tread wear caused by improper rear wheel toe on a front wheel drive vehicle.

PHOTO SEQUENCE 29

TYPICAL PROCEDURE FOR ADJUSTING REAR WHEEL CAMBER AND TOE



P29-1 Be sure the vehicle is properly positioned on an alignment ramp.



P29-2 Perform a prealignment inspection.



P29-3 Be sure the wheel aligner wheel sensors are properly connected to the vehicle.



P29-4 Obtain the front and rear alignment angles using the procedures recommended by the equipment manufacturer. Display the front and rear wheel alignment angles on the aligner monitor.




P29-5 Adjust the camber on the right rear wheel by loosening the cam bolt lock nut on the inner end of the right rear lower control arm and turning the eccentric cam until the camber setting is within specifications. Maintain the cam setting and tighten the lock nut to the specified torque.



P29-6 Adjust the camber on the left rear wheel by loosening the cam bolt lock nut on the inner end of the right rear lower control arm and turning the eccentric cam until the camber setting is within specifications. Maintain the cam setting and tighten the lock nut to the specified torque.



P29-7 Loosen the cam bolt nut on the inner end of the left rear toe link, and rotate the cam bolt to the required toe specification. Maintain the cam bolt position, and tighten the cam bolt nut to the specified torque.



P29-8 Loosen the cam bolt nut on the inner end of the right rear toe link, and rotate the cam bolt to the required toe specification. Maintain the cam bolt position, and tighten the cam bolt nut to the specified torque.




FIGURE 16-54 Adjusting rear wheel toe by changing shim thickness between rear spindle and mounting flange.

edges of the rear spindle mounting flange (Figure 16-54). As mentioned previously, these shims are also used to adjust rear wheel camber.

On some transverse leaf rear suspension systems, a special toe adjusting tool is inserted in openings in the jack pad and the rear lower control rod (Figure 16-55). This tool has a turnbuckle in the center of the tool. When the nut on the inner end of the rear lower control rod is loosened, the turnbuckle is rotated to lengthen or shorten the tool and move the rear lower control rod to adjust the rear wheel toe (Figure 16-56). After the toe is adjusted to specification, the nut on the rear lower control rod bolt must be tightened to the specified torque. Photo Sequence 30 illustrates front and rear suspension adjustments.

On some independent rear suspension systems, an eccentric star wheel on the rear lower control rod may be rotated to adjust the rear wheel toe (Figure 16-57).

On some rear suspension systems with a lower control arm and ball joint, the nut on the tie-rod is loosened, and the tie-rod is rotated to adjust the rear wheel toe (Figure 16-58).




FIGURE 16-55 Special toe adjusting tool for transverse leaf-spring rear suspension.




FIGURE 16-56 Moving lower rear control rod position to adjust rear wheel toe.




FIGURE 16-57 Eccentric star wheel on inner end of lower control rod for toe adjustment.




FIGURE 16-58 Rotating rear tie-rod to change tie-rod length and adjust rear wheel toe.

After the toe is adjusted to specifications, the tie-rod nut must be tightened to the specified torque.

On some front-wheel-drive cars, the rear wheel toe is adjusted by loosening the toe link bolt and moving the wheel in or out to adjust the toe (Figure 16-59). After the rear wheel toe is properly adjusted, the toe link bolt must be tightened to the specified torque. On other front-wheel-drive cars, the rear wheel toe is adjusted by loosening the nut on the inner adjustment link cam nut (Figure 16-60). The cam bolt is rotated to adjust the rear wheel toe. After the rear wheel toe is properly adjusted, the adjustment link cam nut must be tightened to the specified torque. Photo Sequence 30 illustrates front and rear suspension adjustments.

A variety of aftermarket bushing kits are available to adjust rear wheel toe. Some of these kits also adjust rear wheel comber (Figure 16-61).




FIGURE 16-59 Loosening toe link bolt to adjust rear wheel toe.

PHOTO SEQUENCE 30

TYPICAL PROCEDURE FOR PERFORMING FRONT AND REAR SUSPENSION ALIGNMENT ADJUSTMENTS



P30-1 Position vehicle properly on alignment rack with front wheels centered on turntables and rear wheels on slip plates.



P30-2 After prealignment inspection and front and rear ride height measurement, measure front and rear suspension angles with computer wheel aligner.



P30-3 Drill spot welds to remove alignment plate on top of the strut tower. After strut upper mount retaining nuts and alignment plate are removed, shift the strut inward or outward to adjust front wheel camber. Shift the upper strut mount forward or rearward to adjust front wheel caster.



P30-4 Loosen the locknuts and adjust the tie-rod length to adjust front wheel toe.




P30-5 Recheck front suspension alignment readings on the monitor screen.



P30-6 Adjust the left rear wheel camber and toe by rotating the cam bolt on the inner end of the lower control arm. If the rear wheel camber and toe have not been adjusted previously, a rear camber adjusting kit may have to be installed in the inner end of the lower control arm.



P30-7 Adjust the right rear wheel camber and toe by rotating the cam bolt on the inner end of the lower control arm. If the rear wheel camber and toe have not been adjusted previously, a rear camber adjusting kit may have to be installed in the inner end of the lower control arm.



P30-8 Recheck all front and rear alignment readings on the monitor screen. Be sure all readings are within specifications, including the thrust angle.




FIGURE 16-60 Cam bolt for rear wheel toe adjustment.




FIGURE 16-61 Aftermarket bushing kit to adjust rear wheel toe and camber.



SPECIAL TOOLS

Track gauge

Rear wheel tracking refers to the position of the rear wheels in relation to the front wheels. When all four wheels are parallel to the geometric centerline and the thrust line is positioned on the geometric centerline, the rear wheels track directly behind the front wheels.

REAR WHEEL TRACKING MEASUREMENT WITH A TRACK GAUGE

Prior to the introduction of computer alignment systems, wheel alignment equipment performed a two-wheel alignment on the front wheels, and a track gauge was used to measure **rear wheel tracking**. A **track gauge** is connected between the front and rear wheels to determine the rear wheel tracking or thrust line. When all four wheels are parallel to the geometric centerline of the vehicle, the thrust line is positioned at the geometric centerline. Under this condition, the rear wheels track directly behind the front wheels (Figure 16-62).

If the left front of the vehicle is involved in a severe collision, the left front wheel may be driven rearward to a setback condition, and the rear wheels may be moved straight sideways. Under this condition, the rear wheels no longer track directly behind the front wheels (Figure 16-63). The term sideset is applied to the condition where the rear axle is moved straight sideways.

A track gauge is a straight metal bar graduated in inches or millimeters. The scale on the outside edge of the track bar is similar to a tape measure. Three straight metal pointers are mounted in brackets on the track gauge. These pointers are also graduated much like a tape measure. When the wing nuts in the brackets are loosened, the brackets may be moved lengthwise on the track bar. The metal pointers may be adjusted inward or outward in the brackets.

To inspect rear wheel tracking, one of the track gauge pointers is positioned against the rear outside edge of the front wheel rim at spindle height. The other two pointers are positioned on the outside edges of the rear wheel rim at spindle height. The track gauge must be kept parallel to the side of the vehicle (Figure 16-64).




FIGURE 16-62 When all four wheels are parallel to the geometric centerline, the thrust line is positioned at the geometric centerline and the rear wheels track directly behind the front wheels.




FIGURE 16-63 Collision damage causes front wheel setback and improper rear wheel tracking with rear wheel offset.



FIGURE 16-64 Track bar positioned to measure rear wheel tracking.

Rear Wheel Tracking Measurement Procedure

Follow these steps to measure rear wheel tracking:

1. Lift one side of the front suspension with a floor jack and lower the suspension onto a safety stand. Be sure the tire is lifted off the shop floor.
2. Place a lateral runout gauge against the outside edge of the rim lip and rotate the wheel to check wheel runout. (Refer to Chapter 4 for wheel runout measurement.) Place a chalk mark at the location of the maximum wheel runout. If the wheel runout is excessive, replace the wheel.
3. Rotate the chalk mark to the exact top or bottom of the wheel, and remove the safety stand and floor jack to lower the wheel onto the shop floor.
4. Repeat steps 1, 2, and 3 at the other three wheels.
5. Hold the single pointer on the track gauge so it contacts the rear edge of the front rim.
6. Adjust the other two pointers so they contact the outer edges of the rear wheel rim.
7. Adjust the pointers on the rear wheel so the track gauge is parallel to the side of the vehicle. Be sure all three pointers are clamped securely.
8. Move the track gauge to the opposite side of the vehicle and position the pointers in the same location on these wheels. If the vehicle has proper tracking, all three pointers

on the track gauge will contact the front and rear rims at exactly the same location on both sides of the vehicle, and the track gauge will be parallel to the sides of the vehicle.

Examples of Improper Rear Wheel Tracking Measured with a Track Gauge

Rear axle offset

occurs when the rear axle is turned so one rear wheel is moved rearward and the opposite rear wheel is moved forward.

Rear Axle Offset. When the track gauge is positioned on the left side of the vehicle, the rear pointer on the rear wheel must be moved farther inward compared with the pointer at the front edge of the rear rim. On the right side of the vehicle, the front pointer is positioned forward and ahead of the rim edge when the two pointers are positioned on the edges of the rear rim. This indicates the wheelbase is less between the wheels on the right side of the vehicle compared with the left side. The front pointer on the rear rim is some distance from the rim face (Figure 16-65). These pointer positions indicate the right rear wheel has moved forward and the left rear wheel has moved rearward. This **rear axle offset** condition moves the thrust line to the left of the geometric centerline.

Wheel Setback. If a vehicle has been subjected to a severe right front sideways impact, the left front wheel may be driven outward and rearward. The track gauge and pointers are positioned on the right side of the vehicle and then moved to the left side. The front pointer is positioned ahead of the rim edge on the left side, and the track gauge is not parallel to the side of the vehicle (Figure 16-66).




FIGURE 16-65 Track bar measurement of an offset rear axle.




FIGURE 16-66 Track bar measurement of a left front wheel that is moved rearward to setback position.

The track gauge must be moved inward on the front pointer to position the bar parallel to the side of the vehicle. When this adjustment is made, the distance on the front pointer is less on the left side of the vehicle compared with the distance on the right side of the vehicle. These track gauge measurements indicate the left front wheel is moved rearward to a setback position as well as being outward.

Diamond-Shaped Frame Condition. When a vehicle experiences severe collision damage on the left front, the entire left side of the vehicle may be driven rearward in relation to the right side of the chassis. Under this condition, the left front wheel is moved to a setback condition, and the rear axle is offset, which moves the thrust line to the left of the geometric centerline. This particular type of damage is most likely to occur on a rear-wheel-drive vehicle with a frame and a one-piece rear axle.

Since the entire left side of the vehicle is driven rearward, the wheelbase is the same on both sides of the vehicle. Therefore, the track gauge pointers indicate the wheelbase is the same between the front and rear wheels on both sides of the vehicle. However, the two rear track gauge pointers must be adjusted to different lengths to contact the rear rim edges. On the left side of the vehicle, the rear track gauge pointer is some distance from the rear rim edge if these two pointers are set at the same measurement (Figure 16-67).

When the track gauge is positioned on the right side of the vehicle, there is some distance between the front pointer and the edge of the rear rim if both rear pointers are set at the same distance.

Measuring vehicle tracking with a track gauge is a two-person operation and requires a considerable amount of time to perform the wheel runout and track bar measurements. The track gauge also lacks precision accuracy. Computer alignment systems perform the same checks by measuring the thrust line angle, setback, and all the other front and rear suspension alignment angles with speed and accuracy.

CUSTOMER CARE: Those of us involved in the automotive service industry are like everyone else: we do make mistakes. If you make a mistake that results in a customer complaint, always be willing to admit your mistake and correct it. Do not try to cover up the mistake or blame someone else. Customers are usually willing to live with an occasional mistake that is corrected quickly and efficiently.




FIGURE 16-67 A severe left front collision impact moves the entire left side of the vehicle rearward resulting in front wheel setback and rear axle offset, which provides a diamond-shaped chassis.

TABLE 16-1 STEERING AND WHEEL ALIGNMENT DIAGNOSIS

Problem	Symptoms	Possible Causes
Tire tread wear, inside edge	Steering pull, premature tire replacement	Excessive negative camber
Tire tread wear, outside edge	Steering pull, premature tire replacement	Excessive positive camber
Tire tread wear, feathered	Premature tire replacement	Improper toe setting
Tire tread wear, cupped	Wheel vibration	Improper wheel balance
Steering wander	Reduced directional stability	Reduced positive caster or negative caster
Steering pull	Steering pull to the right when driving straight ahead	Reduced positive caster, right-front wheel Excessive positive camber, right-front wheel Excessive toe-out, left-rear wheel
Steering pull	Steering pull to the left when driving straight ahead	Reduced positive caster, right-front wheel Excessive positive camber, right-front wheel Excessive toe-out, right-rear wheel
Steering wheel return	Excessive steering wheel returning force after a turn	Excessive positive caster on front wheels
Steering wheel return	Steering wheel does not return properly after a turn	Binding column or linkage Reduced positive caster on front wheels
Harsh riding	Reduced ride quality when driving on road irregularities	Worn shock absorbers or struts Excessive positive caster, front wheels. Reduced ride height

CASE STUDY

A customer complained that the left rear tire on his Cutlass Calais had suffered severe tread wear in the last 2,000 miles. The technician examined this tire and found the customer was not exaggerating. All the tread wear indicators were showing and the other tires showed very little wear. The customer indicated that the left rear tire tread looked like the tread on the other tires 2,000 miles previously. While checking the tread wear on the left rear tire, the technician noticed the car had been newly painted. Further discussion with the customer revealed the car had been recently purchased, and there was no warranty on the vehicle. During a road test, the technician found that the steering pulled to the left while driving straight ahead. The technician suggested a thorough prealignment inspection and complete four-wheel alignment with a computer alignment system.

During the prealignment inspection, all the steering and suspension components except the left rear

tire appeared to be in normal condition. However, the technician noticed the left rear quarter panel and other body components had been replaced. Apparently the car had suffered severe collision damage in this area.

The four-wheel alignment results were satisfactory except the left rear wheel, which had a 5° toe-in and a thrust angle of 8°. This severe rear toe-in condition had moved the thrust line to the right of the geometric centerline. When the technician referred to the manufacturer's service manual, this information stated the rear wheel toe is not adjustable, and if the rear wheel camber and toe are not within specifications, the rear underbody and suspension should be inspected for damage. The technician located the underbody dimension specifications in the service manual (Figures 16-68 and 16-69).


The technician began checking the rear suspension underbody measurements with a tram gauge. When

dimension M was measured between the center of the bolt heads in the trailing arm brackets, this measurement was 1 in. (25.4 mm) less than specified. This measurement indicated the left rear subframe had been forced inward toward the center of the vehicle, which resulted in the improper toe and thrust angle. Further inspection of the rear axle channel with a long straightedge indicated this channel was bent rearward in the center. The car was sent to the body shop to pull the rear subframe and unitized body back to the original position and provide the specified distance between the center of bolt heads on the trailing arms. Since the rear axle channel is a critical component in

providing rear suspension ride quality and alignment, the customer was advised this component should be replaced. A new rear tire was also installed.

When the rear suspension was reassembled, all the alignment angles were rechecked and the rear wheel toe and thrust line were within specifications. During a road test, there was no evidence of steering pull or any other steering problems.

From this experience, the technician learned the importance of four wheel alignment. The technician also discovered that accurate underbody measurement specifications are absolutely essential.



- * All dimensions are metric.
- * All control points are symmetrical side to side unless otherwise noted.
- * All tolerances are ± 3 mm.

FIGURE 16-68 Underbody measurement specifications and locations.

TERMS TO KNOW

Camber adjustment
 Caster adjustment
 Eccentric cams
 Geometric centerline
 Rear axle offset
 Rear wheel camber
 Rear wheel toe
 Rear wheel tracking
 Setback
 Steering axis inclination (SAI)
 Thrust line
 Toe-in
 Toe-out
 Total toe
 Track gauge

REF	HORIZONTAL	VERTICAL	LOCATION
A	Leading edge of 24 mm gauge hole	Lower surface at gauge hole to datum line	Front end lower tie bar
B	Center of 16 mm gauge hole	None	Front end upper tie bar
C	Leading edge of 20 mm gauge hole	Lower surface at gauge hole to datum line	Motor compartment side rail, forward of transaxle anchor support plate on left side rail, and at rear of engine mounting support on right side rail. For access on right side with air conditioning, remove air compressor.
D	Center of 16 mm gauge hole	None	Front upper surface of motor compartment side rail
E	Center of lower attaching hole in transaxle support anchor plate	Datum line to horizontal centerline of transaxle support anchor plate lower attaching hole	Transaxle support anchor plate on left side rail
F	Center of shock tower strut front attaching hole	Upper surface at shock tower strut front attaching hole	Shock tower
G	Leading edge of oblong master gauge hole	Datum line to horizontal leading edge of oblong master gauge hole	Front suspension lower control arm mount support
H	Center of 16 mm gauge hole	None	Gage hole in upper surface of motor compartment side rail
I	Center of 19 mm gauge hole	Datum line to lower surface at gauge hole	Outboard 19 mm gauge hole in front suspension control arm mounting reinforcement support
J	Center of hood hinge pivot pin head	None	Hood hinge
K	Center of front upper hinge pin hole	Upper surface at hinge pin hole	Front upper door hinge, body side
L	Leading edge of 22 mm gauge hole	Lower surface at leading edge of gauge hole to datum line	Compartment pan longitudinal rail, forward of rear suspension spring seat support
M	Center of attaching bolt head	Datum line to horizontal centerline of attaching bolt head of rear suspension control arm support.	Rear suspension control arm support forward of rear suspension spring seat support
N	Center of 16 mm gauge hole	Datum line to lower surface at gauge hole	Outboard gage hole at rear suspension spring seat support
O	Leading edge of 21 mm gauge hole	Lower surface at gauge hole to datum line	Compartment pan longitudinal rail

FIGURE 16-69 Explanation of underbody horizontal and vertical measurement locations.

ASE-STYLE REVIEW QUESTIONS

1. While discussing camber adjustments on a MacPherson strut front suspension system:
Technician A says an eccentric cam on the strut-to-steering-knuckle bolt may be used to adjust camber.
Technician B says an eccentric on the lower ball joint stud may be used to adjust camber.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
2. While discussing camber adjustment on a short-and-long arm front suspension system with adjusting shims positioned between the upper control arm mounting shaft and the outside of the frame:
Technician A says adding equal shim thickness on both mounting bolts increases negative camber.
Technician B says adding more shim thickness on the front bolt decreases positive camber.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. While diagnosing and adjusting front wheel camber:
A. Front wheel camber is measured with the front wheels turned 20°.
B. The steering pulls to the side with the least amount of positive camber.
C. The right front wheel may have more positive camber to compensate for road crown.
D. The upper strut mount may be moved inward or outward to adjust camber.
4. When diagnosing and adjusting front wheel caster:
A. On some suspensions, the radius rod should be shortened to decrease positive caster.
B. On some twin I-beam suspensions, the I beams may be bent to adjust caster.
C. On some double-wishbone suspensions, a graduated cam on the pivot adjuster is rotated to adjust caster.
D. The steering pulls to the side of the suspension that has the most positive caster.
5. The camber adjustment is within specifications, but the SAI angle is more than specified on the left side of a MacPherson strut front suspension.
Technician A says the camber adjustment bolt may be adjusted to correct the problem.
Technician B says the left front wheel may have a setback condition.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
6. Unequal SAI angles on the left and right sides of the front suspension may cause:
A. Tread wear on the front tires.
B. Brake pull during sudden stops.
C. Bump steer on a rough road.
D. Steering wander while driving straight ahead.
7. On many front suspension systems, the maximum variation between the left and right SAI is:
A. 0.75° C. 1.5°
B. 1° D. 2.5°
8. All of these statements about adjusting front wheel toe are true EXCEPT:
A. If the positive caster is increased on the right front wheel, this wheel moves toward a toe-out position.
B. The tie-rod sleeves may be heated with an acetylene torch to loosen them.
C. The opening in the sleeve clamp must be positioned away from the slots in the tie-rod sleeve.
D. The front wheel toe should be measured with the front wheels straight ahead.
9. A rear independent suspension system has a tie-rod connected from the steering knuckle to the lower control arm.
Technician A says if the tie-rod is lengthened, the rear wheel is moved toward a toe-out position.
Technician B says if the tie-rod is shortened, the positive camber is increased on the rear wheel.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
10. While discussing a vehicle on which the front suspension alignment angles are within manufacturer's specifications, but the thrust line is 7° to the right of the vehicle centerline:
Technician A says this problem may be caused by excessive toe-out on the right rear wheel.
Technician B says this vehicle will tend to steer to the left when driven straight ahead.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

ASE CHALLENGE QUESTIONS

1. A car with a MacPherson strut front suspension has 1.5° positive camber on the left front wheel and 1.5° negative camber on the right front wheel. The most likely cause of this problem is:
A. Worn upper strut mounts.
B. Improperly positioned steering gear.
C. Engine cradle shifted to the right.
D. Bent strut rods.
2. A pickup truck with a MacPherson strut front suspension pulls to the left. Preliminary inspection shows that the SAI is correct, but the camber of the right front wheel is $-1\frac{1}{4}^{\circ}$.
Technician A says a bent spindle could be the cause.
Technician B says the problem may be a worn-out strut.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
3. The nose of a car seems to “push” into the turn when making a right turn.
Technician A says the probable cause is there is not enough left front wheel toe-out on turns.
Technician B says the probable cause is too much positive camber on the left rear wheel.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B
4. “Feathering” type wear of a rear tire is likely caused by:
A. Improper rear wheel camber alignment.
B. Improper rear tire inflation.
C. Improper rear wheel balance.
D. Improper rear wheel toe alignment.
5. The owner of an older pickup says the truck has begun to “wander and shimmy” in the past few months, especially when the bed of the truck is empty.
Technician A says the twin I-beam front suspension caster is probably out of spec.
Technician B says the eyes of the rear leaf springs are probably worn.
Who is correct?
A. A only C. Both A and B
B. B only D. Neither A nor B

Name _____ Date _____

CENTER STEERING WHEEL

Upon completion of this job sheet, you should be able to center a steering wheel.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Task: E-3: Prepare vehicle for wheel alignment on the alignment machine; perform four wheel alignment by checking and adjusting front and rear wheel caster camber; and toe as required; center steering wheel.

Tools and Materials

Tie-rod sleeve adjusting tool

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed _____

1. List the suspension and steering service procedures that may require steering wheel centering after these procedures are completed.

2. The steering wheel is centered properly with the front wheels straight ahead in the shop, but the steering wheel is not centered when driving the vehicle straight ahead. List the causes of this problem.

3. Lift the front end of the vehicle with a hydraulic jack, and position safety stands under the lower control arms. Lower the vehicle onto the safety stands, and place the front wheels in the straight-ahead position.

Are the lower control arms securely supported on safety stands? ☐ Yes ☐ No

Are the front wheels straight ahead? ☐ Yes ☐ No

Instructor check _____

4. Use a piece of chalk to mark each tie-rod sleeve in relation to the tie-rod, and loosen the sleeve clamps.

Are the tie-rod sleeves marked in relation to the tie-rods? ☐ Yes ☐ No

Instructor check _____

5. Position the steering wheel spoke in the position it was in while driving straight ahead during the road test. Turn the steering wheel to the centered position and note the direction of the front wheels.

Direction the front wheels are turned with the steering wheel centered:
right _____ left _____

6. If the steering wheel spoke is low on the left side while driving the vehicle straight ahead, use a tie-rod sleeve rotating tool to shorten the left tie-rod and lengthen the right tie-rod. A one-quarter turn on a tie-rod sleeve moves the steering wheel position approximately one inch. Turn the tie-rod sleeves the proper amount to bring the steering wheel to the centered position. For example, if the steering wheel spoke is two inches off-center, turn each tie-rod sleeve one-half turn.

Left tie-rod sleeve: lengthened _____ shortened _____

Right tie-rod sleeve: lengthened _____ shortened _____

Amount of left tie-rod sleeve rotation _____

Amount of right tie-rod sleeve rotation _____

Is the steering wheel centered with front wheel straight ahead? ☐ Yes ☐ No

Instructor check _____

☐

7. If the steering wheel spoke is low on the right side while driving the vehicle straight ahead, lengthen the left tie-rod and shorten the right tie-rod.

8. Mark each tie-rod sleeve in its new position in relation to the tie-rod. Be sure the sleeve clamp openings are positioned properly, as indicated in this chapter. Tighten the clamp bolts to the specified torque.

Are the tie-rod sleeves marked in relation to tie-rods? ☐ Yes ☐ No

Are the tie-rod sleeve clamps properly installed? ☐ Yes ☐ No

Tie-rod sleeve bolt specified torque _____

Tie-rod sleeve bolt actual torque _____

Instructor check _____

9. Lift the front chassis with a floor jack, and remove the safety stands. Lower the vehicle onto the shop floor, and check the steering wheel position during a road test.

Steering wheel position while driving straight ahead during a road test:

☐ Satisfactory ☐ Unsatisfactory

Instructor's Response _____

Name _____ Date _____

ADJUST FRONT WHEEL ALIGNMENT ANGLES

Upon completion of this job sheet, you should be able to adjust front wheel alignment angles.

NATEF Correlation

This job sheet is related to NATEF Automotive Suspension and Steering Tasks:

E-2. Perform prealignment inspection and measure vehicle ride height; perform necessary action.

E-3. Prepare vehicle for wheel alignment on the alignment machine; perform four-wheel alignment by checking and adjusting front and rear wheel caster, camber, and toe as required; center steering wheel.

E-4. Check toe-out on turns (turning radius); determine necessary action.

E-5. Check steering axis inclination (SAI) and included angle; determine necessary action.

E-7. Check front wheel setback; determine necessary action.

E-8. Check front and/or rear cradle (subframe) alignment; determine necessary action.

Tools and Materials

A vehicle with improperly adjusted front wheel camber, caster, and toe.

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____

VIN _____ Engine type and size _____

Procedure

Task Completed _____

1. Position the vehicle properly on the alignment ramp with the front wheels properly positioned on the turntables and the rear wheels on slip plates.

Are the front wheels properly positioned on turntables? ☐ Yes ☐ No

Are the rear wheels properly positioned on slip plates? ☐ Yes ☐ No

Is the parking brake applied? ☐ Yes ☐ No

Instructor check _____

2. Perform a prealignment inspection and correct any defective conditions or components found during the inspection. List the defective conditions or components, and explain the reasons for your diagnosis.

3. Measure front and rear ride height and correct it if necessary.

Specified front suspension ride height _____

Actual front suspension ride height _____

Specified rear suspension ride height _____

Actual rear suspension ride height _____

List the necessary repairs to correct the front and rear suspension ride height and explain the reasons for your diagnosis.

4. Measure and adjust front wheel camber.

Specified front wheel camber _____

Actual front wheel camber: left _____ right _____

Front wheel camber after adjustment: left _____ right _____

Camber adjustment method _____

5. Measure SAI and included angle.

Specified SAI _____

Actual SAI: left _____ right _____

Specified included angle _____

Actual included angle: left _____ right _____

If the SAI and/or included angle are not within specifications, state the necessary repairs and explain the reasons for your diagnosis.

6. Measure and adjust front wheel caster.

Specified front wheel caster _____

Actual front wheel caster: left _____ right _____

Front wheel caster after adjustment: left _____ right _____

Caster adjustment method _____

7. Inspect camber measurements and adjust if necessary.

Camber adjustment: ☐ Satisfactory ☐ Unsatisfactory

Left front camber readjusted to _____

Right front camber readjusted to _____

8. Measure and adjust front wheel toe.

Task Completed

Specified front wheel toe _____

Actual front wheel toe: left _____ right _____

Total toe _____

Front wheel toe after adjustment: left _____ right _____

Total front wheel toe _____

9. Inspect steering wheel centering with front wheels straight ahead and center the wheel if necessary.

Is steering wheel centered? ☐ Yes ☐ No

Instructor check _____

10. Measure turning angle.

Specified turning angle _____

Actual turning angle left front wheel _____

Actual turning angle right front wheel _____

Turning angle correction required: ☐ Yes ☐ No

Left front wheel turned inward 20°, turning angle on right front wheel _____

Right front wheel turned inward 20°, turning angle on left front wheel _____

If the turning angle is not within specifications, state the necessary repairs and explain the reasons for your diagnosis.

Instructor's Response _____

Name _____ Date _____

ADJUST REAR WHEEL ALIGNMENT ANGLES

Upon completion of this job sheet, you should be able to adjust rear wheel alignment angles.

NATEF Correlation

- This job sheet is related to NATEF Automotive Suspension and Steering Tasks:
- E-2. Perform prealignment inspection and measure vehicle ride height; perform necessary action.
 - E-3. Prepare vehicle for wheel alignment on the alignment machine; perform four-wheel alignment by checking and adjusting front and rear wheel caster, camber, and toe as required; center steering wheel.
 - E-6. Check rear wheel thrust angle; determine necessary action.

Tools and Materials

A vehicle with improperly adjusted rear wheel camber and toe.

Describe the Vehicle Being Worked On:

Year _____ Make _____ Model _____
 VIN _____ Engine type and size _____

Procedure

Task Completed

1. Position the vehicle properly on the alignment ramp with the front wheels properly positioned on the turntables and the rear wheels on slip plates.

Are the front wheels properly positioned on turntables? ☐ Yes ☐ No

Are the rear wheels properly positioned on slip plates? ☐ Yes ☐ No

Is the parking brake applied? ☐ Yes ☐ No

Instructor check _____

2. Perform a prealignment inspection, and correct any defective conditions or components found during the inspection. List the defective conditions or components, and explain the reasons for your diagnosis.

3. Measure front and rear ride height and correct if necessary.

Specified front suspension ride height _____

Actual front suspension ride height _____

Specified rear suspension ride height _____

Actual rear suspension ride height _____

If the rear ride height is not within specifications, state the necessary repairs and explain the reasons for your diagnosis.

4. Measure and adjust camber on left rear wheel.

Specified left rear wheel camber _____

Actual left rear wheel camber _____

Left rear wheel camber after adjustment _____

Camber adjustment method _____

5. Measure left rear wheel toe.

Specified left rear wheel toe _____

Actual left rear wheel toe _____

Left rear wheel toe after adjustment _____

Toe adjustment method _____

6. Measure and adjust camber on right rear wheel.

Specified right rear wheel camber _____

Actual right rear wheel camber _____

Right rear wheel camber after adjustment _____

Camber adjustment method _____

7. Measure right rear wheel toe.

Specified right rear wheel toe _____

Actual right rear wheel toe _____

Right rear wheel toe after adjustment _____

Toe adjustment method _____

8. Measure thrust angle.

Task Completed

Specified thrust angle _____

Actual thrust angle _____

If the thrust angle is not within specifications, state the necessary repairs and explain the reasons for your diagnosis.

9. Road-test vehicle for satisfactory steering and suspension operation.

Steering directional control: ☐ Satisfactory ☐ Unsatisfactory

Complete steering operation: ☐ Satisfactory ☐ Unsatisfactory

Suspension operation: ☐ Satisfactory ☐ Unsatisfactory

If the steering or suspension operation is unsatisfactory, state the necessary repairs and explain the reasons for your diagnosis.

Instructor's Response _____

1. After new tires and new alloy rims are installed on a sports car, the owner complains about steering wander and steering pull in either direction while braking.

Technician A says there may be brake fluid on the front brake linings.

Technician B says the replacement rims may have a different offset than the original rims.

Who is correct?

- A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
2. *Technician A* says when a vehicle pulls to one side, the problem will not be caused by the manual steering gear.
- Technician B* says when an unbalanced power steering gear valve causes a vehicle to pull to one side, the steering effort will be very light in the direction of the pull and normal or heavier in the opposite direction.
- Who is correct?
- A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
3. The outside edge of the left front tire on a rear-wheel-drive car is badly scalloped.
- Technician A* says the cause could be worn ball joints.
- Technician B* says the cause could be incorrect tire pressure.
- Who is correct?
- A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
4. The owner of a large rear-wheel-drive sedan says the front tires squeal loudly during low-speed turns. The most probable cause of this condition is:
- A. Excessive positive camber.
B. Negative caster adjustment.
C. Improper steering axis inclination (SAI).
D. Improper turning angle.

5. A mini-pickup has a severe shudder when the vehicle is started from a stop with a load in the bed.
- Technician A* says the problem may be worn spring eyes.
- Technician B* says the problem may be axle torque wrap-up.

Who is correct?

- A. Technician A C. Both A and B
B. Technician B D. Neither A nor B

6. A cyclic noise ("moaning," "whining," or "howling") that changes pitch with road speed and is present whenever the vehicle is in motion may be caused by any of the following EXCEPT:
- A. Worn differential gears.
B. Rear axle bearings.
C. Incorrect driveshaft runout.
D. Off-road tire tread pattern.

7. *Technician A* says hard steering may be caused by low hydraulic pressure due to a stuck flow control valve in the pump.

Technician B says hard steering may be caused by low hydraulic pressure due to a worn steering gear piston ring or housing bore.

Who is correct?

- A. Technician A C. Both A and B
B. Technician B D. Neither A nor B

8. Tires and wheels on a pickup truck were changed from standard 14-inch to standard 15-inch light-truck rims. The first time the brakes were applied, the truck shook and shuddered. When the 15-inch wheels were replaced by the 14-inch wheels, braking was uneventful.

Technician A says the 15-inch rim is one inch wider, which causes the brakes to grab.

Technician B says the additional inch diameter increases braking leverage, overloading worn suspension bushings.

Who is correct?

- A. Technician A C. Both A and B
B. Technician B D. Neither A nor B

9. While discussing tire tread wear:

Technician A says a scalloped pattern of tire wear indicates an out-of-round wheel or tire.

Technician B says uneven wear on one side of a tire may indicate radial force variation.

Who is correct?

- A. Technician A C. Both A and B
B. Technician B D. Neither A nor B

10. A front-wheel-drive car makes chattering noises only during a hard right turn.
Technician A says the problem is probably caused by an upper spring seat binding.
Technician B says the problem is probably caused by a defective strut bearing.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
11. A customer says he equipped the rear of his minivan with inflatable air shocks to handle heavier trailer hitch tongue weights, but the van's rear end still drags when he hooks up his ski boat trailer.
Technician A says the problem is the air shocks are not heavy-duty.
Technician B says the problem is heavy-duty springs are also needed with the air shocks.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
12. All of the following could cause shock absorber noise EXCEPT:
A. A bent piston rod.
B. Worn shock absorbers.
C. Shock fluid leaks.
D. Extreme temperatures.
13. When a vehicle pulls to one side, any of the following problems may be the cause EXCEPT:
A. Worn ball joints.
B. Reduced curb height.
C. Bent strut rod.
D. Improper turning angle.
14. A customer says when he applied the brakes hard on his front-wheel-drive car, "the whole car shook."
Technician A says the problem could be worn ball joints.
Technician B says the problem could be worn or loose strut rod bushings.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
15. A customer with a sport utility vehicle says after an off-road outing over the weekend, his vehicle pulls to the left on acceleration. Which of the following could cause this problem?
A. Broken leaf spring center bolt.
B. Loose steering unit.
C. Stuck brake pad.
D. Stuck in 4WD.
16. While discussing electronic air suspension:
Technician A says the compressor must be running when a corner of the vehicle is lifted from the ground.
Technician B says on a car with electronic air suspension, the switch should be in the "on" position.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
17. Front wheel "shimmy"—a side-to-side movement of the front wheels that is felt in the steering wheel—may be caused by any of the following EXCEPT:
A. Worn tie-rod ends.
B. Tire/wheel imbalance.
C. Rack bushings and rack alignment.
D. Tight sector shaft adjustment.
18. A customer says her front-wheel-drive car is hard to steer because the steering wheel no longer returns to center. After the turn, she has to bring it back to center.
Technician A says a corroded or stuck strut bearing plate could be the cause of the problem.
Technician B says a bent tension rod could be the cause of the problem.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
19. While discussing four-wheel steering (4WS):
Technician A says only a fault in the main steering angle sensor will cause a DTC in the Honda Prelude 4WS main processing unit.
Technician B says temporary codes in the Honda Prelude 4WS system are stored in memory and recalled each time the ignition key is turned on.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B

20. In a hybrid electric vehicle (HEV) the propulsion motor charges the batteries during:
- A. Wide open throttle.
 - B. Fast vehicle acceleration.
 - C. Idle speed.
 - D. Deceleration.
21. While discussing suspension height:
- Technician A* says raising the suspension height in the rear of a vehicle will affect the front suspension geometry.
- Technician B* says raising the suspension height in the rear of a vehicle could lead to premature rear spring failure.
- Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
22. A vehicle with recirculating ball steering has excessive steering wheel free play.
- Technician A* says a loose worm bearing preload adjustment may cause the problem.
- Technician B* says loose column U-joints may cause the problem.
- Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
23. The engine has recently been replaced in a front-wheel-drive car with power rack and pinion steering. The customer now complains about excessive steering effort. A preliminary check of the steering revealed the fluid level was OK and the belts were not slipping.
- Technician A* says perhaps the rack was knocked out of alignment when the engine was installed.
- Technician B* says perhaps the pressure line was bent or pinched when the engine was installed.
- Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
24. While discussing rear suspension systems:
- Technician A* says semi-independent rear suspension systems momentarily have a slight negative camber and toe-in when the wheel goes over a bump.
- Technician B* says constantly carrying a lot of weight in the rear of a car with semi-independent rear suspension may cause the rear tires to wear on the inside edge.
- Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
25. The owner of a 4WD sport utility vehicle complains about wheel thumping and vibration on tight turns at low speed. The most probable cause of this condition is:
- A. Excessive positive scrub radius.
 - B. Improper steering axis inclination (SAI).
 - C. Transfer case is in 4WD.
 - D. Bent steering knuckle.
26. If a power steering system has the specified pump pressure, but steering effort is excessive than specs, all of the following could cause or contribute to the problem EXCEPT:
- A. Worn front tires.
 - B. Cold fluid.
 - C. Hose restrictions.
 - D. Steering gear malfunction.
27. The customer says his vehicle has a rapid “thumping” noise and a vibration in the steering wheel that is most noticeable when the vehicle is at a steady speed in a long curve.
- Technician A* says the problem could be caused by a tire defect.
- Technician B* says the problem could be improper dynamic wheel balance.
- Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B

28. While discussing power steering fluids:
Technician A says a foamy, milky power steering fluid is caused by mixing automatic transmission fluid with hydraulic fluid intended for power steering use.
Technician B says using automatic transmission fluid instead of power steering hydraulic fluids will lower pump pressure and increase steering effort.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
29. On a car with power rack and pinion steering, the steering suddenly swerves to the right or left when a front wheel strikes a road irregularity. The most likely cause of the problem is:
A. A loose rack bearing adjustment.
B. Worn front struts.
C. Loose steering gear mounting bushings.
D. Bent steering arm.
30. A customer returns to your shop and says she just had steering work done on the car the day before, and it has been pulling to the left since then. A check of the records shows that lower control arm ball joints and both rubber-encapsulated tie-rod ends were replaced.
Technician A says the tie-rod end may have been installed with the wheels turned slightly away from center.
Technician B says the alignment should have been checked after installing the ball joints.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
31. When diagnosing an HEV with a scan tool a U0131 is obtained. This DTC indicates a defect in the:
A. Data network.
B. Inverter.
C. Propulsion motor and related circuit.
D. Generator and related circuit.
32. While discussing excessive vehicle noise and vibration:
Technician A says suspension and driveline vibrations may be amplified by the resonance of the body or steering wheel.
Technician B says noises that phase in and out of hearing range may be two separate noises that alternately amplify then cancel each other.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
33. In a four-wheel active steering system (4WAS), when changing lanes at high speed the:
A. Rear wheels are steering a few degrees in the same direction as the front wheels.
B. Rear wheels are steered 5 degrees in the opposite direction to the front wheels.
C. Camber angle is changed on the rear wheels.
D. The rear wheels remain in the straight ahead position.
34. While discussing unibody and frame problems:
Technician A says an indication of possible frame damage is excessive tire wear when the alignment angles are correct.
Technician B says a worn strut lower ball joint is often an indicator of unibody torsional damage.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
35. While discussing frame damage:
Technician A says wrinkles in the upper flange of a truck frame indicate a sag.
Technician B says diamond-shaped distortion of a 4WD sport utility vehicle frame was possibly caused by towing or being towed from a frame corner.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
36. Power steering fluid is leaking from the high-pressure outlet fitting on a nonsubmerged power steering pump. To correct this problem, you should:
A. Replace the cover seal.
B. Replace the O-ring.
C. Replace the fitting.
D. Replace the check valve.

37. The lock cylinder on a light-duty GM truck with an automatic transmission is very hard to turn between "Off" and "Off-Lock." All of the following could cause this problem EXCEPT:
- A. Broken lock-bolt spring.
 - B. Distorted lock rack.
 - C. Burr on tang of shift gate.
 - D. Shift linkage not adjusted.
38. The steering wheel of a GM car is loose in every other tilt position. Of the following possible causes, which is the most likely to cause this problem?
- A. Housing support screws loose.
 - B. Column misaligned.
 - C. Lock shoe springs broken.
 - D. Loose fit of lock shoe to lock pivot pin.
39. While discussing unibody and frame damage:
Technician A says a vehicle that has been rear-ended could have later problems with steering and tracking.
Technician B says towing a 2,000 pound trailer on a class II hitch bolted to the frame of a minivan will cause diamond distortion of the frame.
Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
40. While discussing a Honda Prelude 4WS system:
Technician A says that before diagnosing the system, the idle speed has to be steady at the specified rpm.
Technician B says before diagnosing the 4WS system, the rear steering center lock pin must be installed.
Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
41. A customer says the steering wheel of her front-wheel-drive car does not return to the center position after a turn. A test drive reveals that the steering wheel is stiff and only returns to within approximately 90° of center after a 180° turn.
Technician A says the problem is memory steer and could be caused by binding in the steering shaft universal joints.
Technician B says memory steer in a front-wheel-drive car may be also caused by binding upper strut mounts.
Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
42. A customer says his front-wheel-drive car shakes and moans when decelerating at low speeds. The most likely cause of the problem is:
- A. Worn upper strut bearings.
 - B. Worn inner drive axle joints.
 - C. Loose wheel bearings.
 - D. Excessive tire inflation pressure.
43. A sport utility vehicle with a power recirculating ball steering gear makes a rattling noise when the steering wheel is turned. This noise is noticeable whether the car is in motion or standing still.
Technician A says the cause of the problem could be a loose pitman arm or shaft.
Technician B says the cause of the problem could be the high-pressure power steering hose touching some part of the vehicle.
Who is correct?
- A. Technician A
 - B. Technician B
 - C. Both A and B
 - D. Neither A nor B
44. A rear-wheel-drive car has a steering wander problem. The cause of this problem could be:
- A. Tire tread wear.
 - B. Loose outer tie-rod ends.
 - C. Worn idler arm.
 - D. All of the above.

45. A customer purchased P-metric tires to replace the 6.00–15 tires on his pickup truck.
Technician A says P-metric tires should not be installed on a vehicle designed to ride on bias-ply tires.
Technician B says radial tires and belted bias-ply tires should never be mixed on the same axle.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
46. Many vehicles have too much play in the steering wheel, usually caused by loose steering components. A check of these components should be:
A. Done with vehicle weight on the tires.
B. Done with a computerized alignment system.
C. Completed after a front wheel alignment.
D. Performed with the vehicle raised and the wheels unsupported.
47. While discussing shock absorber diagnosis:
Technician A says the “bounce test” is the sure way to quickly pinpoint bad shocks and struts.
Technician B says oil film on the lower chamber of a shock or strut indicates leakage and requires replacement.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
48. While discussing front suspension angles:
Technician A says turning angle is fixed by the steering and suspension system design.
Technician B says toe-out on turns may be adjusted with the steering stopper bolts.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
49. While discussing rear suspension alignment:
Technician A says in straight-ahead driving, the rear wheels must track exactly behind the front wheels or the vehicle will not handle correctly.
Technician B says a dynamic tracking rear suspension that lets the rear wheels turn in the same direction as the front wheels makes curve negotiation and lane changes much quicker and safer.
Who is correct?
A. Technician A C. Both A and B
B. Technician B D. Neither A nor B
50. When diagnosing a 4WAS system, during the active tests:
A. The battery pack and 12V battery are tested.
B. The front and rear wheels are steered to the right at the same time.
C. The rear wheels are steered a few degrees in each direction.
B. Specific system components are activated to check component operation.

to convert these	to these	multiply by
TEMPERATURE		
Centigrade Degrees	Fahrenheit Degrees	$C \text{ degrees} \times 1.8 + 32 = F \text{ degrees}$
Fahrenheit Degrees	Centigrade Degrees	$F \text{ degrees} - 32 \times .556 = C \text{ degrees}$

LENGTH

Millimeters	Inches	0.03937
Inches	Millimeters	25.4
Meters	Feet	3.28084
Feet	Meters	0.3048
Kilometers	Miles	0.62137
Miles	Kilometers	1.60935

AREA

Square Centimeters	Square Inches	0.155
Square Inches	Square Centimeters	6.45159

VOLUME

Cubic Centimeters	Cubic Inches	0.06103
Cubic Inches	Cubic Centimeters	16.38703
Cubic Centimeters	Liters	0.001
Liters	Cubic Centimeters	1000
Liters	Cubic Inches	61.025
Cubic Inches	Liters	0.01639
Liters	Quarts	1.05672

to convert these	to these	multiply by
Quarts	Liters	0.94633
Liters	Pints	2.11344
Pints	Liters	0.47317
Liters	Ounces	33.81497
Ounces	Liters	0.02957

WEIGHT

Grams	Ounces	0.03527
Ounces	Grams	28.34953
Kilograms	Pounds	2.20462
Pounds	Kilograms	0.45359

WORK

Centimeter-Kilograms	Inch-Pounds	0.8676
Inch-Pounds	Centimeter-Kilograms	1.15262
Meter Kilograms	Foot-Pounds	7.23301
Foot-Pounds	Newton-Meters	1.3558

PRESSURE

Kilograms/Sq. Cm	Pounds/Sq. Inch	14.22334
Pounds/Sq. Inch	Kilograms/Sq. Cm	0.07031
Bar	Pounds/Sq. Inch	14.504
Pounds/Sq. Inch	Bar	0.06895

Automotive Group

Kent-Moore Division, SPX Corporation
Roseville, MI

Fluke Corporation

Everett, WA

Easco/KD Tools

Lancaster, PA

Hennessy Industries, Inc.

LaVerge, TN

Hunter Engineering Company

Bridgeton, MO

Mac Tools, Inc.

Washington Courthouse, OH

OTC Division, SPX Corporation

Owatonna, MN

Sears Industrial Sales

Cincinnati, OH

Snap-On Tools Corporation

Kenosha, WI

Specialty Products Company

Longmont, CO

Federal Mogul Corporation

Ann Arbor MI

Audi diagnostic tool and service information
<http://www.audi.ddsltd.com>

Chrysler service information:
<http://www.techauthority.daimlerchrysler.com>

General Motors tool and service information
<http://www.gmgoodwrench.com>
<http://www.acdelco.com>

Ford Motor Company vehicle information
<http://www.ford.com>

Helm Incorporation, distributors of service manuals and training publications for many original equipment manufacturers
<http://www.helm.com>

Hyundai service publications
<http://www.hmaservice.com>

Training materials, tools, and equipment
<http://www.dealerequipment.com>

Special service tools
<http://www.spxkentmoore.com>

KIA general information
<http://www.kia.com>

Mac Tools, tool and equipment information
<http://www.mactools.com>

Nissan service manuals, 2000 and later models
<http://www.nissan-techinfo.com>

OTC Division of SPX Corporation, tools and equipment information
<http://www.otctools.com>

Snap-on Tools Corporation, tools and service equipment
<http://www.snapondia.com>

Toyota Motor Corporation, vehicles and parts information
<http://www.toyota.com>

Volkswagen service information
<http://www.ddstld.com>

Volvo service information, 1999 and later models
<http://www.volvovira.com>

Service information pre-1999
<http://www.volvotechinfo.com>

Automotive Service Association (ASA) www.asashop.org
P.O. Box 929
Bedford Texas 76021

International Automotive Technicians Network (iatn) www.iatn.net

Society of Automotive Engineers (SAE) www.sae.org
400 Commonwealth Dr.
Warrendale PA 15096

Moog Service Link www.moogauto.com
Cooper Moog Automotive
P.O. Box 7224
6565 Wells Ave.
St. Louis MO 63177

Accidental air bag deployment An unintended air bag deployment caused by improper service procedures.

Despliegue accidental del Airbag Despliegue imprevisto del Airbag ocasionado por procedimientos de reparación inadecuados.

Active roll stabilization (ARS) ECU A computer that receives input signals and controls output functions in an ARS system.

ECU de estabilización de rodamiento activo (ARS, en inglés) Una computadora que recibe señales de entrada y controla las funciones de salida en un sistema ARS.

Active steering ECU A computer that receives input signals and controls output functions in an active steering system.

ECU de dirección activa Una computadora que recibe señales de entrada y controla las funciones de salida en un sistema de dirección activa.

Advanced vehicle handling (AVH) Computer software on CD that allows the technician to locate the cause of hidden suspension, body, and chassis problems.

Manejo avanzado de vehículos (AVH, en inglés) Programa de software en CD que permite que el técnico localice la causa de problemas ocultos de suspensión, carrocería y chasis.

Air bag deployment module The air bag and deployment canister assembly that is mounted in the steering wheel for the driver's side air bag, or in the dash panel for the passenger's side air bag.

Unidad de despliegue del air bag El conjunto del Airbag y elemento de despliegue montado en el volante de dirección para proteger al conductor, o en el tablero de instrumentos para proteger al pasajero.

Air bag system Is designed to protect the driver and/or passengers in a vehicle collision.

Sistema de bolsa de aire Se diseñó para proteger al conductor y/o a los pasajeros en caso de un choque.

Alignment ramp A metal ramp positioned on the shop floor on which vehicles are placed during wheel alignment procedures.

Rampa de alineación Rampa de metal ubicada en el suelo del taller de reparación de automóviles sobre la que se colocan los vehículos durante los procedimientos de alineación de ruedas.

Antilock brake system (ABS) A computer-controlled system that prevents wheel lockup during brake applications.

Sistema de frenado antibloqueo (ABS) Un sistema controlado por computadora que previene el bloqueo de las ruedas durante la aplicación de los frenos.

Antitheft locking wheel covers Locking wheel covers that help to prevent wheel theft.

Cuberruedas anti-robo Cuberruedas autobloqueantes que ayudan a evitar el robo de las ruedas.

Antitheft wheel nuts Special wheel nuts designed to prevent wheel and tire theft.

Tuercas antirrobo de fijación de las ruedas Tuercas especiales de fijación de las ruedas diseñadas para evitar el robo de las ruedas y los neumáticos.

Approved gasoline storage can A special gasoline container that meets safety requirements.

Bidón aprobado para almacenamiento de gasolina Un recipiente especial para gasolina que cumple los requisitos de seguridad.

Aqueous parts cleaning tank Uses a water-based, environmentally friendly cleaning solution, such as Greasoff® 2, rather than traditional solvents.

Tanque de limpieza de partes acuosas Usa una solución a base de agua y compatible con el medio ambiente, tal como Greasoff® 2, en lugar de los solventes tradicionales.

ASE blue seal of excellence An ASE logo displayed by automotive service shops that employ ASE-certified technicians.

Sello azul de excelencia de la ASE Logotipo exhibido en talleres de reparación de automóviles donde se emplean mecánicos certificados por la ASE.

Axle offset A condition where the complete rear axle assembly has turned so one rear wheel has moved forward, and the opposite rear wheel has moved rearward.

Eje descentrado Una condición en la cual la asamblea total del eje trasero se ha girado para que una rueda se ha movido hacia afrente, y la rueda opuesta trasera se ha movido hacia atrás.

Axle pullers Are usually slide-hammer type. These pullers attach to the axle studs to remove the axle.

Extractores del eje Son generalmente de tipo martillo de corredera. Estos extractores se vinculan a los espárragos roscados del eje para quitarlo.

Backup power supply A voltage source, usually located in the air bag computer, that is used to deploy an air bag if the battery cables are disconnected in a collision.

Alimentación de reserva Fuente de tensión, por lo general localizada en la computadora del Airbag, que se utiliza para desplegar el Airbag si se desconectan los cables de la batería a consecuencia de una colisión.

Ball joint radial measurement Vertical movement in a ball joint because of internal joint wear.

Medida de radial de la junta esférica Movimiento horizontal en una junta esférica ocasionado por el desgaste interno de la misma.

Ball joint removal and installation tools Special tools required for ball joint removal and replacement.

Herramientas para la remoción y el ajuste de la junta esférica Herramientas especiales requeridas para la remoción y el reemplazo de la junta esférica.

Ball joint vertical movement Vertical movement in a ball joint because of internal joint wear.

Movimiento vertical de la junta esférica Un movimiento vertical en la junta esférica debido al desgaste interior de la junta.

Ball joint wear indicator A visual method of checking ball joint wear.

Indicador de desgaste de la junta esférica Método visual de revisar el desgaste interior de una junta esférica.

Bearing brinelling Straight line indentations on the races and rollers.

Acción de Brinnell en un cojinete Hendiduras en línea recta en los anillos y los rodillos.

Bearing fatigue spalling Flaking of the surface metal on the rollers and races.

Escamación y fatiga del cojinete Condición que ocurre cuando el metal de la superficie de los rodillos y los anillos comienza a escamarse.

Bearing fretting A fine, corrosive wear pattern around the races and rollers, with a circular pattern on the races.

Cinceladura del cojinete Desgaste corrosivo y fino alrededor de los anillos y los rodillos que se hace evidente a través de figuras circulares en los anillos.

Bearing indentations Surface indentations on races and rollers caused by hard, foreign particles.

Depresiones del cojinete Las depresiones en la superficie de los anillos y los rodillos causadas por las partículas duras foraneas.

Bearing preload A tension placed on the bearing rollers and races by an adjustment or assembly procedure.

Carga previa del cojinete Tensión aplicada a los rodillos y los anillos del cojinete a través de un procedimiento de ajuste o de montaje.

Bearing pullers Special tools designed for bearing removal.

Extractores de cojinetes Herramientas especiales diseñadas para la remoción del cojinete.

Bearing smears Metal loss from the races and rollers in a circular, blotched pattern.

Ralladuras en los cojinetes Pérdida del metal de los anillos y los rodillos que se hace evidente a través de una figura circular oxidada.

Belows boots Accordion-style boots that provide a seal between the tie rods and the housing on a rack and pinion steering gear.

Botas de fuelles Botas en forma de acordeón que proveen una junta de estanqueidad entre las barras de acoplamiento y el alojamiento en un mecanismo de dirección de cremallera y piñón.

Belt tension gauge A special gauge used to measure drive belt tension.

Calibrador de tensión de la correa de transmisión Calibrador especial que se utiliza para medir la tensión de una correa de transmisión.

Body sway Excessive body movement from side to side.

Oscilación de la carrocería Movimiento lateral excesivo de la carrocería.

Bounce test A shock absorber test in which weight is applied to, and released from, the vehicle bumper.

Prueba de rebote Una prueba de los amortiguadores en la cual se aplica y se quita un peso en el parachoques del vehículo.

Brake parts washer A parts washer designed to wash brake parts without releasing asbestos dust into the atmosphere.

Lavador de partes de freno Un lavador de partes diseñada a lavarlas partes de freno sin dejar escapar el polvo de amianta al medio ambiente.

Brake pedal depressor A special tool installed between the front seat and the brake pedal to apply the brakes during certain wheel alignment measurements.

Depresor del pedal de frenos Una herramienta especial instalada entre el asiento de afrente y el pedal de frenos para aplicar los frenos durante ciertas medidas de alineación de las ruedas.

Brake pedal jack A special tool installed between the front seat and the brake pedal to apply the brakes during certain wheel alignment measurements.

Gato del pedal de freno Herramienta especial instalada entre el asiento delantero y el pedal de freno que se utiliza para aplicar los frenos durante ciertas medidas de alineación de ruedas.

Brake pressure modulator valve (BPMV) An assembly containing a group of solenoid valves that control brake fluid pressure during antilock brake, traction control, and vehicle stability control functions.

Válvula modulador de presión del freno (BPMV) Una asamblea que contiene un grupo de válvulas de solenoide que controlan la presión del fluido de freno durante las funciones de freno antibloqueo, control de tracción, y control de estabilidad del vehículo.

Brake torque test A test that is performed with the brakes applied.

Prueba de torsión de frenos Una prueba que se lleva acabo mientras que se aplicacan los frenos.

Bump steer The tendency of the steering to veer suddenly in one direction when one or both front wheels strike a bump.

Cambio de dirección ocasionado por promontorios en el terreno Tendencia de la dirección a cambiar repentinamente de sentido cuando una o ambas ruedas delanteras golpea un promontorio.

Camber adjustment A method of adjusting the inward or outward tilt of a front or rear wheel in relation to the true vertical centerline of the tire.

Ajuste de la combadura Método de ajustar la inclinación hacia adentro o hacia afuera de una rueda delantera o trasera con relación a la línea central vertical real del neumático.

Camber angle The inward or outward tilt of a line through the center of a front or rear tire in relation to the true vertical centerline of the tire and wheel.

Ángulos de combaduras Inclinación hacia adentro o hacia afuera de una línea a través del centro de una rueda delantera o trasera con relación a la línea central vertical real del neumático y la rueda.

Caster adjustment A method of adjusting the forward or rearward tilt of a line through the center of the upper and lower ball joints, or lower ball joint and upper strut mount, in relation to the true vertical centerline of the tire and wheel viewed from the side.

Ajuste de comba de eje Método de ajustar la inclinación hacia adelante o hacia atrás de una línea a través del centro de las juntas esféricas superior e inferior, o la junta esférica inferior y el montaje

del montante superior, con relación a la línea central vertical real del neumático y la rueda vista desde la parte lateral.

Caster angle A line through the center of the upper and lower ball joints, or lower ball joint and upper strut mount, in relation to the true vertical centerline of the tire and wheel viewed from the side.

Ángulo de comba de eje Línea a través del centro de las juntas esféricas superior e inferior, o la junta esférica inferior y el montaje del montante superior, con relación a la línea central vertical real del neumático y la rueda vista desde la parte lateral.

Camber The position of an imaginary line through the centers of the upper and lower ball joints or upper strut mount and lower ball joint in relation to the line through the tire center viewed from the front.

Ángulo de verticalidad La posición de una línea imaginaria que atraviesa los centros de las articulaciones esféricas superiores e inferiores o del montaje del montante superior y la articulación esférica inferior en relación con la línea que atraviesa el centro del neumático visto de frente.

Caster The position of an imaginary line through the centers of the upper and lower ball joints or upper strut mount and lower ball joint in relation to the a line through the wheel and spindle center viewed from the side.

Ángulo de convexión La posición de una línea imaginaria que atraviesa los centros de las articulaciones esféricas superiores e inferiores o del montaje del montante superior y la articulación esférica inferior en relación con la línea que atraviesa la rueda y el centro del palier visto de perfil.

Caster offset The distance between the caster line and the center of the front spindle.

Desfasaje del ángulo de convexión La distancia entre la línea de tiro y el centro del palier delantero.

Caster trail An alternate term for caster offset.

Rastro del ángulo de convexión Un término alternativo para desfasaje del ángulo de convexión.

Circlip A round circular clip used as a locking device on components such as front drive axles.

Anillo de pistón Un anillo circular que se utiliza como dispositivo de traba en componentes como los ejes rotativos delanteros.

Claw washer A special locking washer used to retain the tie rods to the rack in some rack and pinion steering gears.

Arandelas de garras Arandela de bloqueo especial que se utiliza para sujetar las barras de acoplamiento a la cremallera en algunos mecanismos de dirección de cremallera y piñón.

“C” lock A thick metal locking device used to lock components such as the rear drive axles in place.

Retenedores en C Un dispositivo de cerrojo de metal grueso que sirve para enclavar los componentes en su lugar, tal como los ejes propulsores traseros.

Clock spring electrical connector A conductive ribbon in a plastic container mounted on top of the steering column that maintains electrical contact between the air bag inflator module and the air bag electrical system.

Conector eléctrico de cuerda de reloj Cinta conductiva envuelta en una cubierta plástica montada sobre la parte superior de la columna de dirección, que mantiene el contacto eléctrico entre la unidad infladora y el sistema eléctrico del Airbag.

Coil spring compressor tool A special tool required to compress a coil spring prior to removal of the spring from the strut.

Herramienta para la compresión del muelle helicoidal Herramienta especial requerida para comprimir un muelle helicoidal antes de remover el muelle del montante.

Cold parts washer Uses a non-heated solution to clean metal parts.

Lavador de partes en frío usa una solución en frío para limpiar las partes de metal.

Collapsible steering column A steering column that is designed to collapse when impacted by the driver in a collision to help reduce driver injury.

Columna de dirección plegable Columna de dirección diseñada para plegarse al ser impactada por el conductor durante una colisión con el propósito de reducir las lesiones que el conductor pueda recibir.

Column-drive EPS An electronically controlled steering gear in which the electric motor supplies torque to the steering column shaft.

Transmisión de columna de GPE (guiado de propulsión eléctrica) El primer paso para diagnosticarlo es verificar la queja de falla del cliente. Haga una prueba de carretera al vehículo si es necesario para identificar la falla.

Computer four wheel aligner A type of wheel aligner that uses a computer to measure wheel alignment angles at the front and rear wheels.

Alineador computerizado de cuatro ruedas Tipo de alineador de ruedas que utiliza una computadora para medir los ángulos de alineación de las ruedas delanteras y traseras.

Continuously variable road sensing suspension (CVRSS) An updated version of the road sensing suspension (RSS).

Suspensión detector continuo de variedades (CVRSS) Un sistema de suspensión detector más avanzada.

Control arm bushing tools Special tools required for control arm bushing removal and replacement.

Herramientas para el buje del brazo de mando Herramientas especiales requeridas para la remoción y el reemplazo del buje del brazo de mando.

Control arm movement monitor A monitor available in some computer wheel aligners. On short-and-long arm front suspensions this feature indicates the required shim thickness to provide the specified camber and caster.

Monitor del movimiento del brazo de mando Un monitor disponible en algunos alineadores de ruedas computerizadas. En las suspensiones delanteras tipo brazo largo-y-corto este elemento indica el espesor de la cuña requerido para proveer el ángulo de la inclinación especificado.

Crocus cloth A very fine paper for polishing or removing small abrasions from metal.

Tela fina de esmeril Papel sumamente fino que se utiliza para pulir o remover pequeñas abrasiones del metal.

Curb riding height The distance between the vehicle chassis and the road surface measured at specific locations.

Altura del cotén del viaje Distancia entre el chasis del vehículo y la superficie del camino medida en puntos específicos.

Data link connector (DLC) An electrical connector for computer system diagnosis mounted under the instrument panel or in the engine compartment.

Conector de enlace de datos Conector eléctrico montado debajo del tablero de instrumentos o en el compartimiento del motor, que se utiliza para la diagnosis del sistema informático.

Datum line A straight reference line such as the top of a dedicated bench system.

Línea de datos Línea recta de referencia, como por ejemplo la parte superior de un sistema de banco dedicado.

Dedicated bench system A heavy steel bed with special fixtures for aligning unitized bodies.

Sistema de banco dedicado Asiento pesado de acero con aparatos especiales que se utiliza para la alineación de carrocerías unitarias.

Diagnostic procedure charts Provide step-by-step diagnostic procedures for specific problems.

Cuadros de procedimientos diagnósticos Proveen los procedimientos diagnósticos paso por paso de los problemas específicos.

Diagnostic trouble codes (DTCs) Codes displayed in digital form that represent faults in a computer-controlled system.

Códigos diagnósticos de averías (DTCs) Los códigos manifestados en forma digital que representan las averías en un sistema controlado por computadora.

Dial indicators A precision-measuring device with a stem and a rotary pointer.

Indicador de cuadrante Dispositivo para medidas precisas con vástago y aguja giratoria.

Digital adjustment photos Photos that are available in some computer-controlled wheel aligners to inform the technician regarding suspension adjustment procedures.

Fotos digitales de ajuste Las fotos que son disponibles en algunos alineadores de ruedas controlados por computadoras para informar a los técnicos en cuanto a los procedimientos de ajustes de la suspensión.

Digital signal processor (DSP) An electronic device in some wheel sensors on computer-controlled wheel aligners.

Procesor de señales digitales Un dispositivo electrónico en algunos sensores de ruedas en los alineadores de ruedas controlados por computadora.

Directional stability The tendency of a vehicle steering to remain in the straight-ahead position when driven straight ahead on a smooth, level road surface.

Estabilidad direccional Tendencia de la dirección del vehículo a permanecer en línea recta al ser así conducido en un camino cuya superficie es lisa y nivelada.

Downshift test A test for chassis vibrations performed with the transmission downshifted.

Prueba de cambio descendente Una prueba de las vibraciones del chasis que se efectúan durante un cambio de carrera de transmisión descendente.

Dynamic stability control (DSC) ECU A computer that receives input signals and controls output functions in a DSC system.

ECU de control de estabilidad dinámico (DSC, en inglés) Una computadora que recibe señales de entrada y controla las funciones de salida en un sistema DSC.

Dynamic wheel balance Refers to proper balance of the tire and wheel assembly during tire and wheel rotation.

Equilibrado dinámico de la rueda Se refiere al equilibrado apropiado del ensamblaje de la llanta y la rueda durante su rotación.

Eccentric camber bolt A bolt with an out-of-round metal cam on the bolt head that may be used to adjust camber.

Perno de combadura excéntrica Perno con una leva metálica con defecto de circularidad en su cabeza, que puede utilizarse para ajustar la combadura.

Eccentric cams Out-of-round metal cams mounted on a retaining bolt with the shoulder of the cam positioned against a component. When the cam is rotated, the component position is changed. Delete Eccentric cams or bushings.

Levas excéntricas Las levas de metal ovaladas montadas en un perno retenedor con lo saliente de la leva posicionado contra un componente. Cuando se gira la leva cambia la posición del componente.

Electronic brake and traction control module (EBTCM) A module that controls antilock brake, traction control, and vehicle stability functions.

Módulo electrónico de control del frenado y tracción (EBTCM) Un módulo que controla las funciones del freno antibloqueo, control de tracción, y control de estabilidad del vehículo.

Electronically controlled orifice (ECO) valve A computer-controlled solenoid valve in the power steering pump that controls fluid flow from the pump to the servotronic valve.

Válvula de orificio controlado electrónicamente (ECO, en inglés) Una válvula solenoide controlada por computadora que se encuentra en la bomba de dirección de potencia que controla el flujo de fluidos desde la bomba hasta la válvula servotrónica.

Electronic suspension control (ESC) An electronically controlled suspension system in which the computer controls strut firmness.

Control electrónico de la suspensión (CES) Los vehículos que se equipan con este sistema pueden tener el tablero de control análogo o digital.

Electronic vibration analyzer (EVA) A tester that measures component vibration.

Analizador electrónico de vibraciones Un detector que mide la vibración de un componente.

Electronic wheel balancer A computer-controlled balancer that provides static and dynamic wheel balance.

Equilibrador de ruedas electrónico Un equilibrador controlado por computadora que provee la equilibración estática y dinámico.

Environmental Protection Agency (EPA) A federal government agency that is responsible for air and water quality in the United States.

Agencia de Protección Ambiental (EPA, en inglés) Una agencia del Gobierno Federal responsable de la calidad del aire y del agua en los Estados Unidos.

Fail-safe mode A mode entered by a computer if the computer detects a fault in the system.

Modo de seguridad Un modo iniciado por la computadora si ésta descubre un fallo en el sistema.

Floor jack A hydraulically operated lifting device for vehicle lifting.

Gato de pie Dispositivo activado hidráulicamente que se utiliza para levantar un vehículo.

Flow control valve A special valve that controls fluid movement in relation to system demands.

Válvula de control de flujo Válvula especial que controla el movimiento del fluido de acuerdo a las exigencias del sistema.

Fluorescent trouble lights Contain fluorescent-type bulbs.

Luces de peligro fluorescentes Incluyen bombillas de tipo fluorescente.

Frame flange The upper or lower horizontal edge on a vehicle frame.

Brida del armazón Borde horizontal superior o inferior en el armazón del vehículo.

Frame web The vertical side of a vehicle frame.

Malla del armazón Lado vertical del armazón del vehículo.

Front and rear wheel alignment angle screen A display on a computer wheel aligner that provides readings of the front and rear wheel alignment angles.

Pantalla para la visualización del ángulo de alineación de las ruedas delanteras y traseras Representación visual en una computadora para alineación de ruedas que provee lecturas de los ángulos de alineación de las ruedas delanteras y traseras.

Geometric centerline An imaginary line through the exact center of the front and rear wheels.

Línea central geométrica Línea imaginaria a través del centro exacto de las ruedas delanteras y traseras.

Hazard Communication Standard A forerunner to the Right-To-Know laws published by the Occupational Health and Safety Administration (OSHA).

Estándar de comunicación de riesgos Un precursor de las leyes del derecho a saber publicado por la Administración de Seguridad y Salud Ocupacional (OSHA, en inglés).

Heavy spot Is a location in a tire with excessive weight.

Zona Dura es un lugar en la llanta con peso excesivo.

High-frequency transmitter An electronic device that sends high-frequency voltage signals to a receiver. Some wheel sensors on computer-controlled wheel aligners send high-frequency signals to a receiver in the wheel aligner.

Transmisor de alta frecuencia Un dispositivo electrónico que manda las señales de voltaje de alta frecuencia a un receptor. Algunos sensores de ruedas en los alineadores controlados por computadora mandan señales de alta frecuencia a un receptor en el alineador de ruedas.

History code A fault code in a computer that represents an intermittent defect.

Código histórico Código de fallo en una computadora que representa un defecto intermitente.

Hot cleaning tank Uses a heated solution to clean metal parts.

Tanque de limpieza en caliente Usa una solución caliente para limpiar las partes de metal.

Hydraulic press A hydraulically operated device for disassembling and assembling components that have a tight press-fit.

Prensa hidráulica Dispositivo activado hidráulicamente que se utiliza para desmontar y montar componentes con un fuerte ajuste en prensa.

Ignitable A liquid, solid, or a gas that can be set on fire spontaneously or by an ignition source.

Inflamable Un líquido, sólido o gas que se puede encender espontáneamente o mediante una fuente de ignición.

Incandescent bulb-type trouble lights Contain incandescent-type bulbs.

Luces de peligro con bombilla de tipo incandescente Incluyen bombillas de tipo incandescente.

Included angle The sum of the camber and steering axis inclination (SAI) angles.

Ángulo incluido La suma del ángulo de inclinación de la comba y de ángulo de inclinación del eje de dirección (SAI).

Integral reservoir A reservoir that is joined with another component such as a power steering pump.

Tanque integral Tanque unido a otro componente, como por ejemplo una bomba de la dirección hidráulica.

International system (SI) A system of weights and measures.

Sistema internacional Sistema de pesos y medidas.

Lateral axle sideset The amount that the rear axle is moved straight sideways in relation to the front axle.

Desplazamiento lateral del eje La cantidad que el eje trasero está desplazado directamente hacia un lado en relación al eje delantero.

Lateral chassis movement Movement from side to side.

Movimiento lateral del chasis Movimiento de un lado a otro.

Lateral tire runout The variation in side-to-side movement.

Desviación lateral del neumático Variación del movimiento de un lado a otro.

Machinist's rule A steel ruler used for measuring short distances. These rulers are available in USC or metric measurements.

Regla para mecánicos Regla de acero que se utiliza para medir distancias cortas. Dichas reglas están disponibles en medidas del USC o en medidas métricas.

Main menu A display on a computer wheel aligner from which the technician selects various test procedures.

Menú principal Representación visual en una computadora para alineación de ruedas de la que el mecánico puede elegir varios procedimientos de prueba.

Magnetic wheel alignment gauge A gauge that may be attached magnetically to the wheel hub to indicate some wheel alignment angles.

Indicador de alineación de rueda magnética Un indicador que se puede adjuntar magnéticamente al buje de la rueda para indicar algunos ángulos de alineación de la rueda.

Manual test A shock absorber test in which the lower end of the shock is disconnected from the suspension.

Prueba manual Una prueba del amortiguador en la cual el extremo inferior del amortiguador se desconecta de la suspensión.

Material safety data sheets (MSDSs) List appropriate information about hazardous materials.

Hojas de datos de seguridad del material (MSDS, en inglés) Lista con información adecuada acerca de materiales peligrosos.

Memory steer The tendency of the vehicle steering not to return to the straight-ahead position after a turn but to keep steering in the direction of the turn.

Dirección de memoria Tendencia de la dirección del vehículo a no regresar a la posición de línea recta después de un viraje, sino a continuar girando en el sentido del viraje.

Molybdenum disulphide lithium-based grease A special lubricant containing molybdenum disulphide and lithium that may be used on some steering components.

Grasa de bisulfuro de molibdeno con base de litio Lubricante especial compuesto de bisulfuro de molibdeno y litio que puede utilizarse en algunos componentes de la dirección.

Multipull unitized body straightening system A hydraulically operated system that pulls in more than one location when straightening unitized bodies.

Sistema de tiro múltiple para enderezar la carrocería unitaria Sistema activado hidráulicamente que tira hacia más de una dirección al enderezar carrocerías unitarias.

Multipurpose dry chemical fire extinguisher Contains a dry chemical powder used to extinguish various types of fires.

Extintor de incendios multipropósito de polvo químico seco Contiene un polvo químico seco que se utiliza para apagar diversos tipos de incendios.

National Institute for Automotive Service Excellence (ASE) An organization that provides voluntary automotive technician certification in eight areas of expertise.

Instituto Nacional para la excelencia en la reparación de automóviles Organización que provee una certificación voluntaria de mecánico de automóviles en ocho áreas diferentes de especialización.

Neutral coast-down test A chassis vibration test performed while the vehicle is coasting in neutral.

Prueba de marcha desembragado Una prueba de vibración del chasis que se efectúa mientras que el vehículo marcha desembragado.

Neutral run-up test A vibration test performed by accelerating the engine with the transmission in neutral.

Prueba de aceleración desembragado Una prueba de vibración que se efectúa acelerando el motor con la transmisión desembragada.

OBD II computer systems Have monitoring capabilities and inform the driver if emission levels exceed 1.5 time the normal levels for that vehicle year.

Sistemas de computación OBD II Cuentan con capacidades de monitoreo e informan al conductor si los niveles de emisiones superan 1,5 veces los niveles normales para ese año vehicular.

Occupational Safety and Health Act (OSHA) A federal government agency and related laws in the United States that are responsible for ensuring safe and healthful working conditions.

Administración de Seguridad y Salud Ocupacional (OSHA, en inglés) Una agencia del Gobierno Federal, y sus leyes relacionadas, en los Estados Unidos, responsable de garantizar condiciones de trabajo seguro y saludable.

Onboard Diagnostic II (OBD II) Systems are a type of computer system mandated on cars and light trucks since 1996. OBD II systems have a number of mandated standardized features, including several monitoring systems in the PCM.

Sistemas de Capacidad de diagnóstico a bordo II (CDB II) Son un tipo de sistema computarizado obligatorio en automóviles y camionetas ligeras desde 1996. Los sistemas CDB II tienen un número de características estandarizadas obligatorias que incluyen varios sistemas de monitoreo en el módulo de control del motor (MCM).

On-demand DTCs Diagnostic trouble codes that represent intermittent faults in some computer-controlled systems.

DTCs a solicitud Los códigos de fallos diagnósticos que representan los fallos intermitentes en algunos sistemas controlados por computadora.

Oversteer The tendency of a vehicle to turn sharper than the turn selected by the driver.

Sobreviraje Tendencia de un vehículo a girar más de lo que el conductor desea.

Part-finder database Information available in some computer wheel aligners that allows the technician to access part numbers and prices from many undercar parts manufacturers.

Datos para localización de partes La información disponible en algunos alineadores de ruedas electrónicos que permite que el técnico tenga acceso a los números y precios de partes de muchos de los fabricantes de partes del carro inferior.

Pitman arm puller A special puller required to remove a pitman arm.

Extractor del brazo pitman Extractor especial requerido para la remoción de un brazo pitman.

Plumb bob A weight with a sharp, tapered point that is suspended and centered on a string.

Plomada Balanza con un extremo cónico puntiagudo, suspendida y centrada en una hilera.

Ply separation A parting of the plies in a tire casing.

Separación de estrias División de las estrias en la cubierta de un neumático.

Power steering pressure gauge A gauge and valve with connecting hoses for checking power steering pump pressure.

Calibrador de presión de la dirección hidráulica Calibrador y válvula con mangueras de conexión utilizadas para verificar la presión de la bomba de la dirección hidráulica.

Powertrain control module (PCM) A computer that controls engine and possibly transmission functions.

Unidad de control del tren transmisor de potencia Computadora que controla las funciones del motor y posiblemente las de la transmisión.

Prealignment inspection A check of steering and suspension components prior to a wheel alignment.

Inspección antes de una alineación Verificación de los componentes de la dirección y de la suspensión antes de llevarse a cabo una alineación de ruedas.

Preliminary inspection screen A display on a computer wheel aligner that allows the technician to check and record the condition of many suspension and steering components.

Pantalla para la visualización durante una inspección preliminar Representación visual en una computadora para alineación de ruedas que le permite al mecánico revisar y anotar la condición de un gran número de componentes de la suspensión y de la dirección.

Pressure gauge A gauge that may be connected to a pressure source, such as a power steering pump, to determine pump condition.

Indicador de presión Un manómetro que se puede conectar a una fuente de presión, tal como la bomba de la dirección hidráulica, para determinar la condición de la bomba.

Pressure relief valve A valve designed to limit pressure on a pump, such as a power steering pump.

Válvula de relieve de presión Una válvula diseñada para limitar la presión en una bomba, tal como en una bomba de dirección hidráulica.

Programmed ride control (PRC) A computer-controlled suspension system in which the computer operates an actuator in each strut to control strut firmness.

Control programado del viaje Sistema de suspensión controlado por computadora en el que la computadora opera un accionador en cada uno de los montantes para controlar la firmeza de los mismos.

Rack-drive electronic power steering The electronic power steering (EPS) light in the instrument panel should be illuminated when the ignition switch is turned on, in vehicles with rack-drive electronic power steering.

Cremallera de dirección GPE (guiado de propulsión electrónica) La luz del guiado de propulsión electrónica (GPE) en el tablero de control debe iluminarse cuando el selector de encendido se prende en vehículos con cremallera de dirección GPE.

Radial runout The variations in diameter of a round object such as a tire.

Desviación radial Variaciones en el diámetro de un objeto circular, como por ejemplo un neumático.

Reactive Resource Conservation and Recovery Act (RCRA) Provides specific laws regarding hazardous waste disposal.

Acta de Conservación y Recuperación de Recursos Reactivos (RCRA, en inglés) Proporciona leyes específicas respecto de la eliminación de desechos peligrosos.

Rear axle offset A condition in which the complete rear axle assembly has turned so one rear wheel has moved forward and the opposite rear wheel has moved rearward.

Desviación del eje trasero Condición que ocurre cuando todo el conjunto del eje trasero ha girado de manera que una de las ruedas traseras se ha movido hacia adelante y la opuesta se ha movido hacia atrás.

Rear axle sideset A condition in which the rear axle assembly has moved sideways from its original position.

Resbalamiento lateral del eje trasero Condición que ocurre cuando el conjunto del eje trasero se ha movido lateralmente desde su posición original.

Rear main steering angle sensor An input sensor in the rear steering actuator of an electronically controlled four-wheel steering system.

Sensor principal del ángulo de la dirección trasera Sensor de entrada en el accionador de la dirección trasera de un sistema de dirección en las cuatro ruedas controlado electrónicamente.

Rear steering center lock pin A special pin used to lock the rear steering during specific service procedures in an electronically controlled four-wheel steering system.

Pasador de cierre central de la dirección trasera Pasador especial que se utiliza para bloquear la dirección trasera durante procedimientos de reparación específicos en un sistema de dirección en las cuatro ruedas controlado electrónicamente.

Rear sub steering angle sensor An input sensor in the rear steering actuator of a four-wheel steering system.

Sensor auxiliar del ángulo de la dirección trasera Sensor de entrada en el accionador de la dirección trasera de un sistema de dirección en las cuatro ruedas.

Rear wheel camber The tilt of a line through the center of a rear tire and wheel in relation to the true vertical centerline of the tire and wheel.

Comba de la rueda trasera La inclinación de una línea que atraviesa el centro del neumático y la rueda en relación al eje mediano verdadero del neumático y la rueda.

Rear wheel toe The toe setting on the rear wheels.

Ángulo de inclinación de la rueda trasera El ajuste del ángulo de inclinación en las ruedas traseras.

Rear wheel tracking Refers to the position of the rear wheels in relation to the front wheels.

Encarrilamiento de las ruedas traseras Se refiere a la posición de las ruedas traseras con relación a las ruedas delanteras.

Rebound bumpers Rubber stops that prevent metal-to-metal contact between the suspension and the chassis when a wheel strikes a road irregularity and the suspension moves fully upward.

Paragolpes de rebotes Topes de cauchos que previene el contacto de metal a metal entre la suspensión y el chasis cuando una rueda golpea una irregularidad en el camino y la suspensión se mueva totalmente hacia arriba.

Receiver An electronic device on an aligner that receives signals from the wheel sensors.

Receptor Un dispositivo electrónico de un alineador computerizado de cuatro ruedas que recibe las señales de los sensores de las ruedas.

Remote reservoir A container containing fluid that is mounted separately from the fluid pump.

Tanque remoto Recipiente lleno de líquido que se monta separado de la bomba del fluido.

Ribbed V-belt A belt containing a series of small "V" grooves on the underside of the belt.

Correa nervada en V Correa con una serie de ranuras pequeñas en forma de "V" en la superficie inferior de la misma.

Ride height The distance from a specified chassis location to the road surface.

Altura del viaje La distancia de un punto específico del chasis a la superficie del camino.

Ride height screen A display on a computer wheel aligner that illustrates the locations for ride height measurement.

Pantalla para la visualización de la altura del viaje Representación visual en una computadora para alineación de ruedas que muestra los puntos donde se mide la altura del viaje.

Right-to-Know Laws List the worker's rights regarding the handling of hazardous waste materials.

Leyes del Derecho a saber Lista de los derechos de los trabajadores respecto del manejo de materiales de desecho peligrosos.

Rim clamps Special clamps designed to clamp on the wheel rims and allow the attachment of alignment equipment such as the wheel units on a computer wheel aligner.

Abrazaderas de la llanta Abrazaderas especiales diseñadas para sujetar las llantas de las ruedas y así permitir la fijación del equipo de alineación, como por ejemplo las unidades de la rueda en una computadora para alineación de ruedas.

Road feel A feeling experienced by a driver during a turn when the driver has a positive feeling that the front wheels are turning in the intended direction.

Sensación del camino Sensación experimentada por un conductor durante un viraje cuando está completamente seguro de que las ruedas delanteras están girando en la dirección correcta.

Road test A driving procedure used to diagnose specific vehicle problems.

Prueba de camino Un procedimiento de conducción que se usa para diagnosticar los problemas específicos del vehículo.

Safety and gateway module (SGM) Operates the servotronic valve and the electronically controlled orifice valve in some power steering systems.

Módulo de puerta de enlace y seguridad (SGM, en inglés) Opera la válvula servotrónica y la válvula de orificio controlado electrónicamente en algunos sistemas de dirección de potencia.

Safety stands May be called jack stands.

Bases de seguridad Pueden también llamarse bases del gato.

Scan tool A digital computer system tester used to read trouble codes and perform other diagnostic functions.

Exploradore Un probador del sistema de computadora digital que sirve para leer los códigos de errores y para ejecutar otras funciones diagnósticas.

Seal drivers Designed to maintain even contact with a seal case and prevent seal damage during installation.

Empujadores para sellar Diseñados para mantener un contacto uniforme con el revestimiento de la junta de estanqueidad y evitar el daño de la misma durante el montaje.

Section modulus The measurement of a frame's strength based on height, width, thickness, and the shape of the side rails.

Coeficiente de sección Medida de la resistencia de un armazón, basada en la altura, el ancho, el espesor y la forma de las vigas laterales.

Sector shaft lash Refers to the movement between the sector teeth and ball nut teeth.

Coletazo del eje de sector Se refiere al movimiento entre el dentado del sector y el de la tuerca esférica.

Serpentine belt A ribbed V-belt drive system in which all the belt-driven components are on the same vertical plane.

Correa serpentina Sistema de transmisión con correa nervada en V en el que todos los componentes accionados por una correa se encuentran sobre el mismo plano vertical.

Service check connector A diagnostic connector used to diagnose computer systems. A scan tool may be connected to this connector.

Conector para la revisión de reparaciones Conector diagnóstico que se utiliza para diagnosticar sistemas informáticos. A dicho conector se le puede conectar un verificador de exploración.

Servotronic valve A computer-controlled valve in an active steering system that controls power steering pump pressure in relation to vehicle speed.

Válvula servotrónica Una válvula controlada por computadora en un sistema de dirección activo que controla la presión de la bomba de dirección de potencia de acuerdo con la velocidad del vehículo.

Setback Occurs when one front or rear wheel is driven rearward in relation to the opposite front or rear wheel.

Retroceso Condición que ocurre cuando una de las ruedas delanteras se mueve hacia atrás con relación a la rueda delantera opuesta.

Sheared injected plastic Is inserted into steering column shafts and gearshift tubes to allow these components to collapse if the driver is thrown against the steering column in a collision.

Plástico cortado inyectado Insertado en los árboles de la columna de dirección y en los tubos del cambio de engranajes de velocidad para permitir que estos componentes se pleguen si la columna de dirección es impactada por el conductor durante una colisión.

Shim display screen A display on a computer wheel aligner that shows the technician the thickness and location of the proper shims for rear wheel alignment.

Pantalla de laminillas de ajuste Una presentación en un alineador de ruedas que demuestra al técnico el espesor y localización de las laminillas apropiadas para alineación de las ruedas traseras.

Single-pull unitized body straightening system Hydraulically operated equipment that pulls in one location while straightening unitized bodies.

Sistema enderezador de tiro único para la carrocería unitaria Sistema activado hidráulicamente que tira hacia una dirección al enderezar carrocerías unitarias.

Slip plates Plates that are placed under the rear wheels during a wheel alignment to allow rear wheel movement during rear suspension adjustments.

Placas de patinaje Las placas que se colocan debajo de las ruedas traseras durante un alineación de ruedas traseras para permitir el movimiento de las ruedas traseras durante el ajuste de la suspensión trasera.

Slow acceleration test A chassis vibration test performed by slowly accelerating the vehicle.

Prueba de aceleración lenta Una prueba de vibración del chasis que se efectúa por medio de una aceleración lenta del vehículo.

Soft-jaw vise A vise equipped with soft metal, such as copper, in the jaws.

Tornillo con tenacilla maleable Tornillo equipado con un metal blando, como por ejemplo cobre, en las tenacillas.

Specifications menu A display on a computer wheel aligner that allows the technician to select, enter, alter, and display vehicle specifications.

Menú de especificaciones Representación visual en una computadora para alineación de ruedas que le permite al mecánico seleccionar, introducir datos, cambiar e indicar especificaciones referentes al vehículo.

Splice pack A special connector in a vehicle network that may be disconnected to isolate specific components for diagnostic purposes.

Paquete de empalmes Un conector especial en una red de vehículos que se puede desconectar para aislar componentes específicos con fines de diagnóstico.

Spring compressing tools Tools that are used to compress a coil spring during the removal and replacement procedure.

Herramientas de compresión de resortes Las herramientas que se usan para comprimir un resorte helicoidal durante el procedimiento de remoción y refacción.

Spring insulators Rings usually made from plastic and positioned on each end of a coil spring to reduce noise and vibration transfer to the chassis.

Aisladores de muelles Anillos, por lo general fabricados de plástico y colocados a ambos extremos de un muelle helicoidal, que se

utilizan para disminuir la transferencia de ruido y de vibración al chasis.

Spring silencers Plastic spacers placed between spring leaves to reduce noise.

Amortiguadores de los resortes Las arandelas de plástico puestas entre los muelles de hojas para disminuir el ruido.

Stabilizer bar A round steel bar connected between the front or rear lower control arms that reduces body sway.

Barra estabilizadora Barra circular de acero conectada entre los brazos de mando delantero o trasero que disminuye la oscilación lateral de la carrocería.

Standing acceleration test A vibration test performed during moderate vehicle acceleration.

Prueba de aceleración fijo Una prueba de vibración que se efectúa durante una aceleración moderada del vehículo.

Static balance Refers to the balance of a tire and wheel at rest.

Equilibrio estático Refiere al equilibrio de una rueda y de un neumático y una rueda cuando se ha detenido la marcha del vehículo.

Steering axis inclination (SAI) The tilt of a line through the center of the upper and lower ball joints or through the center of the lower ball joint and the upper strut mount in relation to the true vertical centerline of the tire and wheel.

Inclinación del eje de dirección (SAI) La inclinación de una línea que atraviesa el centro de las juntas esféricas superiores e inferiores o por el centro de la junta esférica inferior y el montaje del tirante superior en relación al eje mediano verdadero del neumático y de la rueda.

Steering effort The amount of effort required by the driver to turn the steering wheel.

Esfuerzo de dirección Amplitud de esfuerzo requerido por parte del conductor para girar el volante de dirección.

Steering effort imbalance Occurs when more effort is required to turn the steering wheel in one direction than in the opposite direction.

Desequilibrio del esfuerzo en dirección Ocurre cuando se requiere más esfuerzo para girar la rueda en una dirección que en la dirección opuesta.

Steering input test A vibration test performed while driving the vehicle through turns.

Prueba de entrada de dirección Una prueba de vibración que se efectúa mientras que el vehículo completa los virajes.

Steering pull The tendency of the steering to pull to the right or left when the vehicle is driven straight ahead on a smooth, straight road surface.

Tiro de la dirección Tendencia de la dirección a desviarse hacia la derecha o hacia la izquierda mientras se conduce el vehículo en línea recta en un camino cuya superficie es lisa y nivelada.

Steering wheel free play The amount of steering wheel movement before the front wheels begin to turn.

Juego libre del volante de dirección Amplitud de movimiento del volante de dirección antes de que las ruedas delanteras comiencen a girar.

Steering wheel locking tool A special tool used to lock the steering wheel during certain wheel alignment procedures.

Herramienta para el cierre del volante de dirección Herramienta especial que se utiliza para bloquear el volante de dirección durante ciertos procedimientos de alineación de ruedas.

Stethoscope A special tool that amplifies sound to help diagnose noise location.

Estetoscopio Herramienta especial que amplifica el sonido para ayudar a diagnosticar la procedencia de los ruidos.

Struts Similar to shock absorbers, but struts also support the steering knuckle.

Montantes Parecidos a los amortiguadores, pero los montantes también sostiene el muñón de dirección.

Strut cartridge The inner components in a strut that may be replaced rather than replacing the complete strut.

Cartucho del montante Componentes internos de un montante que pueden ser reemplazados en vez de tener que reemplazarse todo el montante.

Strut chatter A chattering noise as the steering wheel is turned, often caused by a binding upper strut mount.

Vibración del montante Rechinamiento producido mientras se gira el volante de dirección. A menudo ocasionado por el trabamiento del montaje del montante superior.

Strut rod A rod connected from the lower control arm to the chassis to prevent forward and rearward control arm movement.

Varilla del montante Varilla conectada del brazo de mando inferior al chasis que se utiliza para evitar el movimiento hacia adelante o hacia atrás del brazo de mando.

Strut tower A circular, raised, reinforced area inboard of the front fenders that supports the upper strut mount and strut assembly.

Torre del montante Área circular, elevada y reforzada en la parte interior de los guardafangos delanteros que apoya el conjunto del montante y montaje del montante superior.

Sunburst cracks Cracks that radiate outward from an opening in the vehicle frame.

Grietas radiales Las grietas que radian hacia afuera desde una apertura en el armazón del vehículo.

Suspension adjustment link An adjustable link connected horizontally from the suspension to the chassis.

Biela de ajuste de la suspensión Una biela ajustable conectada horizontalmente de la suspensión al chasis.

Symmetry angle measurements On some computer-controlled wheel aligners, they help the technician determine if out-of-specifications readings may have been caused by collision or frame damage.

Medidas de simetría de los ángulos En algunos alineadores de ruedas controlados por computadora, ayudan al técnico en determinar si las medidas fuera de especificación puedan haber sido causadas por una colisión o un daño al bastidor.

Tapered-head bolts A bolt with a taper on the underside of the head.

Pernos de cabeza cónica Perno con una cabeza cuya superficie inferior es cónica.

Thrust line A line positioned at a 90° angle to the rear axle and projected toward the front of the vehicle.

Línea de empuje Línea colocada a un ángulo de 90° con relación al eje trasero y proyectada hacia la parte frontal del vehículo.

Tie-rod end and ball joint puller A special puller designed for removing tie-rod ends and ball joints.

Extractor para la junta esférica y el extremo de la barra de acoplamiento Extractor especial diseñado para la remoción de las juntas esféricas y los extremos de barras de acoplamiento.

Tie-rod sleeve adjusting tool A special tool required to rotate tie-rod sleeves without damaging the sleeve.

Herramienta para el ajuste del manguito de la barra de acoplamiento Herramienta especial requerida para girar los manguitos de las barras de acoplamiento sin estropearlos.

Tire changer Equipment used to dismount and mount tires on wheel rims.

Cambiador de neumáticos Equipo que se utiliza para desmontar y montar los neumáticos en las llantas de las ruedas.

Tire conicity Occurs when the tire belt is wound off-center in the manufacturing process creating a cone-shaped belt, which results in steering pull.

Conicidad del neumático Condición que ocurre cuando la correa del neumático se devana fuera del centro durante el proceso de fabricación creando así una correa en forma cónica y trayendo como resultado el tiro de la dirección.

Tire inspection screen A screen on a computer-controlled wheel aligner that allows the technician to enter the condition of each vehicle tire.

Pantalla de inspección de los neumáticos Una pantalla en un alineador de ruedas controlado por computadora que permite que el técnico anote la condición de cada neumático del vehículo.

Tire rotation Involves moving each tire and wheel to a different location on the vehicle to increase tire life.

Rotación de los neumáticos Involucra moviendo cada neumático y rueda a una posición diferente en el vehículo para prolongar la vida del neumático.

Tire thump A pounding noise as the tire and wheel rotate, usually caused by improper wheel balance.

Ruido sordo del neumático Ruído similar al de un golpe pesado que se produce mientras el neumático y la rueda están girando. Por lo general este ruido lo ocasiona el desequilibrio de la rueda.

Tire tread depth gauge A special tool required to measure tire tread depth.

Calibrador de la profundidad de la huella del neumático Herramienta especial requerida para medir la profundidad de la huella del neumático.

Tire vibration Vertical or sideways tire oscillations.

Vibración del neumático Oscilaciones verticales o laterales del neumático.

Toe gauge A special tool used to measure front or rear wheel toe.

Calibrador del tope Herramienta especial que se utiliza para medir el tope de las ruedas delanteras o traseras.

Toe-in A condition in which the distance between the front edges of the tires is less than the distance between the rear edges of the tires.

Convergencia Condición que ocurre cuando la distancia entre los bordes frontales de los neumáticos es menor que la distancia entre los bordes traseros de los mismos.

Toe-out A condition in which the distance between the front edges of the tires is more than the distance between the rear edges of the tires.

Divergencia Condición que ocurre cuando la distancia entre los bordes delanteros de los neumáticos es mayor que la distancia entre los bordes traseros de los mismos.

Torque steer The tendency of the steering to pull to one side during hard acceleration on front wheel drive vehicles with unequal length front drive axles.

Dirección de torsión Tendencia de la dirección a desviarse hacia un lado durante una aceleración rápida en un vehículo de tracción delantera con ejes de mando desiguales.

Total toe The sum of the toe angles on both wheels.

Tope total Suma de los ángulos del tope en ambas ruedas.

Track gauge A long straight bar with adjustable pointers used to measure rear wheel tracking in relation to the front wheels.

Calibrador del encarrilamiento Barra larga y recta con agujas ajustables que se utiliza para medir el encarrilamiento de las ruedas traseras con relación a las ruedas delanteras.

Tram gauge A long, straight bar with adjustable pointers used to measure unitized bodies.

Calibrador del tram Barra larga y recta con agujas ajustables que se utiliza para medir carrocerías unitarias.

Tread wear indicators Raised portions near the bottom of the tire tread that are exposed at a specific tread wear.

Indicadores del desgaste del neumático Secciones elevadas cerca de la parte inferior de la huella del neumático que quedan expuestas cuando la huella alcanza una cantidad de desgaste específica.

Trim height The normal chassis riding height on a computer-controlled air suspension system.

Altura equilibrada Altura normal de viaje del chasis en un sistema de suspensión controlado por computadora.

Turning radius gauge A gauge with a degree scale mounted on turntables under the front wheels.

Calibrador del radio de giro Calibrador con una escala de grados montado sobre plataformas giratorias debajo de las ruedas delanteras.

Turntable A mechanical device placed under each front wheel during a wheel alignment to allow the front wheels to be turned in each direction to measure various front suspension angles.

Plataforma giratoria Un dispositivo mecánico colocado debajo de cada rueda delantera durante la alineación de ruedas para permitir girar las ruedas delanteras en cada dirección para medir varios ángulos de la suspensión delantera.

Understeer The tendency of a vehicle not to turn as much as desired by the driver.

Dirección pobre Tendencia de un vehículo a no girar tanto como lo desea el conductor.

U.S. Customary (USC) system A system of weights and measures patterned after the British system.

Sistema usual estadounidense (USC) Sistema de pesos y medidas desarrollado según el modelo del Sistema Imperial Británico.

Vacuum hand pump A mechanical pump with a vacuum gauge and hose used for testing vacuum-operated components.

Bomba de vacío manual Bomba mecánica con un calibrador de vacío y una manguera que se utiliza para probar componentes a depresión.

Vehicle Dynamic Suspension (VDS) Is a computer-controlled air suspension system used on some current model vehicles.

Suspensión dinámica del vehículo (SDV) Es un sistema de suspensión de aire que se usa en algunos vehículos de modelo reciente.

Vehicle lift A hydraulically or air-operated mechanism for lifting vehicles.

Levantamiento del vehículo Mecanismo activado hidráulicamente o por aire que se utiliza para levantar vehículos.

Vehicle wander The tendency of the steering to pull to the right or left when the vehicle is driven straight ahead on a straight road.

Desviación de la marcha del vehículo Tendencia de la dirección a desviarse hacia la derecha o hacia la izquierda cuando se conduce el vehículo en línea recta en un camino cuya superficie es lisa.

V-type belt A drive belt with a V shape.

Correa en V Una correa de transmisión en forma de V.

Woodruff key A half-moon-shaped metal key used to retain a component, such as a pulley, on a shaft.

Chaveta woodruff Chaveta de metal en forma de media luna que se utiliza para sujetar un componente, como por ejemplo una roldana, en un árbol.

Workplace hazardous materials information systems (WHMIS) Are similar to MSDS sheets and they provide information regarding the handling of hazardous waste materials.

Sistemas de información acerca de materiales peligrosos en el lugar de trabajo (WHMIS, en inglés) Son similares a las hojas de datos MSDS y brindan información acerca del manejo de materiales de desecho peligrosos.

A

ABS (antilock brake system), 280
 Accessory drive frequencies, 155–156
 Actuators, 187–188
 rear steering actuator service, 439–440
 Adjustment bolts, 529–531
 Adjustment screens, of computer alignment system, 502–506
 Air bag deployment modules, 295–300
 avoiding accidental deployment, 299
 removal and replacement, 296–297
 Air bag safety, 17
 Air quality, 5
 Air shock absorbers, diagnosis and replacement, 174
 Air springs
 inflation, 264–265
 with integral struts, removal and replacement, 262–264
 removal and disassembly, on VDS systems, 272–274
 removal and installation, 261–262
 Air suspension systems, 261–268
 air spring inflation, 264–265
 air spring removal and installation, 261–262
 air springs with integral struts, removal and replacement, 262–264
 line service, 267–268
 trim height mechanical adjustment, 265–267
 Alcohol use, 12
 Alignment. *See* Wheel alignment
 Alignment angles, 492
 Alignment ramps, 491
 Antilock brake system (ABS), 280
 Antitheft locking wheel covers, 123
 Antitheft wheel nuts, 123
 Aqueous parts cleaning tanks, 25
 Asbestos, 3, 10
 ASE blue seal of excellence, 73
 Automatic transaxles (ATX), 102
 Automatic transmissions, steering column diagnosis, 309–311
 Automotive shops
 cleanliness of, 16–17
 layout, 9
 safety. *see* Safety
 Automotive technicians
 job responsibilities, 72
 obligations of, 70–72
 Automotive training, 70
 Axle offset, 504, 550
 Axle pullers, 42

B

Backup mode, 434
 Backup power supply, 295
 Balancing, tire and wheel servicing and, 120–156
 dynamic wheel balance procedure, 143–145
 electronic wheel balancers, 145–148
 on-car balancing, 149–150
 preliminary wheel balancing checks, 141–142
 static wheel balance procedure, 144
 tire and wheel runout measurement, 138–140
 tire and wheel service, 123–124
 tire and wheel service precautions, 124–127
 tire inflation pressure, 142–143
 tire inspection and repair, 129–130
 tire noises and steering problems, 120–123
 tire pressure monitoring systems, 132–134
 tire remounting procedure, 131–132
 tire rotation, 122–123
 tread wear measurement, 140
 wheel rim service, 130–131
 Ball joint removal and installation tools, 48
 Ball joints
 checking, on twin I-beam axles, 207
 diagnosis and replacement, 211–213, 242
 horizontal measurement, 205
 inspection, 203
 unloading, 204
 vertical measurement, 204–205
 Ball joint vertical movement, 204–205
 Ball joint wear indicator, 203
 Batteries, 2, 5
 disposal, 25
 Bearing brinelling, 90
 Bearing defects, diagnosis of, 89–90
 Bearing fatigue spalling, 90
 Bearing fretting, 112
 Bearing preload, 271, 372
 Bearing pullers, 42
 Bearing races, 93
 Bearings. *See* Wheel bearings
 Bearing smears, 90
 Bellows boots, 388
 Belts, power steering, 335–337
 Belt tension gauge, 336
 Bench grinders, 54
 Bench systems, 469
 Bodies. *See* Frame diagnosis and service
 Body sway, 236
 Bolt mountings, 193
 Bounce tests, 172
 Brake parts washer, 10
 Brake pedal depressors, 497
 Brake pedal jack, 52
 Brake pressure modulator valve (BPMV), 280
 Brake problems, 485–487
 Brake torque test, 152
 Buckle, 462
 Bump steer, 486, 487
 Bushing condition, 171
 Bushings, front lower control arm bushing removal and replacement, 218–219

C

- Camber, 497
- Camber adjustment, 524–530
 - eccentric cams, 531
 - rear wheel, 541–543
 - shims, 524–525
 - slotted strut mounts and frames, 528
 - special adjustment bolts, 529–530
 - special tools for, 530
 - on twin I-beam front suspension systems, 531
- Camber angles, 205
- Camber bolts, 176
- Camber settings, 485
- Carbon monoxide, 2, 5, 12
- Carrying objects, 19–20
- Caster, 499
- Caster adjustment, 531–536
- Caster angles, 205
- Caustic liquids, 2
- Center link, diagnosis and replacement, 313–314, 318
- Certification, ASE, 72–73
- Chassis vibration, 250
- Chassis waddle, 139–140, 250
- Chattering noise, 188
- Circlips, 99, 102
- Claw washers, 401
- Cleanliness, 16–17
- “C” locks, 104
- Clock spring electrical connector, 295–296
- Coil spring compressor tool, 49, 62–64
- Coil spring interference problems, 174
- Coil springs
 - installation, on strut, 179–180
 - installation of strut-and-spring assembly, 181
 - lower control arm and spring replacement, 216–217
 - rear, diagnosis and service, 237
 - removal of strut from, 177–178
- Cold parts washers, 24
- Collapsible steering columns, 301
- Column-drive electronic power steering, 411–414
- Compressed-air equipment safety, 23
- Compressor, coil springs, 49–50
- Computer alignment systems, 53–54, 67–68, 491–508
 - adjustment screens, 502–506
 - diagnostic drawing and test screens, 506–508
 - main menu, 493
 - preliminary inspection screen, 494
 - preliminary procedure, 491–493
 - ride height screen, 495
 - specifications menu, 494
 - tire condition screen, 495–496
 - wheel alignment screens, 497–499
 - wheel runout compensation screen, 496–497
- Computer-controlled suspension system service, 259–284
 - electronic air suspension diagnosis and service, 261–268
 - electronic suspension control systems, 274–276

- preliminary inspection, 259–260
- programmed ride control system diagnosis, 260–261
- scan tool diagnosis of ESC, 276–284
- vehicle dynamic suspension systems, 269–274

Continuously variable road sensing suspension (CVRSS) systems, 275

Control arm bushing tools, 48

Control arm diagnosis and service, 213–222

- front leaf spring inspection and replacement, 212–213
- front lower control arm bushing removal and replacement, 218–219
- lower control arm and ball joint diagnosis and replacement, 242–247
- lower control arm and spring replacement, 216–217
- lower control arm replacement, 213–214
- rebound bumpers, 218
- stabilizer bar diagnosis and replacement, 220
- strut rod diagnosis and replacement, 220–221
- upper control arm removal and replacement, 217–218

Control arm movement monitor, 508

Cords, frayed, 2, 13

Corrosive materials, 26

Crocus cloth, 346

Curb riding height measurement, 201–202, 236–237

Customer satisfaction, 511

Customer service, 42

- attitude toward, 242
- careful vehicle operation and, 15–16
- preventive maintenance promotion, 338
- terminology use, 281
- time estimates, 77

D

- Damper control, 437
- Data link connector (DLC), 265
- Datum line, 467
- Dedicated fixtures, 470
- Diagnostic drawing and test screens, of computer alignment system, 506–508
- Diagnostic procedure charts, 75
- Diagnostic procedures, basic, 41
- Diagnostic trouble codes (DTCs)
 - electronic suspension control systems, 274–278, 280
 - Magnasteer systems, 408
 - programmed ride control system, 260–261
 - rack-drive EPS, 409–410
 - rear wheel steering, 434–436
- Dial indicators, 44, 60–62
- Diamond-shaped frames, 462, 551
- Digital adjustment photos, 506
- Digital signal processor (DSP), 492
- Directional stability, 202, 248
 - lack of, 107
- Distance conversions, 41
- Downshift test, 152
- Drain covers, 2
- Drive axles
 - diagnosis, 99
 - removal, 99–100

Drug use, 12
Dust, 3
Dynamic wheel balance, 143

E

Eccentric camber bolts, 176
Eccentric cams, 525–528
Electrical safety, 13
Electronic air suspension systems, 261–268
 air spring inflation, 264–265
 air spring removal and installation, 261–262
 air springs with integral struts, removal and replacement, 262–264
 line service, 267–268
 trim height mechanical adjustment, 265–267
Electronically controlled shock absorbers, diagnosis, 187–188
Electronic brake and traction control module (EBTCM), 280, 408
Electronic four-wheel steering, 432–451
 damper control, 422
 diagnosis, 434, 437–439
 preliminary inspection, 432
 Quadrasteer diagnosis, 448–449
 rear steering actuator service, 439–446
 trouble codes, 437–439
Electronic power steering (EPS)
 column-drive, 411–414
 rack-drive, 409–410
Electronic suspension control (ESC) systems
 diagnosis, 274–276
 scan tool diagnosis, 276–284
Electronic training, 70
Electronic vibration analyzer (EVA), 151, 153–154
Electronic wheel balancers, 46, 67, 145–148
 with LFM and radial force variation capabilities, 145–148
Employer obligations, 71
End plug seal replacement, 376
Engine and engine firing frequency, 155
Engine coolant, disposal, 26
Environmental Protection Agency (EPA), 26
Equipment
 floor jacks, 56, 57
 hydraulic presses, 55–56
 safety stands, 57–58
 vehicle lifts, 57, 58–59
Equipment cleaning, 23–26
Eye injuries, 7
Eyewash fountains, 7

F

Face shields, 7–8
Fail-safe mode, 434
Falls, 3
Fire extinguishers, 6–7, 15
Fire safety, 14–15
First-aid kits, 8–9
Flammable liquids, 2
Flammable materials, 2
Flexible coupling installation, 308

Floor jacks, 56, 57
Flow control valves, 346–347
Fluids
 disposal, 26
 power steering, 338–339
Four wheel alignment adjustments, 523–552
 camber adjustment, 524–531
 caster adjustment, 531–539
 rear suspension adjustments, 541–543
 rear wheel tracking measurement, 548–550
 SAI correction procedure, 537
 setback measurement and correction procedure, 534–536
 steering wheel centering procedure, 539–540
 toe adjustment, 537–539
Four wheel alignment procedure, 485–511
 bent front strut diagnosis, 510–511
 checking toe change and steering linkage height, 508–510
 with computer alignment systems, 491–497
 preliminary inspection, 485–487
Four-wheel steering, electronic, 432–451
 damper control, 437
 diagnosis, 433, 437–439
 preliminary inspection, 432, 433–434
 Quadrasteer diagnosis, 434
 rear steering actuator service, 439–444
 trouble codes, 437–439
Frame damage
 indications of, 461
 prevention, 461
Frame diagnosis and service, 461–474
 checking frame alignment, 462–468
 measurement of unitized body alignment, 468–471
Frame measurement
 plumb bob method, 464–467
 tram gauge method, 466–467
 of unitized bodies, 468–471
Frame straightening, 467
Frame web, 462
Frame welding, 464
Free play, steering wheel, 307, 371, 387, 388
Front and rear wheel alignment angle screens, 497
Front bearing hub tool, 43
Front drive axles
 diagnosis, 99
 removal, 99–102
Front spring noise diagnosis, 224
Front struts, bent, 510–511
Front suspension adjustments, 545
Front suspension system service, 201–224
 ball joint checking, 207
 ball joint inspection, 203
 ball joint measurement, 204–205
 ball joint replacement, 211–213
 ball joint unloading, 204
 control arm diagnosis and service, 213–222
 curb riding height measurement, 201–202

- diagnosis and service, 202–213, 220
- front steering knuckle diagnosis and service, 207
- front steering knuckle replacement, 210
- torsion bar adjustment, 202–203
- torsion bars, removing and replacing, 222–224

Front wheel alignment. *See also* Wheel alignment, 524

Front wheel bearings, hub unit removal and replacement, 102

Front wheel shimmy, 313

G

- Gasoline safety, 13
- Gasoline storage cans, 13
- Geometric centerline, 543

H

- Hand tool safety, 20
- Harsh ride quality, 188
- Hazard Communication Standard, 27
- Hazardous waste disposal, 26–28
 - Right-to-Know laws, 2
 - safety considerations, 27
- Hazardous waste material, 2
- Heavy objects, lifting and carrying, 19–20
- Heavy spots, 144
- HEV service precautions, 350–351
- High-frequency transmitters, 492
- High-pressure air, 2
- Hoists, 57
- Hot cleaning tanks, 24
- Housekeeping safety, 16–17
- Hub nut torque, 103
- Hydraulic jack safety, 21–22
- Hydraulic presses, 55–56

I

- Idler arms, 318–319
- Ignitable materials, 26
- Incandescent bulbs, 3
- Included angle, 499
- Integral reservoirs, 346
- International system (IS), 39

J

- Jerry cans, 14
- Job responsibilities, 72

L

- Lateral axle sideset, 504
- Lateral chassis movement, 248
- Lateral force measurement (LFM), 145–147
- Lateral movement, 236
- Lateral tire runout, 139–140
- Layout, shop, 9
- Leaf springs
 - front, inspection and replacement, 221–222
 - noise, 224
 - rear, diagnosis and replacement, 247–248
- Leaks
 - oil, 25, 171, 188, 342–343, 375–376
 - wheel rim leak repair, 131

- Length, 40–41
- Lifting equipment, 55–56
- Lifting objects, 19–20
- Lift safety, 21
- Line fittings, 375
- Liquids, disposal of, 26
- Lock systems, 309
- Loose clothing/hair, 2
- Loose steering, 397
- Low riding height, 224, 250
- Lubrication, bearing, 94

M

- Machinist's rule, 46
- Macpherson strut suspension systems
 - lower control arm replacement, 213–215
 - strut and spring removal and replacement, 237–241
 - strut removal and replacement, 176
- Magnasteer systems, 408–409
- Magnetic learning tool, 137
- Magnetic wheel alignment gauge, 52
- Main menu, of computer alignment system, 493
- Main steering angle sensor system, 439
- Maintenance schedules, 376
- Malfunction indicator light (MIL), 356
- Manual steering and suspension systems, diagnosis, 396
- Manual tests, of shock absorbers, 172–174
- Manual transmissions
 - steering column diagnosis, 309–312
 - tilt column diagnosis, 312
- Mass, 40
- Material safety data sheets (MSDS), 28–29
- Measurement equivalents, 40
- Measuring systems, 39–41
- Memory steer, 486
- Metric Conversion Act, 40
- Metric system, 39–40
- Molybdenum disulphide lithium-based grease, 305
- Morning sickness, 401
- Mounting bolts, 171
- Mounting bushings, 171
- Multipull equipment, 471
- Multipurpose dry chemical fire extinguishers, 6–7

N

- National Institute for Automotive Service Excellence (ASE)
 - certification, 72–73
- Neutral coast-down test, 152
- Neutral run-up test, 152
- Noise levels, 3
- Noises
 - chattering, 188
 - diagnostics for, 107
 - front spring, 174–175
 - leaf spring, 221
 - rattling, 188, 236
 - rear suspension, 235
 - strut chatter, 175

suspension, 222, 224, 240
tire, 120
when turning, 377

O

OBD II computer systems, 265, 267
Occupational Safety and Health Act (OSHA), 2
Occupational Safety and Health Administration (OSHA), 27
Oil, disposal, 25
Oil filters, disposal, 275
Oil leakage, 25, 171, 188, 342–343, 375–376
On-board diagnostic II (OBD II) systems, 65, 267, 412
On-car balancing, 149–150
O-ring replacement, 375–376

P

Parts washers
 with agitation immersion tanks, 24
 with electromechanical agitation, 24
Patch installation, 130
Personal safety, 11–12
Pitman arm puller, 50
Pitman arms, 313, 315
Pitman sector shaft lash adjustment, 371, 373
Plug installation, 130
Plumb bob method, of frame measurement, 464
Plumb bobs, 51, 464
Ply separation, 129
Pneumatic test, 270–271
Power steering diagnosis, 407
Power steering lines and hoses
 hose replacement, 349
 inspection and service, 348
Power steering pressure gauge, 49, 59–60
Power steering pumps, 335–357
 belt service, 335–337
 diagnosis, 340–342
 flow control valve and end cover removal and replacement, 346–347
 fluid service, 338–339
 oil leak diagnosis, 342–343
 pressure tests, 344–345, 341
 pulley replacement, 345–346
 replacement, 345
 reservoir removal and replacement, 346
 servicing, 348
Power tool safety, 22–23
Powertrain control module (PCM), 277
Prealignment inspection, 487–489
Preliminary inspection screen, of computer alignment system, 494
Pressure gauges, 49
Pressure relief valves, 348
Programmed ride control (PRC) systems, 260–261
Protective clothing/equipment, 3

Q

Quadrasteer diagnosis, 434–436

R

Rack and pinion steering gear, 387–417
 column-drive EPS, 411
 inner tie-rod end, removing and replacing, 406–407
 Magnasteer systems, 408–409
 manual, diagnosis and service, 395–396
 on-car inspection, 387–389
 power, diagnosis and service, 396–405
 oil leak diagnosis, 399–400
 tie-rod and rack bearing service, 401–405
 turning imbalance diagnosis, 400–401
 power, removal and replacement, 407
 power steering, steering column, and suspension system diagnosis, 407
 rack-drive electronic power steering, 409–410
 removal and replacement, 389–392
 tie-rod service, 395–396
Rack bearing service, 401–405
Rack-drive electronic power steering, 409–410
Radial force variations, 145
Radial tire runout, 138
Rattling noise, 188, 221
Reactive materials, 26
Rear-axle bearing and seal service, 104–107
Rear axle offset, 550
Rear main steering angle sensor, 445
Rear shock absorber visual inspection and bounce test, 173
Rear steering actuator sensors, 445
Rear steering actuator service, 439–446
Rear steering center lock pin, 440
Rear sub steering angle sensor, 445
Rear suspension adjustments, 541–546
 rear wheel camber adjustment, 541–543
 rear wheel toe adjustment, 543
Rear suspension service, 235–250
 calculating vibration frequencies, 154–156
 curb riding height measurement, 236–237
 diagnosis, 250
 leaf-spring diagnosis and replacement, 247–248
 lower control arm and ball joint diagnosis and replacement, 242, 244–247
 noise diagnosis, 235–236
 rear strut, coil spring, and upper mount diagnosis and service, 237, 239–240
 ride harshness diagnosis, 235
 road tests, 151–153
 stabilizer bar diagnosis and service, 248–249
 sway and lateral movement diagnosis, 236
 tie rod inspection and replacement, 250
 track bar diagnosis and replacement, 248
 vibration diagnosis, 150–151
 vibration diagnosis with EVA, 153–154
Rear wheel alignment. *See also* Wheel alignment
 causes of improper, 541
 procedure, 523
Rear wheel bearings, adjusting, 96
Rear wheel camber, 541

- Rear wheel camber adjustment, 541–543
- Rear-wheel-drive vehicles
 - front steering knuckle replacement, 210–211
 - rear-axle bearing and seal service, 104–107
- Rear wheel steering data, 434
- Rear wheel toe, 543
- Rear wheel toe adjustment, 543–546
- Rear wheel tracking measurement, 548, 549–550
- Rebound bumpers, 188, 204
- Receivers, 493
- Recirculating ball steering gear, 369–377
 - adjustments, 371–373
 - pitman sector shaft lash, 371, 373
 - worm shaft thrust bearing preload, 371
 - diagnosis, 369–370
 - oil leak diagnosis, 375
 - replacement, 370
 - seal replacement, 375–376
- Refrigerants, disposal, 26
- Remote reservoirs, 339
- Resource Conservation and Recovery Act (RCRA), 26–27
- Respect, for customers, 471
- Ribbed V-belt, 337
- Ride harshness, 205, 235
- Ride height, 495
- Ride height adjustment, 269–270
- Ride height screen, of computer alignment system, 495
- Right-to-Know laws, 2, 27
- Rim clamps, 52, 491
- Road feel, 373
- Road tests, 151–152, 437, 485

S

- SAE J1930 terminology, 434
- Safety, 1–29
 - air bag, 17–19
 - air quality, 5–6
 - in automotive shop, 10–11
 - carrying, 19
 - in checking frame alignment, 462
 - compressed-air equipment, 23
 - electrical, 13
 - equipment cleaning and, 23–26
 - fire, 14–15
 - gasoline, 13–14
 - hand tool, 20
 - with hazardous wastes, 26–28
 - housekeeping, 16–17
 - hydraulic jack, 21–22
 - importance of, 2
 - lift, 21
 - lifting, 19
 - OSHA, 2
 - personal, 11–12
 - power tool, 22–23
 - safety stand, 21–22
 - shop hazards and, 2–3
 - shop safety rules, 3–5
 - vehicle operation, 15–16
- Safety equipment, 6–9
 - eyewash fountains, 7
 - face shields, 7, 8
 - fire extinguishers, 6–7
 - first-aid kits, 8–9
 - safety glasses, 7, 8
- Safety glasses, 7, 8
- Safety stands, 57–58
- Safety stand safety, 21–22
- Sag, 462
- SAI angle, 500
- Scan tool, 54, 65–67
 - for air spring inflation, 265
 - diagnosis of column-drive EPS, 412
 - diagnosis of ESC, 276–277
 - diagnosis of HEV and EHPS systems, 354–355
 - diagnosis of Magnasteer systems, 408
 - inflate L/H front air spring using, 266–267
 - Quadrasteer diagnosis, 434
 - reading data on electronic suspension control system, 279
- Seal drivers, 42
- Section modulus, 462
- Sector shaft lash, 371, 373
- Self-test
 - of PRC systems, 260
 - of VDS systems, 272
- Serpentine belts, 337
- Service check connector, 438
- Service manuals, 74–77
- Setback, 499, 534, 550
- Setback measurement and correction procedure, 534–536
- Sewer covers, 2
- Shim display screen, 506
- Shims, 524
- Shock absorbers
 - air, 174
 - bounce test, 172
 - diagnosis of electronically controlled, 167–168
 - manual tests, 162–164
 - removal and disassembly, on VDS systems, 176–177
 - replacement, 174–176
 - visual inspections, 171–172
- Shop hazards, 2–3
- Shop layout, 9
- Shop safety equipment, 6–9
- Shop safety rules, 3–5, 10–12
- Shop towels, disposal, 26
- Short-and-long arm (SLA) suspension systems
 - lower control arm and spring replacement, 216–217
 - upper control arm removal and replacement, 217–218
- Side cover O-ring replacement, 398
- Side sway, 464
- Single-pull equipment, 471
- Slip plates, 491
- Slips, 3

- Slow acceleration test, 151
- Smoking, 12
- Society of Automotive Engineers (SAE), 412
- Sodium hydroxide, 19
- Soft-jaw vise, 395
- Solenoids, 187
- Solvents, disposal, 26
- Specifications menu, of computer alignment system, 494
- Spring compressing tools, 177
- Spring insulators, 176
- Spring silencers, 247
- Stabilitrak system, 280
- Stability control system, diagnosis, 280
- Stabilizer bars
 - diagnosis and replacement, 220
 - diagnosis and service, 248
- Standing acceleration test, 153
- Static balance, 144
- Steering angle sensors, 439
- Steering arms, 320
- Steering axis inclination (SAI), 499
 - correction procedure, 537
- Steering column and linkage service, 295–321
 - air bag module removal and replacement, 295–297
 - collapsible steering column inspection, 301
 - diagnosing, removing, and replacing outer tie-rod end, 316–317
 - flexible coupling and universal joint diagnosis and service, 307–308
 - manual, diagnosis, 312
 - steering column diagnosis, 309–312
 - steering column removal and replacement, 300–301
 - steering linkage diagnosis and service, 313–314
 - steering wheel removal and replacement, 296
 - tilt steering column assembly, 305–307
 - tilt steering column disassembly, 302–304
 - tilt steering column inspection and parts replacement, 304–305
- Steering control problems, 224
- Steering dampers, 319
- Steering diagnosis, 416–417
- Steering effort, 202, 338, 400, 407
- Steering effort imbalance, 400
- Steering gear
 - diagnosis, 369–370
 - rack and pinion, 387–417
 - recirculating ball, 369–377
- Steering input test, 152
- Steering knuckles
 - front, diagnosis and service, 207, 210
 - replacement, rear-wheel-drive vehicles, 210–211
- Steering linkage height, 508–510
- Steering position sensor calibration, 413
- Steering problems, 120
- Steering pull, 121–122, 156, 250
- Steering system preliminary diagnosis, active, 414–415
 - preliminary inspection, 415
 - fiber-optic cable service, 415
 - active steering diagnosis system, 416–417
- Steering tools, 42–54
- Steering tuning selection, 414
- Steering wander, 224
- Steering wheel centering procedure, 539–540
- Steering wheel free play, 307–308, 319, 371, 387
- Steering wheel holders, 497
- Steering wheel locking tool, 53
- Steering wheel pad. *See* Air bag deployment modules
- Stethoscopes, 43, 104
- Strut cartridge installation
 - off-car, 173–174
 - on-car, 184–186
- Strut chatter, 174
- Strut mounts, 528
- Strut rod length adjustment, 531
- Strut rods, diagnosis and replacement, 220–221
- Struts
 - bent front, 510–511
 - bounce test, 172
 - diagnosis, 188
 - disposal procedure, 179
 - installation of coil spring on, 179–180
 - installation of strut-and-spring assembly, 181
 - noise diagnosis, 205
 - rear, diagnosis and service, 237, 239–240
 - rear strut replacement, 183
 - removal and replacement, 176–177
 - removal from coil spring, 177–178
 - visual inspections, 171–172
- Strut tower, 174
- Substance abuse, 3, 12
- Sulfuric acid, 5
- Sunburst cracks, 463
- Suspension adjustment link, 245
- Suspension noise, 224
- Suspension problems, 463
- Suspension systems, 382–384
 - computer-controlled, 259–284
 - front, 201–224
 - manual, diagnosis, 396
 - power, diagnosis, 407
 - rear, 235–250
 - SLA, 216–218
 - VDS, 269–274
- Suspension tools, 42–52
- Symmetry angle measurement, 504

T

- Tapered-head bolts, 302
- Tapered roller bearings, service and adjustment of, 90–94
- Thrust line, 499, 543
- Tie rod adjusting tool, 53
- Tie rod end and ball joint puller, 48
- Tie-rod end boots, 442–445
- Tie-rod ends
 - diagnosis, 313
 - installation, 443–444

- removal, 441
 - replacement, 313–314
 - Tie-rods
 - installation, 443–444
 - rack and pinion steering gear tie-rod service, 395–396
 - rear, inspection and replacement, 250
 - removal, 441
 - steering gear, 401–402
 - Tilt steering columns
 - assembly, 305–307
 - diagnosis, 312
 - disassembly, 302–304
 - inspection and parts replacement, 304–305
 - Tire changers, 45–46, 64–65, 124–125, 131, 135
 - Tire condition screen, of computer alignment system, 495
 - Tire conicity, 121, 147
 - Tire dismounting, 124–129
 - Tire diagnosis, 73
 - Tire inflation pressure, 77
 - Tire noises, 120
 - Tire plug installation, 130
 - Tire pressure monitoring systems (TPMS), 132
 - Tire remounting, 131
 - Tire removal, 140
 - Tire rotation, 122
 - Tire runout measurement, 138–139
 - Tire service, 128–129
 - inspection and repair, 129–130
 - precautions, 128
 - Tire thump, 120, 156
 - Tire tread depth gauge, 44
 - Tire tread wear, 141, 207, 221
 - Tire vibration, 120
 - Tire waddle, 140
 - Tire wear diagnosis, 489
 - Tire/wheel frequency, 154–155
 - Toe, rear wheel, 543
 - Toe adjustment, 537–539
 - rear wheel, 543–550
 - Toe change, checking, 508–510
 - Toe gauge, 53
 - Toe-in, 487, 509
 - Toe-out, 497
 - Tools
 - for camber adjustment, 530–531
 - coil spring compressing tool, 62–64
 - computer four wheel aligners, 67–68
 - dial indicators, 60–62
 - electronic wheel balancers, 67
 - power steering pressure gauge, 59
 - scan. *see* Scan tool
 - spring compressing, 177
 - suspension and steering, 42–54
 - tire changes, 65–67
 - Torque sensor calibration, 413–414
 - Torque steer, 487
 - Torque sticks, 50–51
 - Torque wrenches, 50–51
 - Torsion bar adjustment, 202
 - Torsion bars, removing and replacing longitudinally mounted, 222–224
 - Total toe, 497, 538
 - Toxic substances, 26
 - Track bar diagnosis and replacement, 248
 - Track gauge, 53, 466, 548
 - Tracking, rear wheel, 548–551
 - Track-width difference, 506
 - Tram gauge, 51
 - Tram gauge method, of frame measurement, 466–467
 - Transverse beams, 469
 - Tread wear, 142
 - Tread wear indicators, 140, 141
 - Tread wear measurement, 140
 - Trim height, mechanical adjustment, 265–267
 - Turning angle screen, of computer alignment system, 500
 - Turning imbalance diagnosis, 400–401
 - Turning radius gauges, 51
 - Turntables, 499
 - Twin I-beam axles, checking ball joints on, 207
 - Twin I-beam front suspension systems
 - camber adjustment, 531
 - caster adjustment, 533
 - Twist, frame, 462
- ## U
- U-channels, 249
 - Underhood measurements, 472
 - Unitized bodies
 - measurement, 468–471
 - straightening, 471
 - Universal joints, 307–308
 - U.S. customary (USC) system, 39
- ## V
- Vacuum hand pump, 50
 - Valve solenoid/pressure hold test, 280–281
 - Valve solenoid/pressure release test, 282
 - Valve stem removal, 135
 - Vapors, 2
 - Vehicle dynamic suspension (VDS) systems, 269–274
 - air spring and shock absorbers removal and disassembly, 272–274
 - inspection and verification, 269
 - on-demand self-test, 271–272
 - pneumatic test, 270–271
 - ride height adjustment or calibration, 269–270
 - Vehicle exhaust, 5
 - Vehicle identification number (VIN), 74
 - Vehicle lifts (hoists), 57
 - Vehicle operation, safety rules for, 15–16
 - Vehicle pulling/drifting, 397
 - Vehicle wander, 371
 - Ventilation, 5
 - Vertical ball joint measurement, 206

- Vibration, 99
 - chassis, 250
 - diagnosis, 150–153
 - diagnosis with EVA, 153–154
 - tire, 120
 - wheel, 145, 156
- Vibration frequencies, calculating, 154–156
- Volume, 41
- V-type belts, 336
- W**
- Wander, 371
- Wear indicators, 203
- Wheel alignment. *See also* Computer alignment systems; Four wheel alignment procedure
 - diagnosis, 552
 - procedure, 503–504
- Wheel alignment screens, of computer alignment system, 497–502
- Wheel balancer, 46
- Wheel balancing
 - on-car balancing, 149–150
 - preliminary checks, 141–142
 - procedure, 146–147
 - rear wheel balancing, 150
- Wheelbase difference, 505
- Wheel bearings
 - adjusting, 96
 - cleaning, 89–90
 - defects, 90–94
 - front, removal and replacement, 102–103
 - lubrication and assembly, 94
 - tapered roller, service and adjustment, 95–97
- Wheel diagnosis, 156
- Wheel hub unit, 97
- Wheel jounce, 509–510
- Wheel nut tightening, 104, 123
- Wheel removal, 123–124
- Wheel rim leak repair, 131
- Wheel rim service, 130–131
- Wheel runout compensation, 496–497
- Wheel runout measurement, 138–140
- Wheel sensors, 491
- Wheel service, 123–130
 - precautions, 124–128
- Wheel setback, 550–551
- Wheel shimmy, 313
- Wheel vibration, 145, 149
- Wiring harness colors, 188
- Woodruff key, 346
- Workplace hazardous materials information systems (WHMIS), 28
- Worm shaft bearing adjuster plug seal replacement, 376–377
- Y**
- Yield strength, 462

AUTOMOTIVE SUSPENSION & STEERING SYSTEMS

5TH EDITION SHOP MANUAL

DON KNOWLES

Master the knowledge and skills needed to diagnose and service suspension and steering systems for today's cars, SUVs, light duty trucks and now, hybrids, with the latest edition of this highly successful Classroom/Shop Manual package! With the same carefully constructed balance of theory and practice that made previous editions so valuable, the 5th Edition of *Today's Technician: Automotive Suspension & Steering* takes the content to the next level, from coverage of the latest mandatory tire pressure monitoring systems to the newest electronically-controlled suspension systems. And the highly updated, state-of-the-art information doesn't end there; the book also features new information on the most current front and rear suspension designs, recent developments in steering columns and air bag systems, and the latest electronic power steering gears. Reinforcing its practical, user-friendly approach are strategically placed cautions and warnings that emphasize safe working procedures and case studies that link theory to the real-life practices of today's professional, ASE-certified technicians. *Today's Technician: Automotive Suspension & Steering 5th Edition* is a must-have for aspiring and new automotive technicians alike!

LOOK FOR THESE FEATURES

- All-new content on the latest automotive industry trends and developments, including Active Steering System operation and service, Four Wheel Active Steering (4WAS) operation and service, PAX tire systems, Adaptive Cruise Control (ACC), Lane Departure Warning Systems, and Telematics.
- Expanded and updated coverage of Tire Pressure Monitoring Systems (TPMS).
- New, visually exciting four-color format with hundreds of new photographs and line drawings.
- Builds strong foundation in systems examination with an in-depth look at the latest computer-controlled suspension systems.
- Quickly brings readers up-to-speed with critical industry information with a solid introduction to the electric-drive power steering pumps used on some vehicles and hybrid cars, as well as the latest electronic wheel alignment equipment and procedures on most current suspension systems.
- Forms powerful connections between theory and the day-to-day experiences of today's professional, ASE-certified technicians with case studies and practical customer care tips.

DON'T MISS THESE OTHER EXCITING TITLES IN THE TODAY'S TECHNICIAN™ SERIES

Hadfield/Automotive Engine Repair and Rebuilding, 4E
ISBN # 978-1-4354-2824-9

Erjavec/Automatic Transmissions and Transaxles, 5E
ISBN # 978-1-4354-3933-7

Erjavec/Manual Transmissions and Transaxles, 5E
ISBN # 978-1-4354-3933-7

Owen/Automotive Brake Systems, 4E
ISBN # 978-1-4180-6221-7

Hollembeak/Automotive Electricity and Electronics, 5E
ISBN # 978-1-4354-7010-1

Pickerill/Automotive Engine Performance, 5E
ISBN # 978-1-4354-2823-4

Schnubel/Advanced Engine Performance
ISBN # 978-1-4018-7787-3

Hollembeak/Automotive Fuels and Emissions
ISBN # 978-1-4018-3904-8


Owen/Basic Automotive Service and Systems, 3E
ISBN # 978-1-4180-2128-3

TODAY'S TECHNICIAN™ SERIES

An integrated learning system for automotive technology, the Today's Technician Series™ from Delmar, Cengage Learning demonstrates our commitment to providing high-quality books that work for automotive technology programs. We've developed easy-to-use, cross-referenced Classroom and Shop Manuals along with a timesaving Instructor Resource™ to provide a complete system of instructional support. The Series includes titles that correspond to the eight major automotive service areas as defined by ASE, plus additional titles that address advanced topics.

LOOK FOR THESE SERIES FEATURES

- Job Sheets in the Shop Manual to guide readers through procedures covered in the chapter
- Photo Sequences and step-by-step instructions in the Shop Manual for diagnostic and repair procedures
- "Cautions" and "Warnings" throughout the Shop Manual to emphasize safety and the need to carefully follow repair procedures
- Case Studies that provide examples of the diagnostic strategies a technician uses to identify and solve a problem
- ASE-style questions at the end of each chapter in the Shop Manual, plus a sample ASE exam, to help prepare readers for the certification testing
- Author's Notes contained in the Classroom Manual explain difficult concepts in an easy-to-understand straightforward manner
- An Instructor Resource™ containing ready-to-use PowerPoint™ slides, a computerized testbank, Image Library and other helpful resources is available to minimize preparation time for instructors



9781435481145
2015-11-23 11:30

22